



## DTC Troubleshooting: B121D (89)





**DTC B121D or DTC indicator 89:** Humidity/in-car temperature sensor communication error

DTC Description	DTC
B121D Humidity/in-car temperature sensor communication error	

DTC (AC)

1. Problem verification:

- 1. Clear the DTC with the HDS.

Clear DTCs

- 2. Turn the vehicle to the OFF (LOCK) mode and then the ON mode.

- 3. [Do the Self-Diagnostic Function with the HDS or the climate control unit.](#)

- 4. Check for DTCs.

DTC Description	DTC
B121D Humidity/in-car temperature sensor communication error	

*Is DTC B121D or 89 indicated?*

YES The failure is duplicated. Go to step 2.

NO Intermittent failure. Check for loose wires or poor connections on the humidity/in-car temperature sensor circuit.■


2. Climate control unit check:

- 1. Turn the vehicle to the OFF (LOCK) mode after confirming the A/C system is OFF.

- 2. Connect terminals A and B with a jumper wire.

Terminal A Humidity/in-car temperature sensor 4P connector (female terminals) No. 2: ①

Terminal B Humidity/in-car temperature sensor 4P connector (female terminals) No. 4: ②



- 3. Turn the vehicle to the ON mode.

- 4. While pressing the WINDSHIELD DEFROST button, press and hold the ON/OFF button for 10 seconds or more.

## MODE INDICATOR



Does the MODE indicator turn on?

YES Go to step 3.

NO Go to step 4.

### 3. Determine possible failure area (humidity/in-car temperature sensor, others):

-1. Turn the vehicle to the OFF (LOCK) mode.

-2. Disconnect the jumper wire.

-3. Turn the vehicle to the ON mode.

-4. Measure the voltage between test points 1 and 2.

Test condition Vehicle ON mode

Humidity/in-car temperature sensor 4P connector: disconnected

Test point 1 Humidity/in-car temperature sensor 4P connector (female terminals) No. 1: ①

Test point 2 Body ground



Is there about 5 V?

YES [Replace the humidity/in-car temperature sensor.](#)■

NO Go to step 9.

### 4. Open wire check (HUM DATA line):

-1. Turn the vehicle to the OFF (LOCK) mode.

-2. Disconnect the jumper wire.

-3. Disconnect the following connector.  
Climate control unit connector A (32P)

-4. Check for continuity between test points 1 and 2.


Test condition Vehicle OFF (LOCK) mode

Climate control unit connector A (32P): disconnected

Humidity/in-car temperature sensor 4P connector: disconnected

Test point 1  
Test point 2

[Climate control unit connector A \(32P\) No. 7](#)  
Humidity/in-car temperature sensor 4P connector (female terminals) No. 2: ①



*Is there continuity?*

YES The HUM DATA wire is not open. Go to step 5.

NO Repair an open in the HUM DATA wire.■


5. Open wire check (TR line):

- 1. Check for continuity between test points 1 and 2.

Test condition Vehicle OFF (LOCK) mode  
Climate control unit connector A (32P): disconnected  
Humidity/in-car temperature sensor 4P connector: disconnected

Test point 1 [Climate control unit connector A \(32P\) No. 24](#)

Test point 2 Humidity/in-car temperature sensor 4P connector (female terminals) No. 4: ①



*Is there continuity?*

YES The TR wire is not open. Go to step 6.

NO Repair an open in the TR wire.■

6. Shorted wire check (HUM DATA line):

- 1. Check for continuity between test points 1 and 2.

Test condition Vehicle OFF (LOCK) mode  
Climate control unit connector A (32P): disconnected  
Humidity/in-car temperature sensor 4P connector: disconnected

Test point 1 [Climate control unit connector A \(32P\) No. 7](#)

Test point 2 Body ground

*Is there continuity?*

YES Repair a short to ground in the HUM DATA wire.■

NO The HUM DATA wire is OK. Go to step 7.

7. Shorted wire check (TR line):

- 1. Check for continuity between test points 1 and 2.  
 Test condition      Vehicle OFF (LOCK) mode  
                              Climate control unit connector A (32P): disconnected  
                              Humidity/in-car temperature sensor 4P connector: disconnected  
 Test point 1          [Climate control unit connector A \(32P\) No. 24](#)  
 Test point 2          Body ground

*Is there continuity?*

YES    Repair a short to ground in the TR wire.■

NO     The TR wire is OK. Go to step 8.

#### 8. Shorted wire check (HUM DATA line to TR line):

- 1. Disconnect the following connector.  
 Climate control unit connector A (32P)
- 2. Check for continuity between test points 1 and 2.  
 Test condition      Vehicle OFF (LOCK) mode  
                              Climate control unit connector A (32P): disconnected  
                              Humidity/in-car temperature sensor 4P connector: disconnected  
 Test point 1          [Climate control unit connector A \(32P\) No. 7](#)  
 Test point 2          [Climate control unit connector A \(32P\) No. 24](#)


*Is there continuity?*

YES    Repair a short in the HUM DATA wire to the TR wire.■

NO     [Replace the climate control unit.](#)■

#### 9. Open wire check (S 5V line):

- 1. Turn the vehicle to the OFF (LOCK) mode.
- 2. Disconnect the following connector.  
 Climate control unit connector A (32P)
- 3. Check for continuity between test points 1 and 2.  
 Test condition      Vehicle OFF (LOCK) mode  
                              Climate control unit connector A (32P): disconnected  
                              Humidity/in-car temperature sensor 4P connector: disconnected  
 Test point 1          [Climate control unit connector A \(32P\) No. 26](#)  
 Test point 2          Humidity/in-car temperature sensor 4P connector (female terminals) No. 1: ①



*Is there continuity?*

YES The S 5V wire is not open. Go to step 10.

NO Repair an open in the S 5V wire.■

10. Open wire check (SENSOR COM line):

- 1. Check for continuity between test points 1 and 2.

Test condition	Vehicle OFF (LOCK) mode Climate control unit connector A (32P): disconnected Humidity/in-car temperature sensor 4P connector: disconnected
Test point 1	<a href="#">Climate control unit connector A (32P) No. 12</a>
Test point 2	Humidity/in-car temperature sensor 4P connector (female terminals) No. 3: ①



*Is there continuity?*

YES The SENSOR COM wire is OK. Go to step 11.

NO Repair an open in the SENSOR COM wire.■

11. Shorted wire check (S 5V line):

- 1. Check for continuity between test points 1 and 2.

Test condition	Vehicle OFF (LOCK) mode Climate control unit connector A (32P): disconnected Humidity/in-car temperature sensor 4P connector: disconnected
Test point 1	<a href="#">Climate control unit connector A (32P) No. 26</a>
Test point 2	Body ground

*Is there continuity?*

YES Repair a short to ground in the S 5V wire.■

NO [Replace the climate control unit.](#)■