

Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM100000028X1A
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [12/2022 -]
Title: BRAKE CONTROL / DYNAMIC CONTROL SYSTEMS: ELECTRONICALLY CONTROLLED BRAKE SYSTEM: DATA LIST / ACTIVE TEST; 2023 - 2024 MY Prius Prius Prime [12/2022 -]		

DATA LIST / ACTIVE TEST

DATA LIST

NOTICE:

In the table below, the values listed under "Normal Condition" are reference values. Do not depend solely on these reference values when deciding whether a part is faulty or not.

HINT:

Using the GTS to read the Data List allows the values or states of switches, sensors, actuators and other items to be read without removing any parts. This non-intrusive inspection can be very useful because intermittent conditions or signals may be discovered before parts or wiring is disturbed. Reading the Data List information early in troubleshooting is one way to save diagnostic time.

- (a) Warm up the engine.
- (b) Turn the ignition switch off.
- (c) Connect the GTS to the DLC3.
- (d) Turn the ignition switch to ON.
- (e) Turn the GTS on.
- (f) Enter the following menus: Chassis / Brake Booster / Data List.
- (g) Enter the following menus: Chassis / Brake/EPB* / Data List.

*: Electric Parking Brake System

- (h) According to the display on the GTS, read the Data List.

Chassis > Brake Booster > Data List

TESTER DISPLAY	MEASUREMENT ITEM	RANGE	NORMAL CONDITION	DIAGNOSTIC NOTE
Total Distance Traveled - Unit	Total distance traveled unit	km / mile	-	-
Total Distance Traveled	Total distance traveled	Min.: 0 Max.: 16777215	-	-
Solenoid Power Supply Voltage	Solenoid power supply voltage value	Min.: 0.0 V Max.: 25.5 V	-	Changes in proportion to auxiliary battery voltage
Stop Light SW	Stop light switch assembly (STP terminal input)	OFF / ON	OFF: Brake pedal released ON: Brake pedal depressed	HINT: The brake pedal state is determined using the voltage at terminal STP

TESTER DISPLAY	MEASUREMENT ITEM	RANGE	NORMAL CONDITION	DIAGNOSTIC NOTE
Parking Brake SW	Parking brake status	OFF / ON	OFF: Parking brake released ON: Parking brake applied	-
Buzzer	Meter buzzer	OFF / ON	OFF: Buzzer off ON: Buzzer on	-
Dealer Mode	Dealer Mode (Signal Check mode or Calibration mode) status	OFF / ON	OFF: Normal mode ON: Dealer Mode (Signal Check mode or Calibration mode)	<p>HINT:</p> <ul style="list-style-type: none"> For details on Dealer Mode (Signal Check), refer to Signal Check*1 For details on Dealer Mode (Calibration), refer to Reset Memory / Calibration*2
Reservoir Warning SW	Brake fluid level warning switch	OFF / ON	OFF: Reservoir level normal ON: Reservoir level low	-
ECB Solenoid (SGH)	Switching solenoid valve (SGH)	OFF / ON	OFF: Solenoid off ON: Solenoid on	ECB: Electronically Controlled Brake System
ECB Solenoid (SSA)	Switching solenoid valve (SSA)	OFF / ON	OFF: Solenoid off ON: Solenoid on	ECB: Electronically Controlled Brake System
IGP_PT2	IGP_PT2 status	OFF / ON	OFF: IGP_PT2 OFF ON: IGP_PT2 ON	-
Stroke Sensor	Brake pedal stroke sensor 1	Min.: 0.0 V Max.: 5.0 V	Brake pedal released: 0.6 to 1.4 V	Reading increases when brake pedal is depressed
Quantity of Brake Pedal Stroke	Brake pedal stroke amount	Min.: 0 mm Max.: 255 mm	Brake pedal released: 0 mm	Reading increases when brake pedal is depressed
Servo Pressure	Pressure value of servo	Min.: 0.00 MPa Max.: 24.48 MPa	Brake pedal released: 0.00 to 1.53 MPa	Brake pedal is being depressed: Changes in proportion to the depression force of the brake pedal

TESTER DISPLAY	MEASUREMENT ITEM	RANGE	NORMAL CONDITION	DIAGNOSTIC NOTE
Voltage of Stroke Sensor	Voltage of brake pedal stroke sensor 1	Min.: 0.0 V Max.: 5.0 V	-	-
Brake Pedal Stroke Change Speed	Brake pedal stroke rate of change	Min.: -2560 mm/s Max.: 2540 mm/s	Brake pedal released or depressed and held: 0 mm/s	Brake pedal is being moved: Changes in proportion to the operation speed of the brake pedal
Target Oil Pressure	Wheel target hydraulic pressure	Min.: 0.00 MPa Max.: 20.00 MPa	-	Changes according to the target wheel cylinder hydraulic pressure
VCSK Voltage Value	VCSK voltage value	Min.: 0.000 V Max.: 5.500 V	4.800 to 5.200 V	-
SGH Solenoid Current	Switching solenoid valve (SGH) current	Min.: 0.000 A Max.: 3.000 A	0.000 to 1.500 A	-
SSA Solenoid Current	Switching solenoid valve (SSA) current	Min.: 0.000 A Max.: 3.000 A	0.000 to 1.500 A	-
ECB Main Relay	Main relay operation request	OFF / ON	OFF: Relay off ON: Relay on	ECB: Electronically Controlled Brake System
Brake Booster Motor	Brake booster motor status	OFF / ON	OFF: Motor off ON: Motor on	-
Linear Solenoid (SLM1)	Linear solenoid valve (SLM1) current	Min.: 0.000 A Max.: 0.504 A	-	-
Linear Solenoid (SLM2)	Linear solenoid valve (SLM2) current	Min.: 0.000 A Max.: 0.504 A	-	-
The Number of Capacitor Operation	Displays the number of integration control supply operations	Min.: 0 Max.: 255	-	-
Gap Hold Chamber Oil Pressure	Pressure value of stroke simulator	Min.: 0.00 MPa Max.: 24.48 MPa	Brake pedal released: 0.00 to 1.53 MPa	Brake pedal is being depressed: Changes in proportion to the depression force of the brake pedal

TESTER DISPLAY	MEASUREMENT ITEM	RANGE	NORMAL CONDITION	DIAGNOSTIC NOTE
Gap Hold Chamber Oil Pressure Grade	Amount of change in stroke simulator oil pressure	Min.: -30 MPa/s Max.: 225 MPa/s	-	-
Linear Solenoid Current (SLM1)	Linear solenoid valve (SLM1) current	Min.: 0.000 A Max.: 1.500 A	Brake pedal released: 0 A	-
Linear Solenoid Current (SLM2)	Linear solenoid valve (SLM2) current	Min.: 0.000 A Max.: 1.500 A	Brake pedal released: 0 A	-
IGR Voltage	IGR voltage value	Min.: 0.0 V Max.: 25.5 V	-	Changes in proportion to auxiliary battery voltage
BS Voltage	BS voltage value	Min.: 0.0 V Max.: 25.5 V	-	Changes in proportion to auxiliary battery voltage
BM Voltage	BM voltage value	Min.: 0.0 V Max.: 25.5 V	-	Changes in proportion to auxiliary battery voltage
Zero point Calibrated Value of Phase U Current Monitor	Displays zero point calibrated value of phase U current monitor for brushless motor	Min.: -32.768 A Max.: 32.767 A	-	-
Zero point Calibrated Value of Phase V Current Monitor	Displays zero point calibrated value of phase V current monitor for brushless motor	Min.: -32.768 A Max.: 32.767 A	-	-
Zero point Calibrated Value of Phase W Current Monitor	Displays zero point calibrated value of phase W current monitor for brushless motor	Min.: -32.768 A Max.: 32.767 A	-	-
Thermistor1 Temperature for Inverter Circuit	Temperature of thermistor1 in inverter circuit	Min.: -327.68°C (-558°F) Max.: 327.67°C (622°F)	-	-
Thermistor2 Temperature for	Temperature of thermistor2 in inverter	Min.: -327.68°C (-558°F)	-	-

TESTER DISPLAY	MEASUREMENT ITEM	RANGE	NORMAL CONDITION	DIAGNOSTIC NOTE
Inverter Circuit	circuit	Max.: 327.67°C (-622°F)		
Brushless Motor Inverter end Voltage	Inverter end voltage for brushless motor	Min.: 0.00 V Max.: 655.35 V	-	Changes in proportion to auxiliary battery voltage
Brushless Motor Required Rotation Speed (with Rotation Angle Sensor)	Requested brushless motor rotation speed	Min.: -32768 rpm Max.: 32767 rpm	Brake pedal released: 0 rpm	-
Brushless Motor Actual Rotation Speed (with Rotation Angle Sensor)	Actual brushless motor rotation speed	Min.: -32768 rpm Max.: 32767 rpm	Brake pedal released: 0 rpm	-
Brushless Motor Operation Status (with Rotation Angle Sensor)	Operation status of brushless motor	Abnormal / Stop / Synchronization drive / Extended Induced voltage	-	-
Gap Hold Chamber Pressure Sensor Open History	History of momentary open in gap pressure sensor	None / Exist	-	-
Down Stream Voltage Solenoid Relay	Solenoid relay downstream voltage	Min.: 0.0 V Max.: 25.5 V	-	Changes in proportion to auxiliary battery voltage
CBKP Voltage	CBKP voltage value	Min.: 0.0 V Max.: 25.5 V	-	Changes in proportion to auxiliary battery voltage

*1: for performing Dealer Mode (Signal Check): Click here [INFO](#)

*2: for entering Dealer Mode (Calibration): Click here [INFO](#)

Chassis > Brake/EPB > Data List

TESTER DISPLAY	MEASUREMENT ITEM	RANGE	NORMAL CONDITION	DIAGNOSTIC NOTE
Total Distance Traveled - Unit	Total distance traveled unit	km / mile	-	-

TESTER DISPLAY	MEASUREMENT ITEM	RANGE	NORMAL CONDITION	DIAGNOSTIC NOTE
Total Distance Traveled	Total distance traveled	Min.: 0 Max.: 16777215	-	-
FR Wheel Speed	Front wheel speed sensor RH reading	Min.: 0.0 km/h (0 mph) Max.: 6553.5 km/h (4072 mph)	Vehicle stopped: 0.0 km/h (0 mph)	When driving at constant speed: No large fluctuations
FL Wheel Speed	Front wheel speed sensor LH reading	Min.: 0.0 km/h (0 mph) Max.: 6553.5 km/h (4072 mph)	Vehicle stopped: 0.0 km/h (0 mph)	When driving at constant speed: No large fluctuations
RR Wheel Speed	Rear wheel speed sensor RH reading	Min.: 0.0 km/h (0 mph) Max.: 6553.5 km/h (4072 mph)	Vehicle stopped: 0.0 km/h (0 mph)	When driving at constant speed: No large fluctuations
RL Wheel Speed	Rear wheel speed sensor LH reading	Min.: 0.0 km/h (0 mph) Max.: 6553.5 km/h (4072 mph)	Vehicle stopped: 0.0 km/h (0 mph)	When driving at constant speed: No large fluctuations
FR Wheel Acceleration	Front wheel RH acceleration	Min.: -200.840 m/s ² Max.: 199.271 m/s ²	Vehicle stopped: 0.000 m/s ² During deceleration: -200.840 to 0.000 m/s ² During acceleration: 0.000 to 199.271 m/s ²	During deceleration/acceleration: Changes continuously

TESTER DISPLAY	MEASUREMENT ITEM	RANGE	NORMAL CONDITION	DIAGNOSTIC NOTE
FL Wheel Acceleration	Front wheel LH acceleration	Min.: -200.840 m/s ² Max.: 199.271 m/s ²	Vehicle stopped: 0.000 m/s ² During deceleration: -200.840 to 0.000 m/s ² During acceleration: 0.000 to 199.271 m/s ²	During deceleration/acceleration: Changes continuously
RR Wheel Acceleration	Rear wheel RH acceleration	Min.: -200.840 m/s ² Max.: 199.271 m/s ²	Vehicle stopped: 0.000 m/s ² During deceleration: -200.840 to 0.000 m/s ² During acceleration: 0.000 to 199.271 m/s ²	During deceleration/acceleration: Changes continuously
RL Wheel Acceleration	Rear wheel LH acceleration	Min.: -200.840 m/s ² Max.: 199.271 m/s ²	Vehicle stopped: 0.000 m/s ² During deceleration: -200.840 to 0.000 m/s ² During acceleration: 0.000 to 199.271 m/s ²	During deceleration/acceleration: Changes continuously
Master Cylinder Sensor 1	Master cylinder pressure sensor pressure (value detected by ECU)	Min.: -1.00 MPa Max.: 23.99 MPa	Brake pedal released: -1.00 to 0.00 MPa	Reading increases when brake pedal is depressed
Zero Point of M/C	Memorized zero point value of master cylinder pressure sensor	Min.: -12.5 MPa Max.: 12.4 MPa	-	-
Master Cylinder Sensor Temperature	Master cylinder pressure sensor temperature	Min.: -80°C (-112°F) Max.: 175°C (347°F)	Current master cylinder pressure sensor temperature	-
M/C Sensor Grade	Master cylinder pressure sensor change (value detected by ECU)	Min.: -30 MPa/s Max.: 225 MPa/s	Brake pedal released or pedal held at constant position: 0 MPa/s	When brake pedal is being operated: Changes in proportion with the pedal movement speed
Lateral G	Lateral G	Min.: -25.105 m/s ²	Turning right: -25.105 to 0.000 m/s ²	During turning: Changes in proportion with lateral acceleration

TESTER DISPLAY	MEASUREMENT ITEM	RANGE	NORMAL CONDITION	DIAGNOSTIC NOTE
		Max.: 24.908 m/s ²	Turning left: 0.000 to 24.908 m/s ²	
Forward and Rearward G	Forward and rearward G	Min.: -25.105 m/s ² Max.: 24.908 m/s ²	During deceleration: -25.105 to 0.000 m/s ² During acceleration: 0.000 to 24.908 m/s ²	During acceleration/deceleration: Changes in proportion with acceleration
Zero Point of Decele2	Memorized zero point value of lateral G	Min.: -25.105 m/s ² Max.: 24.908 m/s ²	-	-
Zero Point of Decele	Memorized zero point value of forward and rearward G	Min.: -25.105 m/s ² Max.: 24.908 m/s ²	-	-
Yaw Rate Sensor Value	Yaw rate sensor value	Min.: -128°/s Max.: 127°/s	Vehicle stopped: 0°/s Turning right: -128 to 0°/s Turning left: 0 to 127°/s	-
Zero Point of Yaw Rate Sensor	Memorized zero point value of yaw rate sensor	Min.: -128°/s Max.: 127°/s	After completing zero point calibration: °/s	-
Steering Angle Value	Steering angle sensor value	Min.: -3276.8° Max.: 3276.7°	Turning left: 0.0 to 3276.7° Turning right: -3276.8 to 0.0°	-
Zero Point of Steering Angle	Memorized zero point value of steering angle sensor	Min.: -3276.8° Max.: 3276.7°	-	-
MT Voltage Value	ABS motor drive voltage value	Min.: 0.0 V Max.: 25.5 V	-	Changes in proportion to auxiliary battery voltage HINT:

TESTER DISPLAY	MEASUREMENT ITEM	RANGE	NORMAL CONDITION	DIAGNOSTIC NOTE
				This is the voltage downstream of the ABS motor as monitored by the No. 2 skid control ECU (brake actuator assembly)
Solenoid Power Supply Voltage	Solenoid power supply voltage value	Min.: 0.0 V Max.: 25.5 V	-	Changes in proportion to auxiliary battery voltage HINT: This is the voltage output (which supplies power to each solenoid) from the No. 2 skid control ECU (brake actuator assembly) to the ABS solenoid relay
Vehicle Speed	Vehicle speed (Vehicle speed signal output to combination meter assembly)	Min.: 0.0 km/h (0 mph) Max.: 6553.5 km/h (4072 mph)	Vehicle stopped: 0.0 km/h (0 mph)	When driving at constant speed: No large fluctuations
Accelerator Opening Angle %	Percentage of accelerator pedal opening angle	Min.: 0.0% Max.: 127.5%	Accelerator pedal released: 0.0%	During accelerator pedal operation: Changes in proportion with the pedal movement
Shift Lever Position	Shift position information	fail / 1st / 2nd / 3rd / 4th / 5th / 6th / B / D/M / N / P / R / No input	Actual shift position	-
TRC(TRAC)/VSC OFF Mode	TRAC/VSC off mode	Normal mode (TRC(TRAC) ON/VSC ON) / TRC(TRAC) OFF mode (TRC(TRAC) OFF/VSC ON) / VSC	Normal mode (TRC(TRAC) ON/VSC ON): Normal mode TRC(TRAC) OFF mode (TRC(TRAC) OFF/VSC ON): TRAC off mode VSC expert mode (VSC expert mode MID ON): VSC expert mode	-

TESTER DISPLAY	MEASUREMENT ITEM	RANGE	NORMAL CONDITION	DIAGNOSTIC NOTE
		expert mode (VSC expert mode MID ON) / VSC OFF mode (TRC(TRAC) OFF/VSC OFF)	VSC OFF mode (TRC(TRAC) OFF/VSC OFF): VSC off mode	
Brake Hold Control Mode	Brake hold control mode	Out of control mode / Pressure hold mode / Pressure release mode / EPB lock mode	<p>Out of control mode: Brake hold control system is off or brake hold control system is stand-by mode (brake hold standby indicator light is illuminated)</p> <p>Pressure hold mode: Brake hold control is operating (brake hold operated indicator light is illuminated)</p> <p>Pressure release mode: Brake hold control is released (brake hold operated indicator light not illuminated)</p> <p>EPB lock mode: Parking brake is engaged during brake hold control</p>	<p>HINT:</p> <ul style="list-style-type: none"> EPB: Electric Parking Brake System If the brake pedal is not depressed for 3 minutes or more after entering pressure hold mode, the system automatically changes to EPB lock mode
FR Target Oil Pressure	Front wheel RH target oil pressure	Min.: 0.0 MPa Max.: 20.0 MPa	-	Different according to target oil pressure of each wheel
FL Target Oil Pressure	Front wheel LH target oil pressure	Min.: 0.0 MPa Max.: 20.0 MPa	-	Different according to target oil pressure of each wheel
RR Target Oil Pressure	Rear wheel RH target oil pressure	Min.: 0.0 MPa Max.: 20.0 MPa	-	Different according to target oil pressure of each wheel
RL Target Oil Pressure	Rear wheel LH target oil pressure	Min.: 0.0 MPa Max.: 20.0 MPa	-	Different according to target oil pressure of each wheel

TESTER DISPLAY	MEASUREMENT ITEM	RANGE	NORMAL CONDITION	DIAGNOSTIC NOTE
Vehicle Speed Grade	Vehicle acceleration/deceleration	Min.: -25.105 m/s ² Max.: 24.908 m/s ²	Vehicle stopped: 0.000 m/s ² During deceleration: -25.105 to 0.000 m/s ² During acceleration: 0.000 to 24.908 m/s ²	During driving: Changes in proportion with vehicle acceleration/deceleration
Vehicle Stop Time from IG ON	Time vehicle stopped after ignition switch turned to ON	Min.: 0 s Max.: 1275 s	-	-
Travel Distance from IG ON	Driving time after ignition switch turned to ON	Min.: 0 s Max.: 1275 s	-	-
Stop Light SW	Stop light switch assembly status (STP or STP2 terminal input)	OFF / ON	OFF: Brake pedal released ON: Brake pedal depressed	<p>HINT:</p> <ul style="list-style-type: none"> Stop light control relay (stop light switch assembly) off: STP terminal status displayed. Stop light control relay (stop light switch assembly) on: STP2 terminal status displayed.
Parking Brake SW	Parking brake status	OFF / ON	OFF: Parking brake released ON: Parking brake applied	-
Brake Hold Switch	Brake hold switch (electric parking brake switch assembly) (BH terminal input)	OFF / ON	OFF: Brake hold switch (electric parking brake switch assembly) OFF ON: Brake hold switch (electric parking brake switch assembly) ON	<p>HINT:</p> <p>The brake hold switch (electric parking brake switch assembly) state is determined using the voltage at terminal BH</p>
Stop Light Relay	Stop light control relay (stop light switch assembly) status (STP terminal input)	OFF / ON	OFF: Stop light control relay (stop light switch assembly) off and brake pedal released ON: Stop light control relay (stop light switch assembly) on or brake pedal depressed	<p>HINT:</p> <p>The voltage of power supplied to the stop lights is measured at the STP terminal.</p>
Inspection Mode	Inspection mode	OFF / ON	OFF: Normal mode ON: Inspection mode	-

TESTER DISPLAY	MEASUREMENT ITEM	RANGE	NORMAL CONDITION	DIAGNOSTIC NOTE
TRC(TRAC) Control	TRAC control status	Out of controlling / Under Controlling	Out of controlling: Not during control Under Controlling: During control	-
TRC(TRAC) Engine Control	TRAC throttle control status	Out of controlling / Under Controlling	Out of controlling: Not during control Under Controlling: During control	-
TRC(TRAC) Brake Control	TRAC brake control status	Out of controlling / Under Controlling	Out of controlling: Not during control Under Controlling: During control	-
FR Wheel VSC Ctrl Status	Front wheel RH VSC control status	Out of controlling / Under Controlling	Out of controlling: Not during control Under Controlling: During control	-
FL Wheel VSC Ctrl Status	Front wheel LH VSC control status	Out of controlling / Under Controlling	Out of controlling: Not during control Under Controlling: During control	-
RR Wheel VSC Ctrl Status	Rear wheel RH VSC control status	Out of controlling / Under Controlling	Out of controlling: Not during control Under Controlling: During control	-
RL Wheel VSC Ctrl Status	Rear wheel LH VSC control status	Out of controlling / Under Controlling	Out of controlling: Not during control Under Controlling: During control	-
FR Wheel ABS Ctrl Status	Front wheel RH ABS control status	Out of controlling / Under Controlling	Out of controlling: Not during control Under Controlling: During control	-
FL Wheel ABS Ctrl Status	Front wheel LH ABS control status	Out of controlling / Under Controlling	Out of controlling: Not during control Under Controlling: During control	-

TESTER DISPLAY	MEASUREMENT ITEM	RANGE	NORMAL CONDITION	DIAGNOSTIC NOTE
RR Wheel ABS Ctrl Status	Rear wheel RH ABS control status	Out of controlling / Under Controlling	Out of controlling: Not during control Under Controlling: During control	-
RL Wheel ABS Ctrl Status	Rear wheel LH ABS control status	Out of controlling / Under Controlling	Out of controlling: Not during control Under Controlling: During control	-
BA Ctrl Status	BA control status	OFF / ON	OFF: Not during control ON: During control	-
PBA Ctrl Status	PBA control status	OFF / ON	OFF: Not during control ON: During control	-
Stop Light Relay State for ECU Control	Stop light control relay (stop light switch assembly) status (STPO terminal output) (for ECU control)	OFF / ON	OFF: Stop light control relay (stop light switch assembly) off (Stop light off) ON: Stop light control relay (stop light switch assembly) on (Stop light on)	-
Solenoid State for ECU Control	ABS solenoid relay status (for ECU control)	OFF / ON	OFF: ABS solenoid relay not operating ON: ABS solenoid relay operating	-
Motor State for ECU Control	ABS motor relay status (for ECU control)	OFF / ON	OFF: ABS motor relay not operating ON: ABS motor relay operating	-
Buzzer	Meter buzzer	OFF / ON	OFF: Buzzer off ON: Buzzer on	-
Dealer Mode	Dealer Mode (Signal Check mode or Calibration mode) status	OFF / ON	OFF: Normal mode ON: Dealer Mode (Signal Check mode or Calibration mode)	<p>HINT:</p> <ul style="list-style-type: none"> For details on Dealer Mode (Signal Check), refer to Signal Check*1 For details on Dealer Mode (Calibration), refer to Reset Memory / Calibration*2

TESTER DISPLAY	MEASUREMENT ITEM	RANGE	NORMAL CONDITION	DIAGNOSTIC NOTE
Zero Point Memory State of Steering Angle Sensor	Steering angle sensor zero point memorization status	Zero point is not memorized / Zero point is memorized	-	HINT: The steering angle sensor zero point is acquired when the vehicle is being driven in a straight line at a speed of 35 km/h (22 mph) or more for approximately 5 seconds
Regenerative Cooperation	Regenerative cooperation	OFF / ON	OFF: Not operating ON: Operating	-
TRC(TRAC)/VSC OFF SW	VSC OFF switch (electric parking brake switch assembly) (CSW terminal input)	OFF / ON	OFF: VSC OFF switch (electric parking brake switch assembly) OFF ON: VSC OFF switch (electric parking brake switch assembly) ON	HINT: The VSC OFF switch (electric parking brake switch assembly) state is determined using the voltage at terminal CSW
IGP_PT2	IGP_PT2 status	OFF / ON	OFF: IGP_PT2 OFF ON: IGP_PT2 ON	-
FR Wheel	Front right wheel rotation direction	Forward / Back	When driving forward: forward When reversing: Back	-
FL Wheel	Front left wheel rotation direction	Forward / Back	When driving forward: forward When reversing: Back	-
RR Wheel	Rear right wheel rotation direction	Forward / Back	When driving forward: forward When reversing: Back	-
RL Wheel	Rear left wheel rotation direction	Forward / Back	When driving forward: forward When reversing: Back	-
Brake Hold Ready	Brake hold control permission status	Not in stand-by mode / Stand-by mode	Not in stand-by mode: Brake hold function not operating (brake hold standby indicator light not illuminated) Stand-by mode: Brake hold function stand-by state (brake hold standby indicator light illuminated)	-

TESTER DISPLAY	MEASUREMENT ITEM	RANGE	NORMAL CONDITION	DIAGNOSTIC NOTE
Stroke Sensor2	Brake pedal stroke sensor 2	Min.: 0.0 V Max.: 5.0 V	Brake pedal released: 3.6 to 4.4 V	Reading decreases when brake pedal is depressed
Quantity of Brake Pedal Stroke	Brake pedal stroke amount	Min.: 0 mm Max.: 255 mm	Brake pedal released: 0 mm	Reading increases when brake pedal is depressed
Voltage of Stroke Sensor2	Voltage of brake pedal stroke sensor 2	Min.: 0.0 V Max.: 5.0 V	-	-
FR Regenerative Request	FR regenerative request torque	Min.: 0 Nm Max.: 1048560 Nm	-	Changes according to brake pedal force (When depressing the brake pedal lightly after reaching 30 km/h (19 mph) or more, avoiding sudden braking.)
FR Regenerative Operation	FR regenerative operation torque	Min.: 0 Nm Max.: 1048560 Nm	-	Changes according to brake pedal force (When depressing the brake pedal lightly after reaching 30 km/h (19 mph) or more, avoiding sudden braking.)
Brake Pedal Stroke Change Speed	Brake pedal stroke rate of change	Min.: -2560 mm/s Max.: 2540 mm/s	Brake pedal released or depressed and held: 0 mm/s	Brake pedal is being moved: Changes in proportion to the operation speed of the brake pedal
VCSK Voltage Value	VSK2 voltage value	Min.: 0.000 V Max.: 5.500 V	4.800 to 5.200 V	-
ABS Solenoid (SRLR)	Rear pressure reduction solenoid LH status	OFF / ON	OFF: Not operating ON: Operating (pressure reduction)	HINT: The solenoid valve controls the brake fluid pressure of the wheel cylinder of the vehicle

TESTER DISPLAY	MEASUREMENT ITEM	RANGE	NORMAL CONDITION	DIAGNOSTIC NOTE
ABS Solenoid (SRLH)	Rear pressure holding solenoid LH status	OFF / ON	OFF: Not operating ON: Operating (pressure holding)	HINT: The solenoid valve controls the brake fluid pressure of the wheel cylinder of the vehicle
ABS Solenoid (SRRR)	Rear pressure reduction solenoid RH status	OFF / ON	OFF: Not operating ON: Operating (pressure reduction)	HINT: The solenoid valve controls the brake fluid pressure of the wheel cylinder of the vehicle
ABS Solenoid (SRRH)	Rear pressure holding solenoid RH status	OFF / ON	OFF: Not operating ON: Operating (pressure holding)	HINT: The solenoid valve controls the brake fluid pressure of the wheel cylinder of the vehicle
ABS Solenoid (SFRL)	Front pressure reduction solenoid LH status	OFF / ON	OFF: Not operating ON: Operating (pressure reduction)	HINT: The solenoid valve controls the brake fluid pressure of the wheel cylinder of the vehicle
ABS Solenoid (SFLH)	Front pressure holding solenoid LH status	OFF / ON	OFF: Not operating ON: Operating (pressure holding)	HINT: The solenoid valve controls the brake fluid pressure of the wheel cylinder of the vehicle
ABS Solenoid (SFRR)	Front pressure reduction solenoid RH status	OFF / ON	OFF: Not operating ON: Operating (pressure reduction)	HINT: The solenoid valve controls the brake fluid pressure of the wheel cylinder of the vehicle
ABS Solenoid (SFRH)	Front pressure holding solenoid RH status	OFF / ON	OFF: Not operating ON: Operating (pressure holding)	HINT: The solenoid valve controls the brake fluid pressure of the wheel cylinder of the vehicle

TESTER DISPLAY	MEASUREMENT ITEM	RANGE	NORMAL CONDITION	DIAGNOSTIC NOTE
TRC(TRAC)/VSC Solenoid (SM2)	Master cylinder cut solenoid (Brake Pressure Control Solenoid "B") status	OFF / ON	OFF: Not operating ON: Operating (pressure regulation)	HINT: Depending on the operating conditions, the master cylinder cut solenoid valves regulate the brake fluid pressure generated by the pump motor
TRC(TRAC)/VSC Solenoid (SM1)	Master cylinder cut solenoid (Brake Pressure Control Solenoid "A") status	OFF / ON	OFF: Not operating ON: Operating (pressure regulation)	HINT: Depending on the operating conditions, the master cylinder cut solenoid valves regulate the brake fluid pressure generated by the pump motor
ABS Motor Relay	Motor relay	OFF / ON	OFF: Motor relay off ON: Motor relay on	-
Solenoid Relay	Solenoid relay	OFF / ON	OFF: Solenoid relay off ON: Solenoid relay on	-
STPO	Stop light control relay (stop light switch assembly) status (STPO terminal output)	OFF / ON	OFF: Stop light control relay (stop light switch assembly) off (Stop light off) ON: Stop light control relay (stop light switch assembly) on (Stop light on)	HINT: When STPO is ON, the stop light control relay (stop light switch assembly) turns ON and the stop lights illuminate
I GR Voltage	IG1 voltage value	Min.: 0.0 V Max.: 25.5 V	-	Changes in proportion to auxiliary battery voltage
+BS Voltage	+BS voltage value	Min.: 0.0 V Max.: 25.5 V	-	Changes in proportion to auxiliary battery voltage
+BM Voltage	BM voltage value	Min.: 0.0 V Max.: 25.5 V	-	Changes in proportion to auxiliary battery voltage

TESTER DISPLAY	MEASUREMENT ITEM	RANGE	NORMAL CONDITION	DIAGNOSTIC NOTE
Voltage Difference between Motor Input-Output Terminal	Voltage difference between motor input-output terminal	Min.: -640.00 V Max.: 639.98 V	-	-
Yaw Rate Sensor 1 Higher Resolution Signal	Yaw rate sensor 1 higher resolution signal	Min.: -327.68 deg/sec Max.: 327.67 deg/sec	Turning right: -327.68 to 0.00 deg/sec Turning left: 327.68 to 0.00 deg/sec	-
Yaw Rate Sensor 2 Higher Resolution Signal	Yaw rate sensor 2 higher resolution signal	Min.: -327.68 deg/sec Max.: 327.67 deg/sec	Turning right: -327.68 to 0.00 deg/sec Turning left: 327.68 to 0.00 deg/sec	-
GL1 GX Sensor Higher Resolution Signal	GL1 GX sensor higher resolution signal	Min.: -32768 mG Max.: 32767 mG	During deceleration: -32768 to 0 mG During acceleration: 0 to 32767 mG	-
GL2 GY Sensor Higher Resolution Signal	GL2 GY sensor higher resolution signal	Min.: -32768 mG Max.: 32767 mG	Turning right: -32768 to 0 mG Turning left: 0 to 32767 mG	-
Request Acceleration of Upper Limit from Toyota Safety Sense	Request acceleration of upper limit from Toyota safety sense	Min.: -32.768 m/s ² Max.: 32.767 m/s ²	During deceleration: -32.768 to 0 m/s ² During acceleration: 0 to 32.767 m/s ²	-
Request Acceleration of Lower Limit from Toyota Safety Sense	Request acceleration of lower limit from Toyota safety sense	Min.: -32.768 m/s ² Max.: 32.767 m/s ²	During deceleration: -32.768 to 0 m/s ² During acceleration: 0 to 32.767 m/s ²	-
Request Acceleration and Deceleration ID	Request acceleration and deceleration ID of upper	Min.: 0 Max.: 63	Not during control: 0	-

TESTER DISPLAY	MEASUREMENT ITEM	RANGE	NORMAL CONDITION	DIAGNOSTIC NOTE
of Upper Limit from Toyota Safety Sense	limit from Toyota safety sense			
Request Acceleration and Deceleration ID of Lower Limit from Toyota Safety Sense	Request acceleration and deceleration ID of lower limit from Toyota safety sense	Min.: 0 Max.: 63	Not during control: 0	-
Target Acceleration of Upper Limit from Vehicle Motion Control	Target acceleration of upper limit from vehicle motion control	Min.: -1310.72 m/s ² Max.: 1310.68 m/s ²	During deceleration: -1310.72 to 0.00 m/s ² During acceleration: 0.00 to 1310.68 m/s ²	-
Target Acceleration of Lower Limit from Vehicle Motion Control	Target acceleration of lower limit from vehicle motion control	Min.: -1310.72 m/s ² Max.: 1310.68 m/s ²	During deceleration: -1310.72 to 0.00 m/s ² During acceleration: 0.00 to 1310.68 m/s ²	-
Target Acceleration and Deceleration ID of Upper Limit from Vehicle Motion Control	Target acceleration and deceleration ID of upper limit from vehicle motion control	Min.: 0 Max.: 63	Not during control: 0	-
Target Acceleration and Deceleration ID of Lower Limit from Vehicle Motion Control	Target acceleration and deceleration ID of lower limit from vehicle motion control	Min.: 0 Max.: 63	Not during control: 0	-
Target Driving Force of Upper Limit from Vehicle Motion Control	Target driving force of upper limit from vehicle motion control	Min.: -65536 N Max.: 65534 N	<ul style="list-style-type: none"> When the shift state is other than R (reverse) During deceleration: -65536 to 0 N 	-

TESTER DISPLAY	MEASUREMENT ITEM	RANGE	NORMAL CONDITION	DIAGNOSTIC NOTE
			<p>During acceleration: 0 to 65534 N</p> <ul style="list-style-type: none"> When the shift state is R (reverse) <p>During deceleration: 0 to 65534 N</p> <p>During acceleration: -65536 to 0 N</p>	
Target Driving Force of Lower Limit from Vehicle Motion Control	Target driving force of lower limit from vehicle motion control	Min.: -65536 N Max.: 65534 N	<ul style="list-style-type: none"> When the shift state is other than R (reverse) <p>During deceleration: -65536 to 0 N</p> <p>During acceleration: 0 to 65534 N</p> <ul style="list-style-type: none"> When the shift state is R (reverse) <p>During deceleration: 0 to 65534 N</p> <p>During acceleration: -65536 to 0 N</p>	-
Brakes Specifications Change by C-BEST	Brakes specifications change by C-BEST	None / Exist	-	-
SLM2 Refresh Drive Completed Status	Linear solenoid (SLM2) refresh complete/incomplete	Not Complete / Complete	Complete: Linear solenoid (SLM2) refresh complete Not complete: Linear solenoid (SLM2) refresh incomplete	-
Zero Point of G Sensor Learning Status	G sensor zero point learning complete/incomplete	Complete / Not Complete	Complete: G sensor zero point learning complete Not complete: G sensor zero point learning incomplete	-

TESTER DISPLAY	MEASUREMENT ITEM	RANGE	NORMAL CONDITION	DIAGNOSTIC NOTE
Zero Point of Yaw Rate Sensor Learning Status	Yaw rate sensor zero point learning complete/incomplete	Complete / Not Complete	Complete: Yaw rate sensor zero point learning complete Not complete: Yaw rate sensor zero point learning incomplete	-
Linear Solenoid Valve Offset Learning Status	Linear solenoid valve offset learning complete/incomplete	Complete / Not Complete	Complete: Linear solenoid valve offset learning complete Not complete: Linear solenoid valve offset learning incomplete	-
Zero Point of Stroke Sensor Learning Status	Stroke sensor zero point learning complete/incomplete	Complete / Not Complete	Complete: Stroke sensor zero point learning complete Not complete: Stroke sensor zero point learning incomplete	-
System Variant Learning Status	System variant learning complete/incomplete	Complete / Not Complete	Complete: System variant learning complete Not complete: System variant learning incomplete	-
Drive Mode Select Customize Item EPS Available	Drive mode select customize item EPS available	Not Applicable / Applicable	-	-
Drive Mode Select Customize Item Adaptive Variable Suspension System Available	Drive mode select customize item adaptive variable suspension system available	Not Applicable / Applicable	-	-
Drive Mode Select Customize Item Brake Available	Drive mode select customize item brake available	Not Applicable / Applicable	-	-

*1: for performing Dealer Mode (Signal Check): Click here [INFO](#)

*2: for entering Dealer Mode (Calibration): Click here [INFO](#)

Chassis > Steering Angle Sensor > Data List

TESTER DISPLAY	MEASUREMENT ITEM	RANGE	NORMAL CONDITION	DIAGNOSTIC NOTE
Total Distance Traveled	Total distance traveled	Min.: 0 Max.: 16777215	-	-
Total Distance Traveled - Unit	Total distance traveled unit	km / mile	-	-
Steering Angle Signal Information	Steering angle value (Rotation to the left side is positive)	Min.: -3072.0 deg Max.: 3070.5 deg	Turning left: 0.0 to 3070.5 deg Turning right: -3072.0 to 0.0 deg	During steering operation: Changes in proportion with steering wheel rotation
Sensor Malfunction Factor (Current)	Sensor malfunction factor (current)	Normal / Angle Velocity / AD / Sensor Element / Steering Angle Value / Steering Angle Value of RAM Stuck	-	-
Sensor Malfunction Factor (Past)	Sensor malfunction factor (past)	Normal / Angle Velocity / AD / Sensor Element / Steering Angle Value / Steering Angle Value of RAM Stuck	-	-
Total Distance Traveled (When Sensor Malfunction occurred)	Total distance traveled (when sensor malfunction occurred)	Min.: 0 Max.: 16777215	-	-
Total Distance Traveled - Unit (When Sensor Malfunction occurred)	Total distance traveled unit (when sensor malfunction occurred)	km / mile	-	-

CHECK FOR INTERMITTENT PROBLEMS

HINT:

A momentary interruption (open circuit) in the connectors and/or wire harnesses between the sensors and ECUs can be detected using the Data List function of the GTS.

- (a) Turn the ignition switch off.
- (b) Connect the GTS to the DLC3.
- (c) Turn the ignition switch to ON.
- (d) Turn the GTS on.

(e) Enter the following menus: Chassis / Brake Booster / Data List.

(f) Enter the following menus: Chassis / Brake/EPB* / Data List.

*: Electric Parking Brake System

(g) Follow the directions on the GTS to display the Data List and select areas where momentary interruptions should be monitored.

HINT:

A momentary interruption (open circuit) cannot be detected for 3 seconds after the ignition switch is turned to ON (initial check).

Chassis > Brake Booster > Data List

TESTER DISPLAY	MEASUREMENT ITEM	RANGE	NORMAL CONDITION	DIAGNOSTIC NOTE
Stop Switch Open	Momentary interruption (open circuit) status in wire harness between No. 1 skid control ECU (brake booster with master cylinder assembly) and stop light switch assembly status	Normal / Under intermittent	Normal: Normal Under intermittent: Momentary interruption	-
Stroke Open	Brake pedal stroke sensor 1 open detection	Normal / Under intermittent	Normal: Normal Under intermittent: Momentary interruption	-
Servo Pressure Sensor Open	Servo pressure sensor open detection	Normal / Under intermittent	Normal: Normal Under intermittent: Momentary interruption	-
Gap Hold Chamber Pressure Sensor Open	Gap pressure sensor open detection	Normal / Under intermittent	Normal: Normal Under intermittent: Momentary interruption	-

Chassis > Brake/EPB > Data List

TESTER DISPLAY	MEASUREMENT ITEM	RANGE	NORMAL CONDITION	DIAGNOSTIC NOTE
FR Speed Open	Front speed sensor RH open detection	Normal / Under intermittent	Normal: Normal Under intermittent: Momentary interruption	-

TESTER DISPLAY	MEASUREMENT ITEM	RANGE	NORMAL CONDITION	DIAGNOSTIC NOTE
FL Speed Open	Front speed sensor LH open detection	Normal / Under intermittent	Normal: Normal Under intermittent: Momentary interruption	-
RR Speed Open	Rear speed sensor RH open detection	Normal / Under intermittent	Normal: Normal Under intermittent: Momentary interruption	-
RL Speed Open	Rear speed sensor LH open detection	Normal / Under intermittent	Normal: Normal Under intermittent: Momentary interruption	-
Yaw Rate Open	Yaw rate sensor (airbag ECU assembly) open detection	Normal / Under intermittent	Normal: Normal Under intermittent: Momentary interruption	-
Deceleration Open	Acceleration sensor (airbag ECU assembly) open detection	Normal / Under intermittent	Normal: Normal Under intermittent: Momentary interruption	-
Steering Open	Steering angle sensor open detection	Normal / Under intermittent	Normal: Normal Under intermittent: Momentary interruption	-
Master Cylinder Open	Master cylinder pressure sensor open detection	Normal / Under intermittent	Normal: Normal Under intermittent: Momentary interruption	-
FR Speed Sensor Voltage Open	Front speed sensor RH voltage open detection	Normal / Under intermittent	Normal: Normal Under intermittent:	-

TESTER DISPLAY	MEASUREMENT ITEM	RANGE	NORMAL CONDITION	DIAGNOSTIC NOTE
			Momentary interruption	
FL Speed Sensor Voltage Open	Front speed sensor LH voltage open detection	Normal / Under intermittent	Normal: Normal Under intermittent: Momentary interruption	-
RR Speed Sensor Voltage Open	Rear speed sensor RH voltage open detection	Normal / Under intermittent	Normal: Normal Under intermittent: Momentary interruption	-
RL Speed Sensor Voltage Open	Rear speed sensor LH voltage open detection	Normal / Under intermittent	Normal: Normal Under intermittent: Momentary interruption	-
M/C Pressure Sensor Noise	Master cylinder pressure sensor noise detection	Normal / Under intermittent	Normal: Noise is not detected Under intermittent: Noise is detected	-
Yaw Rate Sensor Voltage Open	Yaw rate sensor (airbag ECU assembly) voltage open detection	Normal / Under intermittent	Normal: Normal Under intermittent: Momentary interruption	-
Master Cylinder Pressure Sensor Power Supply Open	Master cylinder pressure sensor power supply voltage status	Normal / Under intermittent	Normal: Normal Under intermittent: Momentary interruption	-
Solenoid Power Supply Open	Solenoid power supply voltage status	Normal / Under intermittent	Normal: Normal Under intermittent: Momentary interruption	-

TESTER DISPLAY	MEASUREMENT ITEM	RANGE	NORMAL CONDITION	DIAGNOSTIC NOTE
Motor Power Supply Open	Motor power supply voltage status	Normal / Under intermittent	Normal: Normal Under intermittent: Momentary interruption	-
Stop Switch Open	Momentary interruption (open circuit) status in wire harness between No. 2 skid control ECU (brake actuator assembly) and stop light switch assembly status	Normal / Under intermittent	Normal: Normal Under intermittent: Momentary interruption	-
A/C ECU Communication Open	Air conditioning amplifier assembly communication open detection	Normal / Under intermittent	Normal: Normal Under intermittent: Momentary interruption	-
Air Bag ECU Communication Open	Airbag ECU assembly communication open detection	Normal / Under intermittent	Normal: Normal Under intermittent: Momentary interruption	-
Stroke2 Open	Brake pedal stroke sensor 2 open detection	Normal / Under intermittent	Normal: Normal Under intermittent: Momentary interruption	-
HV Communication Open	Hybrid vehicle control ECU communication open detection	Normal / Under intermittent	Normal: Normal Under intermittent: Momentary interruption	-
Body ECU Communication Open	Main body ECU (multiplex network body ECU) communication open detection	Normal / Under intermittent	Normal: Normal Under intermittent: Momentary interruption	-

(h) Push the line graph button to display the line graph.

(i) Check for intermittent shorts, etc.

OK:

Normal is displayed.

HINT:

If "Under intermittent" remains displayed on the GTS, measure the resistance between the skid control ECU and each sensor, hybrid vehicle control ECU or airbag ECU assembly.


- (j) While observing the screen, gently jiggle the connectors or wire harnesses between the ECUs and sensors, or between ECUs.

OK:

Normal is displayed.

HINT:

- If a momentary interruption occurs and Under intermittent is displayed on the GTS, Under intermittent will remain displayed on the GTS for 1 second after the circuit returns to normal.



- If the display changes, this indicates that there has been a momentary interruption (open circuit) in the connector and/or wire harness. In this case, repair or replace the connectors and/or wire harnesses as one of them is faulty.

ACTIVE TEST

HINT:

Using the GTS to perform Active Tests allows relays, VSVs, actuators and other items to be operated without removing any parts. This non-intrusive functional inspection can be very useful because intermittent operation may be discovered before parts or wiring is disturbed. Performing Active Tests early in troubleshooting is one way to save diagnostic time. Data List information can be displayed while performing Active Tests.

- Warm up the engine.
- Turn the ignition switch off.
- Connect the GTS to the DLC3.
- Turn the ignition switch to ON.
- Turn the GTS on.
- Enter the following menus: Chassis / Brake Booster / Active Test.
- Enter the following menus: Chassis / Brake/EPB* / Active Test.
 - *: Electric Parking Brake System
- According to the display on the GTS, perform the Active Test.

NOTICE:

- Although the Active Test automatically turns off the actuator after approximately 5 seconds in order to protect the actuator, do not operate the actuator repeatedly without sufficient waiting time in between.
- To protect the solenoids, do not operate the solenoids repeatedly without sufficient waiting time in between.

- Do not depress the brake pedal when only the pressure release solenoids valves are ON.
- Do not operate more than one solenoid at the same time, except for when operating the pressure hold solenoid and pressure release solenoid of the same wheel.

Chassis > Brake Booster > Active Test

TESTER DISPLAY	MEASUREMENT ITEM	CONTROL RANGE	RESTRICT CONDITION	DIAGNOSTIC NOTE
ECB Solenoid	Switching solenoid (SSA, SGH)	Solenoid Start (Activate) Solenoid SSA / SGH	Vehicle condition: <ul style="list-style-type: none"> • Vehicle stopped • Shift position is in the P or N • Apply the parking brake <p>HINT: To protect actuator and Solenoid(s), this test will continue for 25 seconds.</p>	<ul style="list-style-type: none"> • Check that the GTS display for the solenoid (SSA or SGH) changes to ON/OFF during Solenoid Start (Activate) • ECB: Electronically Controlled Brake System
ECB Main Relay	Main relay	OFF / ON	Vehicle condition: Vehicle stopped <p>HINT: To protect this Actuator and Solenoid, this test will only last 5 seconds.</p>	ECB: Electronically Controlled Brake System
Brake Booster Motor	Brake booster motor	OFF / ON	Vehicle condition: <ul style="list-style-type: none"> • Vehicle stopped • Shift position is in the P or N • Apply the parking brake <p>HINT: To protect this Drive Circuit and Solenoid, this test will only last 10 seconds.</p>	-
Linear Solenoid (SLM1)	Linear solenoid (SLM1)	Solenoid Start (Activate) Solenoid SLM1	Vehicle condition: <ul style="list-style-type: none"> • Vehicle stopped • Shift position is in the P or N • Apply the parking brake <p>HINT: To protect this Drive Circuit and Solenoid,</p>	-

TESTER DISPLAY	MEASUREMENT ITEM	CONTROL RANGE	RESTRICT CONDITION	DIAGNOSTIC NOTE
			this test will only last 2 seconds.	
Linear Solenoid (SLM2)	Linear solenoid (SLM2)	Solenoid Start (Activate) Solenoid SLM2	Vehicle condition: <ul style="list-style-type: none"> Vehicle stopped Shift position is in the P or N Apply the parking brake HINT: To protect this Drive Circuit and Solenoid, this test will only last 2 seconds.	-

Chassis > Brake/EPB > Active Test

TESTER DISPLAY	MEASUREMENT ITEM	CONTROL RANGE	RESTRICT CONDITION	DIAGNOSTIC NOTE
EBS Relay	Emergency brake signal operation	Relay Start	Vehicle condition: Vehicle stopped HINT: To protect this Actuator and Solenoid, this test will only last 5 seconds.	Whether the hazard warning lights blink when the EBS Relay is on can be confirmed. (w/ Emergency Brake Signal)
ABS Solenoid	Pressure holding solenoid (SFRH, SFLH, SRRH, SRLH) Pressure reduction solenoid (SFRR, SFLR, SRRR, SRLR)	Solenoid Start (Activate) Solenoid SFRH / SFLH / SRRH / SRLH / SFRR / SFLR / SRRR / SRLR	Vehicle condition: <ul style="list-style-type: none"> Vehicle stopped Shift position is in the P or N Apply the parking brake HINT: To protect actuator and Solenoid(s), this test will continue for 25 seconds.	Check that the GTS display for the solenoid (SRLR, SRLH, SRRR, SRRH, SFLR, SFLH, SFRR or SFRH) changes to ON/OFF during Solenoid Start (Activate)
VSC Solenoid	Master cylinder cut solenoid (SM1, SM2)	Solenoid Start (Activate) Solenoid SM1 / SM2	Vehicle condition: <ul style="list-style-type: none"> Vehicle stopped Shift position is in the P or N Apply the parking brake 	Check that the GTS display for the solenoid (SM1 or SM2) changes to ON/OFF during Solenoid Start (Activate)

TESTER DISPLAY	MEASUREMENT ITEM	CONTROL RANGE	RESTRICT CONDITION	DIAGNOSTIC NOTE
			<p>HINT: To protect actuator and Solenoid(s), this test will continue for 25 seconds.</p>	
Motor Relay	ABS motor relay	OFF / ON	<p>Vehicle condition: Vehicle stopped</p> <p>HINT: To protect this Actuator and Solenoid, this test will only last 5 seconds.</p>	Operating sound of motor can be heard
Solenoid Relay	Solenoid relay	OFF / ON	<p>Vehicle condition: Vehicle stopped</p> <p>HINT: To protect this Actuator and Solenoid, this test will only last 5 seconds.</p>	Perform the Active Test and check that the voltage displayed for the solenoid power supply voltage Data List item changes.
Stop Lamp Relay	Stop light control relay (stop light switch assembly)	OFF / ON	<p>Vehicle condition: Vehicle stopped</p> <p>HINT: To protect this Actuator and Solenoid, this test will only last 5 seconds.</p>	With the brake pedal released, check that the stop lights illuminate and the value of Stop Light Relay on the GTS changes to ON when Stop Lamp Relay is ON

