

Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM100000028W2I
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [12/2022 -]
Title: M20A-FXS (ENGINE CONTROL): SFI SYSTEM: HOW TO PROCEED WITH TROUBLESHOOTING; 2023 - 2024 MY Prius Prius Prime [12/2022 -]		

HOW TO PROCEED WITH TROUBLESHOOTING

CAUTION / NOTICE / HINT

HINT:

*: Use the GTS.

PROCEDURE

1. VEHICLE BROUGHT TO WORKSHOP

NEXT



2. CUSTOMER PROBLEM ANALYSIS

NEXT



3. CONNECT GTS TO DLC3*

HINT:

If the display indicates a communication malfunction, inspect the DLC3.

When any CAN communication system DTCs are output, perform troubleshooting for the CAN communication system first.

NEXT



4. CHECK DTC AND FREEZE FRAME DATA*

(a) Check for DTCs.

Powertrain > Engine > Trouble Codes

(b) Check for Freeze Frame Data.

Click here [INFO](#)

HINT:

Record or print DTCs and Freeze Frame Data if necessary.

NEXT



5.	CHECK VEHICLE CONTROL HISTORY (RoB) AND VEHICLE CONTROL HISTORY FREEZE FRAME DATA*
-----------	---

(a) Check for Vehicle Control History (RoB) and Vehicle Control History Freeze Frame Data.

Powertrain > Engine > Utility

TESTER DISPLAY
Vehicle Control History (RoB)

HINT:

Print Vehicle Control History (RoB) and Vehicle Control History Freeze Frame Data if necessary.

NEXT



6.	CLEAR DTC AND FREEZE FRAME DATA*
-----------	---

(a) Clear the DTCs and Freeze Frame Data.

Powertrain > Engine > Clear DTCs

NEXT



7.	CONDUCT VISUAL INSPECTION
-----------	----------------------------------


NEXT



8. SELECT CHECK MODE DIAGNOSIS*

(a) Change the ECM from normal mode to check mode.

Powertrain > Engine > Utility



NEXT



9. CONFIRM PROBLEM SYMPTOMS

(a) Confirm the problem symptoms.

HINT:

If the engine does not start, first perform the "Check DTC" procedure and "Conduct Basic Inspection" procedure below.

RESULT	PROCEED TO
Malfunction does not occur	A
Malfunction occurs	B

B **GO TO STEP 11**

A



10. SIMULATE SYMPTOMS

HINT:

Refer to Symptom Simulation.

Click here [INFO](#)

NEXT



11. CHECK DTC*

(a) Check for DTCs.

Powertrain > Engine > Trouble Codes

RESULT	PROCEED TO
DTCs are output	A
DTCs are not output	B

B  **GO TO STEP 13****A****12. REFER TO DTC CHART****HINT:**

Refer to Diagnostic Trouble Code Chart.

NEXT**13. CONDUCT BASIC INSPECTION**

(a) Conduct basic inspection.

Click here 

RESULT	PROCEED TO
Malfunctioning parts not confirmed	A
Malfunctioning parts confirmed	B

B  **GO TO STEP 18****A**



14.	REFER TO PROBLEM SYMPTOMS TABLE
------------	--

HINT:

Refer to Problem Symptoms Table.

Click here [INFO](#)

RESULT	PROCEED TO
Malfunctioning circuit confirmed	A
Malfunctioning parts confirmed	B

B **GO TO STEP 18**

A



15.	CHECK ECM POWER SOURCE CIRCUIT
------------	---------------------------------------

(a) Check the ECM power source circuit.

Click here [INFO](#)

NEXT



16.	CONDUCT CIRCUIT INSPECTION
------------	-----------------------------------

RESULT	PROCEED TO
Malfunction not confirmed	A
Malfunction confirmed	B

B **GO TO STEP 19**

A
▼**17. CHECK FOR INTERMITTENT PROBLEMS**

(a) Check for intermittent problems.

Click here [INFO](#)

NEXT
▼**18. CONDUCT PARTS INSPECTION****NEXT**
▼**19. IDENTIFY PROBLEM****NEXT**
▼**20. ADJUST AND/OR REPAIR****NEXT**
▼**21. CONDUCT CONFIRMATION TEST****NEXT** ► **END**