


Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM10000002BLU4
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [03/2023 -]
Title: M20A-FXS (ENGINE CONTROL): SFI SYSTEM: P001313; Camshaft Position "B" - Actuator Bank 1 Circuit Open; 2023 - 2024 MY Prius Prius Prime [03/2023 -]		

DTC	P001313	Camshaft Position "B" - Actuator Bank 1 Circuit Open
------------	----------------	---

DESCRIPTION

The Variable Valve Timing (VVT) system (for exhaust side) adjusts the exhaust valve timing to improve driveability. The engine oil pressure turns the VVT controller (camshaft timing exhaust gear assembly) to adjust the valve timing.

The cam timing oil control solenoid assembly operates according to signals received from the ECM to control the position of the camshaft timing oil control valve assembly (exhaust camshaft timing gear bolt assembly) and supply engine oil. The camshaft timing oil control valve assembly (exhaust camshaft timing gear bolt assembly) moves when the ECM applies 12 V to the cam timing oil control solenoid assembly. The ECM changes the energizing time of the cam timing oil control solenoid assembly (duty-cycle) in accordance with the camshaft position, crankshaft position, throttle position, etc.



DTC NO.	DETECTION ITEM	DTC DETECTION CONDITION	TROUBLE AREA	MIL	DTC OUTPUT FROM	PRIORITY	NOTE
P001313	Camshaft Position "B" - Actuator Bank 1 Circuit Open	Open or short in cam timing oil control solenoid assembly circuit (1 trip detection logic).	<ul style="list-style-type: none"> Open or short in cam timing oil control solenoid assembly circuit Cam timing oil control solenoid assembly ECM 	Comes on	Engine	A	SAE Code: P0013

MONITOR DESCRIPTION

This DTC is designed to detect an open or short in the cam timing oil control solenoid assembly circuit. If the cam timing oil control solenoid assembly duty-cycle is excessively high or low while the ignition switch is ON or the engine is running, the ECM will illuminate the MIL and store this DTC.

MONITOR STRATEGY

Related DTCs	P0013: Cam timing oil control solenoid assembly range check
Required Sensors/Components (Main)	Cam timing oil control solenoid assembly
Required Sensors/Components (Related)	-
Frequency of Operation	Continuous
Duration	1 second
MIL Operation	Immediate
Sequence of Operation	None

TYPICAL ENABLING CONDITIONS

All

Monitor runs whenever the following DTCs are not stored	None
All of the following conditions are met	-
Auxiliary battery voltage	8 V or higher
Ignition switch	ON
Time after ignition switch off to ON	0.5 seconds or more

Case 1

Either of the following conditions is met	A or B
A. Both of the following conditions are met	-
Auxiliary battery voltage	11 V or higher, and less than 13 V

Target duty cycle	Less than 70%
B. Both of the following conditions are met	-
Auxiliary battery voltage	13 V or higher
Target duty cycle	Less than 80%

Case 2

Both of the following conditions are met	-
Current cut status	Not cut
Target duty cycle	22.5% or higher

TYPICAL MALFUNCTION THRESHOLDS**Case 1**

Output duty cycle	100% or higher
-------------------	----------------

Case 2

Output duty cycle	0% or less
-------------------	------------

CONFIRMATION DRIVING PATTERN**HINT:**

- After repair has been completed, clear the DTC and then check that the vehicle has returned to normal by performing the following All Readiness check procedure.

[Click here](#) INFO

- When clearing the permanent DTCs, refer to the "CLEAR PERMANENT DTC" procedure.

[Click here](#) INFO

- Clear the DTCs (even if no DTCs are stored, perform the clear DTC procedure).
- Turn the ignition switch off and wait for at least 30 seconds.
- Put the engine in Inspection Mode (Maintenance Mode).

[Click here](#) INFO

- Start the engine [A].
- Wait 5 seconds or more [B].
- Enter the following menus: Powertrain / Engine / Trouble Codes [C].
- Read the pending DTCs.

HINT:

- If a pending DTC is output, the system is malfunctioning.
- If a pending DTC is not output, perform the following procedure.

- Enter the following menus: Powertrain / Engine / Utility / All Readiness.
- Input the DTC: P001313.
- Check the DTC judgment result.

HINT:


- If the judgment result is NORMAL, the system is normal.
- If the judgment result is ABNORMAL, the system has a malfunction.

- If the judgment result is INCOMPLETE, perform steps [A] through [C] again.
- [A] to [C]: Normal judgment procedure.

The normal judgment procedure is used to complete DTC judgment and also used when clearing permanent DTCs.

- When clearing the permanent DTCs, do not disconnect the cable from the auxiliary battery terminal or attempt to clear the DTCs during this procedure, as doing so will clear the universal trip and normal judgment histories.

WIRING DIAGRAM



CAUTION / NOTICE / HINT

NOTICE:

- Vehicle Control History may be stored in the hybrid vehicle control ECU if the engine is malfunctioning. Certain vehicle condition information is recorded when Vehicle Control History is stored. Reading the vehicle conditions recorded in both the freeze frame data and Vehicle Control History can be useful for troubleshooting.

for HEV Model: [Click here](#) INFO

for PHEV Model: [Click here](#) INFO

(Select Powertrain in Health Check and then check the time stamp data.)

- If any "Engine Malfunction" Vehicle Control History item has been stored in the hybrid vehicle control ECU, make sure to clear it. However, as all Vehicle Control History items are cleared simultaneously, if any Vehicle Control History items other than "Engine Malfunction" are stored, make sure to perform any troubleshooting for them before clearing Vehicle Control History.

for HEV Model: [Click here](#) INFO

for PHEV Model: [Click here](#) INFO

PROCEDURE

1.	CLEAR DTC
-----------	------------------

Pre-procedure1

(a) None

Procedure1

(b) Clear the DTC after recording the Freeze Frame Data and DTC.

Powertrain > Engine > Clear DTCs

Post-procedure1

(c) Turn the ignition switch off and wait for at least 30 seconds.

NEXT




2. READ OUTPUT DTC (DTC P001313)

Pre-procedure1

(a) Put the engine in Inspection Mode (Maintenance Mode).

Powertrain > Hybrid Control > Utility



(b) Start the engine.

Procedure1

(c) Read the DTCs.

Powertrain > Engine > Trouble Codes

RESULT	PROCEED TO
DTCs are not output	A
P001313 is output	B

Post-procedure1


(d) None

A **CHECK FOR INTERMITTENT PROBLEMS**

B



3. INSPECT CAM TIMING OIL CONTROL SOLENOID ASSEMBLY

Click here 

NG  **REPLACE CAM TIMING OIL CONTROL SOLENOID ASSEMBLY**

OK


4. CHECK HARNESS AND CONNECTOR (CAM TIMING OIL CONTROL SOLENOID ASSEMBLY - ECM)

Pre-procedure1

- (a) Disconnect the cam timing oil control solenoid assembly connector.
- (b) Disconnect the ECM connector.

Procedure1

- (c) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(C22,C52\).](#)

[Click Connector\(C22\).](#)

[Click Connector\(C52\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION	RESULT
C22-2 (+) - C52-26 (OE1+)	Always	Below 1 Ω	Ω
C22-1 (-) - C52-25 (OE1-)	Always	Below 1 Ω	Ω
C22-2 (+) or C52-26 (OE1+) - Body ground and other terminals	Always	10 kΩ or higher	kΩ
C22-1 (-) or C52-25 (OE1-) - Body ground and other terminals	Always	10 kΩ or higher	kΩ

Post-procedure1

- (d) None

OK  **REPLACE ECM**

NG  **REPAIR OR REPLACE HARNESS OR CONNECTOR**

