

<b>Last Modified:</b> 12-04-2024	6.11:8.1.0	<b>Doc ID:</b> RM100000002BIHB
<b>Model Year Start:</b> 2023	<b>Model:</b> Prius Prime	<b>Prod Date Range:</b> [03/2023 - ]
<b>Title:</b> M20A-FXS (ENGINE MECHANICAL): CYLINDER BLOCK: DISASSEMBLY; 2023 - 2024 MY Prius Prius Prime [03/2023 - ]		

## DISASSEMBLY

### CAUTION / NOTICE / HINT

The necessary procedures (adjustment, calibration, initialization or registration) that must be performed after parts are removed and installed, or replaced during engine unit removal/installation are shown below.

#### **Necessary Procedures After Parts Removed/Installed/Replaced**

REPLACED PART OR PERFORMED PROCEDURE	NECESSARY PROCEDURE	EFFECT/INOPERATIVE FUNCTION WHEN NECESSARY PROCEDURE NOT PERFORMED	LINK
Replacement of ECM	Perform Vehicle Identification Number (VIN) registration	DTC is output	<a href="#">INFO</a>
	ECU configuration	-	<a href="#">INFO</a>
	Update ECU security key	Vehicle Control History (RoB) are stored	<a href="#">INFO</a>
<ul style="list-style-type: none"> <li>Replacement of throttle body with motor assembly</li> <li>Cleaning the deposits from the throttle body with motor assembly</li> <li>Replacement of cam timing control motor with EDU assembly*</li> <li>Replacement of camshaft timing gear assembly*</li> <li>Replacement of camshaft (for</li> </ul>	Inspection after repair	<ul style="list-style-type: none"> <li>Poor idle, etc.</li> <li>Engine start function, etc.</li> </ul>	<a href="#">INFO</a>

\*: Even when not replacing the part, it is necessary to perform the specified necessary procedures after installation.

\*1: Also necessary after performing a tire rotation.

\*2: It is not necessary to perform this procedure if the tire pressure warning valve and transmitters are installed to the same location.

\*3: The vehicle height changes because of tire replacement.

\*4: If matchmarks were not placed when removing parts related to steering operation, perform end position initial setting.

REPLACED PART OR PERFORMED PROCEDURE	NECESSARY PROCEDURE	EFFECT/INOPERATIVE FUNCTION WHEN NECESSARY PROCEDURE NOT PERFORMED	LINK
intake or exhaust camshaft) <ul style="list-style-type: none"> <li>• Replacement of camshaft timing exhaust gear assembly</li> <li>• Replacement of fuel (engine room side) pump assembly (for high pressure side)</li> <li>• Replacement of ignition coil assembly</li> <li>• Replacement of engine assembly</li> <li>• Gas leak from exhaust system is repaired</li> <li>• Replacement of cylinder head sub-assembly</li> <li>• Replacement of port fuel injector assembly</li> <li>• Replacement of direct fuel injector assembly</li> <li>• Replacement of EGR valve assembly</li> <li>• Replacement of air fuel ratio sensor (sensor 1)</li> <li>• Replacement of knock control sensor</li> <li>• Replacement of spark plug</li> </ul>			

\*: Even when not replacing the part, it is necessary to perform the specified necessary procedures after installation.

\*1: Also necessary after performing a tire rotation.

\*2: It is not necessary to perform this procedure if the tire pressure warning valve and transmitters are installed to the same location.

\*3: The vehicle height changes because of tire replacement.

\*4: If matchmarks were not placed when removing parts related to steering operation, perform end position initial setting.

REPLACED PART OR PERFORMED PROCEDURE	NECESSARY PROCEDURE	EFFECT/INOPERATIVE FUNCTION WHEN NECESSARY PROCEDURE NOT PERFORMED	LINK
<ul style="list-style-type: none"> <li>Replacement of piston or piston ring</li> </ul>			
Replacement of inverter with converter assembly	ECU configuration	-	<a href="#">INFO</a>
	Resolver learning	<ul style="list-style-type: none"> <li>DTCs are stored</li> <li>Slight vibration at a vehicle speed of 5 km/h (3 mph) or less</li> <li>Shock or vibration during acceleration</li> </ul>	for M20A-FXS HEV Model: <a href="#">INFO</a> for M20A-FXS PHEV Model: <a href="#">INFO</a>
<b>for PHEV Model:</b> Replacement of service plug grip	High voltage fuse accumulated load history reset	DTCs are stored	<a href="#">INFO</a>
Replacement of hybrid vehicle transaxle assembly	<ul style="list-style-type: none"> <li>Resolver learning</li> <li>Initialize resolver</li> </ul>	<ul style="list-style-type: none"> <li>DTCs are stored</li> <li>Slight vibration at a vehicle speed of 5 km/h (3 mph) or less</li> <li>Shock or vibration during acceleration</li> </ul>	for M20A-FXS HEV Model: <a href="#">INFO</a> for M20A-FXS PHEV Model: <a href="#">INFO</a>
Suspension parts	Rear television camera assembly optical axis (Back camera position setting)	Parking Assist Monitor System	<a href="#">INFO</a>
	Parking assist ECU initialization	Panoramic View Monitor System	<a href="#">INFO</a>
		Advanced Park	<a href="#">INFO</a>
Tires	<ul style="list-style-type: none"> <li>Initialization*1*2</li> </ul>	Tire Pressure Warning System	Refer to Procedures Necessary When
<p>*: Even when not replacing the part, it is necessary to perform the specified necessary procedures after installation.</p> <p>*1: Also necessary after performing a tire rotation.</p> <p>*2: It is not necessary to perform this procedure if the tire pressure warning valve and transmitters are installed to the same location.</p> <p>*3: The vehicle height changes because of tire replacement.</p> <p>*4: If matchmarks were not placed when removing parts related to steering operation, perform end position initial setting.</p>			

REPLACED PART OR PERFORMED PROCEDURE	NECESSARY PROCEDURE	EFFECT/INOPERATIVE FUNCTION WHEN NECESSARY PROCEDURE NOT PERFORMED	LINK
	<ul style="list-style-type: none"> <li>Tire Position Identification*1*2</li> </ul>		Replacing Parts (for Tire Pressure Warning System) table below <a href="#">INFO</a>
	Rear television camera assembly optical axis (Back camera position setting)	Parking Assist Monitor System	<a href="#">INFO</a>
	Parking assist ECU initialization*3	Panoramic View Monitor System	<a href="#">INFO</a>
		Advanced Park	<a href="#">INFO</a>
No. 2 steering intermediate shaft assembly*4	End position initial setting	-	<a href="#">INFO</a>
Replacement of front bumper assembly*	Front television camera view adjustment	Panoramic View Monitor System	<a href="#">INFO</a>
		Advanced Park	<a href="#">INFO</a>
Front wheel alignment adjustment	Perform "Calibration"	<ul style="list-style-type: none"> <li>DTCs are stored</li> <li>ABS warning light illuminates</li> <li>Brake system warning light (yellow indicator) illuminates</li> <li>Slip indicator light illuminates</li> <li>Electronically controlled brake system disabled or malfunctions</li> </ul>	<a href="#">INFO</a>

\*: Even when not replacing the part, it is necessary to perform the specified necessary procedures after installation.

\*1: Also necessary after performing a tire rotation.

\*2: It is not necessary to perform this procedure if the tire pressure warning valve and transmitters are installed to the same location.

\*3: The vehicle height changes because of tire replacement.

\*4: If matchmarks were not placed when removing parts related to steering operation, perform end position initial setting.

### HINT:

When the cable is disconnected / reconnected to the auxiliary battery terminal, systems temporarily stop operating. However, each system has a function that completes learning the first time the system is used.

### Items for which learning is completed by driving the vehicle


EFFECT/INOPERATIVE FUNCTION WHEN NECESSARY PROCEDURE NOT PERFORMED	NECESSARY PROCEDURES	LINK
Front Camera System	Drive the vehicle straight ahead at 35 km/h (22 mph) or more for 5 seconds or more.	<a href="#">INFO</a>

### Items for which learning is completed by operating the vehicle normally




EFFECT/INOPERATIVE FUNCTION WHEN NECESSARY PROCEDURE NOT PERFORMED	NECESSARY PROCEDURES	LINK
Power Door Lock Control System*1 <ul style="list-style-type: none"> <li>Back door opener</li> </ul>	Perform door unlock operation with door control switch or electrical key transmitter sub-assembly switch.	<a href="#">INFO</a>
Power Back Door System*2	Reset back door close position	<a href="#">INFO</a>
Air Conditioning System	<p><b>for HEV Model:</b></p> <p>After the ignition switch is turned to ON, the servo motor standard position is recognized.</p> <p><b>for PHEV Model:</b></p> <p>After the ignition switch is turned to ON, the servo motor and cooler expansion valve standard position is recognized.</p>	-
*1: w/o Power Back Door System		
*2: w/ Power Back Door System		


## CAUTION / NOTICE / HINT

### COMPONENTS (DISASSEMBLY)




PROCEDURE		PART NAME CODE	!		
1	NO. 1 VENTILATION CASE	12211	INFO	-	-
2	CYLINDER BLOCK WITH HEAD STRAIGHT SCREW PLUG	11432R	INFO	-	-
3	INSPECT CONNECTING ROD THRUST CLEARANCE	-	INFO	-	-
4	INSPECT CONNECTING ROD OIL CLEARANCE	-	INFO	-	-
5	PISTON WITH CONNECTING ROD	-	INFO	-	-
6	CONNECTING ROD BEARING	13041	-	-	-
7	INSPECT CRANKSHAFT THRUST CLEARANCE	-	INFO	-	-
8	CRANKSHAFT BEARING CAP	-	INFO	-	-
9	CRANKSHAFT	13411	-	-	-
10	CRANKSHAFT THRUST WASHER	11791	-	-	-
11	CRANKSHAFT BEARING	11711	-	-	-

PROCEDURE		PART NAME CODE			
12	PISTON RING SET	13011	<a href="#">INFO</a>	-	-
13	PISTON PIN	-	<a href="#">INFO</a>	-	-
14	NO. 1 OIL NOZZLE SUB-ASSEMBLY	15708	<a href="#">INFO</a>	-	-
15	NO. 2 OIL NOZZLE SUB-ASSEMBLY	15709	<a href="#">INFO</a>	-	-
16	RING PIN	-	<a href="#">INFO</a>	-	-
17	STRAIGHT PIN	-	<a href="#">INFO</a>	-	-

*1	CONNECTING ROD BEARING CAP	-	-
*a	<p><b>HINT:</b> As the illustration shown is an example, the actual details may differ.</p>	-	-
	Tightening torque for "Major areas involving basic vehicle performance such as moving/turning/stopping": N*m (kgf*cm, ft.*lbf)	•	Non-reusable part
*T1	1st: 38 (387, 28) 2nd: Turn 90°	-	-


## PROCEDURE

### 1. REMOVE NO. 1 VENTILATION CASE

	<p><b>CAUTION:</b></p> <ul style="list-style-type: none"> <li>When the No. 1 ventilation case is fastened using only bolt A: Perform this procedure only when replacement of the No. 1 ventilation case is necessary.</li> <li>When the No. 1 ventilation case is fastened using bolt B: Do not remove and install the No. 1 ventilation case.</li> </ul>
---	---



*a	Bolt A	*b	Bolt B
----	--------	----	--------




## 2. REMOVE CYLINDER BLOCK WITH HEAD STRAIGHT SCREW PLUG



- (1) Using a 10 mm hexagon socket wrench, remove the cylinder block with head straight screw plug and gasket from the cylinder block sub-assembly.

## 3. INSPECT CONNECTING ROD THRUST CLEARANCE



- (1) Using a dial indicator, measure the thrust clearance while moving the connecting rod sub-assembly back and forth.

Standard Thrust Clearance:

0.160 to 0.512 mm (0.00630 to 0.0202 in.)


Maximum Thrust Clearance:

0.512 mm (0.0202 in.)

- (2) If the thrust clearance is more than the maximum, replace the connecting rod. If necessary, replace the crankshaft.

## 4. INSPECT CONNECTING ROD OIL CLEARANCE






*a	Alignment Mark	-	-
----	----------------	---	---

- (1) Note the alignment marks on the connecting rod and connecting rod bearing cap so that they can be reinstalled to their original locations.
- (2) Using an E12 "TORX" socket wrench, remove the 2 connecting rod bolts, then remove the connecting rod bearing cap and connecting rod bearing together as a set.
- (3) Clean the crank pin and connecting rod bearing and check the crank pin and connecting rod bearing for pitting and scratches.

**NOTICE:**

Check the crank pin and connecting rod bearing for pitting and scratches.



*a	Plastigage	*b	Front Mark
*c	Paint Mark	*d	90°
*e	Front of Engine	*f	1, 2 or 3 Mark

- (1) Lay a strip of Plastigage on the crank pin.
- (2) Check that the front mark of the connecting rod bearing cap is facing the correct direction, and install the connecting rod bearing cap to the connecting rod.
- (3) Apply a light coat of engine oil to the threads and under the heads of the 2 connecting rod bolts.
- (4) Using an E12 "TORX" socket wrench, install and alternately tighten the 2 connecting rod bolts in several steps.

**Torque:**

**38 N·m {387 kgf·cm, 28 ft·lbf}**

- (5) Mark the front of each connecting rod bolt with paint.
- (6) Tighten the connecting rod bolts 90° as shown in the illustration.

**NOTICE:**

Do not turn the crankshaft during the measurement.

- (7) Using an E12 "TORX" socket wrench, remove the 2 connecting rod bolts and connecting rod bearing cap.
- (8) Measure the Plastigage at its widest point.

Standard Oil Clearance:

0.032 to 0.065 mm (0.00126 to 0.00256 in.)

Maximum Oil Clearance:

0.065 mm (0.00256 in.)

**HINT:**

If replacing a connecting rod bearing, select a new one with the same number as marked on the connecting rod bearing cap. There are 3 sizes of standard connecting rod bearings, marked "1", "2" or "3" accordingly.

Standard Connecting Rod Big End Inside Diameter:

MARK	SPECIFIED CONDITION
1	51.000 to 51.008 mm (2.00787 to 2.00818 in.)
2	51.008 to 51.016 mm (2.00818 to 2.00850 in.)
3	51.016 to 51.024 mm (2.00850 to 2.00881 in.)

Standard Connecting Rod Bearing Center Wall Thickness:

MARK	SPECIFIED CONDITION
1	1.483 to 1.487 mm (0.0584 to 0.0585 in.)
2	1.487 to 1.491 mm (0.0585 to 0.0587 in.)
3	1.491 to 1.495 mm (0.0587 to 0.0589 in.)

Standard Crank Pin Diameter:

47.992 to 48.000 mm (1.88945 to 1.88976 in.)


**NOTICE:**

Remove the Plastigage completely after the measurement.


(9) If the oil clearance is more than the maximum, replace the connecting rod bearings.

(10) Perform the inspection above for each cylinder.

## 5. REMOVE PISTON WITH CONNECTING ROD




(1) Using a ridge reamer, remove all the carbon from the top of each cylinder.



## 6. REMOVE CONNECTING ROD BEARING



## 7. INSPECT CRANKSHAFT THRUST CLEARANCE



(1) Using a dial indicator, measure the crankshaft thrust clearance while prying the crankshaft back and forth with a screwdriver.

Standard Thrust Clearance:

0.02 to 0.22 mm (0.000787 to 0.00866 in.)

Maximum Thrust Clearance:


0.22 mm (0.00866 in.)

Standard Crankshaft Thrust Washer Thickness:

2.415 to 2.465 mm (0.0951 to 0.0970 in.)


- (2) If the thrust clearance is more than the maximum, replace the crankshaft thrust washers as a set. If necessary, replace the crankshaft.

## 8. REMOVE CRANKSHAFT BEARING CAP




- (1) Uniformly loosen and remove the 10 crankshaft bearing cap set bolts in several steps in the order shown in the illustration.
- (2) While moving the crankshaft bearing cap back and forth using 2 crankshaft bearing cap set bolts, remove the crankshaft bearing cap together with the crankshaft bearing.

## 9. REMOVE CRANKSHAFT




## 10. REMOVE CRANKSHAFT THRUST WASHER



## 11. REMOVE CRANKSHAFT BEARING




## 12. REMOVE PISTON RING SET



(1) Using a piston ring expander, remove the No. 1 compression ring and No. 2 compression ring from the piston.

(2) Remove the oil ring expander, upper side rail and lower side rail from the piston by hand.

## 13. REMOVE PISTON PIN



*1	Front Mark Cutout Portion	-	-
----	---------------------------	---	---

(1) Using a screwdriver with its tip wrapped with protective tape, pry out the piston pin hole snap ring (front side) from the piston.

**NOTICE:**

- Do not remove the piston pin hole snap ring (rear side) unless it has to be replaced.
- Be careful not to damage the piston when removing the piston pin hole snap ring (rear side).


(2) Gradually heat each piston to between 80 and 90°C (176 and 194°F).

**CAUTION:**

Be sure to wear protective gloves.


(3) Using a brass bar and a hammer, lightly tap out the piston pin and remove the connecting rod.

**14. REMOVE NO. 1 OIL NOZZLE SUB-ASSEMBLY**





- (1) Using a 5 mm hexagon socket wrench, remove the 4 bolts and 4 No. 1 oil nozzle sub-assemblies from the cylinder block sub-assembly.

## 15. REMOVE NO. 2 OIL NOZZLE SUB-ASSEMBLY



- (1) Using a 5 mm hexagon socket wrench, remove the 4 bolts and 4 No. 2 oil nozzle sub-assemblies from the cylinder block sub-assembly.

## 16. REMOVE RING PIN



## 17. REMOVE STRAIGHT PIN



