

Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM100000029ZXE
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [12/2022 -]
Title: M20A-FXS (FUEL): FUEL PRESSURE SENSOR (for High Pressure): INSPECTION; 2023 - 2024 MY Prius Prius Prime [12/2022 -]		

INSPECTION

PROCEDURE

1. INSPECT FUEL PRESSURE SENSOR

(a) Check the fuel pressure sensor output voltage.


(1) Apply 5 V between terminals 1 (VC) and 2 (E2).

NOTICE:

- Be careful when connecting the leads, as the fuel pressure sensor may be damaged if the leads are connected to the wrong terminals.
- Do not apply more than 6 V to terminals 1 (VC) or 2 (E2).

HINT:

If a stable power supply is not available, connect 4 nickel-metal hydride batteries (1.2 V each) or equivalent in series.




*a	Component without harness connected (Fuel Pressure Sensor)
*b	Voltage Applied between Terminals

(2) Measure the voltage according to the value(s) in the table below.

Standard Voltage:

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
3 (PR) - 2 (E2)	Pressure not applied to fuel pressure sensor	Approximately 0.4 to 0.6 V*



*a	Component without harness connected (Fuel Pressure Sensor)
----	--

*: The output voltage changes depending on the voltage applied to the terminals.

If the result is not as specified, replace the fuel pressure sensor.

