


<b>Last Modified:</b> 12-04-2024	6.11:8.1.0	<b>Doc ID:</b> RM1000000029QX4
<b>Model Year Start:</b> 2023	<b>Model:</b> Prius Prime	<b>Prod Date Range:</b> [12/2022 - ]
<b>Title:</b> HYBRID / BATTERY CONTROL: ACCELERATOR PEDAL SENSOR: REMOVAL; 2023 - 2024 MY Prius Prius Prime [12/2022 - ]		

## REMOVAL

### CAUTION / NOTICE / HINT


#### COMPONENTS (REMOVAL)



	PROCEDURE	PART NAME CODE			
1	ACCELERATOR PEDAL PAD	78118	-	-	-
2	ACCELERATOR PEDAL (WITH SENSOR) ROD ASSEMBLY	78110K	<a href="#">INFO</a>	-	-

## PROCEDURE


### 1. REMOVE ACCELERATOR PEDAL PAD



### 2. REMOVE ACCELERATOR PEDAL (WITH SENSOR) ROD ASSEMBLY

**NOTICE:**

- Avoid physical shock to the accelerator pedal (with sensor) rod assembly.
- If the accelerator pedal (with sensor) rod assembly has been struck or dropped, replace it.
- Do not disassemble the accelerator pedal (with sensor) rod assembly.
- The accelerator pedal (with sensor) rod assembly does not require lubrication.
- Do not apply oil or other lubricants to the accelerator pedal (with sensor) rod assembly. If applied, the accelerator pedal (with sensor) rod assembly must be replaced.



c

