

Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM100000029A44
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [12/2022 -]
Title: HYBRID / BATTERY CONTROL: HYBRID BATTERY SYSTEM (for M20A-FXS): P0ABF28; Hybrid/EV Battery Current Sensor "A" Signal Bias Level Out of Range / Zero Adjustment Failure; 2023 - 2024 MY Prius Prius Prime [12/2022 -]		

DTC	P0ABF28	Hybrid/EV Battery Current Sensor "A" Signal Bias Level Out of Range / Zero Adjustment Failure
------------	----------------	--

DESCRIPTION

Refer to the description for DTC P0ABF11.

Click here [INFO](#)

DTC NO.	DETECTION ITEM	DTC DETECTION CONDITION	TROUBLE AREA	MIL	WARNING INDICATE	DTC OUTPUT FROM	PRIORITY	NOTE
P0ABF28	Hybrid/EV Battery Current Sensor "A" Signal Bias Level Out of Range / Zero Adjustment Failure	The offset value of the battery current sensor is excessively large. (1 trip detection logic)	<ul style="list-style-type: none"> No. 1 traction battery device box Battery ECU assembly Wire harness or connector 	Comes on	Master Warning: Comes on	HV Battery	A	SAE Code: POACO

HINT:

- Make sure to perform Current Sensor Offset Learning after replacing a battery current sensor.
- This DTC may be output if Current Sensor Offset Learning has not been completed.

MONITOR DESCRIPTION

If the battery ECU assembly detects a malfunction in a battery current sensor, the battery ECU assembly will illuminate the MIL and store a DTC.

MONITOR STRATEGY

Related DTCs	P0ACO (INF P0ABF28): Current sensor malfunction
Required sensors/components	Battery current sensor
Frequency of operation	Continuous
Duration	TMC's intellectual property
MIL operation	1 driving cycle
Sequence of operation	None

TYPICAL ENABLING CONDITIONS

The monitor will run whenever the following DTCs are not stored	TMC's intellectual property
Other conditions belong to TMC's intellectual property	-

TYPICAL MALFUNCTION THRESHOLDS

TMC's intellectual property	-
-----------------------------	---

COMPONENT OPERATING RANGE

Battery ECU assembly	DTC P0AC0 (INF P0ABF28) is not detected
----------------------	---

CONFIRMATION DRIVING PATTERN

HINT:

- After repair has been completed, clear the DTC and then check that the vehicle has returned to normal by performing the following All Readiness check procedure.

[Click here](#) INFO

- When clearing the permanent DTCs, refer to the "CLEAR PERMANENT DTC" procedure.

[Click here](#) INFO

- Clear the DTCs (even if no DTCs are stored, perform the clear DTC procedure).
- Turn the ignition switch off and wait for 2 minutes or more.
- Drive the vehicle on urban roads for approximately 10 minutes.[*1]
- Turn the ignition switch off and wait for 2 minutes or more.[*2]
- Turn the ignition switch to ON and turn the GTS on.[*3]
- With ignition switch ON and wait for 10 seconds or more.[*4]

HINT:

[*1] to [*4]: Normal judgment procedure.

The normal judgment procedure is used to complete DTC judgment and also used when clearing permanent DTCs.

- Enter the following menus: Powertrain / HV Battery / Utility / All Readiness.
- Check the DTC judgment result.

HINT:

- If the judgment result shows NORMAL, the system is normal.
- If the judgment result shows ABNORMAL, the system has a malfunction.
- If the judgment result shows INCOMPLETE, perform the normal judgment procedure again.

WIRING DIAGRAM

Refer to the wiring diagram for DTC P0ABF11.

[Click here](#) INFO

CAUTION / NOTICE / HINT

CAUTION:

Refer to the precautions before inspecting high voltage circuit.

[Click here](#) INFO

NOTICE:

- After the ignition switch is turned off, there may be a waiting time before disconnecting the negative (-) auxiliary battery terminal.

[Click here](#) INFO

- When disconnecting and reconnecting the auxiliary battery

HINT:

When disconnecting and reconnecting the auxiliary battery, there is an automatic learning function that completes learning when the respective system is used.

[Click here](#) INFO

PROCEDURE

1.	CHECK DTC OUTPUT (HV BATTERY, HYBRID CONTROL)
-----------	--

Pre-procedure1

(a) None

Procedure1

(b) Check for DTCs.

Powertrain > HV Battery > Trouble Codes

Powertrain > Hybrid Control > Trouble Codes

RESULT	PROCEED TO
"P0ABF28" only is output, or DTCs except the ones in the table below are also output.	A
DTCs of hybrid battery system in the table below are output.	B
DTCs of hybrid control system in the table below are output.	C

SYSTEM	RELEVANT DTC	
Hybrid battery system	P060A47	Hybrid/EV Battery Energy Control Module Monitoring Processor Watchdog / Safety MCU Failure
	P060B49	Hybrid/EV Battery Energy Control Module A/D Processing Internal Electronic Failure
	P060687	Hybrid/EV Battery Energy Control Module Processor to Monitoring Processor Missing Message
	P062F46	Hybrid/EV Battery Energy Control Module EEPROM Calibration / Parameter Memory Failure
Hybrid control system	P0A1F94	Hybrid/EV Battery Energy Control Module Unexpected Operation

Post-procedure1

(c) Turn the ignition switch off.

B ► GO TO DTC CHART (HYBRID BATTERY SYSTEM)

C ► GO TO DTC CHART (HYBRID CONTROL SYSTEM)

A



2.

CHECK HARNESS AND CONNECTOR (BATTERY ECU ASSEMBLY - NO. 1 TRACTION BATTERY DEVICE BOX)

CAUTION:

Be sure to wear insulated gloves and protective goggles.

Pre-procedure1

(a) Check that the service plug grip is not installed.


NOTICE:

After removing the service plug grip, do not turn the ignition switch to ON (READY), unless instructed by the repair manual because this may cause a malfunction.

(b) Disconnect the battery ECU assembly connector.

NOTICE:


Before disconnecting the connector, check that it is not loose or disconnected.



(c) Disconnect the battery current sensor connector from the No. 1 traction battery device box.

NOTICE:

Before disconnecting the connector, check that it is not loose or disconnected.



Procedure1

(d) Measure the resistance according to the value(s) in the tables below.

Standard Resistance (Check for Open):



[Click Location & Routing\(R40,R47\).](#)

[Click Connector\(R40\).](#)

[Click Connector\(R47\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
R40-6 (IB1) - R47-2 (IB1)	Ignition switch off	Below 1 Ω
R40-18 (GIB) - R47-3 (GIB)	Ignition switch off	Below 1 Ω
R40-5 (IB0) - R47-4 (IB0)	Ignition switch off	Below 1 Ω
R40-17 (VIB) - R47-1 (VIB)	Ignition switch off	Below 1 Ω

Standard Resistance (Check for Short):



[Click Location & Routing\(R40,R47\).](#)

[Click Connector\(R40\).](#)

[Click Connector\(R47\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
R40-6 (IB1) or R47-2 (IB1) - Body ground and other terminals	Ignition switch off	10 k Ω or higher
R40-18 (GIB) or R47-3 (GIB) - Body ground and other terminals	Ignition switch off	10 k Ω or higher
R40-5 (IB0) or R47-4 (IB0) - Body ground and other terminals	Ignition switch off	10 k Ω or higher
R40-17 (VIB) or R47-1 (VIB) - Body ground and other terminals	Ignition switch off	10 k Ω or higher

Post-procedure1

(e) Reconnect the battery current sensor connector to the No. 1 traction battery device box.

(f) Reconnect the battery ECU assembly connector.

NG  **REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK


3. CHECK NO.1 TRACTION BATTERY DEVICE BOX (BATTERY CURRENT SENSOR (IB0))

CAUTION:

Be sure to wear insulated gloves and protective goggles.

Pre-procedure1

(a) Check that the service plug grip is not installed.

NOTICE:

After removing the service plug grip, do not turn the ignition switch to ON (READY), unless instructed by the repair manual because this may cause a malfunction.

(b) Connect the cable to the negative (-) auxiliary battery terminal.

(c) Turn the ignition switch to ON.

Procedure1

(d) Using a toyota electrical tester set to 40 V, measure the VIB voltage according to the value(s) in the table below.




[Click Location & Routing\(R47\).](#)

[Click Connector\(R47\).](#)

TESTER CONNECTION	TESTER CONNECTION
R47-1 (VIB) - R47-3 (GIB)	Ignition switch ON

NOTICE:

- Turning the ignition switch to ON with the service plug grip removed causes other DTCs to be stored. Clear the DTCs after performing this inspection.
- Be sure to set the toyota electrical tester to 40 V when performing this test.



*a	Component with harness connected (No. 1 Traction Battery Device Box (Battery Current Sensor))
----	--

(e) Using a toyota electrical tester set to 4 V, measure the IB0 voltage according to the value(s) in the table below.

 EWD INFO


[Click Location & Routing\(R47\).](#)

[Click Connector\(R47\).](#)

TESTER CONNECTION	TESTER CONNECTION
R47-4 (IB0) - R47-3 (GIB)	Ignition switch ON

NOTICE:

Be sure to set the toyota electrical tester to 4 V when performing this test.



*a	Component with harness connected (No. 1 Traction Battery Device Box (Battery Current Sensor))
----	--

(f) Compare the measured values of the IB0 terminal voltage and VIB terminal voltage using the following formula:

$IB0 \text{ voltage} - 0.584 \times VIB \text{ Voltage} = \text{less than } 0.060 \text{ V}$
$IB0 \text{ voltage} - 0.584 \times VIB \text{ Voltage} = -0.060 \text{ V or higher}$

RESULT	PROCEED TO
Within the specified range above	A
Other than above	B

Post-procedure1

(g) Turn the ignition switch off.

(h) Disconnect the cable from the negative (-) auxiliary battery terminal.

B ▶ REPLACE NO.1 TRACTION BATTERY DEVICE BOX



4. CHECK NO.1 TRACTION BATTERY DEVICE BOX (BATTERY CURRENT SENSOR (IB1))

CAUTION:

Be sure to wear insulated gloves.

Pre-procedure1

(a) Check that the service plug grip is not installed.

NOTICE:

After removing the service plug grip, do not turn the ignition switch to ON (READY), unless instructed by the repair manual because this may cause a malfunction.

(b) Connect the cable to the negative (-) auxiliary battery terminal.

(c) Turn the ignition switch to ON.

Procedure1

(d) Using a toyota electrical tester set to 40 V, measure the VIB voltage according to the value(s) in the table below.




[Click Location & Routing\(R47\)](#)

[Click Connector\(R47\)](#)

TESTER CONNECTION	TESTER CONNECTION
R47-1 (VIB) - R47-3 (GIB)	Ignition switch ON

NOTICE:

- Turning the ignition switch to ON with the service plug grip removed causes other DTCs to be stored. Clear the DTCs after performing this inspection.
- Be sure to set the toyota electrical tester to 40 V when performing this test.



*a	Component with harness connected (No. 1 Traction Battery Device Box (Battery Current Sensor))
----	--

(e) Using a toyota electrical tester set to 4 V, measure the IB1 voltage according to the value(s) in the table below.

 EWD INFO


[Click Location & Routing\(R47\).](#)

[Click Connector\(R47\).](#)

TESTER CONNECTION	TESTER CONNECTION
R47-2 (IB1) - R47-3 (GIB)	Ignition switch ON

NOTICE:

Be sure to set the toyota electrical tester to 4 V when performing this test.



*a Component with harness connected (No. 1 Traction Battery Device Box (Battery Current Sensor))

(f) Compare the measured values of the IB1 terminal voltage and VIB terminal voltage using the following formula:

CONDITION
$IB1 \text{ voltage} - 0.416 \times VIB \text{ Voltage} = \text{less than } 0.060 \text{ V}$
$IB1 \text{ voltage} - 0.416 \times VIB \text{ Voltage} = -0.060 \text{ V or higher}$

RESULT	PROCEED TO
Within the specified range above.	A
Other than above	B

Post-procedure1

(g) Turn the ignition switch off.

(h) Disconnect the cable from the negative (-) auxiliary battery terminal.

B  **REPLACE NO.1 TRACTION BATTERY DEVICE BOX****A****5. REPLACE BATTERY ECU ASSEMBLY****HINT:**Click here **NEXT****6. SIMULATION TEST**

Pre-procedure1

(a) None

Procedure1

(b) Clear the DTCs and freeze frame data.

Powertrain > HV Battery > Clear DTCs

Post-procedure1

(c) Drive the vehicle on urban roads for approximately 10 minutes.

(d) Turn the ignition switch off and wait for 2 minutes or more.

(e) Turn the ignition switch to ON and wait for 10 seconds or more.

NEXT**7. CHECK DTC OUTPUT (HV BATTERY)**

Pre-procedure1

(a) None

Procedure1

(b) Check for DTCs.

Powertrain > HV Battery > Trouble Codes

RESULT	PROCEED TO
DTCs are not output.	A
P0ABF28 is also output.	B

Post-procedure1

(c) Turn the ignition switch off.

(d) None

A ► **END****B** ► **REPLACE NO.1 TRACTION BATTERY DEVICE BOX**