

<b>Last Modified:</b> 12-04-2024	6.11:8.1.0	<b>Doc ID:</b> RM10000002BHUQ
<b>Model Year Start:</b> 2023	<b>Model:</b> Prius Prime	<b>Prod Date Range:</b> [03/2023 - ]
<b>Title:</b> HYBRID / BATTERY CONTROL: HYBRID BATTERY SYSTEM (for PHEV Model): P0ABF2A; Hybrid/EV Battery Current Sensor "A" Signal Stuck In Range; 2023 - 2024 MY Prius Prime [03/2023 - ]		

<b>DTC</b>	<b>P0ABF2A</b>	<b>Hybrid/EV Battery Current Sensor "A" Signal Stuck In Range</b>
------------	----------------	---

## DESCRIPTION

Refer to the description for DTC P0ABF11.

Click here [INFO](#)

DTC NO.	DETECTION ITEM	DTC DETECTION CONDITION	TROUBLE AREA	MIL	WARNING INDICATE	DTC OUTPUT FROM	PRIORITY	NOTE
P0ABF2A	Hybrid/EV Battery Current Sensor "A" Signal Stuck In Range	The hybrid battery voltage is changing but the hybrid battery current sensor output does not change.  (1 trip detection logic)	<ul style="list-style-type: none"> <li>No. 1 traction battery device box assembly</li> <li>Battery ECU assembly</li> </ul>	Comes on	Master Warning:  Comes on	HV Battery	A	SAE Code:  P0AC0

## MONITOR DESCRIPTION

If the battery ECU assembly detects a malfunction in a battery current sensor, the battery ECU assembly will illuminate the MIL and store a DTC.

## MONITOR STRATEGY

Related DTCs	P0AC0 (INF P0ABF2A): Current sensor malfunction
Required sensors/components	Battery current sensor
Frequency of operation	Continuous
Duration	TMC's intellectual property
MIL operation	1 driving cycle
Sequence of operation	None

## TYPICAL ENABLING CONDITIONS

The monitor will run whenever the following DTCs are not stored	TMC's intellectual property
Other conditions belong to TMC's intellectual property	-

## TYPICAL MALFUNCTION THRESHOLDS

TMC's intellectual property	-
-----------------------------	---

## COMPONENT OPERATING RANGE

Battery ECU assembly	DTC P0AC0 (INF P0ABF2A) is not detected
----------------------	---

## CONFIRMATION DRIVING PATTERN

**HINT:**

- After repair has been completed, clear the DTC and then check that the vehicle has returned to normal by performing the following All Readiness check procedure.

Click here [INFO](#)

- When clearing the permanent DTCs, refer to the "CLEAR PERMANENT DTC" procedure.

Click here [INFO](#)

1. Clear the DTCs (even if no DTCs are stored, perform the clear DTC procedure).
2. Turn the ignition switch off and wait for 2 minutes or more.
3. Drive the vehicle on urban roads for approximately 10 minutes.[\*1]

**HINT:**

[\*1]: Normal judgment procedure.

The normal judgment procedure is used to complete DTC judgment and also used when clearing permanent DTCs.

4. Enter the following menus: Powertrain / HV Battery / Utility / All Readiness.
5. Check the DTC judgment result.

**HINT:**

- If the judgment result shows NORMAL, the system is normal.
- If the judgment result shows ABNORMAL, the system has a malfunction.
- If the judgment result shows INCOMPLETE or N/A, perform the normal judgment procedure again.

## PROCEDURE

<b>1.</b>	<b>CHECK DTC OUTPUT (HV BATTERY, HYBRID CONTROL)</b>
-----------	--

Pre-procedure1

(a) None

Procedure1

(b) Check for DTCs.

**Powertrain > HV Battery > Trouble Codes**

**Powertrain > Hybrid Control > Trouble Codes**

RESULT	PROCEED TO
"P0ABF2A" only is output, or DTCs except the ones in the table below are also output.	A

RESULT	PROCEED TO
DTCs of hybrid battery system in the table below are output.	B
DTCs of hybrid control system in the table below are output.	C

SYSTEM	RELEVANT DTC	
Hybrid battery system	P060A47	Hybrid/EV Battery Energy Control Module Monitoring Processor Watchdog / Safety MCU Failure
	P060B49	Hybrid/EV Battery Energy Control Module A/D Processing Internal Electronic Failure
	P060687	Hybrid/EV Battery Energy Control Module Processor to Monitoring Processor Missing Message
	P0ABF11	Hybrid/EV Battery Current Sensor "A" Circuit Short to Ground
	P0ABF15	Hybrid/EV Battery Current Sensor "A" Circuit Short to Auxiliary Battery or Open
	P0B0E11	Hybrid/EV Battery Current Sensor "B" Circuit Short to Ground
	P0B0E15	Hybrid/EV Battery Current Sensor "B" Circuit Short to Auxiliary Battery or Open
	P1CBB12	Hybrid/EV Battery Current Sensor Power Supply Circuit Short to Auxiliary Battery
	P1CBB14	Hybrid/EV Battery Current Sensor Power Supply Circuit Short to Ground or Open
	P2BE411	Hybrid/EV Battery Pack Current Sensor "C" Low Circuit Short to Ground
	P2BE415	Hybrid/EV Battery Pack Current Sensor "C" High Circuit Short to Auxiliary Battery or Open
Hybrid control system	P0A1F94	Hybrid/EV Battery Energy Control Module Unexpected Operation

Post-procedure1

(c) Turn the ignition switch off.

**B** ► **GO TO DTC CHART (HYBRID BATTERY SYSTEM)**

**C** ► **GO TO DTC CHART (HYBRID CONTROL SYSTEM)**

**A**



<b>2.</b>	<b>CHECK DTC OUTPUT (HV BATTERY)</b>
-----------	--------------------------------------

Pre-procedure1

(a) None

Procedure1

(b) Check for DTCs.

**Powertrain > HV Battery > Trouble Codes**

RESULT	PROCEED TO
"P1A001C, P1A051C, P1A0A1C or P301A1C" is not output.	A
"P1A001C, P1A051C, P1A0A1C or P301A1C" is also output.	B

Post-procedure1

(c) Turn the ignition switch off.

**B**  **GO TO DTC CHART (HYBRID BATTERY SYSTEM)**

**A**



<b>3.</b>	<b>READ VALUE USING GTS</b>
-----------	-----------------------------

Pre-procedure1

(a) Turn the ignition switch to ON.

**NOTICE:**

Do not turn the ignition switch to ON (READY).

Procedure1

(b) Check the voltage of each "Hybrid/EV Battery Cell Voltage" of "Hybrid/EV Battery Cell 1 to 72 Voltage" in the Data List with the ignition switch ON.

**NOTICE:**

Select "Hybrid/EV Battery Cell 1 to 72 Voltage" only. (Do not select any other Data List items.)

**Powertrain > HV Battery > Data List**

TESTER DISPLAY
Hybrid/EV Battery Cell 1 Voltage
Hybrid/EV Battery Cell 2 Voltage
Hybrid/EV Battery Cell 3 Voltage
Hybrid/EV Battery Cell 4 Voltage


TESTER DISPLAY
Hybrid/EV Battery Cell 5 Voltage
Hybrid/EV Battery Cell 6 Voltage
Hybrid/EV Battery Cell 7 Voltage
Hybrid/EV Battery Cell 8 Voltage
Hybrid/EV Battery Cell 9 Voltage
Hybrid/EV Battery Cell 10 Voltage
Hybrid/EV Battery Cell 11 Voltage
Hybrid/EV Battery Cell 12 Voltage
Hybrid/EV Battery Cell 13 Voltage
Hybrid/EV Battery Cell 14 Voltage
Hybrid/EV Battery Cell 15 Voltage
Hybrid/EV Battery Cell 16 Voltage
Hybrid/EV Battery Cell 17 Voltage
Hybrid/EV Battery Cell 18 Voltage
Hybrid/EV Battery Cell 19 Voltage
Hybrid/EV Battery Cell 20 Voltage
Hybrid/EV Battery Cell 21 Voltage
Hybrid/EV Battery Cell 22 Voltage
Hybrid/EV Battery Cell 23 Voltage

TESTER DISPLAY
Hybrid/EV Battery Cell 24 Voltage
Hybrid/EV Battery Cell 25 Voltage
Hybrid/EV Battery Cell 26 Voltage
Hybrid/EV Battery Cell 27 Voltage
Hybrid/EV Battery Cell 28 Voltage
Hybrid/EV Battery Cell 29 Voltage
Hybrid/EV Battery Cell 30 Voltage
Hybrid/EV Battery Cell 31 Voltage
Hybrid/EV Battery Cell 32 Voltage
Hybrid/EV Battery Cell 33 Voltage
Hybrid/EV Battery Cell 34 Voltage
Hybrid/EV Battery Cell 35 Voltage
Hybrid/EV Battery Cell 36 Voltage
Hybrid/EV Battery Cell 37 Voltage
Hybrid/EV Battery Cell 38 Voltage
Hybrid/EV Battery Cell 39 Voltage
Hybrid/EV Battery Cell 40 Voltage
Hybrid/EV Battery Cell 41 Voltage
Hybrid/EV Battery Cell 42 Voltage

TESTER DISPLAY
Hybrid/EV Battery Cell 43 Voltage
Hybrid/EV Battery Cell 44 Voltage
Hybrid/EV Battery Cell 45 Voltage
Hybrid/EV Battery Cell 46 Voltage
Hybrid/EV Battery Cell 47 Voltage
Hybrid/EV Battery Cell 48 Voltage
Hybrid/EV Battery Cell 49 Voltage
Hybrid/EV Battery Cell 50 Voltage
Hybrid/EV Battery Cell 51 Voltage
Hybrid/EV Battery Cell 52 Voltage
Hybrid/EV Battery Cell 53 Voltage
Hybrid/EV Battery Cell 54 Voltage
Hybrid/EV Battery Cell 55 Voltage
Hybrid/EV Battery Cell 56 Voltage
Hybrid/EV Battery Cell 57 Voltage
Hybrid/EV Battery Cell 58 Voltage
Hybrid/EV Battery Cell 59 Voltage
Hybrid/EV Battery Cell 60 Voltage
Hybrid/EV Battery Cell 61 Voltage

TESTER DISPLAY
Hybrid/EV Battery Cell 62 Voltage
Hybrid/EV Battery Cell 63 Voltage
Hybrid/EV Battery Cell 64 Voltage
Hybrid/EV Battery Cell 65 Voltage
Hybrid/EV Battery Cell 66 Voltage
Hybrid/EV Battery Cell 67 Voltage
Hybrid/EV Battery Cell 68 Voltage
Hybrid/EV Battery Cell 69 Voltage
Hybrid/EV Battery Cell 70 Voltage
Hybrid/EV Battery Cell 71 Voltage
Hybrid/EV Battery Cell 72 Voltage





Specified Condition:

Any "Hybrid/EV Battery Cell Voltage" changes by 0.05 V or more, 60 seconds after the ignition switch is turned to ON. (The difference between the maximum and minimum voltage is 0.05 V or more.)

RESULT	PROCEED TO
The change in voltage of any "Hybrid/EV Battery Cell Voltage" is 0.05 V or more.	A
Other than above	B

Post-procedure1

(c) Turn the ignition switch off.

**A** ▶ REPLACE BATTERY ECU ASSEMBLY

**B** ▶ REPLACE NO. 1 TRACTION BATTERY DEVICE BOX ASSEMBLY

