

| | | |
|--|---------------------------|--------------------------------------|
| Last Modified: 12-04-2024 | 6.11:8.1.0 | Doc ID: RM10000002BHUU |
| Model Year Start: 2023 | Model: Prius Prime | Prod Date Range: [03/2023 -] |
| Title: HYBRID / BATTERY CONTROL: HYBRID BATTERY SYSTEM (for PHEV Model): P1A6017,P1A6317,P31AA17; Hybrid/EV Battery Stack 2 Cell Circuit Voltage Above Threshold; 2023 - 2024 MY Prius Prime [03/2023 -] | | |

| | | |
|------------|----------------|---|
| DTC | P1A6017 | Hybrid/EV Battery Stack 2 Cell Circuit Voltage Above Threshold |
|------------|----------------|---|

| | | |
|------------|----------------|---|
| DTC | P1A6317 | Hybrid/EV Battery Stack 3 Cell Circuit Voltage Above Threshold |
|------------|----------------|---|

| | | |
|------------|----------------|---|
| DTC | P31AA17 | Hybrid/EV Battery Stack 1 Cell Circuit Voltage Above Threshold |
|------------|----------------|---|

DESCRIPTION

The HV battery is composed of 72 cells (3.7 V each) in series. The battery ECU assembly monitors the voltage of each HV battery cell to detect malfunctions of the HV battery.

| DTC NO. | DETECTION ITEM | DTC DETECTION CONDITION | TROUBLE AREA | MIL | WARNING INDICATE | DTC OUTPUT FROM | PRIORITY | NOTE |
|---------|--|--|--|----------|---------------------------------|-----------------|----------|------------------------|
| P1A6017 | Hybrid/EV Battery Stack 2 Cell Circuit Voltage Above Threshold | Charging continues to be performed after the voltage of any cell of the No. 2 HV supply stack sub-assembly has exceeded the threshold. (1 trip detection logic) | <ul style="list-style-type: none"> No. 2 HV supply stack sub-assembly Hybrid vehicle control ECU | Comes on | Master Warning: Comes on | HV Battery | A | SAE Code: P1A60 |
| P1A6317 | Hybrid/EV Battery Stack 3 Cell Circuit Voltage Above Threshold | Charging continues to be performed after the voltage of any cell of the No. 3 HV supply stack sub-assembly has exceeded the threshold. (1 trip detection logic) | <ul style="list-style-type: none"> No. 3 HV supply stack sub-assembly Hybrid vehicle control ECU | Comes on | Master Warning: Comes on | HV Battery | A | SAE Code: P1A63 |

| DTC NO. | DETECTION ITEM | DTC DETECTION CONDITION | TROUBLE AREA | MIL | WARNING INDICATE | DTC OUTPUT FROM | PRIORITY | NOTE |
|---------|--|--|--|----------|---------------------------------|-----------------|----------|------------------------|
| P31AA17 | Hybrid/EV Battery Stack 1 Cell Circuit Voltage Above Threshold | Charging continues to be performed after the voltage of any cell of the No. 1 HV supply stack sub-assembly has exceeded the threshold. (1 trip detection logic) | <ul style="list-style-type: none"> No. 1 HV supply stack sub-assembly Hybrid vehicle control ECU | Comes on | Master Warning: Comes on | HV Battery | A | SAE Code: P31AA |

MONITOR DESCRIPTION

If the battery ECU assembly detects that the voltage of a HV battery cell is excessively high, the battery ECU assembly will illuminate the MIL and store a DTC.

MONITOR STRATEGY

| | |
|-----------------------------|--|
| Related DTCs | P1A60 (INF P1A6017), P1A63 (INF P1A6317), P31AA (INF P31AA17): Cell voltage high |
| Required sensors/components | Battery ECU assembly |
| Frequency of operation | Continuous |
| Duration | TMC's intellectual property |
| MIL operation | 1 driving cycle |
| Sequence of operation | None |

TYPICAL ENABLING CONDITIONS

| | |
|---|-----------------------------|
| The monitor will run whenever the following DTCs are not stored | TMC's intellectual property |
| Other conditions belong to TMC's intellectual property | - |

TYPICAL MALFUNCTION THRESHOLDS

| | |
|-----------------------------|---|
| TMC's intellectual property | - |
|-----------------------------|---|

COMPONENT OPERATING RANGE

| | |
|----------------------|---|
| Battery ECU assembly | DTC P1A60 (INF P1A6017) is not detected DTC P1A63 (INF P1A6317) is not detected DTC P31AA (INF P31AA17) is not detected |
|----------------------|---|

CONFIRMATION DRIVING PATTERN

HINT:

- After repair has been completed, clear the DTC and then check that the vehicle has returned to normal by performing the following All Readiness check procedure.

Click here [INFO](#)

- When clearing the permanent DTCs, refer to the "CLEAR PERMANENT DTC" procedure.

Click here [INFO](#)

1. Clear the DTCs (even if no DTCs are stored, perform the clear DTC procedure).
2. Turn the ignition switch off and wait for 2 minutes or more.
3. Drive the vehicle on urban roads for approximately 10 minutes.[*1]

HINT:

[*1]: Normal judgment procedure.

The normal judgment procedure is used to complete DTC judgment and also used when clearing permanent DTCs.

4. Enter the following menus: Powertrain / HV Battery / Utility / All Readiness.
5. Check the DTC judgment result.

HINT:

- If the judgment result shows NORMAL, the system is normal.
- If the judgment result shows ABNORMAL, the system has a malfunction.
- If the judgment result shows INCOMPLETE or N/A, perform the normal judgment procedure again.

CAUTION / NOTICE / HINT

CAUTION:

Refer to the precautions before inspecting high voltage circuit.

Click here [INFO](#)

NOTICE:

- After the ignition switch is turned off, there may be a waiting time before disconnecting the auxiliary negative (-) battery terminal.

Click here [INFO](#)

- When disconnecting and reconnecting the auxiliary battery.

HINT:

When disconnecting and reconnecting the auxiliary battery, there is an automatic learning function that completes learning when the respective system is used.

Click here [INFO](#)

PROCEDURE

| | |
|-----------|--------------------------------------|
| 1. | CHECK DTC OUTPUT (HV BATTERY) |
|-----------|--------------------------------------|

Pre-procedure1

(a) None

Procedure1

(b) Check for DTCs.

Powertrain > HV Battery > Trouble Codes

| RESULT | PROCEED TO |
|----------------------------------|------------|
| POC3000 or P31B300 is not output | A |
| POC3000 or P31B300 is output | B |

Post-procedure1

(c) Turn the ignition switch off.

B ► **GO TO STEP 3**

A



| | |
|-----------|------------------|
| 2. | CHECK DTC |
|-----------|------------------|

(a) Check the DTCs that were output when the vehicle was brought to the workshop.

| RESULT | PROCEED TO |
|---------------------------|------------|
| "P1A6017" is also output. | A |
| "P1A6317" is also output. | B |
| "P31AA17" is also output. | C |

A ► **REPLACE NO. 2 HV SUPPLY STACK SUB-ASSEMBLY**

B ► **REPLACE NO. 3 HV SUPPLY STACK SUB-ASSEMBLY**

C ► **REPLACE NO. 1 HV SUPPLY STACK SUB-ASSEMBLY**

| | |
|-----------|------------------|
| 3. | CHECK DTC |
|-----------|------------------|

(a) Check the DTCs that were output when the vehicle was brought to the workshop.

| RESULT | PROCEED TO |
|---------------------------|------------|
| "P1A6017" is also output. | A |
| "P1A6317" is also output. | B |
| "P31AA17" is also output. | C |

B ► GO TO STEP 5

C ► GO TO STEP 6

A



4. REPLACE NO. 2 HV SUPPLY STACK SUB-ASSEMBLY

HINT:

Click here [INFO](#)

NEXT ► REPLACE HYBRID VEHICLE CONTROL ECU

5. REPLACE NO. 3 HV SUPPLY STACK SUB-ASSEMBLY

HINT:

Click here [INFO](#)

NEXT ► REPLACE HYBRID VEHICLE CONTROL ECU

6. REPLACE NO. 1 HV SUPPLY STACK SUB-ASSEMBLY

HINT:

Click here [INFO](#)

NEXT ► REPLACE HYBRID VEHICLE CONTROL ECU

