

Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM10000002BHVZ
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [03/2023 -]
Title: HYBRID / BATTERY CONTROL: HYBRID BATTERY SYSTEM (for PHEV Model): P1AC49E-P1AC69E; Hybrid/EV Battery Stack 1 Current Interrupt Device Stuck On; 2023 - 2024 MY Prius Prime [03/2023 -]		

DTC	P1AC49E	Hybrid/EV Battery Stack 1 Current Interrupt Device Stuck On
------------	----------------	--

DTC	P1AC59E	Hybrid/EV Battery Stack 2 Current Interrupt Device Stuck On
------------	----------------	--

DTC	P1AC69E	Hybrid/EV Battery Stack 3 Current Interrupt Device Stuck On
------------	----------------	--

DESCRIPTION

Refer to the description for DTC P1AC413.

Click here [INFO](#)

DTC NO.	DETECTION ITEM	DTC DETECTION CONDITION	TROUBLE AREA	MIL	WARNING INDICATE	DTC OUTPUT FROM	PRIORITY	NOTE
P1AC49E	Hybrid/EV Battery Stack 1 Current Interrupt Device Stuck On	Conductivity returns after high voltage circuit disconnected by CID operation. (1 trip detection logic)	<ul style="list-style-type: none"> No. 1 HV supply stack sub-assembly Battery voltage sensor 	Comes on	Master Warning: Comes on	HV Battery	A	SAE Code: P1AC4
P1AC59E	Hybrid/EV Battery Stack 2 Current Interrupt Device Stuck On	Conductivity returns after high voltage circuit disconnected by CID operation. (1 trip detection logic)	<ul style="list-style-type: none"> No. 2 HV supply stack sub-assembly Battery voltage sensor 	Comes on	Master Warning: Comes on	HV Battery	A	SAE Code: P1AC5
P1AC69E	Hybrid/EV Battery Stack 3 Current Interrupt Device Stuck On	Conductivity returns after high voltage circuit disconnected by CID operation.	<ul style="list-style-type: none"> No. 3 HV supply stack sub-assembly Battery voltage sensor 	Comes on	Master Warning: Comes on	HV Battery	A	SAE Code: P1AC6

DTC NO.	DETECTION ITEM	DTC DETECTION CONDITION	TROUBLE AREA	MIL	WARNING INDICATE	DTC OUTPUT FROM	PRIORITY	NOTE
		(1 trip detection logic)						

MONITOR DESCRIPTION

If a current interrupt device (CID) located in a HV battery cell is shut off, the battery ECU assembly prohibits charging and discharging, illuminates the MIL and stores a DTC.

MONITOR STRATEGY

Related DTCs	P1AC4 (INF P1AC49E): Hybrid/EV Battery Cell Voltage Low Pack 1 Stack "A" at CID interception P1AC5 (INF P1AC59E): Hybrid/EV Battery Cell Voltage Low Pack 1 Stack "B" at CID interception P1AC6 (INF P1AC69E): Hybrid/EV Battery Cell Voltage Low Pack 1 Stack "C" at CID interception
Required sensors/components	Battery ECU assembly
Frequency of operation	Continuous
Duration	TMC's intellectual property
MIL operation	1 driving cycle
Sequence of operation	None

TYPICAL ENABLING CONDITIONS

The monitor will run whenever the following DTCs are not stored	TMC's intellectual property
Other conditions belong to TMC's intellectual property	-

TYPICAL MALFUNCTION THRESHOLDS

TMC's intellectual property	-
-----------------------------	---

COMPONENT OPERATING RANGE

Battery ECU assembly	DTC P1AC4 (INF P1AC49E) is not detected DTC P1AC5 (INF P1AC59E) is not detected DTC P1AC6 (INF P1AC69E) is not detected
----------------------	---

CONFIRMATION DRIVING PATTERN

HINT:

- After repair has been completed, clear the DTC and then check that the vehicle has returned to normal by performing the following All Readiness check procedure.

[Click here](#) 

- When clearing the permanent DTCs, refer to the "CLEAR PERMANENT DTC" procedure.

Click here [INFO](#)

1. Clear the DTCs (even if no DTCs are stored, perform the clear DTC procedure).
2. Turn the ignition switch off and wait for 2 minutes or more.
3. Turn the ignition switch to ON and wait for 10 seconds or more.[*1]
4. Turn the ignition switch off and wait for 2 minutes or more.[*2]
5. Turn the ignition switch to ON (READY) and wait for 30 seconds or more.[*3]

HINT:

[*1] to [*3]: Normal judgment procedure.

The normal judgment procedure is used to complete DTC judgment and also used when clearing permanent DTCs.

6. Enter the following menus: Powertrain / HV Battery / Utility / All Readiness.
7. Check the DTC judgment result.

HINT:

- If the judgment result shows NORMAL, the system is normal.
- If the judgment result shows ABNORMAL, the system has a malfunction.
- If the judgment result shows INCOMPLETE or N/A, perform the normal judgment procedure again.

WIRING DIAGRAM

Refer to the wiring diagram for DTC P1A001C.

Click here [INFO](#)

CAUTION / NOTICE / HINT

CAUTION:

Refer to the precautions before inspecting high voltage circuit.

Click here [INFO](#)

NOTICE:

- After the ignition switch is turned off, there may be a waiting time before disconnecting the auxiliary negative (-) battery terminal.

Click here [INFO](#)

- When disconnecting and reconnecting the auxiliary battery.

HINT:

When disconnecting and reconnecting the auxiliary battery, there is an automatic learning function that completes learning when the respective system is used.

Click here [INFO](#)

PROCEDURE

1.	CHECK DTC OUTPUT (HV BATTERY, HYBRID CONTROL)
-----------	--

Pre-procedure1

(a) None

Procedure1

(b) Check for DTCs.

Powertrain > HV Battery > Trouble Codes

Powertrain > Hybrid Control > Trouble Codes

RESULT	PROCEED TO
"P1AC49E, P1AC59E or P1AC69E" only is output, or DTCs except the ones in the table below are also output.	A
DTCs of hybrid battery system in the table below are output.	B
DTCs of hybrid control system in the table below are output.	C

SYSTEM	RELEVANT DTC	
Hybrid battery system	P060A47	Hybrid/EV Battery Energy Control Module Monitoring Processor Watchdog / Safety MCU Failure
	P060B49	Hybrid/EV Battery Energy Control Module A/D Processing Internal Electronic Failure
	P060687	Hybrid/EV Battery Energy Control Module Processor to Monitoring Processor Missing Message
Hybrid control system	P0A1F94	Hybrid/EV Battery Energy Control Module Unexpected Operation

Post-procedure1

(c) Turn the ignition switch off.

B ► **GO TO DTC CHART (HYBRID BATTERY SYSTEM)**

C ► **GO TO DTC CHART (HYBRID CONTROL SYSTEM)**

A



2.	CHECK DTC
-----------	------------------

(a) Check the DTCs that were output when the vehicle was brought to the workshop.

RESULT	PROCEED TO
"P1AC49E" is also output.	A
"P1AC59E" is also output.	B

RESULT	PROCEED TO
"P1AC69E" is also output.	C

B ► GO TO STEP 6

C ► GO TO STEP 9

A
▼

3.	CHECK CONNECTOR CONNECTION CONDITION (BATTERY VOLTAGE SENSOR CONNECTOR)
-----------	--

CAUTION:

Be sure to wear insulated gloves and protective goggles.

Pre-procedure1

(a) Check that the service plug grip is not installed.

NOTICE:

After removing the service plug grip, do not turn the ignition switch to ON (READY), unless instructed by the repair manual because this may cause a malfunction.

Procedure1

(b) Check the connections of the battery voltage sensor connectors.


HINT:

Click here [INFO](#)

OK:

The connector is connected securely and there are no contact problems.

Result:



RESULT		PROCEED TO
OK		A
Not connected securely	The terminals are not damaged or corroded	B
Connector is not connected securely	The terminals are damaged or corroded	C

Post-procedure1

(c) None

B ▶ **CONNECT SECURELY**

C ▶ **REPLACE NO. 1 HV SUPPLY STACK SUB-ASSEMBLY**

A
▼

4.	CHECK BATTERY VOLTAGE SENSOR (VA1 - VA24)
-----------	--

NOTICE:

Make sure to use tester probes with a diameter of approximately 0.5 mm (0.0197 in.) when measuring the voltage.

Pre-procedure1


(a) Remove the battery voltage sensor.

HINT:

[Click here](#) 

Procedure1

(b) Measure the voltage according to the value(s) in the table below.



*a	Component without harness connected (Battery Voltage Sensor)	-	-
----	---	---	---

Standard Voltage:

HYBRID BATTERY CELL	TESTER CONNECTION (TESTER PROBE POLARITY)	CONDITION	SPECIFIED CONDITION
1	z18-6 (GA0) (-) - z18-5 (VA1) (+)	Always	0.3 to 1.0 V
2	z18-5 (VA1) (-) - z18-4 (VA2) (+)	Always	0.3 to 1.0 V
3	z18-4 (VA2) (-) - z18-1 (VA3) (+)	Always	0.3 to 1.0 V
4	z18-1 (VA3) (-) - z18-3 (VA4) (+)	Always	0.3 to 1.0 V
5	z18-3 (VA4) (-) - z17-27 (VA5) (+)	Always	0.3 to 1.0 V
6	z17-27 (VA5) (-) - z17-17 (VA6) (+)	Always	0.3 to 1.0 V
7	z17-17 (VA6) (-) - z17-16 (VA7) (+)	Always	0.3 to 1.0 V
8	z17-16 (VA7) (-) - z17-4 (VA8) (+)	Always	0.3 to 1.0 V
9	z17-4 (VA8) (-) - z17-3 (VA9) (+)	Always	0.3 to 1.0 V
10	z17-3 (VA9) (-) - z17-15 (VA10) (+)	Always	0.3 to 1.0 V
11	z17-15 (VA10) (-) - z17-14 (VA11) (+)	Always	0.3 to 1.0 V
12	z17-14 (VA11) (-) - z17-13 (VA12) (+)	Always	0.3 to 1.0 V
13	z17-12 (GA1) (-) - z17-23 (VA13) (+)	Always	0.3 to 1.0 V

HYBRID BATTERY CELL	TESTER CONNECTION (TESTER PROBE POLARITY)	CONDITION	SPECIFIED CONDITION
14	z17-23 (VA13) (-) - z17-11 (VA14) (+)	Always	0.3 to 1.0 V
15	z17-11 (VA14) (-) - z17-10 (VA15) (+)	Always	0.3 to 1.0 V
16	z17-10 (VA15) (-) - z17-9 (VA16) (+)	Always	0.3 to 1.0 V
17	z17-9 (VA16) (-) - z17-8 (VA17) (+)	Always	0.3 to 1.0 V
18	z17-8 (VA17) (-) - z17-20 (VA18) (+)	Always	0.3 to 1.0 V
19	z17-20 (VA18) (-) - z17-7 (VA19) (+)	Always	0.3 to 1.0 V
20	z17-7 (VA19) (-) - z17-2 (VA20) (+)	Always	0.3 to 1.0 V
21	z17-2 (VA20) (-) - z17-1 (VA21) (+)	Always	0.3 to 1.0 V
22	z17-1 (VA21) (-) - z17-6 (VA22) (+)	Always	0.3 to 1.0 V
23	z17-6 (VA22) (-) - z17-5 (VA23) (+)	Always	0.3 to 1.0 V
24	z17-5 (VA23) (-) - z17-18 (VA24) (+)	Always	0.3 to 1.0 V

NOTICE:

- Make sure to check the polarity of each terminal (positive (+) or negative (-)) before connecting a tester.
- Be sure to set the Toyota electrical tester to diode range when performing this test.
- Read the voltage after the value has stabilized.
- In order to avoid damaging the terminals of the battery voltage sensor, make sure to use tester probes with a diameter of approximately 0.5 mm (0.0197 in.) when measuring the voltage of the battery voltage sensor.

RESULT	PROCEED TO
The voltage between the terminals is 0.3 to 1.0 V.	A
Other than above	B

Post-procedure1

(c) Install the battery voltage sensor.

A ► **REPLACE NO. 1 HV SUPPLY STACK SUB-ASSEMBLY****B****5. REPLACE NO. 1 HV SUPPLY STACK SUB-ASSEMBLY****HINT:**Click here **NEXT** ► **REPLACE BATTERY VOLTAGE SENSOR**

6. CHECK CONNECTOR CONNECTION CONDITION (BATTERY VOLTAGE SENSOR CONNECTOR)

CAUTION:

Be sure to wear insulated gloves and protective goggles.

Pre-procedure1

(a) Check that the service plug grip is not installed.

NOTICE:

After removing the service plug grip, do not turn the ignition switch to ON (READY), unless instructed by the repair manual because this may cause a malfunction.

Procedure1

(b) Check the connections of the battery voltage sensor connectors.


HINT:

[Click here](#) INFO

OK:

The connector is connected securely and there are no contact problems.

Result:



RESULT		PROCEED TO
OK		A
Not connected securely	The terminals are not damaged or corroded	B
Not connected securely	The terminals are damaged or corroded	C

Post-procedure1

(c) None

B ▶ **CONNECT SECURELY**

C ▶ **REPLACE NO. 2 HV SUPPLY STACK SUB-ASSEMBLY**

A
▼

7. CHECK BATTERY VOLTAGE SENSOR (VA25 - VA48)

NOTICE:

Make sure to use tester probes with a diameter of approximately 0.5 mm (0.0197 in.) when measuring the voltage.

Pre-procedure1


(a) Remove the battery voltage sensor.

HINT:

[Click here](#) INFO

Procedure1

(b) Measure the voltage according to the value(s) in the table below.



*a	Component without harness connected (Battery Voltage Sensor)	-	-
----	---	---	---

Standard Voltage:

HYBRID BATTERY CELL	TESTER CONNECTION (TESTER PROBE POLARITY)	CONDITION	SPECIFIED CONDITION
25	z20-12 (GA2) (-) - z20-11 (VA25) (+)	Always	0.3 to 1.0 V
26	z20-11 (VA25) (-) - z20-10 (VA26) (+)	Always	0.3 to 1.0 V

HYBRID BATTERY CELL	TESTER CONNECTION (TESTER PROBE POLARITY)	CONDITION	SPECIFIED CONDITION
27	z20-10 (VA26) (-) - z20-9 (VA27) (+)	Always	0.3 to 1.0 V
28	z20-9 (VA27) (-) - z20-8 (VA28) (+)	Always	0.3 to 1.0 V
29	z20-8 (VA28) (-) - z20-20 (VA29) (+)	Always	0.3 to 1.0 V
30	z20-20 (VA29) (-) - z20-7 (VA30) (+)	Always	0.3 to 1.0 V
31	z20-7 (VA30) (-) - z20-2 (VA31) (+)	Always	0.3 to 1.0 V
32	z20-2 (VA31) (-) - z20-1 (VA32) (+)	Always	0.3 to 1.0 V
33	z20-1 (VA32) (-) - z20-6 (VA33) (+)	Always	0.3 to 1.0 V
34	z20-6 (VA33) (-) - z20-5 (VA34) (+)	Always	0.3 to 1.0 V
35	z20-5 (VA34) (-) - z20-18 (VA35) (+)	Always	0.3 to 1.0 V
36	z20-18 (VA35) (-) - z19-21 (VA36) (+)	Always	0.3 to 1.0 V
37	z19-13 (GA3) (-) - z19-2 (VA37) (+)	Always	0.3 to 1.0 V
38	z19-2 (VA37) (-) - z19-12 (VA38) (+)	Always	0.3 to 1.0 V
39	z19-12 (VA38) (-) - z19-11 (VA39) (+)	Always	0.3 to 1.0 V
40	z19-11 (VA39) (-) - z19-10 (VA40) (+)	Always	0.3 to 1.0 V
41	z19-10 (VA40) (-) - z19-9 (VA41) (+)	Always	0.3 to 1.0 V
42	z19-9 (VA41) (-) - z19-8 (VA42) (+)	Always	0.3 to 1.0 V
43	z19-8 (VA42) (-) - z19-7 (VA43) (+)	Always	0.3 to 1.0 V
44	z19-7 (VA43) (-) - z19-6 (VA44) (+)	Always	0.3 to 1.0 V
45	z19-6 (VA44) (-) - z19-5 (VA45) (+)	Always	0.3 to 1.0 V
46	z19-5 (VA45) (-) - z19-4 (VA46) (+)	Always	0.3 to 1.0 V
47	z19-4 (VA46) (-) - z19-1 (VA47) (+)	Always	0.3 to 1.0 V
48	z19-1 (VA47) (-) - z19-3 (VA48) (+)	Always	0.3 to 1.0 V

NOTICE:

- Make sure to check the polarity of each terminal (positive (+) or negative (-)) before connecting a tester.
- Be sure to set the Toyota electrical tester to diode range when performing this test.
- Read the voltage after the value has stabilized.
- In order to avoid damaging the terminals of the battery voltage sensor, make sure to use tester probes with a diameter of approximately 0.5 mm (0.0197 in.) when measuring the voltage of the battery voltage sensor.

RESULT	PROCEED TO
The voltage between the terminals is 0.3 to 1.0 V.	A
Other than above	B

Post-procedure1

(c) Install the battery voltage sensor.

A ▶ REPLACE NO. 2 HV SUPPLY STACK SUB-ASSEMBLY

B



8. REPLACE NO. 2 HV SUPPLY STACK SUB-ASSEMBLY

HINT:

Click here [INFO](#)

NEXT ▶ REPLACE BATTERY VOLTAGE SENSOR

9. CHECK CONNECTOR CONNECTION CONDITION (BATTERY VOLTAGE SENSOR CONNECTOR)

CAUTION:

Be sure to wear insulated gloves and protective goggles.

Pre-procedure1

(a) Check that the service plug grip is not installed.

NOTICE:

After removing the service plug grip, do not turn the ignition switch to ON (READY), unless instructed by the repair manual because this may cause a malfunction.

Procedure1

(b) Check the connections of the battery voltage sensor connectors.


HINT:

Click here [INFO](#)

OK:

The connector is connected securely and there are no contact problems.

Result:



RESULT		PROCEED TO
OK		A
Not connected securely	The terminals are not damaged or corroded	B

RESULT		PROCEED TO
Not connected securely	The terminals are damaged or corroded	C

Post-procedure1

(c) None

B ► **CONNECT SECURELY**

C ► **REPLACE NO. 3 HV SUPPLY STACK SUB-ASSEMBLY**

A



10.	CHECK BATTERY VOLTAGE SENSOR (VA49 - VA72)
------------	---

NOTICE:

Make sure to use tester probes with a diameter of approximately 0.5 mm (0.0197 in.) when measuring the voltage.

Pre-procedure1


(a) Remove the battery voltage sensor.

HINT:

[Click here](#) 

Procedure1

(b) Measure the voltage according to the value(s) in the table below.



*a	Component without harness connected (Battery Voltage Sensor)	-	-
----	---	---	---

Standard Voltage:

HYBRID BATTERY CELL	TESTER CONNECTION (TESTER PROBE POLARITY)	CONDITION	SPECIFIED CONDITION
49	z22-11 (GA4) (-) - z22-10 (VA49) (+)	Always	0.3 to 1.0 V
50	z22-10 (VA49) (-) - z22-9 (VA50) (+)	Always	0.3 to 1.0 V
51	z22-9 (VA50) (-) - z22-3 (VA51) (+)	Always	0.3 to 1.0 V
52	z22-3 (VA51) (-) - z22-8 (VA52) (+)	Always	0.3 to 1.0 V
53	z22-8 (VA52) (-) - z22-2 (VA53) (+)	Always	0.3 to 1.0 V
54	z22-2 (VA53) (-) - z22-7 (VA54) (+)	Always	0.3 to 1.0 V
55	z22-7 (VA54) (-) - z22-1 (VA55) (+)	Always	0.3 to 1.0 V
56	z22-1 (VA55) (-) - z22-6 (VA56) (+)	Always	0.3 to 1.0 V
57	z22-6 (VA56) (-) - z21-17 (VA57) (+)	Always	0.3 to 1.0 V
58	z21-17 (VA57) (-) - z21-16 (VA58) (+)	Always	0.3 to 1.0 V
59	z21-16 (VA58) (-) - z21-4 (VA59) (+)	Always	0.3 to 1.0 V
60	z21-4 (VA59) (-) - z21-3 (VA60) (+)	Always	0.3 to 1.0 V
61	z21-15 (GA5) (-) - z21-14 (VA61) (+)	Always	0.3 to 1.0 V

HYBRID BATTERY CELL	TESTER CONNECTION (TESTER PROBE POLARITY)	CONDITION	SPECIFIED CONDITION
62	z21-14 (VA61) (-) - z21-13 (VA62) (+)	Always	0.3 to 1.0 V
63	z21-13 (VA62) (-) - z21-12 (VA63) (+)	Always	0.3 to 1.0 V
64	z21-12 (VA63) (-) - z21-11 (VA64) (+)	Always	0.3 to 1.0 V
65	z21-11 (VA64) (-) - z21-10 (VA65) (+)	Always	0.3 to 1.0 V
66	z21-10 (VA65) (-) - z21-9 (VA66) (+)	Always	0.3 to 1.0 V
67	z21-9 (VA66) (-) - z21-8 (VA67) (+)	Always	0.3 to 1.0 V
68	z21-8 (VA67) (-) - z21-7 (VA68) (+)	Always	0.3 to 1.0 V
69	z21-7 (VA68) (-) - z21-2 (VA69) (+)	Always	0.3 to 1.0 V
70	z21-2 (VA69) (-) - z21-1 (VA70) (+)	Always	0.3 to 1.0 V
71	z21-1 (VA70) (-) - z21-6 (VA71) (+)	Always	0.3 to 1.0 V
72	z21-6 (VA71) (-) - z21-5 (VA72) (+)	Always	0.3 to 1.0 V

NOTICE:

- Make sure to check the polarity of each terminal (positive (+) or negative (-)) before connecting a tester.
- Be sure to set the Toyota electrical tester to diode range when performing this test.
- Read the voltage after the value has stabilized.
- In order to avoid damaging the terminals of the battery voltage sensor, make sure to use tester probes with a diameter of approximately 0.5 mm (0.0197 in.) when measuring the voltage of the battery voltage sensor.

RESULT	PROCEED TO
The voltage between the terminals is 0.3 to 1.0 V.	A
Other than above	B

Post-procedure1

(c) Install the battery voltage sensor.

A ► **REPLACE NO. 3 HV SUPPLY STACK SUB-ASSEMBLY****B****11. REPLACE NO. 3 HV SUPPLY STACK SUB-ASSEMBLY****HINT:**Click here **NEXT** ► **REPLACE BATTERY VOLTAGE SENSOR**