


<b>Last Modified:</b> 12-04-2024	6.11:8.1.0	<b>Doc ID:</b> RM100000028ZWE
<b>Model Year Start:</b> 2023	<b>Model:</b> Prius Prime	<b>Prod Date Range:</b> [12/2022 - ]
<b>Title:</b> HYBRID / BATTERY CONTROL: HYBRID CONTROL SYSTEM (for M20A-FXS): Drive Mode Select Switch Circuit; 2023 - 2024 MY Prius Prime [12/2022 - ]		

**Drive Mode Select Switch Circuit**

**DESCRIPTION**

When the drive mode select switch (combination switch assembly) is operated, a switch signal is sent to the hybrid vehicle control ECU and the hybrid vehicle control ECU changes the drive mode.

**WIRING DIAGRAM**



**PROCEDURE**

- 1. READ VALUE USING GTS (CAN BUS CHECK)**

Click here [INFO](#)

RESULT	PROCEED TO
All of the ECUs and sensors that are currently connected to the CAN communication system are displayed	A
None of the ECUs and sensors that are currently connected to the CAN communication system are displayed, or some of them are not displayed	B

**B**  **GO TO CAN COMMUNICATION SYSTEM**

**A**



<b>2.</b>	<b>CHECK DTC OUTPUT (HEALTH CHECK)</b>
-----------	--

Click here [INFO](#)

RESULT	PROCEED TO
No DTCs are output	A
DTCs are output	B

**B**  **GO TO DTC CHART**

**A**



<b>3.</b>	<b>CHECK DRIVE MODE STATUS</b>
-----------	--------------------------------

- (a) Turn the ignition switch to ON.
- (b) Operate the drive mode select switch (combination switch assembly) to change the drive mode.
- (c) Check that the drive mode indicator is displayed on the multi-information display and changes according to the selected drive mode.

RESULT	PROCEED TO
The display changes according to the drive mode select switch operation	A
The display does not change according to the drive mode select switch operation	B

(d) Turn the power switch off.

**A**  **GO TO PROBLEM SYMPTOMS TABLE**

**B**



**4. READ VALUE USING GTS (DRIVE MODE SWITCH)**

(a) Read the value displayed on the GTS.

**Powertrain > Hybrid Control > Data List**

TESTER DISPLAY
Drive Mode Switch-
Drive Mode Switch+

RESULT	PROCEED TO
The display changes according to the drive mode select switch operation	A
Other than above	B

(b) Turn the ignition switch off.

**A**  **CHECK METER / GAUGE SYSTEM** 

**B**



**5. INSPECT DRIVE MODE SELECT SWITCH (COMBINATION SWITCH ASSEMBLY)**

Click here 

**NG**  **REPLACE COMBINATION SWITCH ASSEMBLY**

**OK**



**6. CHECK HARNESS AND CONNECTOR (DRIVE MODE SELECT SWITCH (COMBINATION SWITCH ASSEMBLY) - BODY GROUND)**

- (a) Disconnect the drive mode select switch (combination switch assembly) connector.
- (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K22\)](#)  
[Click Connector\(K22\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K22-7 (E) - Body ground	Always	Below 1 Ω

- (c) Reconnect the drive mode select switch (combination switch assembly) connector.

**NG** ► REPAIR OR REPLACE HARNESS OR CONNECTOR



**7. CHECK HARNESS AND CONNECTOR (HYBRID VEHICLE CONTROL ECU - DRIVE MODE SELECT SWITCH (COMBINATION SWITCH ASSEMBLY))**

- (a) Disconnect the hybrid vehicle control ECU connector.
- (b) Disconnect the drive mode select switch (combination switch assembly) connector.
- (c) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K11,K22\)](#)  
[Click Connector\(K11\)](#)  
[Click Connector\(K22\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K11-37 (DMS-) - K22-12 (DMS-)	Always	Below 1 Ω
K11-38 (DMS+) - K22-5 (DMS+)	Always	Below 1 Ω
K11-37 (DMS-) or K22-12 (DMS-) - Body ground	Always	10 kΩ or higher
K11-38 (DMS+) or K22-5 (DMS+) - Body ground	Always	10 kΩ or higher

- (d) Reconnect the drive mode select switch (combination switch assembly) connector.

(e) Reconnect the hybrid vehicle control ECU connector.

**OK**  **REPLACE HYBRID VEHICLE CONTROL ECU** 

**NG**  **REPAIR OR REPLACE HARNESS OR CONNECTOR**

