


Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM100000028ZUL
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [12/2022 -]
Title: HYBRID / BATTERY CONTROL: HYBRID CONTROL SYSTEM (for M20A-FXS): ECU Power Source Circuit; 2023 - 2024 MY Prius Prime [12/2022 -]		

ECU Power Source Circuit

DESCRIPTION

If the ignition switch is ON, the hybrid vehicle control ECU applies current to the MREL terminal to turn the IGCT-MAIN NO. 1 relay on. This supplies power to the +B1 terminal.

WIRING DIAGRAM



CAUTION / NOTICE / HINT

NOTICE:

- After the ignition switch is turned off, there may be a waiting time before disconnecting the negative (-) auxiliary battery terminal.

Click here [INFO](#)

- When disconnecting and reconnecting the auxiliary battery

HINT:


When disconnecting and reconnecting the auxiliary battery, there is an automatic learning function that completes learning when the respective system is used.

[Click here](#) **INFO**

PROCEDURE

1. CHECK HYBRID VEHICLE CONTROL ECU (+B1 VOLTAGE)

- (a) Turn the ignition switch to ON.
- (b) Measure the voltage according to the value(s) in the table below.



*a	Component with harness connected (Hybrid Vehicle Control ECU)	-	-
----	---	---	---

Standard Voltage:



[Click Location & Routing\(K11\)](#)

[Click Connector\(K11\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K11-8 (+B1) - Body ground	Ignition switch ON	11 to 14 V

- (c) Turn the ignition switch off.

NG **GO TO STEP 3**

OK

2. CHECK HARNESS AND CONNECTOR (HYBRID VEHICLE CONTROL ECU - BODY GROUND)

- (a) Disconnect the hybrid vehicle control ECU connectors.
- (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(A57,K11\)](#)

[Click Connector\(A57\)](#)

[Click Connector\(K11\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
A57-12 (E01) - Body ground	Always	Below 1 Ω
A57-24 (E12) - Body ground	Always	Below 1 Ω
K11-1 (E1) - Body ground	Always	Below 1 Ω


- (c) Reconnect the hybrid vehicle control ECU connectors.

OK ► [GO TO PROBLEM SYMPTOMS TABLE](#)

NG ► [REPAIR OR REPLACE HARNESS OR CONNECTOR](#)

3.	CHECK HYBRID VEHICLE CONTROL ECU (MREL TERMINAL VOLTAGE)
-----------	---

- (a) Turn the ignition switch to ON.
- (b) Measure the voltage according to the value(s) in the table below.



*a	Component with harness connected (Hybrid Vehicle Control ECU)	-	-
----	---	---	---

Standard Voltage:



[Click Location & Routing\(K11\)](#)

[Click Connector\(K11\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K11-10 (MREL) - Body ground	Ignition switch ON	11 to 14 V

(c) Turn the Ignition switch off.

NG  **REPLACE HYBRID VEHICLE CONTROL ECU**

Click here 

OK



4. CHECK FUSE (PM-IGCT)

(a) Remove the PM-IGCT fuse from the No. 1 engine room relay block and No. 1 junction block assembly.

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
PM-IGCT fuse	Always	Below 1 Ω

(c) Install the PM-IGCT fuse.

NG  **GO TO STEP 11**

OK



5. CHECK FUSE (IGCT-MAIN NO. 1)

(a) Remove the IGCT-MAIN NO. 1 fuse from the No. 1 engine room relay block and No. 1 junction block assembly.

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
IGCT-MAIN NO. 1 fuse	Always	Below 1 Ω

(c) Install the IGCT-MAIN NO. 1 fuse.

NG  **GO TO STEP 12**

OK




6. INSPECT RELAY (IGCT-MAIN NO. 1)

(a) Remove the IGCT-MAIN NO. 1 relay from the No. 1 engine room relay block and No. 1 junction block assembly.

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
3 - 5	Auxiliary battery voltage not applied between terminals 1 and 2	10 kΩ or higher
	Auxiliary battery voltage applied between terminals 1 and 2	Below 1 Ω



*1 IGCT-MAIN NO. 1 Relay

(c) Install the IGCT-MAIN NO. 1 relay.

NG  **REPLACE RELAY (IGCT-MAIN NO. 1)**

OK



7. CHECK HARNESS AND CONNECTOR (HYBRID VEHICLE CONTROL ECU - NO. 1 ENGINE ROOM RELAY BLOCK AND NO. 1 JUNCTION BLOCK ASSEMBLY)

(a) Disconnect the hybrid vehicle control ECU connector.

(b) Remove the PM-IGCT fuse from the No. 1 engine room relay block and No. 1 junction block assembly.

(c) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K11\)](#)

[Click Connector\(K11\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K11-8 (+B1) - 2 (PM-IGCT fuse holder)	Always	Below 1 Ω

(d) Install the PM-IGCT fuse.

(e) Reconnect the hybrid vehicle control ECU connector.

NG ► REPAIR OR REPLACE HARNESS OR CONNECTOR

OK



8.	CHECK HARNESS AND CONNECTOR (NO. 1 ENGINE ROOM RELAY BLOCK AND NO. 1 JUNCTION BLOCK ASSEMBLY)
-----------	--

(a) Remove the IGCT-MAIN NO. 1 fuse, PM-IGCT fuse and IGCT-MAIN NO. 1 relay from the No. 1 engine room relay block and No. 1 junction block assembly.

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
5 (IGCT-MAIN NO. 1 relay holder) - 2 (IGCT-MAIN NO. 1 fuse holder)	Always	Below 1 Ω
3 (IGCT-MAIN NO. 1 relay holder) - 1 (PM-IGCT fuse holder)	Always	Below 1 Ω

(c) Install the IGCT-MAIN NO. 1 fuse, PM-IGCT fuse and IGCT-MAIN NO. 1 relay.

NG ► REPAIR OR REPLACE HARNESS OR CONNECTOR

OK



9.	CHECK HARNESS AND CONNECTOR (HYBRID VEHICLE CONTROL ECU - NO. 1 ENGINE ROOM RELAY BLOCK AND NO. 1 JUNCTION BLOCK ASSEMBLY)
-----------	---

(a) Disconnect the hybrid vehicle control ECU connector.

(b) Remove the IGCT-MAIN NO. 1 relay from the No. 1 engine room relay block and No. 1 junction block assembly.

(c) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K11\)](#)

[Click Connector\(K11\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K11-10 (MREL) - 1 (IGCT-MAIN NO. 1 relay holder)	Always	Below 1 Ω
K11-10 (MREL) or 1 (IGCT-MAIN NO. 1 relay holder) - Body ground and other terminals	Always	10 k Ω or higher

(d) Install the IGCT-MAIN NO. 1 relay.

(e) Reconnect the hybrid vehicle control ECU connector.

NG **REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK



10.	CHECK HARNESS AND CONNECTOR (NO. 1 ENGINE ROOM RELAY BLOCK AND NO. 1 JUNCTION BLOCK ASSEMBLY - BODY GROUND)
------------	--

(a) Remove the IGCT-MAIN NO. 1 relay from the No. 1 engine room relay block and No. 1 junction block assembly.

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
2 (IGCT-MAIN NO. 1 relay holder) - Body ground	Always	Below 1 Ω

(c) Install the IGCT-MAIN NO. 1 relay.

OK **CHECK FOR INTERMITTENT PROBLEMS**

NG **REPAIR OR REPLACE HARNESS OR CONNECTOR**

11.**CHECK HARNESS AND CONNECTOR (HYBRID VEHICLE CONTROL ECU - NO. 1 ENGINE ROOM RELAY BLOCK AND NO. 1 JUNCTION BLOCK ASSEMBLY)**

- (a) Remove the PM-IGCT fuse from the No. 1 engine room relay block and No. 1 junction block assembly.
- (b) Disconnect the hybrid vehicle control ECU connector.
- (c) Measure the resistance according to the value(s) in the table below.

Standard Resistance:


[Click Location & Routing\(K11\)](#)
[Click Connector\(K11\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K11-8 (+B1) or 2 (PM-IGCT fuse holder) - Body ground and other terminals	Always	10 kΩ or higher

- (d) Reconnect the hybrid vehicle control ECU connector.
- (e) Install the PM-IGCT fuse.

OK ► **REPLACE FUSE (PM-IGCT)**
NG ► **GO TO STEP 13**
12.**CHECK HARNESS AND CONNECTOR (NO. 1 ENGINE ROOM RELAY BLOCK AND NO. 1 JUNCTION BLOCK ASSEMBLY)**

- (a) Remove the IGCT-MAIN NO. 1 fuse, PM-IGCT fuse and IGCT-MAIN NO. 1 relay from the No. 1 engine room relay block and No. 1 junction block assembly.
- (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
5 (IGCT-MAIN NO. 1 relay holder) or 2 (IGCT-MAIN NO. 1 fuse holder) - Body ground and other terminals	Always	10 kΩ or higher
3 (IGCT-MAIN NO. 1 relay holder) or 1 (PM-IGCT fuse holder) - Body ground and other terminals	Always	10 kΩ or higher

- (c) Install the IGCT-MAIN NO. 1 fuse, PM-IGCT fuse and IGCT-MAIN NO. 1 relay.

OK ► **REPLACE FUSE (IGCT-MAIN NO. 1)**
NG ► **GO TO STEP 14**

13.	REPAIR OR REPLACE HARNESS OR CONNECTOR
------------	---

NEXT ▶ **REPLACE FUSE (PM-IGCT)**

14.	REPAIR OR REPLACE HARNESS OR CONNECTOR
------------	---

NEXT ▶ **REPLACE FUSE (IGCT-MAIN NO. 1)**

