

Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM100000028ZXU
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [12/2022 -]
Title: HYBRID / BATTERY CONTROL: MOTOR GENERATOR CONTROL SYSTEM (for M20A-FXS): P0C5013,P0C501F,P0C5A13,P0C5A1F; Drive Motor "A" Position Sensor Circuit "A" Circuit Open; 2023 - 2024 MY Prius Prius Prime [12/2022 -]		

DTC	P0C5013	Drive Motor "A" Position Sensor Circuit "A" Circuit Open
------------	----------------	---

DTC	P0C501F	Drive Motor "A" Position Sensor Circuit "A" Circuit Intermittent
------------	----------------	---

DTC	P0C5A13	Drive Motor "A" Position Sensor Circuit "B" Circuit Open
------------	----------------	---

DTC	P0C5A1F	Drive Motor "A" Position Sensor Circuit "B" Circuit Intermittent
------------	----------------	---

DTC SUMMARY

MALFUNCTION DESCRIPTION

These DTCs indicate that the resolver output signal is abnormal. The cause of this malfunction may be one of the following:

AREA	MAIN MALFUNCTION DESCRIPTION
Inverter low-voltage circuit	The connectors are not connected properly
Hybrid vehicle transaxle assembly	<ul style="list-style-type: none"> Open circuit in the motor resolver circuit Motor (MG2) internal malfunction (entry of foreign matter, etc.)
Wire harness between the resolver and inverter with converter assembly	<ul style="list-style-type: none"> Open circuit in the wire harness The connectors are not connected properly
Inside of inverter	Inverter with converter assembly internal circuit malfunction

DESCRIPTION

Refer to the system description for the Motor Resolver Circuit.

Click here [INFO](#)

DTC NO.	DETECTION ITEM	DTC DETECTION CONDITION	TROUBLE AREA	MIL	WARNING INDICATE	DTC OUTPUT FROM	PRIORITY	NOTE
P0C5013	Drive Motor "A" Position Sensor Circuit "A" Circuit Open	Open in motor resolver sin phase circuit (1 trip detection logic)	<ul style="list-style-type: none"> Inverter with converter assembly Hybrid vehicle transaxle assembly Wire harness or connector 	Comes on	Master Warning: Comes on	Motor Generator	A	SAE Code: P0C50
P0C501F	Drive Motor "A" Position Sensor Circuit "A" Circuit Intermittent	Open in motor resolver sin phase circuit detected when DTC P0C7917, P0E5717, P0D3319, P1C5D19, P1C5F19 or P1C5E19 is stored. (1 trip detection logic)	<ul style="list-style-type: none"> Inverter with converter assembly Hybrid vehicle transaxle assembly Wire harness or connector 	Does not come on	Master Warning: Does not come on	Motor Generator	A	SAE Code: P0C54
P0C5A13	Drive Motor "A" Position Sensor Circuit "B" Circuit Open	Open in motor resolver cos phase circuit (1 trip detection logic)	<ul style="list-style-type: none"> Inverter with converter assembly Hybrid vehicle transaxle assembly Wire harness or connector 	Comes on	Master Warning: Comes on	Motor Generator	A	SAE Code: P0C5A
P0C5A1F	Drive Motor "A" Position Sensor Circuit "B" Circuit Intermittent	Open in motor resolver cos phase circuit detected when DTC P0C7917, P0E5717, P0D3319, P1C5D19, P1C5F19 or	<ul style="list-style-type: none"> Inverter with converter assembly Hybrid vehicle transaxle assembly Wire harness or 	Does not come on	Master Warning: Does not come on	Motor Generator	A	SAE Code: P0C5E

DTC NO.	DETECTION ITEM	DTC DETECTION CONDITION	TROUBLE AREA	MIL	WARNING INDICATE	DTC OUTPUT FROM	PRIORITY	NOTE
		P1C5E19 is stored. (1 trip detection logic)	connector					

HINT:

If either of these DTCs is output, an open in the sin or cos phase circuit is suspected.

MONITOR DESCRIPTION

The motor generator control ECU monitors the motor resolver output signal. If the motor generator control ECU detects output signals that are out of the normal range or specification, it will conclude that there is a malfunction in the motor resolver. If a malfunction is detected, the motor generator control ECU will illuminate the MIL and store a DTC.

MONITOR STRATEGY

Related DTCs	P0C50 (INF P0C5013): Circuit discontinuity P0C5A (INF P0C5A13): Circuit discontinuity
Required sensors/components	Motor resolver
Frequency of operation	Continuous
Duration	TMC's intellectual property
MIL operation	1 driving cycle
Sequence of operation	None

TYPICAL ENABLING CONDITIONS

The monitor will run whenever the following DTCs are not stored	TMC's intellectual property
Other conditions belong to TMC's intellectual property	-

TYPICAL MALFUNCTION THRESHOLDS

TMC's intellectual property	-
-----------------------------	---

COMPONENT OPERATING RANGE

Motor generator control ECU	DTC P0C50 (INF P0C5013) is not detected DTC P0C5A (INF P0C5A13) is not detected
-----------------------------	--

CONFIRMATION DRIVING PATTERN**HINT:**

- After repair has been completed, clear the DTC and then check that the vehicle has returned to normal by performing the following All Readiness check procedure.

[Click here](#) **INFO**

- When clearing the permanent DTCs, refer to the "CLEAR PERMANENT DTC" procedure.

[Click here](#) **INFO**

1. Clear the DTCs (even if no DTCs are stored, perform the clear DTC procedure).
2. Turn the ignition switch off and wait for 2 minutes or more.
3. Turn the ignition switch to ON and wait for 5 seconds or more. [*1]
4. Turn the ignition switch to ON (READY) and wait for 5 seconds or more. [*2]
5. Depress the accelerator pedal of the vehicle with the engine stopped and the shift lever in P to start the engine. [*3]
6. Drive the vehicle forward with the shift lever in D for 5 m (16 ft.) or more. [*4]
7. Drive the vehicle backward with the shift lever in R for 5 m (16 ft.) or more. [*5]

HINT:

[*1] to [*5]: Normal judgment procedure.

The normal judgment procedure is used to complete DTC judgment and also used when clearing permanent DTCs.

8. Enter the following menus: Powertrain / Motor Generator / Utility / All Readiness.
9. Check the DTC judgment result.

HINT:

- If the judgment result shows NORMAL, the system is normal.
- If the judgment result shows ABNORMAL, the system has a malfunction.
- If the judgment result shows INCOMPLETE, perform the normal judgment procedure again.

WIRING DIAGRAM

Refer to the wiring diagram for the Motor Resolver Circuit.

[Click here](#) **INFO**

CAUTION / NOTICE / HINT

CAUTION:

Refer to the precautions before inspecting high voltage circuit.

[Click here](#) **INFO**

NOTICE:

- After the ignition switch is turned off, there may be a waiting time before disconnecting the negative (-) auxiliary battery terminal.

[Click here](#) **INFO**

- When disconnecting and reconnecting the auxiliary battery.

HINT:

When disconnecting and reconnecting the auxiliary battery, there is an automatic learning function that completes learning when the respective system is used.

[Click here](#) **INFO**

HINT:

- If the problem symptom cannot be reproduced, performing a road test on a road on which the vehicle tends to vibrate will make it easier to reproduce the symptom.
- If the resolver is malfunctioning, the vehicle may not drive smoothly.
- When inspecting the connectors, if it is difficult to judge if a connector was disconnected, deformed or improperly secured, disconnect and reconnect the connector and then check for DTCs again. Check if the same DTC is output. If the same DTC is not output, improper connection of connectors is suspected.

- As a malfunction detection threshold may be exceeded when performing the vibration or heat connector inspections, make sure to perform the following inspection to check that the DTC was not stored due to the malfunction of a part.
- P0C5013, P0C501F, P0C5A13 or P0C5A1F may be output as a result of the malfunction indicated by the DTCs in table below.
 - a. The chart above is listed in inspection order of priority.
 - b. Check DTCs that are output at the same time by following the listed order. (The main cause of the malfunction can be determined without performing unnecessary inspections.)

Table 1

MALFUNCTION CONTENT	SYSTEM	RELEVANT DTC	
Insulation malfunction	Hybrid control system	P1C7C49	Hybrid/EV Battery Voltage System Isolation (A/C Area) Internal Electronic Failure
		P1C7D49	Hybrid/EV Battery Voltage System Isolation (Hybrid/EV Battery Area) Internal Electronic Failure
		P1C7E49	Hybrid/EV Battery Voltage System Isolation (Transaxle Area) Internal Electronic Failure
		P1C7F49	Hybrid/EV Battery Voltage System Isolation (Direct Current Area) Internal Electronic Failure
		P1C8049	Hybrid/EV Battery Voltage System Isolation (Rear Motor Area) Internal Electronic Failure

Table 2

MALFUNCTION CONTENT	SYSTEM	RELEVANT DTC	
Microcomputer malfunction	Motor generator control system	P0A1B47	Drive Motor "A" Control Module Watchdog / Safety MC Failure
		P1C2B1C	Drive Motor "A" Control Module A/D Converter Circuit Voltage Out of Range
		P1C2B49	Drive Motor "A" Control Module A/D Converter Circuit Internal Electronic Failure
		P1C2B71	Drive Motor "A" Control Module A/D Converter Circuit Actuator Stuck
		P1CB038	Drive Motor "A" Position Sensor REF Signal Frequency Incorrect
	Hybrid control system	P0A1B49	Drive Motor "A" Control Module Internal Electronic Failure
Power source circuit malfunction	Motor generator control system	P06B01C	Generator Control Module Position Sensor REF Power Source Circuit Voltage Out of Range
		P06D61C	Generator Control Module Offset Power Circuit Voltage Out of Range

PROCEDURE

1.	CHECK CONNECTOR CONNECTION CONDITION (INVERTER WITH CONVERTER ASSEMBLY CONNECTOR)
-----------	--

Click here [INFO](#)

RESULT	PROCEED TO
OK	A
NG (The connector is not connected securely.)	B
NG (The terminals are not making secure contact or are deformed, or water or foreign matter exists in the connector.)	C

B ▶ **CONNECT SECURELY**

C ▶ **REPAIR OR REPLACE HARNESS OR CONNECTOR**

A
▼

2.	CHECK MOTOR RESOLVER CIRCUIT
-----------	-------------------------------------

Click here [INFO](#)

HINT:

If the "Motor Resolver Circuit" inspection results are normal, perform the next step.

NEXT ▶ **REPLACE INVERTER WITH CONVERTER ASSEMBLY**

