

Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM10000002BI81
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [03/2023 -]
Title: HYBRID / BATTERY CONTROL: MOTOR GENERATOR CONTROL SYSTEM (for PHEV Model): P2C8C11,P2C8C15,P2CA511,P2CA515; DC/DC Converter Temperature Sensor "D" Circuit Low Circuit Short to Ground; 2023 - 2024 MY Prius Prime [03/2023 -]		

DTC	P2C8C11	DC/DC Converter Temperature Sensor "D" Circuit Low Circuit Short to Ground
------------	----------------	---

DTC	P2C8C15	DC/DC Converter Temperature Sensor "D" Circuit High Circuit Short to Battery or Open
------------	----------------	---

DTC	P2CA511	DC/DC Converter Temperature Sensor "E" Circuit Low Circuit Short to Ground
------------	----------------	---

DTC	P2CA515	DC/DC Converter Temperature Sensor "E" Circuit High Circuit Short to Battery or Open
------------	----------------	---

DESCRIPTION

The motor generator control ECU (MG ECU) located in the inverter with converter assembly detects the temperature of the boost converter using the temperature sensor built into the boost converter. The motor generator control ECU (MG ECU) detects malfunctions in the boost converter temperature sensor and its wiring.

DTC NO.	DETECTION ITEM	DTC DETECTION CONDITION	TROUBLE AREA	MIL	WARNING INDICATE	DTC OUTPUT FROM	PRIORITY	NOTE
P2C8C11	DC/DC Converter Temperature Sensor "D" Circuit Low Circuit Short to Ground	Short to ground detected in boost converter temperature sensor (upper) signal circuit (1 trip detection logic)	Inverter with converter assembly	Comes on	Master Warning: Comes on	Motor Generator	A	SAE Code: P2C8E
P2C8C15	DC/DC Converter Temperature Sensor "D" Circuit High Circuit Short to Battery or Open	Open or short to +B detected in boost converter temperature sensor (upper) signal circuit (1 trip detection logic)	Inverter with converter assembly	Comes on	Master Warning: Comes on	Motor Generator	A	SAE Code: P2C8F

DTC NO.	DETECTION ITEM	DTC DETECTION CONDITION	TROUBLE AREA	MIL	WARNING INDICATE	DTC OUTPUT FROM	PRIORITY	NOTE
P2CA511	DC/DC Converter Temperature Sensor "E" Circuit Low Circuit Short to Ground	Short to ground detected in boost converter temperature sensor (lower) signal circuit (1 trip detection logic)	Inverter with converter assembly		Comes on	Master Warning: Comes on	Motor Generator A	SAE Code: P2CA6
P2CA515	DC/DC Converter Temperature Sensor "E" Circuit High Circuit Short to Battery or Open	Open or short to +B detected in boost converter temperature sensor (lower) signal circuit (1 trip detection logic)	Inverter with converter assembly		Comes on	Master Warning: Comes on	Motor Generator A	SAE Code: P2CA7

MONITOR DESCRIPTION

If the motor generator control ECU detects a malfunction in the boost converter temperature sensor circuit, the motor generator control ECU will illuminate the MIL and store a DTC.

MONITOR STRATEGY

Related DTCs	P2C8E (INF P2C8C11): DC/DC Converter Temperature Sensor "D" Range check P2C8F (INF P2C8C15): DC/DC Converter Temperature Sensor "D" Range check P2CA6 (INF P2CA511): DC/DC Converter Temperature Sensor "E" Range check P2CA7 (INF P2CA515): DC/DC Converter Temperature Sensor "E" Range check
Required sensors/components	DC/DC converter temperature sensor
Frequency of operation	Continuous
Duration	TMC's intellectual property
MIL operation	Immediately
Sequence of operation	None

TYPICAL ENABLING CONDITIONS

The monitor will run whenever the following DTCs are not stored	TMC's intellectual property
Other conditions belong to TMC's intellectual property	-

TYPICAL MALFUNCTION THRESHOLDS

TMC's intellectual property	-
-----------------------------	---

COMPONENT OPERATING RANGE

Motor generator control ECU	DTC P2C8E (INF P2C8C11) is not detected DTC P2C8F (INF P2C8C15) is not detected DTC P2CA6 (INF P2CA511) is not detected DTC P2CA7 (INF P2CA515) is not detected
-----------------------------	--

CONFIRMATION DRIVING PATTERN

HINT:

- After repair has been completed, clear the DTC and then check that the vehicle has returned to normal by performing the following All Readiness check procedure.

Click here [INFO](#)

- When clearing the permanent DTCs, refer to the "CLEAR PERMANENT DTC" procedure.

Click here [INFO](#)

1. Clear the DTCs (even if no DTCs are stored, perform the clear DTC procedure).
2. Turn the ignition switch off and wait for 2 minutes or more.
3. Turn the ignition switch to ON and wait for 5 seconds or more. [*1]

HINT:

[*1]: Normal judgment procedure.

The normal judgment procedure is used to complete DTC judgment and also used when clearing permanent DTCs.

4. Enter the following menus: Powertrain / Motor Generator / Utility / All Readiness.
5. Check the DTC judgment result.

HINT:

- If the judgment result shows NORMAL, the system is normal.
- If the judgment result shows ABNORMAL, the system has a malfunction.
- If the judgment result shows INCOMPLETE, perform the normal judgment procedure again.

PROCEDURE

1.	REPLACE INVERTER WITH CONVERTER ASSEMBLY
----	---

Click here [INFO](#)

NEXT  **COMPLETED**

