

<b>Last Modified:</b> 12-04-2024	6.11:8.1.0	<b>Doc ID:</b> RM100000029X3C
<b>Model Year Start:</b> 2023	<b>Model:</b> Prius Prime	<b>Prod Date Range:</b> [12/2022 - ]
<b>Title:</b> SEAT: FRONT POWER SEAT CONTROL SYSTEM (w/ Memory): B265196; Reclining Sensor (Motor) Component Internal Failure; 2023 - 2024 MY Prius Prius Prime [12/2022 - ]		


<b>DTC</b>	<b>B265196</b>	<b>Reclining Sensor (Motor) Component Internal Failure</b>
------------	----------------	--

## DESCRIPTION

When the position control ECU assembly LH does not receive a reclining motor position sensor signal despite the seat having been moved forward or rearward by power seat motor operation, this DTC is stored.

DTC NO.	DETECTION ITEM	DTC DETECTION CONDITION	TROUBLE AREA	DTC OUTPUT FROM	PRIORITY
B265196	Reclining Sensor (Motor) Component Internal Failure	Reclining motor position sensor signal not received when power seat moved forward or rearward	<ul style="list-style-type: none"> <li>Position control ECU assembly LH</li> <li>Reclining motor (front seatback frame sub-assembly LH)</li> <li>Wire harness or connector</li> </ul>	Driver Seat	A

## WIRING DIAGRAM



## CAUTION / NOTICE / HINT

**NOTICE:**

- Make sure to initialize the position control ECU assembly LH after replacing the position control ECU assembly LH, seat assembly or any related parts (including removal and installation).

Click here [INFO](#)

- Initializing the position control ECU assembly LH will clear the seat position memory.

**PROCEDURE****1. CLEAR DTC**

(a) Clear the DTCs.

**Body Electrical > Driver Seat > Clear DTCs**

**NEXT****2. CHECK FOR DTC**

(a) Check for DTCs.

**Body Electrical > Driver Seat > Trouble Codes**

RESULT	PROCEED TO
B265196 is not output	A
B265196 is output	B

**A**  **USE SIMULATION METHOD TO CHECK**


**B****3. PERFORM ACTIVE TEST USING GTS**

(a) Perform the Active Test according to the display on the GTS.

**Body Electrical > Driver Seat > Active Test**

TESTER DISPLAY	MEASUREMENT ITEM	CONTROL RANGE	DIAGNOSTIC NOTE
Reclining Motor	Seat reclining operation	Front/Rear	-

**Body Electrical > Driver Seat > Active Test**



OK:  
Reclining motor operates normally.

**NG** **GO TO STEP 7**

**OK**

**4. CHECK POSITION CONTROL ECU ASSEMBLY LH**

Pre-procedure1

(a) Disconnect the d2 reclining motor (front seatback frame sub-assembly LH) connector.

Procedure1

(b) Measure the voltage according to the value(s) in the table below.

Standard Voltage:



[Click Location & Routing\(d2\).](#)

[Click Connector\(d2\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION	RESULT
d2-2 - d2-3	Reclining switch on	4.8 to 5.1 V	V

Post-procedure1

(c) None

**NG** **GO TO STEP 6**

**OK**

**5. CHECK RECLINING MOTOR (FRONT SEATBACK FRAME SUB-ASSEMBLY LH)**

Pre-procedure1

(a) Reconnect the d2 reclining motor (front seatback frame sub-assembly LH) connector.

Procedure1

(b) Measure the voltage according to the value(s) in the table below.

Standard Voltage:




[Click Location & Routing\(d2\).](#)

[Click Connector\(d2\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION	RESULT
d2-2 - Body ground	Reclining motor operating	4.5 to 4.8 V	V

Result:

PROCEED TO
OK
NG



\*a Component with harness connected (Reclining Motor (Front Seatback Frame Sub-assembly LH))

Post-procedure1

(c) None

**OK** **REPLACE POSITION CONTROL ECU ASSEMBLY LH**  
INFO

**NG** **REPLACE RECLINING MOTOR (FRONT SEATBACK FRAME SUB-ASSEMBLY LH)**

<b>6.</b>	<b>CHECK HARNESS AND CONNECTOR (POSITION CONTROL ECU ASSEMBLY LH - RECLINING MOTOR (FRONT SEATBACK FRAME SUB-ASSEMBLY LH))</b>
-----------	--

Pre-procedure1

(a) Disconnect the b13 position control ECU assembly LH connector.

Procedure1

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(b13,d2\)](#)

[Click Connector\(b13\)](#)

[Click Connector\(d2\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION	RESULT
b13-11 (SSRR) - d2-2	Always	Below 1 $\Omega$	$\Omega$
b13-11 (SSRR) or d2-2 - Body ground	Always	10 k $\Omega$ or higher	k $\Omega$
b13-12 (SGND) - d2-3	Always	Below 1 $\Omega$	$\Omega$
b13-12 (SGND) or d2-3 - Body ground	Always	10 k $\Omega$ or higher	k $\Omega$

Post-procedure1

(c) None

**OK** **REPLACE POSITION CONTROL ECU ASSEMBLY LH**

**NG** **REPAIR OR REPLACE HARNESS OR CONNECTOR**

<b>7.</b>	<b>INSPECT RECLINING MOTOR (FRONT SEATBACK FRAME SUB-ASSEMBLY LH)</b>
-----------	---

**HINT:**

[Click here](#)

**NG** **REPLACE RECLINING MOTOR (FRONT SEATBACK FRAME SUB-ASSEMBLY LH)**

**OK**



<b>8.</b>	<b>CHECK HARNESS AND CONNECTOR (POSITION CONTROL ECU ASSEMBLY LH - RECLINING MOTOR (FRONT SEATBACK FRAME SUB-ASSEMBLY LH))</b>
-----------	--

Pre-procedure1

(a) Disconnect the b11 and b12 position control ECU assembly LH connectors.

Procedure1

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(b11,d2,b12\)](#)

[Click Connector\(b11\)](#)

[Click Connector\(d2\)](#)

[Click Connector\(b12\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION	RESULT
b11-10 (RCL+) - d2-4	Always	Below 1 $\Omega$	$\Omega$
b11-10 (RCL+) or d2-4 - Body ground	Always	10 k $\Omega$ or higher	k $\Omega$
b12-6 (RCL-) - d2-1	Always	Below 1 $\Omega$	$\Omega$
b12-6 (RCL-) or d2-1 - Body ground	Always	10 k $\Omega$ or higher	k $\Omega$

Post-procedure1

(c) None

**OK** **REPLACE POSITION CONTROL ECU ASSEMBLY LH**

[INFO](#)

**NG** **REPAIR OR REPLACE HARNESS OR CONNECTOR**

