


<b>Last Modified:</b> 12-04-2024	6.11:8.1.0	<b>Doc ID:</b> RM100000029X3H
<b>Model Year Start:</b> 2023	<b>Model:</b> Prius Prime	<b>Prod Date Range:</b> [12/2022 - ]
<b>Title:</b> SEAT: FRONT POWER SEAT CONTROL SYSTEM (w/ Memory): Front Power Seat does not Operate with Front Power Seat Switch; 2023 - 2024 MY Prius Prius Prime [12/2022 - ]		

## Front Power Seat does not Operate with Front Power Seat Switch

## DESCRIPTION

Signals are input into the position control ECU assembly LH. The built-in ECU manages the signals received from the power seat switch and operates each motor. If the position control ECU assembly LH receives more than 2 motor operation signals for the same motor, the motor will be stopped. Manual operation resumes when the position control ECU assembly LH receives only 1 signal.

## WIRING DIAGRAM



## CAUTION / NOTICE / HINT

### NOTICE:

- Inspect the fuses for circuits related to this system before performing the following procedure.
- Make sure to initialize the position control ECU assembly LH after replacing the position control ECU assembly LH, seat assembly or any related parts (including removal and installation).

Click here [INFO](#)

- Initializing the position control ECU assembly LH will clear the seat position memory.

## PROCEDURE

**1. CHECK FRONT POWER SEAT OPERATION**

(a) Check that each function of the power seat operates normally by using the front power seat switch assembly LH.

Click here [INFO](#)

RESULT	PROCEED TO
All power seat functions do not operate	A
One or more power seat functions do not operate	B

**B** ► [GO TO OTHER DIAGNOSIS PROCEDURE \(One or more Power Seat Motors do not Operate\)](#)

**A**  
▼

**2. INSPECT FRONT POWER SEAT SWITCH ASSEMBLY LH**

Click here [INFO](#)

**NG** ► [REPLACE FRONT POWER SEAT SWITCH ASSEMBLY LH](#)

Click here [INFO](#)

**OK**  
▼

**3. CHECK HARNESS AND CONNECTOR (POSITION CONTROL ECU ASSEMBLY LH - POWER SUPPLY)**

(a) Disconnect the b11 and b13 position control ECU assembly LH connectors.

(b) Measure the voltage according to the value(s) in the table below.

Standard Voltage:



[Click Location & Routing\(b11,b13\)](#)

[Click Connector\(b11\)](#)[Click Connector\(b13\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
b11-3 (+B) - Body ground	Ignition switch off	11 to 14 V
b13-15 (SYSB) - Body ground	Ignition switch off	11 to 14 V
b13-1 (IG) - Body ground	Ignition switch ON	11 to 14 V
b13-1 (IG) - Body ground	Ignition switch off	Below 1 V

**NG**  **REPAIR OR REPLACE HARNESS OR CONNECTOR****OK**

<b>4.</b>	<b>CHECK HARNESS AND CONNECTOR (POSITION CONTROL ECU ASSEMBLY LH - BODY GROUND)</b>
-----------	---

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:

[Click Location & Routing\(b11\)](#)[Click Connector\(b11\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
b11-2 (GND) - Body ground	Always	Below 1 $\Omega$

**NG**  **REPAIR OR REPLACE HARNESS OR CONNECTOR****OK**

<b>5.</b>	<b>CHECK HARNESS AND CONNECTOR (POSITION CONTROL ECU ASSEMBLY LH - FRONT POWER SEAT SWITCH ASSEMBLY LH)</b>
-----------	---

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:

[Click Location & Routing\(b13,b7\)](#)

[Click Connector\(b13\)](#)

[Click Connector\(b7\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
b13-12 (SGND) - b7-20 (E)	Always	Below 1 $\Omega$

**OK** ▶ REPLACE POSITION CONTROL ECU ASSEMBLY LH

Click here [INFO](#)

**NG** ▶ REPAIR OR REPLACE HARNESS OR CONNECTOR

