


<b>Last Modified:</b> 12-04-2024	6.11:8.1.0	<b>Doc ID:</b> RM100000028UXB
<b>Model Year Start:</b> 2023	<b>Model:</b> Prius Prime	<b>Prod Date Range:</b> [12/2022 - ]
<b>Title:</b> SUPPLEMENTAL RESTRAINT SYSTEMS: AIRBAG SYSTEM: B00D512; Restraint System Passenger Disable Indicator Circuit Short to Battery; 2023 - 2024 MY Prius Prius Prime [12/2022 - ]		

<b>DTC</b>	<b>B00D512</b>	<b>Restraint System Passenger Disable Indicator Circuit Short to Battery</b>
------------	----------------	--

## DESCRIPTION

DTC NO.	DETECTION ITEM	DTC DETECTION CONDITION	TROUBLE AREA	WARNING INDICATE	DTC OUTPUT FROM	PRIORITY	TEST MODE / CHECK MODE
B00D512	Restraint System Passenger Disable Indicator Circuit Short to Battery	<ul style="list-style-type: none"> <li>The airbag ECU assembly detects a short circuit +B signal in the passenger airbag ON/OFF indicator "OFF" circuit when the airbag ECU assembly sends an "ON" request signal to the "OFF" indicator in the passenger airbag ON/OFF indicator.</li> <li>Passenger airbag ON/OFF indicator malfunction</li> <li>Airbag ECU assembly malfunction</li> </ul>	<ul style="list-style-type: none"> <li>Harness or connector</li> <li>Passenger airbag ON/OFF indicator (map light assembly)</li> <li>Airbag ECU assembly</li> </ul>	Comes on	SRS Airbag	A	Does not apply to test/check mode

## WIRING DIAGRAM



## CAUTION / NOTICE / HINT

### NOTICE:

- After the ignition switch is turned off, there may be a waiting time before disconnecting the negative (-) auxiliary battery terminal.

Click here [INFO](#)

### HINT:

When disconnecting and reconnecting the auxiliary battery, there is an automatic learning function that completes learning when the respective system is used.

Click here [INFO](#)

- After replacing the airbag ECU assembly, refer to work procedure.

Click here [INFO](#)

## PROCEDURE

### 1. CHECK CONNECTION OF CONNECTORS

Pre-procedure1

- Turn the ignition switch off.
- Disconnect the cable from the negative (-) auxiliary battery terminal, and wait for at least 60 seconds.

Procedure1

- Check that the connectors are properly connected to the airbag ECU assembly and map light assembly.

OK:

The connectors are properly connected.

Post-procedure1


- None

**NG**  **CONNECT CONNECTORS PROPERLY**

**OK**

## 2. CHECK CONNECTORS

Pre-procedure1



(a) Disconnect the airbag ECU assembly connector.

*1	Map Light Assembly
*2	Airbag ECU Assembly
*3	Wire Harness

(b) Disconnect the map light assembly connector.

Procedure1

(c) Check that the terminals of the connectors are not deformed or damaged.

OK:

The terminals are not deformed or damaged.

Post-procedure1

(d) None

**NG** ► REPAIR OR REPLACE HARNESS OR CONNECTOR**OK**

## 3. CHECK HARNESS AND CONNECTOR (CHECK FOR SHORT TO +B IN THE CIRCUIT)

Pre-procedure1

(a) Connect the cable to the negative (-) auxiliary battery terminal, and wait for at least 2 seconds.

(b) Turn the ignition switch to ON.

Procedure1

(c) Measure the voltage according to the value(s) in the table below.

Standard Voltage:



[Click Location & Routing\(K1,U1\)](#)


[Click Connector\(K1\)](#)

[Click Connector\(U1\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION	RESULT
K1-34 (P-AB) or U1-19 (P-AB) - Body ground	Ignition switch ON	Below 1 V	V

Result:

PROCEED TO
OK
NG



*1	Map Light Assembly
*2	Airbag ECU Assembly
*3	Wire Harness
*a	Front view of wire harness connector (to Map Light Assembly)
*b	Front view of wire harness connector (to Airbag ECU Assembly)

Post-procedure1

(d) Turn the ignition switch off.

(e) Disconnect the cable from the negative (-) auxiliary battery terminal, and wait for at least 60 seconds.


**NG** **REPAIR OR REPLACE HARNESS OR CONNECTOR**



**4. CHECK PASSENGER AIRBAG ON/OFF INDICATOR**

Pre-procedure1

(a) Connect the map light assembly connector.



*1	Map Light Assembly
*2	Airbag ECU Assembly
*3	Wire Harness
*a	Front view of wire harness connector (to Airbag ECU Assembly)

(b) Using a service wire, connect terminal 34 (P-AB) of connector B and body ground.

**NOTICE:**

Do not forcibly insert the service wire into the terminals of the connector when connecting a service wire.

(c) Connect the cable to the negative (-) auxiliary battery terminal, and wait for at least 2 seconds.

(d) Turn the ignition switch to ON.

Procedure1

(e) Check the passenger airbag ON/OFF indicator operation.

OK:

The passenger airbag ON/OFF indicator "OFF" come on.

Post-procedure1

- (f) Turn the ignition switch off.
- (g) Disconnect the cable from the negative (-) auxiliary battery terminal, and wait for at least 60 seconds.
- (h) Disconnect the service wire from connector B.

**OK** ► REPLACE AIRBAG ECU ASSEMBLY INFO

**NG** ► REPLACE MAP LIGHT ASSEMBLY

