

Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM1000000029IN0
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [12/2022 -]
Title: LIGHTING (INT): LIGHTING SYSTEM: Ambient Illumination Light Circuit; 2023 - 2024 MY Prius Prius Prime [12/2022 -]		


Ambient Illumination Light Circuit

DESCRIPTION

The main body ECU (multiplex network body ECU) controls the operation of the following lights:

- No. 1 Interior Illumination Light Assembly (No. 1 Instrument Panel Garnish Sub-assembly)
- No. 2 Interior Illumination Light Assembly (for Front Passenger Side) (No. 2 Instrument Panel Garnish Sub-assembly)
- No. 2 Interior Illumination Light Assembly (for Center) (No. 2 Instrument Panel Garnish Sub-assembly)

WIRING DIAGRAM



CAUTION / NOTICE / HINT

NOTICE:

- Inspect the fuses for circuits related to this system before performing the following procedure.
- Before replacing the main body ECU (multiplex network body ECU), refer to Registration.

[Click here](#) INFO

PROCEDURE

1. PERFORM ACTIVE TEST USING GTS

(a) Perform the Active Test according to the display on the GTS.

Body Electrical > Main Body > Active Test

TESTER DISPLAY	MEASUREMENT ITEM	CONTROL RANGE	DIAGNOSTIC NOTE
Extended Illumination 1	Turns on the following lights: <ul style="list-style-type: none"> No. 2 Interior Illumination Light Assembly (for Front Passenger Side) (No. 2 Instrument Panel Garnish Sub-assembly) 	OFF or ON	Perform the Active Test with the vehicle stopped and ignition switch ON.
Extended Illumination 2	Turns on the following lights: <ul style="list-style-type: none"> No. 1 Interior Illumination Light Assembly (No. 1 Instrument Panel Garnish Sub-assembly) No. 2 Interior Illumination Light Assembly (for Center) (No. 2 Instrument Panel Garnish Sub-assembly) 	OFF or ON	Perform the Active Test with the vehicle stopped and ignition switch ON.

Body Electrical > Main Body > Active Test

TESTER DISPLAY
Extended Illumination 1

Body Electrical > Main Body > Active Test

TESTER DISPLAY
Extended Illumination 2

RESULT	PROCEED TO
OK	A
NG (No. 2 interior illumination light assembly (for front passenger side) (No. 2 instrument panel garnish sub-assembly) does not come on)	B
NG (No. 1 interior illumination light assembly (No. 1 instrument panel garnish sub-assembly) does not come on)	C

RESULT	PROCEED TO
NG (No. 2 interior illumination light assembly (for center) (No. 2 instrument panel garnish sub-assembly) does not come on)	D
NG (No. 1 interior illumination light assembly (No. 1 instrument panel garnish sub-assembly) and No. 2 interior illumination light assembly (for center) (No. 2 instrument panel garnish sub-assembly) do not come on)	E
NG (All lights do not come on)	F

A ► **USE SIMULATION METHOD TO CHECK**

C ► **GO TO STEP 5**

D ► **GO TO STEP 8**

E ► **GO TO STEP 11**

F ► **GO TO STEP 13**

B



2.	INSPECT NO. 2 INTERIOR ILLUMINATION LIGHT ASSEMBLY (for FRONT PASSENGER SIDE) (NO. 2 INSTRUMENT PANEL GARNISH SUB-ASSEMBLY)
-----------	--

Click here [INFO](#)

NG ► **REPLACE NO. 2 INTERIOR ILLUMINATION LIGHT ASSEMBLY (for FRONT PASSENGER SIDE) (NO. 2 INSTRUMENT PANEL GARNISH SUB-ASSEMBLY)**

OK



3.	CHECK HARNESS AND CONNECTOR (NO. 2 INTERIOR ILLUMINATION LIGHT ASSEMBLY (for FRONT PASSENGER SIDE) - MAIN BODY ECU (MULTIPLEX NETWORK BODY ECU))
-----------	---

(a) Disconnect the K16 main body ECU (multiplex network body ECU) connector.

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K16,K51\)](#)

[Click Connector\(K16\)](#)

[Click Connector\(K51\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K16-10 (LED1) - K51-1 (E)	Always	Below 1 Ω
K16-10 (LED1) or K51-1 (E) - Body ground	Always	10 k Ω or higher

NG **REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK



4. CHECK HARNESS AND CONNECTOR (NO. 2 INTERIOR ILLUMINATION LIGHT ASSEMBLY (for FRONT PASSENGER SIDE) - POWER DISTRIBUTION BOX ASSEMBLY)

- (a) Disconnect the K20 power distribution box assembly connector.
 (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K51,K20\)](#)

[Click Connector\(K51\)](#)

[Click Connector\(K20\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K51-5 (B) - K20-44	Always	Below 1 Ω
K51-5 (B) or K20-44 - Body ground	Always	10 k Ω or higher

OK **REPLACE MAIN BODY ECU (MULTIPLEX NETWORK BODY ECU)**

NG **REPAIR OR REPLACE HARNESS OR CONNECTOR**

5. INSPECT NO. 1 INTERIOR ILLUMINATION LIGHT ASSEMBLY (NO. 1 INSTRUMENT PANEL GARNISH SUB-ASSEMBLY)

Click here

NG ► **REPLACE NO. 1 INTERIOR ILLUMINATION LIGHT ASSEMBLY (NO. 1 INSTRUMENT PANEL GARNISH SUB-ASSEMBLY)**

OK



6.	CHECK HARNESS AND CONNECTOR (NO. 1 INTERIOR ILLUMINATION LIGHT ASSEMBLY - MAIN BODY ECU (MULTIPLEX NETWORK BODY ECU))
-----------	--

- (a) Disconnect the K16 main body ECU (multiplex network body ECU) connector.
 (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K16,K52\).](#)

[Click Connector\(K16\).](#)

[Click Connector\(K52\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K16-14 (LED2) - K52-1 (E)	Always	Below 1 Ω
K16-14 (LED2) or K52-1 (E) - Body ground	Always	10 k Ω or higher

NG ► **REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK



7.	CHECK HARNESS AND CONNECTOR (NO. 1 INTERIOR ILLUMINATION LIGHT ASSEMBLY - POWER DISTRIBUTION BOX ASSEMBLY)
-----------	---

- (a) Disconnect the K20 power distribution box assembly connector.
 (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K52,K20\).](#)

[Click Connector\(K52\).](#)

[Click Connector\(K20\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K52-5 (B) - K20-44	Always	Below 1 Ω
K52-5 (B) or K20-44 - Body ground	Always	10 kΩ or higher

OK ► **USE SIMULATION METHOD TO CHECK**

NG ► **REPAIR OR REPLACE HARNESS OR CONNECTOR**

8.	INSPECT NO. 2 INTERIOR ILLUMINATION LIGHT ASSEMBLY (for CENTER) (NO. 2 INSTRUMENT PANEL GARNISH SUB-ASSEMBLY)
-----------	--

Click here 

NG ► **REPLACE NO. 2 INTERIOR ILLUMINATION LIGHT ASSEMBLY (for CENTER) (NO. 2 INSTRUMENT PANEL GARNISH SUB-ASSEMBLY)**

OK



9.	CHECK HARNESS AND CONNECTOR (NO. 2 INTERIOR ILLUMINATION LIGHT ASSEMBLY (for CENTER) - MAIN BODY ECU (MULTIPLEX NETWORK BODY ECU))
-----------	---

- (a) Disconnect the K16 main body ECU (multiplex network body ECU) connector.
- (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K16,K95\)](#)

[Click Connector\(K16\)](#)

[Click Connector\(K95\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K16-14 (LED2) - K95-1 (E)	Always	Below 1 Ω
K16-14 (LED2) or K95-1 (E) - Body ground	Always	10 kΩ or higher

NG ► **REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK



10.	CHECK HARNESS AND CONNECTOR (NO. 2 INTERIOR ILLUMINATION LIGHT ASSEMBLY (for CENTER) - POWER DISTRIBUTION BOX ASSEMBLY)
------------	--

- (a) Disconnect the K20 power distribution box assembly connector.
- (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K95,K20\).](#)

[Click Connector\(K95\).](#)

[Click Connector\(K20\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K95-5 (B) - K20-44	Always	Below 1 Ω
K95-5 (B) or K20-44 - Body ground	Always	10 kΩ or higher

OK ► **USE SIMULATION METHOD TO CHECK**

NG ► **REPAIR OR REPLACE HARNESS OR CONNECTOR**

11.	CHECK HARNESS AND CONNECTOR (NO. 1 INTERIOR ILLUMINATION LIGHT ASSEMBLY - MAIN BODY ECU (MULTIPLEX NETWORK BODY ECU))
------------	--

- (a) Disconnect the K16 main body ECU (multiplex network body ECU) connector.
- (b) Disconnect the K52 No. 1 interior illumination light assembly (No. 1 instrument panel garnish sub-assembly) connector.
- (c) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K16,K52\).](#)

[Click Connector\(K16\).](#)

[Click Connector\(K52\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K16-14 (LED2) - K52-1 (E)	Always	Below 1 Ω
K16-14 (LED2) or K52-1 (E) - Body ground	Always	10 kΩ or higher

NG ► **REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK



12.	CHECK HARNESS AND CONNECTOR (NO. 1 INTERIOR ILLUMINATION LIGHT ASSEMBLY - POWER DISTRIBUTION BOX ASSEMBLY)
------------	---

- (a) Disconnect the K20 power distribution box assembly connector.
- (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K52,K20\)](#)

[Click Connector\(K52\)](#)

[Click Connector\(K20\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K52-5 (B) - K20-44	Always	Below 1 Ω
K52-5 (B) or K20-44 - Body ground	Always	10 kΩ or higher

OK **REPLACE MAIN BODY ECU (MULTIPLEX NETWORK BODY ECU)**

NG **REPAIR OR REPLACE HARNESS OR CONNECTOR**

13.	CHECK HARNESS AND CONNECTOR (POWER DISTRIBUTION BOX ASSEMBLY - POWER SOURCE)
------------	---

- (a) Disconnect the A15 power distribution box assembly connectors.
- (b) Measure the voltage according to the value(s) in the table below.

Standard Voltage:



[Click Location & Routing\(A15\)](#)

[Click Connector\(A15\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
A15-1 - Body ground	Ignition switch off	11 to 14 V

NG **REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK

**14. INSPECT POWER DISTRIBUTION BOX ASSEMBLY**

- (a) Disconnect the K20 power distribution box assembly connectors.
- (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(A15,K20\).](#)

[Click Connector\(A15\).](#)

[Click Connector\(K20\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
A15-1 - K20-44	Always	Below 1 Ω

NG **REPLACE POWER DISTRIBUTION BOX ASSEMBLY**

OK

**15. CHECK HARNESS AND CONNECTOR (MAIN BODY ECU (MULTIPLEX NETWORK BODY ECU) - ILLUMINATION LIGHTS)**

- (a) Disconnect the K16 main body ECU (multiplex network body ECU) connector.
- (b) Disconnect the K51 No. 2 interior illumination light assembly (for front passenger side) (No. 2 instrument panel garnish sub-assembly) connector.
- (c) Disconnect the K52 No. 1 interior illumination light assembly (No. 1 instrument panel garnish sub-assembly) connector.
- (d) Disconnect the K95 No. 2 interior illumination light assembly (for center) (No. 2 instrument panel garnish sub-assembly) connector.
- (e) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K16,K51,K52,K95\).](#)

[Click Connector\(K16\).](#)

[Click Connector\(K51\).](#)

[Click Connector\(K52\)](#)

[Click Connector\(K95\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K16-10 (LED1) - K51-1 (E)	Always	Below 1 Ω
K16-14 (LED2) - K52-1 (E)	Always	Below 1 Ω
K16-14 (LED2) - K95-1 (E)	Always	Below 1 Ω
K16-10 (LED1) or K51-1 (E) - Body ground	Always	10 k Ω or higher
K16-14 (LED2) or K52-1 (E) - Body ground	Always	10 k Ω or higher
K16-14 (LED2) or K95-1 (E) - Body ground	Always	10 k Ω or higher

NG  **REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK



16.	CHECK HARNESS AND CONNECTOR (ILLUMINATION LIGHTS - POWER DISTRIBUTION BOX ASSEMBLY)
------------	--

(a) Disconnect the K20 power distribution box assembly connector.

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K51,K20,K52,K95\)](#)

[Click Connector\(K51\)](#)

[Click Connector\(K20\)](#)

[Click Connector\(K52\)](#)

[Click Connector\(K95\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K51-5 (B) - K20-44	Always	Below 1 Ω
K52-5 (B) - K20-44	Always	Below 1 Ω
K95-5 (B) - K20-44	Always	Below 1 Ω
K51-5 (B) or K20-44 - Body ground	Always	10 k Ω or higher
K52-5 (B) or K20-44 - Body ground	Always	10 k Ω or higher
K95-5 (B) or K20-44 - Body ground	Always	10 k Ω or higher

OK  **REPLACE MAIN BODY ECU (MULTIPLEX NETWORK BODY ECU)** 

NG ▶ REPAIR OR REPLACE HARNESS OR CONNECTOR

