

Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM10000002BM37
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [12/2022 -]
Title: LIGHTING (INT): LIGHTING SYSTEM: Illumination Notification does not Operate; 2023 - 2024 MY Prius Prius Prime [12/2022 -]		


Illumination Notification does not Operate

DESCRIPTION

The following lights flash as an illumination notification:

- No. 1 Interior Illumination Light Assembly (No. 1 Instrument Panel Garnish Sub-assembly)
- No. 2 Interior Illumination Light Assembly (for Front Passenger Side) (No. 2 Instrument Panel Garnish Sub-assembly)
- No. 2 Interior Illumination Light Assembly (for Center) (No. 2 Instrument Panel Garnish Sub-assembly)

WIRING DIAGRAM



CAUTION / NOTICE / HINT

NOTICE:

- Inspect the fuses for circuits related to this system before performing the following procedure.
- Before replacing the main body ECU (multiplex network body ECU), refer to Registration.

[Click here](#) INFO

- By performing customization using the GTS, check that "Illumination Notification" is "ON".

[Click here](#) INFO

- Using meter / gauge system customization, check that "PDA" is "ON".

[Click here](#) INFO

PROCEDURE

1. CHECK FOR DTCs (HEALTH CHECK)

(a) Using the GTS, perform a health check.

OK:

DTCs are not output by any system other than the front camera system (Front Recognition Camera).

RESULT	PROCEED TO
DTC is not output	A
DTC is output	B

B ▶ **GO TO FRONT CAMERA SYSTEM** INFO

A
▼

2. PERFORM ACTIVE TEST USING GTS

(a) Perform the Active Test according to the display on the GTS.

Body Electrical > Main Body > Active Test

TESTER DISPLAY	MEASUREMENT ITEM	CONTROL RANGE	DIAGNOSTIC NOTE
Extended Illumination 1	Turns on the following lights: <ul style="list-style-type: none"> • No. 2 Interior Illumination Light Assembly (for Front Passenger Side) (No. 2 Instrument Panel Garnish Sub-assembly) 	OFF or ON	Perform the Active Test with the vehicle stopped and ignition switch ON.
Extended Illumination 2	Turns on the following lights: <ul style="list-style-type: none"> • No. 1 Interior Illumination Light Assembly (No. 1 Instrument Panel Garnish Sub-assembly) 	OFF or ON	Perform the Active Test with the vehicle stopped and ignition switch ON.

TESTER DISPLAY	MEASUREMENT ITEM	CONTROL RANGE	DIAGNOSTIC NOTE
	<ul style="list-style-type: none"> No. 2 Interior Illumination Light Assembly (for Center) (No. 2 Instrument Panel Garnish Sub-assembly) 		

Body Electrical > Main Body > Active Test

TESTER DISPLAY
Extended Illumination 1

Body Electrical > Main Body > Active Test

TESTER DISPLAY
Extended Illumination 2

RESULT	PROCEED TO
OK	A
NG (No. 2 interior illumination light assembly (for front passenger side) (No. 2 instrument panel garnish sub-assembly) does not come on)	B
NG (No. 1 interior illumination light assembly (No. 1 instrument panel garnish sub-assembly) does not come on)	C
NG (No. 2 interior illumination light assembly (for center) (No. 2 instrument panel garnish sub-assembly) does not come on)	D
NG (No. 1 interior illumination light assembly (No. 1 instrument panel garnish sub-assembly) and No. 2 interior illumination light assembly (for center) (No. 2 instrument panel garnish sub-assembly) do not come on)	E
NG (All lights do not come on)	F

A ► USE SIMULATION METHOD TO CHECK**C ► GO TO STEP 6****D ► GO TO STEP 9****E ► GO TO STEP 12****F ► GO TO STEP 14**

B**3.****INSPECT NO. 2 INTERIOR ILLUMINATION LIGHT ASSEMBLY (for FRONT PASSENGER SIDE) (NO. 2 INSTRUMENT PANEL GARNISH SUB-ASSEMBLY)**Click here **NG**  **REPLACE NO. 2 INTERIOR ILLUMINATION LIGHT ASSEMBLY (for FRONT PASSENGER SIDE) (NO. 2 INSTRUMENT PANEL GARNISH SUB-ASSEMBLY)****OK****4.****CHECK HARNESS AND CONNECTOR (NO. 2 INTERIOR ILLUMINATION LIGHT ASSEMBLY (for FRONT PASSENGER SIDE) - MAIN BODY ECU (MULTIPLEX NETWORK BODY ECU))**

- (a) Disconnect the K16 main body ECU (multiplex network body ECU) connector.
- (b) Disconnect the K51 No. 2 interior illumination light assembly (for front passenger side) (No. 2 instrument panel garnish sub-assembly) connector.
- (c) Measure the resistance according to the value(s) in the table below.

Standard Resistance:

[Click Location & Routing\(K16,K51\)](#)[Click Connector\(K16\)](#)[Click Connector\(K51\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K16-10 (LED1) - K51-1 (E)	Always	Below 1 Ω
K16-10 (LED1) or K51-1 (E) - Body ground	Always	10 k Ω or higher

NG  **REPAIR OR REPLACE HARNESS OR CONNECTOR****OK**

5. CHECK HARNESS AND CONNECTOR (NO. 2 INTERIOR ILLUMINATION LIGHT ASSEMBLY (for FRONT PASSENGER SIDE) - POWER DISTRIBUTION BOX ASSEMBLY)

- (a) Disconnect the K20 power distribution box assembly connector.
 (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K51,K20\).](#)

[Click Connector\(K51\).](#)

[Click Connector\(K20\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K51-5 (B) - K20-44	Always	Below 1 Ω
K51-5 (B) or K20-44 - Body ground	Always	10 kΩ or higher

OK ► REPLACE MAIN BODY ECU (MULTIPLEX NETWORK BODY ECU) [INFO](#)

NG ► REPAIR OR REPLACE HARNESS OR CONNECTOR

6. INSPECT NO. 1 INTERIOR ILLUMINATION LIGHT ASSEMBLY (NO. 1 INSTRUMENT PANEL GARNISH SUB-ASSEMBLY)

Click here [INFO](#)

NG ► REPLACE NO. 1 INTERIOR ILLUMINATION LIGHT ASSEMBLY (NO. 1 INSTRUMENT PANEL GARNISH SUB-ASSEMBLY)

OK



7. CHECK HARNESS AND CONNECTOR (NO. 1 INTERIOR ILLUMINATION LIGHT ASSEMBLY - MAIN BODY ECU (MULTIPLEX NETWORK BODY ECU))

- (a) Disconnect the K16 main body ECU (multiplex network body ECU) connector.
 (b) Disconnect the K52 No. 1 interior illumination light assembly (No. 1 instrument panel garnish sub-assembly) connector.
 (c) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K16,K52\).](#)

[Click Connector\(K16\).](#)

[Click Connector\(K52\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K16-14 (LED2) - K52-1 (E)	Always	Below 1 Ω
K16-14 (LED2) or K52-1 (E) - Body ground	Always	10 k Ω or higher

NG ► REPAIR OR REPLACE HARNESS OR CONNECTOR

OK



8.	CHECK HARNESS AND CONNECTOR (NO. 1 INTERIOR ILLUMINATION LIGHT ASSEMBLY - POWER DISTRIBUTION BOX ASSEMBLY)
-----------	---

(a) Disconnect the K20 power distribution box assembly connector.

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K52,K20\).](#)

[Click Connector\(K52\).](#)

[Click Connector\(K20\).](#)


TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K52-5 (B) - K20-44	Always	Below 1 Ω
K52-5 (B) or K20-44 - Body ground	Always	10 k Ω or higher

OK ► USE SIMULATION METHOD TO CHECK

NG ► REPAIR OR REPLACE HARNESS OR CONNECTOR

9.	INSPECT NO. 2 INTERIOR ILLUMINATION LIGHT ASSEMBLY (for CENTER) (NO. 2 INSTRUMENT PANEL GARNISH SUB-ASSEMBLY)
-----------	--

Click here [INFO](#)

NG  **REPLACE NO. 2 INTERIOR ILLUMINATION LIGHT ASSEMBLY (for CENTER) (NO. 2 INSTRUMENT PANEL GARNISH SUB-ASSEMBLY)**

OK



10.	CHECK HARNESS AND CONNECTOR (NO. 2 INTERIOR ILLUMINATION LIGHT ASSEMBLY (for CENTER) - MAIN BODY ECU (MULTIPLEX NETWORK BODY ECU))
------------	---

- (a) Disconnect the K16 main body ECU (multiplex network body ECU) connector.
- (b) Disconnect the K95 No. 2 interior illumination light assembly (for center) (No. 2 instrument panel garnish sub-assembly) connector.
- (c) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K16,K95\).](#)

[Click Connector\(K16\).](#)

[Click Connector\(K95\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K16-14 (LED2) - K95-1 (E)	Always	Below 1 Ω
K16-14 (LED2) or K95-1 (E) - Body ground	Always	10 k Ω or higher

NG  **REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK



11.	CHECK HARNESS AND CONNECTOR (NO. 2 INTERIOR ILLUMINATION LIGHT ASSEMBLY (for CENTER) - POWER DISTRIBUTION BOX ASSEMBLY)
------------	--

- (a) Disconnect the K20 power distribution box assembly connector.
- (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K95,K20\).](#)

[Click Connector\(K95\)](#)

[Click Connector\(K20\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K95-5 (B) - K20-44	Always	Below 1 Ω
K95-5 (B) or K20-44 - Body ground	Always	10 k Ω or higher

OK  **USE SIMULATION METHOD TO CHECK**

NG  **REPAIR OR REPLACE HARNESS OR CONNECTOR**

12.

CHECK HARNESS AND CONNECTOR (NO. 1 INTERIOR ILLUMINATION LIGHT ASSEMBLY - MAIN BODY ECU (MULTIPLEX NETWORK BODY ECU))

- (a) Disconnect the K16 main body ECU (multiplex network body ECU) connector.
- (b) Disconnect the K52 No. 1 interior illumination light assembly (No. 1 instrument panel garnish sub-assembly) connector.
- (c) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K16,K52\)](#)

[Click Connector\(K16\)](#)

[Click Connector\(K52\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K16-14 (LED2) - K52-1 (E)	Always	Below 1 Ω
K16-14 (LED2) or K52-1 (E) - Body ground	Always	10 k Ω or higher

NG  **REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK



13.

CHECK HARNESS AND CONNECTOR (NO. 1 INTERIOR ILLUMINATION LIGHT ASSEMBLY - POWER DISTRIBUTION BOX ASSEMBLY)

- (a) Disconnect the K20 power distribution box assembly connector.
- (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K52,K20\).](#)

[Click Connector\(K52\).](#)

[Click Connector\(K20\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K52-5 (B) - K20-44	Always	Below 1 Ω
K52-5 (B) or K20-44 - Body ground	Always	10 k Ω or higher

OK **REPLACE MAIN BODY ECU (MULTIPLEX NETWORK BODY ECU)**

NG **REPAIR OR REPLACE HARNESS OR CONNECTOR**

14.	CHECK HARNESS AND CONNECTOR (POWER DISTRIBUTION BOX ASSEMBLY - POWER SOURCE)
------------	---

(a) Disconnect the A15 power distribution box assembly connectors.

(b) Measure the voltage according to the value(s) in the table below.

Standard Voltage:



[Click Location & Routing\(A15\).](#)

[Click Connector\(A15\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
A15-1 - Body ground	Ignition switch off	11 to 14 V

NG **REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK



15.	INSPECT POWER DISTRIBUTION BOX ASSEMBLY
------------	--

(a) Disconnect the K20 power distribution box assembly connectors.

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(A15,K20\).](#)

[Click Connector\(A15\).](#)

[Click Connector\(K20\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
A15-1 - K20-44	Always	Below 1 Ω

NG **REPLACE POWER DISTRIBUTION BOX ASSEMBLY**

OK



16.	CHECK HARNESS AND CONNECTOR (MAIN BODY ECU (MULTIPLEX NETWORK BODY ECU) - ILLUMINATION LIGHTS)
------------	---

- (a) Disconnect the K16 main body ECU (multiplex network body ECU) connector.
- (b) Disconnect the K51 No. 2 interior illumination light assembly (for front passenger side) (No. 2 instrument panel garnish sub-assembly) connector.
- (c) Disconnect the K52 No. 1 interior illumination light assembly (No. 1 instrument panel garnish sub-assembly) connector.
- (d) Disconnect the K95 No. 2 interior illumination light assembly (for center) (No. 2 instrument panel garnish sub-assembly) connector.
- (e) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K16,K51,K52,K95\).](#)

[Click Connector\(K16\).](#)

[Click Connector\(K51\).](#)

[Click Connector\(K52\).](#)

[Click Connector\(K95\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K16-10 (LED1) - K51-1 (E)	Always	Below 1 Ω
K16-14 (LED2) - K52-1 (E)	Always	Below 1 Ω
K16-14 (LED2) - K95-1 (E)	Always	Below 1 Ω
K16-10 (LED1) or K51-1 (E) - Body ground	Always	10 k Ω or higher
K16-14 (LED2) or K52-1 (E) - Body ground	Always	10 k Ω or higher

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K16-14 (LED2) or K95-1 (E) - Body ground	Always	10 k Ω or higher

NG  **REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK



17.	CHECK HARNESS AND CONNECTOR (ILLUMINATION LIGHTS - POWER DISTRIBUTION BOX ASSEMBLY)
------------	--

- (a) Disconnect the K20 power distribution box assembly connector.
 (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K51,K20,K52,K95\)](#)

[Click Connector\(K51\)](#)

[Click Connector\(K20\)](#)

[Click Connector\(K52\)](#)

[Click Connector\(K95\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K51-5 (B) - K20-44	Always	Below 1 Ω
K52-5 (B) - K20-44	Always	Below 1 Ω
K95-5 (B) - K20-44	Always	Below 1 Ω
K51-5 (B) or K20-44 - Body ground	Always	10 k Ω or higher
K52-5 (B) or K20-44 - Body ground	Always	10 k Ω or higher
K95-5 (B) or K20-44 - Body ground	Always	10 k Ω or higher

OK  **REPLACE MAIN BODY ECU (MULTIPLEX NETWORK BODY ECU)** 

NG  **REPAIR OR REPLACE HARNESS OR CONNECTOR**

