


| | | |
|---|---------------------------|--------------------------------------|
| Last Modified: 12-04-2024 | 6.11:8.1.0 | Doc ID: RM1000000029INB |
| Model Year Start: 2023 | Model: Prius Prime | Prod Date Range: [12/2022 -] |
| Title: LIGHTING (INT): LIGHTING SYSTEM: Rear Door Courtesy Switch Circuit; 2023 - 2024 MY Prius Prius Prime [12/2022 -] | | |

Rear Door Courtesy Switch Circuit

DESCRIPTION

The main body ECU (multiplex network body ECU) detects the condition of the rear door courtesy light switch assembly.

WIRING DIAGRAM



CAUTION / NOTICE / HINT

NOTICE:

Before replacing the main body ECU (multiplex network body ECU), refer to Registration.

Click here [INFO](#)

PROCEDURE

| | |
|-----------|-----------------------------|
| 1. | READ VALUE USING GTS |
|-----------|-----------------------------|

(a) Read the Data List according to the display on the GTS.

Body Electrical > Main Body > Data List

| TESTER DISPLAY | MEASUREMENT ITEM | RANGE | NORMAL CONDITION | DIAGNOSTIC NOTE |
|--------------------------------|--|---------------|---|-----------------|
| RR Door Courtesy Switch Status | Rear door courtesy light switch assembly (for RH) signal | Close or Open | Close: Rear door RH closed Open: Rear door RH open | - |
| RL Door Courtesy Switch Status | Rear door courtesy light switch assembly (for LH) signal | Close or Open | Close: Rear door LH closed Open: Rear door LH open | - |

Body Electrical > Main Body > Data List

| |
|--------------------------------|
| TESTER DISPLAY |
| RR Door Courtesy Switch Status |
| RL Door Courtesy Switch Status |

OK:
Normal conditions listed above are displayed.

| RESULT | PROCEED TO |
|---|------------|
| OK | A |
| NG ("RL Door Courtesy Switch Status" is not normal) | B |
| NG ("RR Door Courtesy Switch Status" is not normal) | C |

A ▶ **PROCEED TO NEXT SUSPECTED AREA SHOWN IN PROBLEM SYMPTOMS TABLE** [INFO](#)

C ▶ **GO TO STEP 5**

B
▼

| | |
|-----------|--|
| 2. | INSPECT REAR DOOR LOCK WITH MOTOR ASSEMBLY LH |
|-----------|--|

Click here [INFO](#)

NG  **REPLACE REAR DOOR LOCK WITH MOTOR ASSEMBLY**
LH 

OK


3. CHECK HARNESS AND CONNECTOR (REAR DOOR LOCK WITH MOTOR ASSEMBLY LH - POWER DISTRIBUTION BOX ASSEMBLY)

- (a) Disconnect the R17 power distribution box assembly connector.
- (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



- [Click Location & Routing\(M1,R17\)](#)
- [Click Connector\(M1\)](#)
- [Click Connector\(R17\)](#)

| TESTER CONNECTION | CONDITION | SPECIFIED CONDITION |
|--------------------------------------|-----------|---------------------|
| M1-10 (CTYL) - R17-28 | Always | Below 1 Ω |
| M1-10 (CTYL) or R17-28 - Body ground | Always | 10 kΩ or higher |

NG  **REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK


4. INSPECT POWER DISTRIBUTION BOX ASSEMBLY

- (a) Remove the main body ECU (multiplex network body ECU) from the power distribution box assembly.

Click here 

- (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



- [Click Location & Routing\(R17,z1\)](#)
- [Click Connector\(R17\)](#)
- [Click Connector\(z1\)](#)

| TESTER CONNECTION | CONDITION | SPECIFIED CONDITION |
|----------------------|-----------|---------------------|
| R17-28 - z1-6 (LCTY) | Always | Below 1 Ω |

OK ▶ REPLACE MAIN BODY ECU (MULTIPLEX NETWORK BODY ECU) [INFO](#)

NG ▶ REPLACE POWER DISTRIBUTION BOX ASSEMBLY [INFO](#)

5. INSPECT REAR DOOR LOCK WITH MOTOR ASSEMBLY RH

Click here [INFO](#)

NG ▶ REPLACE REAR DOOR LOCK WITH MOTOR ASSEMBLY RH [INFO](#)

OK
▼

6. CHECK HARNESS AND CONNECTOR (REAR DOOR LOCK WITH MOTOR ASSEMBLY RH - POWER DISTRIBUTION BOX ASSEMBLY)

- (a) Disconnect the R17 power distribution box assembly connector.
 - (b) Measure the resistance according to the value(s) in the table below.
- Standard Resistance:



- [Click Location & Routing\(L1,R17\).](#)
- [Click Connector\(L1\)](#)
- [Click Connector\(R17\)](#)

| TESTER CONNECTION | CONDITION | SPECIFIED CONDITION |
|------------------------------------|-----------|---------------------|
| L1-5 (CTYR) - R17-1 | Always | Below 1 Ω |
| L1-5 (CTYR) or R17-1 - Body ground | Always | 10 kΩ or higher |

NG ▶ REPAIR OR REPLACE HARNESS OR CONNECTOR

OK
▼

7. INSPECT POWER DISTRIBUTION BOX ASSEMBLY

(a) Remove the main body ECU (multiplex network body ECU) from the power distribution box assembly.

Click here [INFO](#)

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(R17,z1\).](#)

[Click Connector\(R17\).](#)

[Click Connector\(z1\).](#)

| TESTER CONNECTION | CONDITION | SPECIFIED CONDITION |
|---------------------|-----------|---------------------|
| R17-1 - z1-1 (RCTY) | Always | Below 1 Ω |

OK ▶ REPLACE MAIN BODY ECU (MULTIPLEX NETWORK BODY ECU) [INFO](#)

NG ▶ REPLACE POWER DISTRIBUTION BOX ASSEMBLY [INFO](#)

