


Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM100000029H11
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [12/2022 -]
Title: METER / GAUGE / DISPLAY: METER / GAUGE SYSTEM: Steering Pad Switch Circuit; 2023 - 2024 MY Prius Prius Prime [12/2022 -]		

[Steering Pad Switch Circuit](#)

DESCRIPTION

The combination meter assembly and steering pad switch assembly are connected via direct line. The multi-information display in the combination meter assembly is operated using the switches of the steering pad switch assembly.

WIRING DIAGRAM



CAUTION / NOTICE / HINT

NOTICE:

- When replacing the combination meter assembly, always replace it with a new one. If a combination meter assembly which was installed to another vehicle is used, the information stored in it will not match the information from the vehicle and a DTC may be stored.
- When replacing the combination meter assembly, update the ECU security key.

Click here [INFO](#)

PROCEDURE

1.	PERFORM ACTIVE TEST USING GTS
-----------	--------------------------------------

(a) Perform the Active Test according to the display on the GTS.


Body Electrical > Combination Meter > Active Test

TESTER DISPLAY	MEASUREMENT ITEM	CONTROL RANGE	DIAGNOSTIC NOTE
Multi Switch (Up)	Performs the same operation as pressing the up switch on steering pad switch	OFF or ON	-
Multi Switch (Down)	Performs the same operation as pressing the down switch on steering pad switch	OFF or ON	-
Multi Switch (Left)	Performs the same operation as pressing the left switch on steering pad switch	OFF or ON	-
Multi Switch (Right)	Performs the same operation as pressing the right switch on steering pad switch	OFF or ON	-
Multi Switch (Enter)	Performs the same operation as pressing the OK switch on steering pad switch	OFF or ON	-
Multi Switch (Back)	Performs the same operation as pressing the back switch on steering pad switch	OFF or ON	-


Body Electrical > Combination Meter > Active Test

TESTER DISPLAY
Multi Switch (Up)


Body Electrical > Combination Meter > Active Test




Body Electrical > Combination Meter > Active Test




Body Electrical > Combination Meter > Active Test



Body Electrical > Combination Meter > Active Test



Body Electrical > Combination Meter > Active Test



RESULT	PROCEED TO
Active Test can be performed correctly	A
Active Test cannot be performed correctly	B

B ▶ REPLACE COMBINATION METER ASSEMBLY

A ▼

2.	READ VALUE USING GTS
-----------	-----------------------------

(a) Read the Data List according to the display on the GTS.

Body Electrical > Combination Meter > Data List

TESTER DISPLAY	MEASUREMENT ITEM	RANGE	NORMAL CONDITION	DIAGNOSTIC NOTE
Multi Switch (Up)	Up switch on steering pad switch operation	OFF or ON	OFF: Switch released ON: Switch pushed	-
Multi Switch (Down)	Down switch on steering pad switch operation	OFF or ON	OFF: Switch released ON: Switch pushed	-
Multi Switch (Left)	Left switch on steering pad switch operation	OFF or ON	OFF: Switch released ON: Switch pushed	-
Multi Switch (Right)	Right switch on steering pad switch operation	OFF or ON	OFF: Switch released ON: Switch pushed	-
Multi Switch (Enter)	OK switch on steering pad switch operation	OFF or ON	OFF: Switch released ON: Switch pushed	-
Multi Switch (Back)	Back switch on steering pad switch operation	OFF or ON	OFF: Switch released ON: Switch pushed	-

Body Electrical > Combination Meter > Data List

TESTER DISPLAY
Multi Switch (Up)
Multi Switch (Down)
Multi Switch (Left)
Multi Switch (Right)
Multi Switch (Enter)
Multi Switch (Back)

RESULT	PROCEED TO
The value of the Data List item is correct, and the combination meter assembly operates correctly	A
The value of the Data List item is correct, but the combination meter assembly does not operate correctly	B
The Data List item changes correctly	C

A ► **USE SIMULATION METHOD TO CHECK**

B ► **REPLACE COMBINATION METER ASSEMBLY**

C



3.	INSPECT STEERING PAD SWITCH ASSEMBLY
-----------	---

Click here [INFO](#)

NG ► **REPLACE STEERING PAD SWITCH ASSEMBLY** [INFO](#)

OK



4.	INSPECT SPIRAL CABLE SUB-ASSEMBLY
-----------	--


Click here [INFO](#)

NG ► **REPLACE SPIRAL CABLE SUB-ASSEMBLY** [INFO](#)

OK



5.	CHECK COMBINATION METER ASSEMBLY (OUTPUT VOLTAGE)
-----------	--



*a Front view of wire harness connector (to Spiral Cable Sub-assembly)

(a) Measure the voltage according to the value(s) in the table below.

Standard Voltage:



[Click Location & Routing\(K96\).](#)

[Click Connector\(K96\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K96-11 (+DP) - Body ground	Ignition switch ON	4.8 to 5.2 V
K96-10 (+DP2) - Body ground	Ignition switch ON	4.8 to 5.2 V

NG ► GO TO STEP 9

OK
▼

6.	CONFIRM MODEL
-----------	----------------------

(a) Choose the model to be inspected.

RESULT	PROCEED TO
w/ radio and display receiver assembly	A
w/o Radio and Display Receiver Assembly	B

B ► GO TO STEP 8



7. CHECK HARNESS AND CONNECTOR (RADIO AND DISPLAY RECEIVER ASSEMBLY - SPIRAL CABLE SUB-ASSEMBLY AND BODY GROUND)

- (a) Disconnect the K80 radio and display receiver assembly connector.
 (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K80,K96\)](#)

[Click Connector\(K80\)](#)

[Click Connector\(K96\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K80-20 (SWG) - K96-4 (EAU)	Always	Below 1 Ω
K80-1 (GND1) - Body ground	Always	Below 1 Ω

OK ► REPLACE RADIO AND DISPLAY RECEIVER ASSEMBLY

NG ► REPAIR OR REPLACE HARNESS OR CONNECTOR

8. CHECK HARNESS AND CONNECTOR (SPIRAL CABLE SUB-ASSEMBLY - BODY GROUND)

- (a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K96\)](#)

[Click Connector\(K96\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K96-4 (EAU) - Body ground	Always	Below 1 Ω

OK ► REPLACE COMBINATION METER ASSEMBLY

NG ► REPAIR OR REPLACE HARNESS OR CONNECTOR

9.

CHECK HARNESS AND CONNECTOR (SPIRAL CABLE SUB-ASSEMBLY - COMBINATION METER ASSEMBLY)

- (a) Disconnect the K19 combination meter assembly connector.
- (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K96,K19\).](#)

[Click Connector\(K96\).](#)

[Click Connector\(K19\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K96-11 (+DP) - K19-29 (MSM+)	Always	Below 1 Ω
K96-10 (+DP2) - K19-12 (MSTI)	Always	Below 1 Ω
K96-11 (+DP) or K19-29 (MSM+) - Body ground	Always	10 k Ω or higher
K96-10 (+DP2) or K19-12 (MSTI) - Body ground	Always	10 k Ω or higher

OK ► **REPLACE COMBINATION METER ASSEMBLY**

NG ► **REPAIR OR REPLACE HARNESS OR CONNECTOR**

