

| | | |
|---|---------------------------|--------------------------------------|
| Last Modified: 12-04-2024 | 6.11:8.1.0 | Doc ID: RM100000029C1Z |
| Model Year Start: 2023 | Model: Prius Prime | Prod Date Range: [12/2022 -] |
| Title: ADVANCED PARK: ADVANCED PARK: U117987; Lost Communication with Image Processing Module "B" (ch2); 2023 - 2024 MY Prius Prius Prime [12/2022 -] | | |

| | | |
|------------|----------------|--|
| DTC | U117987 | Lost Communication with Image Processing Module "B" (ch2) |
|------------|----------------|--|

DESCRIPTION

This DTC is output when the clearance warning ECU assembly detects lost communication with the parking assist ECU.


| DTC NO. | DETECTION ITEM | DTC DETECTION CONDITION | TROUBLE AREA | DTC OUTPUT FROM | PRIORITY |
|---------|---|---|---|-------------------|----------|
| U117987 | Lost Communication with Image Processing Module "B" (ch2) | The clearance warning ECU assembly is unable to receive communication from the parking assist ECU | <ul style="list-style-type: none"> • Harness or connector • Clearance warning ECU assembly • Parking assist ECU • Forward recognition camera • Millimeter wave radar sensor assembly | Clearance Warning | A |

| PATTERN | DTC OUTPUT PART NAME (DISPLAY ON GTS) | | | | SUSPECTED AREA (MALFUNCTION STATUS) |
|-----------|---------------------------------------|--|----------------------------|---------------------------------------|---|
| | CLEARANCE WARNING ECU ASSEMBLY | PARKING ASSIST ECU | FORWARD RECOGNITION CAMERA | MILLIMETER WAVE RADAR SENSOR ASSEMBLY | |
| | CLEARANCE WARNING | CIRCUMFERENCE MONITORING CAMERA CONTROL MODULE | FRONT RECOGNITION CAMERA | | |
| | U117987 | U11B687 | U023587 | U010487 | |
| Pattern 1 | ○ | ○ | ○ | ○ | Harness or connector (Open or short) Millimeter wave radar sensor assembly |

○: DTC is output
 -: DTC is not output

| PATTERN | DTC OUTPUT PART NAME (DISPLAY ON GTS) | | | | SUSPECTED AREA (MALFUNCTION STATUS) |
|--|--|--|----------------------------|---------------------------------------|---|
| | CLEARANCE WARNING ECU ASSEMBLY | PARKING ASSIST ECU | FORWARD RECOGNITION CAMERA | MILLIMETER WAVE RADAR SENSOR ASSEMBLY | |
| | CLEARANCE WARNING | CIRCUMFERENCE MONITORING CAMERA CONTROL MODULE | FRONT RECOGNITION CAMERA | | |
| | U117987 | U11B687 | U023587 | U010487 | |
| | | | | | (Internal malfunction) |
| | | | | | Clearance warning ECU assembly (Internal malfunction) |
| | | | | | Parking assist ECU (Internal malfunction) |
| | | | | | Forward recognition camera (Internal malfunction) |
| Pattern 2 | ○ | ○ | - | - | Harness or connector (Open or short) |
| | | | | | Parking assist ECU (Internal malfunction) |
| | | | | | Clearance warning ECU assembly (Internal malfunction) |
| Pattern 3 | ○ | - | - | - | Clearance warning ECU assembly (Internal malfunction) |
| | | | | | Parking assist ECU (Internal malfunction) |
| ○: DTC is output -: DTC is not output | | | | | |

WIRING DIAGRAM



CAUTION / NOTICE / HINT

NOTICE:

- Before measuring the resistance of the CAN bus, turn the ignition switch off and leave the vehicle for 1 minute or more without operating the key or any switches, or opening or closing the doors. After that, disconnect the cable from the negative (-) auxiliary battery terminal and leave the vehicle for 1 minute or more before measuring the resistance.
- After the ignition switch is turned off, there may be a waiting time before disconnecting the negative (-) auxiliary battery terminal.

[Click here](#) INFO

- When disconnecting and reconnecting the auxiliary battery

HINT:

When disconnecting and reconnecting the auxiliary battery, there is an automatic learning function that completes learning when the respective system is used.

[Click here](#) INFO

HINT:

- Operating the ignition switch, any other switches or a door triggers related ECU and sensor communication on the CAN. This communication will cause the resistance value to change.
- Even after DTCs are cleared, if a DTC is stored again after driving the vehicle for a while, the malfunction may be occurring due to vibration of the vehicle. In such a case, wiggling the ECUs or wire harness while performing the inspection below may help determine the cause of the malfunction.

PROCEDURE

| | |
|-----------|-----------------------|
| 1. | CHECK FOR DTCs |
|-----------|-----------------------|

(a) Read each DTC and check the diagnosis pattern using the table below.

- Chassis > Circumference Monitoring Camera Control Module > Trouble Codes**
- Body Electrical > Clearance Warning > Trouble Codes**
- Chassis > Front Recognition Camera > Trouble Codes**
- Body Electrical > Front Radar Sensor > Trouble Codes**

| PATTERN | DTC OUTPUT PART NAME (DISPLAY ON GTS) | | | |
|-----------|--|--|--------------------------|--------------------|
| | CLEARANCE WARNING | CIRCUMFERENCE MONITORING CAMERA CONTROL MODULE | FRONT RECOGNITION CAMERA | FRONT RADAR SENSOR |
| Pattern 1 | U117987 | U11B687 | U023587 | U010487 |
| Pattern 2 | U117987 | U11B687 | - | - |
| Pattern 3 | U117987 | - | - | - |

| RESULT | PROCEED TO |
|-----------|------------|
| Pattern 1 | A |
| Pattern 2 | B |
| Pattern 3 | C |

A **GO TO FRONT CAMERA SYSTEM** INFO

C **GO TO STEP 4**

B

| | |
|-----------|---|
| 2. | CHECK CAN BUS MAIN WIRE (CLEARANCE WARNING ECU ASSEMBLY) |
|-----------|---|

Pre-procedure1

- (a) Disconnect the cable from the negative (-) auxiliary battery terminal.
- (b) Disconnect the R36 clearance warning ECU connector.

Procedure1

(c) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(R36\).](#)

[Click Connector\(R36\).](#)

| TESTER CONNECTION | CONDITION | SPECIFIED CONDITION | RESULT |
|-------------------------------|---|---------------------|----------|
| R36-35 (CAPH) - R36-36 (CAPL) | Cable disconnected from negative (-) auxiliary battery terminal | 54 to 69 Ω | Ω |

Post-procedure1

(d) None

OK **REPLACE CLEARANCE WARNING ECU ASSEMBLY**

NG



| | |
|-----------|---|
| 3. | CHECK CAN BUS MAIN WIRE (PARKING ASSIST ECU) |
|-----------|---|

Pre-procedure1

(a) Reconnect the R36 clearance warning ECU connector.

(b) Disconnect the R34 parking assist ECU connector.

Procedure1

(c) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(R34\).](#)

[Click Connector\(R34\).](#)

| TESTER CONNECTION | CONDITION | SPECIFIED CONDITION | RESULT |
|-----------------------------|---|---------------------|----------|
| R34-8 (CAPH) - R34-9 (CAPL) | Cable disconnected from negative (-) auxiliary battery terminal | 54 to 69 Ω | Ω |

Post-procedure1

(d) None

OK ▶ REPLACE PARKING ASSIST ECU

NG ▶ REPAIR OR REPLACE CAN MAIN WIRE OR CONNECTOR

4. CHECK PARKING ASSIST ECU

Pre-procedure1

- (a) Disconnect the U10 forward recognition camera connector.
- (b) Disconnect the A21 millimeter wave radar sensor assembly connector.
- (c) Disconnect the R36 Clearance warning ECU assembly connector.

Procedure1

- (d) Using an oscilloscope, check the waveform.

OK:



[Click Location & Routing\(R36\)](#)

[Click Connector\(R36\)](#)

| TESTER CONNECTION | CONDITION | TOOL SETTING | SPECIFIED CONDITION |
|-------------------------------|--------------------|----------------------|---------------------|
| R36-35 (CAPH) - R36-36 (CAPL) | Ignition switch ON | 1V/DIV., 100µs./DIV. | Pulse generation |

Post-procedure1

- (e) None

OK ▶ REPLACE CLEARANCE WARNING ECU ASSEMBLY

NG ▶ REPLACE PARKING ASSIST ECU

