

<b>Last Modified:</b> 12-04-2024	6.11:8.1.0	<b>Doc ID:</b> RM10000002BLUL
<b>Model Year Start:</b> 2023	<b>Model:</b> Prius Prime	<b>Prod Date Range:</b> [03/2023 - ]
<b>Title:</b> M20A-FXS (ENGINE CONTROL): SFI SYSTEM: P010064; Mass or Volume Air Flow Sensor "A" Signal Plausibility Failure; 2023 - 2024 MY Prius Prius Prime [03/2023 - ]		

<b>DTC</b>	<b>P010064</b>	<b>Mass or Volume Air Flow Sensor "A" Signal Plausibility Failure</b>
------------	----------------	-----------------------------------------------------------------------

## DESCRIPTION

Refer to DTC P010012.

Click here [INFO](#)

DTC NO.	DETECTION ITEM	DTC DETECTION CONDITION	TROUBLE AREA	MIL	DTC OUTPUT FROM	PRIORITY	NOTE
P010064	Mass or Volume Air Flow Sensor "A" Signal Plausibility Failure	All of the following conditions are met (2 trip detection logic). <ol style="list-style-type: none"> <li>The engine is running.</li> <li>The engine coolant temperature is 70°C (158°F) or higher.</li> <li>The throttle position sensor voltage is 0.2 V or higher, and less than 2 V.</li> <li>Average engine load value ratio is less than 0.85, or higher than 1.15 (varies with estimated engine load). Average engine load value ratio = Average engine load based on mass air flow meter sub-assembly output / Average engine load estimated from driving conditions</li> </ol>	<ul style="list-style-type: none"> <li>Mass air flow meter sub-assembly</li> <li>Intake system</li> <li>PCV hose connections</li> <li>EGR valve assembly</li> </ul>	Comes on	Engine	B	SAE Code: P0101

DTC NO.	DETECTION ITEM	DTC DETECTION CONDITION	TROUBLE AREA	MIL	DTC OUTPUT FROM	PRIORITY	NOTE
		5. Average air fuel ratio is less than -16%, or higher than 18%.					

## MONITOR DESCRIPTION

The mass air flow meter sub-assembly is a sensor that measures the amount of air flowing through the throttle valve. The ECM uses this information to determine fuel injection timing and to provide an appropriate air fuel ratio. Inside the mass air flow meter sub-assembly, there is a heated platinum wire which is exposed to the flow of intake air. By applying a specific electrical current to the wire, the ECM heats it to a specific temperature. The flow of incoming air cools both the wire and an internal thermistor, affecting their resistance. To maintain a constant current value, the ECM varies the voltage applied to the mass air flow meter sub-assembly. The voltage level is proportional to the airflow through the sensor, and the ECM uses it to calculate the intake air volume.

The ECM monitors the average engine load value ratio to check the mass air flow meter sub-assembly for malfunctions. The average engine load value ratio is obtained by comparing the average engine load calculated from the mass air flow meter sub-assembly output to the average engine load estimated from the driving conditions, such as the engine speed and the throttle opening angle. If the average engine load value ratio is below the threshold value, the ECM determines that the intake air volume is low, and if the average engine load value ratio is above the threshold value, the ECM determines that the intake air volume is high. If either of these conditions is detected in 2 consecutive driving cycles, the ECM illuminates the MIL and stores this DTC.

## MONITOR STRATEGY

Related DTCs	P0101: Mass air flow meter rationality
Required Sensors/Components (Main)	Mass air flow meter sub-assembly
Required Sensors/Components (Related)	Crankshaft position sensor Camshaft position sensor Engine coolant temperature sensor Throttle position sensor
Frequency of Operation	Continuous
Duration	10 times
MIL Operation	2 driving cycles
Sequence of Operation	None

## TYPICAL ENABLING CONDITIONS

All of the following conditions are met	-
Throttle position voltage	0.2 V or higher, and less than 2 V
Time after engine start	5 seconds or more
Auxiliary battery voltage	10.5 V or higher
Engine coolant temperature	70°C (158°F) or higher

Estimated load	30% or higher, and less than 70%
Mass air flow meter circuit fail (P0102, P0103)	Not detected
Intake air temperature sensor circuit fail (P0112, P0113)	Not detected
Engine coolant temperature sensor circuit fail (P0117, P0118)	Not detected
Crankshaft position sensor circuit fail (P0335, P0337, P0338)	Not detected
Throttle position sensor circuit fail (P0121, P0122, P0123, P0222, P0223, P2135)	Not detected
Canister pressure sensor circuit fail (P0452, P0453)	Not detected
Leak detection pump fail (P2401, P2402)	Not detected
Evap system vent valve fail (P2421, P2422)	Not detected

## **TYPICAL MALFUNCTION THRESHOLDS**

Both of the following conditions are met	-
Average engine load value ratio	Less than 0.85, or higher than 1.15 (varies with estimated engine load)
Average air fuel ratio	Less than -16%, or higher than 18%

## **CONFIRMATION DRIVING PATTERN**


### **HINT:**

- After repair has been completed, clear the DTC and then check that the vehicle has returned to normal by performing the following All Readiness check procedure.

[Click here](#) **INFO**

- When clearing the permanent DTCs, refer to the "CLEAR PERMANENT DTC" procedure.

[Click here](#) **INFO**



1. Clear the DTCs (even if no DTCs are stored, perform the clear DTC procedure).
2. Turn the ignition switch off and wait for at least 30 seconds.
3. Put the engine in Inspection Mode (Maintenance Mode).

Click here [INFO](#)

4. Start the engine and warm it up until the engine coolant temperature is 70°C (158°F) or higher [A].
5. Press the EV/HV mode selection switch to select HV mode. (for PHEV Model)
6. With the engine running, drive the vehicle at approximately 80 km/h (50 mph) to 112 km/h (70 mph) for 5 minutes or more [B].

**CAUTION:**

When performing the confirmation driving pattern, obey all speed limits and traffic laws.

**HINT:**

- Drive while keeping the engine load as stable as possible.
- If the engine stops, further depress the accelerator pedal to restart the engine.

7. Enter the following menus: Powertrain / Engine / Trouble Codes [C].
8. Read the pending DTCs.

**HINT:**

- If a pending DTC is output, the system is malfunctioning.
- If a pending DTC is not output, perform the following procedure.

9. Enter the following menus: Powertrain / Engine / Utility / All Readiness.
10. Input the DTC: P010064.
11. Check the DTC judgment result.

**HINT:**

- If the judgment result is NORMAL, the system is normal.
- If the judgment result is ABNORMAL, the system is malfunctioning.
- If the judgment result is INCOMPLETE, perform steps [B] through [C] again.
- [A] to [C]: Normal judgment procedure.

The normal judgment procedure is used to complete DTC judgment and also used when clearing permanent DTCs.

- When clearing the permanent DTCs, do not disconnect the cable from the auxiliary battery terminal or attempt to clear the DTCs during this procedure, as doing so will clear the universal trip and normal judgment histories.

## WIRING DIAGRAM

Refer to DTC P010012.

Click here [INFO](#)

## CAUTION / NOTICE / HINT

### NOTICE:

- Vehicle Control History may be stored in the hybrid vehicle control ECU if the engine is malfunctioning. Certain vehicle condition information is recorded when Vehicle Control History is stored. Reading the vehicle conditions recorded in both the Freeze Frame Data and Vehicle Control History can be useful for troubleshooting.

for HEV Model: Click here [INFO](#)

for PHEV Model: Click here [INFO](#)

(Select Powertrain in Health Check and then check the time stamp data.)

- If any "Engine Malfunction" Vehicle Control History item has been stored in the hybrid vehicle control ECU, make sure to clear it. However, as all Vehicle Control History items are cleared simultaneously, if any Vehicle Control History items other than "Engine Malfunction" are stored, make sure to perform any troubleshooting for them before clearing Vehicle Control History.

for HEV Model: Click here [INFO](#)

for PHEV Model: Click here [INFO](#)

## PROCEDURE

<b>1.</b>	<b>CHECK ANY OTHER DTCs OUTPUT (IN ADDITION TO DTC P010064)</b>
-----------	-----------------------------------------------------------------

(a) Read the DTCs.

**Powertrain > Engine > Trouble Codes**

RESULT	PROCEED TO
P010064 and other DTCs are output	A
P010064 is output	B

### HINT:

If any DTCs other than P010064 are output, troubleshoot those DTCs first.

**A**  **GO TO DTC CHART**

**B**  


**2. CHECK INTAKE SYSTEM**

(a) Check the intake system for vacuum leaks.

Click here [INFO](#)

OK:

No leaks from intake system.


**HINT:**

Perform "Inspection After Repair" after repairing or replacing the intake system.

Click here [INFO](#)

**NG**  **REPAIR OR REPLACE INTAKE SYSTEM**

**OK**

**3. CHECK PCV VALVE AND HOSE CONNECTIONS**

(a) Check the PCV hose connections.

(b) Check the PCV valve.

Click here [INFO](#)

OK:

PCV hose and PCV valve are connected correctly and are not damaged.


**NG**  **REPAIR OR REPLACE PCV VALVE OR HOSE**

**OK**


<b>4.</b>	<b>PERFORM ACTIVE TEST USING GTS (CONTROL THE EGR STEP POSITION)</b>
-----------	----------------------------------------------------------------------

Pre-procedure1

(a) Put the engine in Inspection Mode (Maintenance Mode).

**Powertrain > Hybrid Control > Utility**



(b) Start the engine and warm it up until the engine coolant temperature reaches 75°C (167°F) or higher.

**Powertrain > Engine > Data List****HINT:**

The A/C switch and all accessories should be off.

Procedure1

(c) Confirm that the value of Data List item Engine Independent is "Operate" then check the value of Intake Manifold Absolute Pressure while performing the Active Test.

**Powertrain > Engine > Active Test****NOTICE:**

- Do not leave the EGR valve open for 10 seconds or more during the Active Test.
- Be sure to return the EGR valve to step 0 when the Active Test is completed.
- Do not open the EGR valve 30 steps or more during the Active Test.

OK:

The value of Intake Manifold Absolute Pressure changes in response to the EGR step position when the value of Engine Independent is "Operate".

Standard:

-	CONTROL THE EGR STEP POSITION (ACTIVE TEST)	
	0 STEPS	0 TO 30 STEPS
Intake Manifold Absolute Pressure (Data List)	(EGR valve is fully closed)	Intake Manifold Absolute Pressure value is at least +10 kPa (1.45 psi) higher than when EGR valve is fully closed

**HINT:**

- If the value of Data List item Engine Independent is "Not Opr" when the engine is idling, charge control is being performed. Perform the Active Test after charge control is complete ("Operate" is displayed).
- While performing the Active Test, if the increase in the value of Intake Manifold Absolute Pressure is small, the EGR valve assembly may be malfunctioning.
- Even if the EGR valve assembly is malfunctioning, rough idling or an increase in the value of Intake Manifold Absolute Pressure may occur while performing the Active Test. However, the amount that the value of Intake Manifold Absolute Pressure increases will be smaller than normal.

RESULT	PROCEED TO
Intake Manifold Absolute Pressure value is at least +10 kPa (1.45 psi) higher than when EGR valve is fully closed	A
None of the above conditions are met	B

Post-procedure1

(d) None

**A** **GO TO STEP 6**

**B**



<b>5.</b>	<b>INSPECT EGR VALVE ASSEMBLY</b>
-----------	-----------------------------------

Pre-procedure1

(a) Remove the EGR valve assembly.

**HINT:**

[Click here](#)

Procedure1

(b) Check if the EGR valve is stuck open.

OK:



EGR valve is tightly closed.

Post-procedure1

(c) None

**NG**  **REPLACE EGR VALVE ASSEMBLY**

**OK**



<b>6.</b>	<b>INSPECT MASS AIR FLOW METER SUB-ASSEMBLY</b>
-----------	-------------------------------------------------

Click here 

**NEXT**



<b>7.</b>	<b>CLEAR DTC</b>
-----------	------------------

Pre-procedure1

(a) None

Procedure1

(b) Clear the DTCs.

**Powertrain > Engine > Clear DTCs**

Post-procedure1

(c) Turn the ignition switch off and wait for at least 30 seconds.

**NEXT**



<b>8.</b>	<b>CONFIRM WHETHER MALFUNCTION HAS BEEN SUCCESSFULLY REPAIRED</b>
-----------	-------------------------------------------------------------------

Pre-procedure1

(a) Drive the vehicle in accordance with the driving pattern described in Confirmation Driving Pattern.

Procedure1

(b) Check the DTC judgment result.

**Powertrain > Engine > Utility**

TESTER DISPLAY
All Readiness

GTS DISPLAY	DESCRIPTION
NORMAL	<ul style="list-style-type: none"> <li>• DTC judgment completed</li> <li>• System normal</li> </ul>
ABNORMAL	<ul style="list-style-type: none"> <li>• DTC judgment completed</li> <li>• System abnormal</li> </ul>
INCOMPLETE	<ul style="list-style-type: none"> <li>• DTC judgment not completed</li> <li>• Perform driving pattern after confirming DTC enabling conditions</li> </ul>

(c) Input the DTC: P010064.

Post-procedure1

(d) None

**NEXT**  **END**

