

<b>Last Modified:</b> 12-04-2024	6.11:8.1.0	<b>Doc ID:</b> RM1000000029A4L
<b>Model Year Start:</b> 2023	<b>Model:</b> Prius Prime	<b>Prod Date Range:</b> [12/2022 - ]
<b>Title:</b> HYBRID / BATTERY CONTROL: HYBRID BATTERY SYSTEM (for M20A-FXS): P33EC16,P33ED16; (Extreme) Hybrid/EV Battery Stack 1 Cell Circuit Voltage Below Threshold; 2023 - 2024 MY Prius Prius Prime [12/2022 - ]		

<b>DTC</b>	<b>P33EC16</b>	<b>(Extreme) Hybrid/EV Battery Stack 1 Cell Circuit Voltage Below Threshold</b>
------------	----------------	---

<b>DTC</b>	<b>P33ED16</b>	<b>(Extreme) Hybrid/EV Battery Stack 2 Cell Circuit Voltage Below Threshold</b>
------------	----------------	---

## DESCRIPTION

If the voltage of an HV battery cell is lower than the threshold for a certain amount of time, the battery ECU assembly will interpret this as a malfunction.

DTC NO.	DETECTION ITEM	DTC DETECTION CONDITION	TROUBLE AREA	MIL	WARNING INDICATE	DTC OUTPUT FROM	PRIORITY	NOTE
P33EC16	(Extreme) Hybrid/EV Battery Stack 1 Cell Circuit Voltage Below Threshold	The voltage of any cell of the No. 1 HV supply stack sub-assembly has decreased excessively.  (1 trip detection logic)	<ul style="list-style-type: none"> <li>• HV battery</li> <li>• Battery ECU assembly</li> </ul>	Comes on	Master Warning: Comes on	HV Battery	A	SAE Code: P33EC
P33ED16	(Extreme) Hybrid/EV Battery Stack 2 Cell Circuit Voltage Below Threshold	The voltage of any cell of the No. 2 HV supply stack sub-assembly has decreased excessively.  (1 trip detection logic)	<ul style="list-style-type: none"> <li>• HV battery</li> <li>• Battery ECU assembly</li> </ul>	Comes on	Master Warning: Comes on	HV Battery	A	SAE Code: P33ED

### **CAUTION:**

Do not charge the HV battery using the THS charger if DTC P33EC16 or P33ED16 is output.

## MONITOR DESCRIPTION

If the battery ECU assembly detects voltage drop in the battery cells, the battery ECU assembly will illuminate the MIL and store a DTC.

## MONITOR STRATEGY

Related DTCs	P33EC (INF P33EC16), P33ED (INF P33ED16): Cell voltage too low
Required sensors/components	Battery ECU assembly
Frequency of operation	Continuous
Duration	TMC's intellectual property
MIL operation	Immediately
Sequence of operation	None

## TYPICAL ENABLING CONDITIONS

The monitor will run whenever the following DTCs are not stored	TMC's intellectual property
Other conditions belong to TMC's intellectual property	-

## TYPICAL MALFUNCTION THRESHOLDS

TMC's intellectual property	-
-----------------------------	---

## COMPONENT OPERATING RANGE

Battery ECU assembly	DTC P33EC (INF P33EC16) is not detected DTC P33ED (INF P33ED16) is not detected
----------------------	--

## CONFIRMATION DRIVING PATTERN

### HINT:

- After repair has been completed, clear the DTC and then check that the vehicle has returned to normal by performing the following All Readiness check procedure.

[Click here](#) INFO

- When clearing the permanent DTCs, refer to the "CLEAR PERMANENT DTC" procedure.

[Click here](#) INFO

- Clear the DTCs (even if no DTCs are stored, perform the clear DTC procedure).
- Turn the ignition switch off and wait for 2 minutes or more.
- Drive the vehicle on urban roads for approximately 10 minutes.[\*1]

### HINT:

[\*1]: Normal judgment procedure.

The normal judgment procedure is used to complete DTC judgment and also used when clearing permanent DTCs.

- Enter the following menus: Powertrain / HV Battery / Utility / All Readiness.
- Check the DTC judgment result.

### HINT:

- If the judgment result shows NORMAL, the system is normal.
- If the judgment result shows ABNORMAL, the system has a malfunction.
- If the judgment result shows INCOMPLETE, perform the normal judgment procedure again.

## WIRING DIAGRAM

Refer to the wiring diagram for DTC P1A001C.

Click here [INFO](#)

## CAUTION / NOTICE / HINT

### CAUTION:

Refer to the precautions before inspecting high voltage circuit.

Click here [INFO](#)

### NOTICE:

- After the ignition switch is turned off, there may be a waiting time before disconnecting the negative (-) auxiliary battery terminal.

Click here [INFO](#)

- When disconnecting and reconnecting the auxiliary battery

### HINT:

When disconnecting and reconnecting the auxiliary battery, there is an automatic learning function that completes learning when the respective system is used.

Click here [INFO](#)

## PROCEDURE

<b>1.</b>	<b>CHECK DTC OUTPUT (HV BATTERY, HYBRID CONTROL)</b>
-----------	--

Pre-procedure1

(a) None

Procedure1

(b) Check for DTCs.

**Powertrain > HV Battery > Trouble Codes**

**Powertrain > Hybrid Control > Trouble Codes**

RESULT	PROCEED TO
"P33EC16 or P33ED16" only is output, or DTCs except the ones in the table below are also output.	A
DTCs of hybrid battery system in the table below are output.	B
DTCs of hybrid control system in the table below are output.	C

SYSTEM	RELEVANT DTC	
Hybrid battery system	P060A47	Hybrid/EV Battery Energy Control Module Monitoring Processor Watchdog / Safety MCU Failure
	P060B49	Hybrid/EV Battery Energy Control Module A/D Processing Internal Electronic Failure

SYSTEM	RELEVANT DTC	
	P060687	Hybrid/EV Battery Energy Control Module Processor to Monitoring Processor Missing Message
	P0E2D00	Hybrid/EV Battery Energy Control Module Hybrid/EV Battery Monitor Performance
Hybrid control system	P0A1F94	Hybrid/EV Battery Energy Control Module Unexpected Operation

Post-procedure1

(c) Turn the ignition switch off.

**B** ► **GO TO DTC CHART (HYBRID BATTERY SYSTEM)**

**C** ► **GO TO DTC CHART (HYBRID CONTROL SYSTEM)**

**A**



<b>2.</b>	<b>CHECK DTC</b>
-----------	------------------

(a) Check the DTCs that were output when the vehicle was brought to the workshop.

RESULT	PROCEED TO
"P33EC16" is also output.	A
"P33ED16" is also output.	B

**B** ► **GO TO STEP 8**

**A**



<b>3.</b>	<b>CHECK CONNECTOR CONNECTION CONDITION (BATTERY ECU ASSEMBLY CONNECTOR)</b>
-----------	--

Click here 

RESULT	PROCEED TO
OK	A

RESULT		PROCEED TO
Not connected securely	The terminals are not damaged or corroded	B
Not connected securely	The terminals are damaged or corroded	C

**B** ► **CONNECT SECURELY**

**C** ► **REPLACE HV BATTERY**

**A**



<b>4.</b>	<b>CHECK FREEZE FRAME DATA (HYBRID/EV BATTERY CELL VOLTAGE)</b>
-----------	---

Pre-procedure1

(a) None

Procedure1

(b) Read the value of freeze frame data items "Hybrid/EV battery cell 1 voltage" through "Hybrid/EV battery cell 30 voltage" for DTC P33EC16 and make a note if the value of any is 1.2 V or less.

**Powertrain > HV Battery > Trouble Codes**

Post-procedure1

(c) Turn the ignition switch off.

**NEXT**



<b>5.</b>	<b>CHECK HV BATTERY (HV BATTERY CELL VOLTAGE 1 - 30)</b>
-----------	--

**CAUTION:**

- Be sure to wear insulated gloves and protective goggles.
- Disconnect only the connector corresponding to the HV battery cell to be checked. Do not disconnect the other connectors.

**NOTICE:**

Make sure to use tester probes with a diameter of approximately 0.5 mm (0.0197 in.) when measuring the voltage of each HV battery cell.


Pre-procedure1

(a) Check that the service plug grip is not installed.

**NOTICE:**

After removing the service plug grip, do not turn the ignition switch to ON (READY), unless instructed by the repair manual because this may cause a malfunction.

(b) Disconnect the battery ECU assembly connector.



## Procedure1

(c) Measure the voltage according to the value(s) in the table below.

**HINT:**

Measure the voltage of the HV battery cells whose value in the freeze frame data was 1.2 V or less only.

HV BATTERY CELL	TESTER CONNECTION	CONDITION
1	z11-19 (GA0) - z11-41 (VA1)	Always
2	z11-41 (VA1) - z11-18 (VA2)	Always
3	z11-18 (VA2) - z11-40 (VA3)	Always
4	z11-40 (VA3) - z11-17 (VA4)	Always
5	z11-17 (VA4) - z11-39 (VA5)	Always
6	z11-39 (VA5) - z11-16 (VA6)	Always
7	z11-16 (VA6) - z11-38 (VA7)	Always
8	z11-38 (VA7) - z11-15 (VA8)	Always
9	z11-15 (VA8) - z11-37 (VA9)	Always
10	z11-37 (VA9) - z11-14 (VA10)	Always
11	z11-14 (VA10) - z11-36 (VA11)	Always
12	z11-36 (VA11) - z11-13 (VA12)	Always
13	z11-13 (VA12) - z11-35 (VA13)	Always
14	z11-35 (VA13) - z11-12 (VA14)	Always
15	z11-12 (VA14) - z11-34 (VA15)	Always
16	z11-34 (VA15) - z11-11 (VA16)	Always
17	z11-11 (VA16) - z11-33 (VA17)	Always
18	z11-33 (VA17) - z11-10 (VA18)	Always

HV BATTERY CELL	TESTER CONNECTION	CONDITION
19	z11-10 (VA18) - z11-32 (VA19)	Always
20	z11-32 (VA19) - z11-9 (VA20)	Always
21	z11-9 (VA20) - z11-31 (VA21)	Always
22	z11-31 (VA21) - z11-7 (VA22)	Always
23	z11-29 (GA1) - z11-6 (VA23)	Always
24	z11-6 (VA23) - z11-28 (VA24)	Always
25	z11-28 (VA24) - z11-5 (VA25)	Always
26	z11-5 (VA25) - z11-27 (VA26)	Always
27	z11-27 (VA26) - z11-4 (VA27)	Always
28	z11-4 (VA27) - z11-26 (VA28)	Always
29	z11-26 (VA28) - z11-3 (VA29)	Always
30	z11-3 (VA29) - z11-23 (VA30)	Always

**CAUTION:**

Make sure not to cross the electrodes of an electrical tester measurement terminals.

**NOTICE:**

Make sure to check the polarity of each terminal (positive (+) or negative (-)) before connecting a tester.

RESULT	PROCEED TO
The voltage between the terminals is 1.2 V or less.	A
Other than above	B

Post-procedure1

(d) Reconnect the battery ECU assembly connector.

**B**  **REPLACE BATTERY ECU ASSEMBLY**

**A**



<b>6.</b>	<b>CHECK BATTERY ECU ASSEMBLY (GA0 - VA30)</b>
-----------	--

**NOTICE:**

Make sure to use tester probes with a diameter of approximately 0.5 mm (0.0197 in.) when measuring the resistance.

Pre-procedure1

(a) Remove the battery ECU assembly.

**HINT:**


[Click here](#) **INFO**

Procedure1

(b) Measure the resistance according to the value(s) in the table below.

**HINT:**

Only inspect the terminals of the battery ECU assembly which correspond to the HV battery cells which measured 1.2 V or less in the previous step.



*a	Component without harness connected (Battery ECU Assembly)	-	-
----	---	---	---

Standard Resistance:



HV BATTERY CELL	TESTER CONNECTION (TESTER PROBE POLARITY)	CONDITION	SPECIFIED CONDITION
1	z11-19 (GA0) (-) - z11-41 (VA1) (+)	Always	50 kΩ or more
2	z11-41 (VA1) (-) - z11-18 (VA2) (+)	Always	50 kΩ or more
3	z11-18 (VA2) (-) - z11-40 (VA3) (+)	Always	50 kΩ or more
4	z11-40 (VA3) (-) - z11-17 (VA4) (+)	Always	50 kΩ or more
5	z11-17 (VA4) (-) - z11-39 (VA5) (+)	Always	50 kΩ or more
6	z11-39 (VA5) (-) - z11-16 (VA6) (+)	Always	50 kΩ or more
7	z11-16 (VA6) (-) - z11-38 (VA7) (+)	Always	50 kΩ or more
8	z11-38 (VA7) (-) - z11-15 (VA8) (+)	Always	50 kΩ or more
9	z11-15 (VA8) (-) - z11-37 (VA9) (+)	Always	50 kΩ or more
10	z11-37 (VA9) (-) - z11-14 (VA10) (+)	Always	50 kΩ or more
11	z11-14 (VA10) (-) - z11-36 (VA11) (+)	Always	50 kΩ or more
12	z11-36 (VA11) (-) - z11-13 (VA12) (+)	Always	50 kΩ or more
13	z11-13 (VA12) (-) - z11-35 (VA13) (+)	Always	50 kΩ or more
14	z11-35 (VA13) (-) - z11-12 (VA14) (+)	Always	50 kΩ or more
15	z11-12 (VA14) (-) - z11-34 (VA15) (+)	Always	50 kΩ or more
16	z11-34 (VA15) (-) - z11-11 (VA16) (+)	Always	50 kΩ or more
17	z11-11 (VA16) (-) - z11-33 (VA17) (+)	Always	50 kΩ or more
18	z11-33 (VA17) (-) - z11-10 (VA18) (+)	Always	50 kΩ or more
19	z11-10 (VA18) (-) - z11-32 (VA19) (+)	Always	50 kΩ or more
20	z11-32 (VA19) (-) - z11-9 (VA20) (+)	Always	50 kΩ or more
21	z11-9 (VA20) (-) - z11-31 (VA21) (+)	Always	50 kΩ or more
22	z11-31 (VA21) (-) - z11-7 (VA22) (+)	Always	50 kΩ or more
23	z11-29 (GA1) (-) - z11-6 (VA23) (+)	Always	50 kΩ or more
24	z11-6 (VA23) (-) - z11-28 (VA24) (+)	Always	50 kΩ or more
25	z11-28 (VA24) (-) - z11-5 (VA25) (+)	Always	50 kΩ or more
26	z11-5 (VA25) (-) - z11-27 (VA26) (+)	Always	50 kΩ or more
27	z11-27 (VA26) (-) - z11-4 (VA27) (+)	Always	50 kΩ or more
28	z11-4 (VA27) (-) - z11-26 (VA28) (+)	Always	50 kΩ or more
29	z11-26 (VA28) (-) - z11-3 (VA29) (+)	Always	50 kΩ or more
30	z11-3 (VA29) (-) - z11-23 (VA30) (+)	Always	50 kΩ or more

**NOTICE:**

- Make sure to check the polarity of each terminal (positive (+) or negative (-)) before connecting a tester.
- Read the resistance after the value has stabilized.
- In order to avoid damaging the terminals of the battery ECU assembly, make sure to use tester probes with a diameter of approximately 0.5 mm (0.0197 in.) when measuring the resistance of the battery ECU assembly.

RESULT	PROCEED TO
The voltage between the terminals is 50 kΩ or more.	A
Other than above	B

Post-procedure1

(c) Install the battery ECU assembly.

**A** ▶ REPLACE HV BATTERY

**B**



<b>7.</b>	<b>REPLACE HV BATTERY</b>
-----------	---------------------------

**HINT:**

Click here [INFO](#)

**NEXT** ▶ REPLACE BATTERY ECU ASSEMBLY

<b>8.</b>	<b>CHECK CONNECTOR CONNECTION CONDITION (BATTERY ECU ASSEMBLY CONNECTOR)</b>
-----------	--

Click here [INFO](#)

RESULT		PROCEED TO
OK		A
Not connected securely	The terminals are not damaged or corroded	B
Not connected securely	The terminals are damaged or corroded	C

**B** ▶ CONNECT SECURELY

**C** ▶ REPLACE HV BATTERY

**A**



**9. CHECK FREEZE FRAME DATA (HYBRID/EV BATTERY CELL VOLTAGE)**

Pre-procedure1

(a) None

Procedure1

(b) Read the value of freeze frame data items "Hybrid/EV battery cell 31 voltage" through "Hybrid/EV battery cell 60 voltage" for DTC P33ED16 and make a note if the value of any is 1.2 V or less.

**Powertrain > HV Battery > Trouble Codes**

Post-procedure1

(c) Turn the ignition switch off.

**NEXT****10. CHECK HV BATTERY (HV BATTERY CELL VOLTAGE 31 - 60)****CAUTION:**

- Be sure to wear insulated gloves and protective goggles.
- Disconnect only the connector corresponding to the HV battery cell to be checked. Do not disconnect the other connectors.

**NOTICE:**

Make sure to use tester probes with a diameter of approximately 0.5 mm (0.0197 in.) when measuring the voltage of each HV battery cell.


Pre-procedure1

(a) Check that the service plug grip is not installed.

**NOTICE:**

After removing the service plug grip, do not turn the ignition switch to ON (READY), unless instructed by the repair manual because this may cause a malfunction.

(b) Disconnect the battery ECU assembly connector.



### Procedure1

(c) Measure the voltage according to the value(s) in the table below.

#### HINT:

Measure the voltage of the HV battery cells whose value in the freeze frame data was 1.2 V or less only.

HV BATTERY CELL	TESTER CONNECTION	CONDITION
31	z13-22 (VAD) - z13-44 (VA31)	Always
32	z13-44 (VA31) - z13-21 (VA32)	Always
33	z13-21 (VA32) - z13-43 (VA33)	Always
34	z13-43 (VA33) - z13-20 (VA34)	Always
35	z13-20 (VA34) - z13-42 (VA35)	Always
36	z13-42 (VA35) - z13-19 (VA36)	Always
37	z13-19 (VA36) - z13-16 (VA37)	Always
38	z13-35 (GA2) - z13-12 (VA38)	Always
39	z13-12 (VA38) - z13-34 (VA39)	Always
40	z13-34 (VA39) - z13-11 (VA40)	Always
41	z13-11 (VA40) - z13-33 (VA41)	Always
42	z13-33 (VA41) - z13-10 (VA42)	Always
43	z13-10 (VA42) - z13-32 (VA43)	Always
44	z13-32 (VA43) - z13-9 (VA44)	Always
45	z13-9 (VA44) - z13-31 (VA45)	Always
46	z13-31 (VA45) - z13-8 (VA46)	Always
47	z13-8 (VA46) - z13-30 (VA47)	Always
48	z13-30 (VA47) - z13-7 (VA48)	Always
49	z13-7 (VA48) - z13-29 (VA49)	Always
50	z13-29 (VA49) - z13-6 (VA50)	Always
51	z13-6 (VA50) - z13-28 (VA51)	Always

HV BATTERY CELL	TESTER CONNECTION	CONDITION
52	z13-28 (VA51) - z13-5 (VA52)	Always
53	z13-5 (VA52) - z13-27 (VA53)	Always
54	z13-27 (VA53) - z13-4 (VA54)	Always
55	z13-4 (VA54) - z13-26 (VA55)	Always
56	z13-26 (VA55) - z13-3 (VA56)	Always
57	z13-3 (VA56) - z13-25 (VA57)	Always
58	z13-25 (VA57) - z13-2 (VA58)	Always
59	z13-2 (VA58) - z13-24 (VA59)	Always
60	z13-24 (VA59) - z13-23 (VA60)	Always

**CAUTION:**

Make sure not to cross the electrodes of an electrical tester measurement terminals.

**NOTICE:**

Make sure to check the polarity of each terminal (positive (+) or negative (-)) before connecting a tester.

RESULT	PROCEED TO
The voltage between the terminals is 1.2 V or less.	A
Other than above	B

Post-procedure1

(d) Reconnect the battery ECU assembly connector.

**B**  **REPLACE BATTERY ECU ASSEMBLY**

**A**



<b>11.</b>	<b>CHECK BATTERY ECU ASSEMBLY (VAD - VA60)</b>
------------	--

**NOTICE:**

Make sure to use tester probes with a diameter of approximately 0.5 mm (0.0197 in.) when measuring the resistance.

Pre-procedure1

(a) Remove the battery ECU assembly.

**HINT:**


Click here 

Procedure1

(b) Measure the resistance according to the value(s) in the table below.

**HINT:**

Only inspect the terminals of the battery ECU assembly which correspond to the HV battery cells which measured 1.2 V or less in the previous step.



*a	Component without harness connected (Battery ECU Assembly)	-	-
----	---	---	---

Standard Resistance:

HV BATTERY CELL	TESTER CONNECTION (TESTER PROBE POLARITY)	CONDITION	SPECIFIED CONDITION
31	z13-22 (VAD) (-) - z13-44 (VA31) (+)	Always	50 kΩ or more
32	z13-44 (VA31) (-) - z13-21 (VA32) (+)	Always	50 kΩ or more

HV BATTERY CELL	TESTER CONNECTION (TESTER PROBE POLARITY)	CONDITION	SPECIFIED CONDITION
33	z13-21 (VA32) (-) - z13-43 (VA33) (+)	Always	50 kΩ or more
34	z13-43 (VA33) (-) - z13-20 (VA34) (+)	Always	50 kΩ or more
35	z13-20 (VA34) (-) - z13-42 (VA35) (+)	Always	50 kΩ or more
36	z13-42 (VA35) (-) - z13-19 (VA36) (+)	Always	50 kΩ or more
37	z13-19 (VA36) (-) - z13-16 (VA37) (+)	Always	50 kΩ or more
38	z13-35 (GA2) (-) - z13-12 (VA38) (+)	Always	50 kΩ or more
39	z13-12 (VA38) (-) - z13-34 (VA39) (+)	Always	50 kΩ or more
40	z13-34 (VA39) (-) - z13-11 (VA40) (+)	Always	50 kΩ or more
41	z13-11 (VA40) (-) - z13-33 (VA41) (+)	Always	50 kΩ or more
42	z13-33 (VA41) (-) - z13-10 (VA42) (+)	Always	50 kΩ or more
43	z13-10 (VA42) (-) - z13-32 (VA43) (+)	Always	50 kΩ or more
44	z13-32 (VA43) (-) - z13-9 (VA44) (+)	Always	50 kΩ or more
45	z13-9 (VA44) (-) - z13-31 (VA45) (+)	Always	50 kΩ or more
46	z13-31 (VA45) (-) - z13-8 (VA46) (+)	Always	50 kΩ or more
47	z13-8 (VA46) (-) - z13-30 (VA47) (+)	Always	50 kΩ or more
48	z13-30 (VA47) (-) - z13-7 (VA48) (+)	Always	50 kΩ or more
49	z13-7 (VA48) (-) - z13-29 (VA49) (+)	Always	50 kΩ or more
50	z13-29 (VA49) (-) - z13-6 (VA50) (+)	Always	50 kΩ or more
51	z13-6 (VA50) (-) - z13-28 (VA51) (+)	Always	50 kΩ or more
52	z13-28 (VA51) (-) - z13-5 (VA52) (+)	Always	50 kΩ or more
53	z13-5 (VA52) (-) - z13-27 (VA53) (+)	Always	50 kΩ or more
54	z13-27 (VA53) (-) - z13-4 (VA54) (+)	Always	50 kΩ or more
55	z13-4 (VA54) (-) - z13-26 (VA55) (+)	Always	50 kΩ or more
56	z13-26 (VA55) (-) - z13-3 (VA56) (+)	Always	50 kΩ or more
57	z13-3 (VA56) (-) - z13-25 (VA57) (+)	Always	50 kΩ or more
58	z13-25 (VA57) (-) - z13-2 (VA58) (+)	Always	50 kΩ or more
59	z13-2 (VA58) (-) - z13-24 (VA59) (+)	Always	50 kΩ or more
60	z13-24 (VA59) (-) - z13-23 (VA60) (+)	Always	50 kΩ or more

**NOTICE:**

- Make sure to check the polarity of each terminal (positive (+) or negative (-)) before connecting a tester.
- Read the resistance after the value has stabilized.
- In order to avoid damaging the terminals of the battery ECU assembly, make sure to use tester probes with a diameter of approximately 0.5 mm (0.0197 in.) when measuring the resistance of the battery ECU assembly.

RESULT	PROCEED TO
The voltage between the terminals is 50 kΩ or more.	A

RESULT	PROCEED TO
Other than above	B

Post-procedure1

(c) Install the battery ECU assembly.

**A** ► **REPLACE HV BATTERY**

**B**



<b>12.</b>	<b>REPLACE HV BATTERY</b>
------------	---------------------------

**HINT:**

[Click here](#)

**INFO**

**NEXT** ► **REPLACE BATTERY ECU ASSEMBLY**

