

<b>Last Modified:</b> 12-04-2024	6.11:8.1.0	<b>Doc ID:</b> RM10000002BHVW
<b>Model Year Start:</b> 2023	<b>Model:</b> Prius Prime	<b>Prod Date Range:</b> [03/2023 - ]
<b>Title:</b> HYBRID / BATTERY CONTROL: HYBRID BATTERY SYSTEM (for PHEV Model): P0E6D11; Hybrid/EV Battery Charging System Precharge Contactor Control Circuit Short to Ground; 2023 - 2024 MY Prius Prime [03/2023 - ]		

<b>DTC</b>	<b>P0E6D11</b>	<b>Hybrid/EV Battery Charging System Precharge Contactor Control Circuit Short to Ground</b>
------------	----------------	--

## DESCRIPTION

Refer to the description for DTC P0D0A11.

Click here [INFO](#)

DTC NO.	DETECTION ITEM	DTC DETECTION CONDITION	TROUBLE AREA	MIL	WARNING INDICATE	DTC OUTPUT FROM	PRIORITY	NOTE
P0E6D11	Hybrid/EV Battery Charging System Precharge Contactor Control Circuit Short to Ground	Short to ground in the CHRP circuit:  Primary circuit of CHRP is malfunctioning. (1 trip detection logic)	<ul style="list-style-type: none"> <li>No. 1 traction battery device box assembly</li> <li>Battery ECU assembly</li> <li>Wire harness or connector</li> </ul>	Comes on / Does not come on	Master Warning:  Comes on	HV Battery	A	SAE Code:  P0E6F

## MONITOR DESCRIPTION

If the battery ECU assembly detects a malfunction of its HV battery charging system precharge contactor control circuit (CHRP), the battery ECU assembly illuminates the MIL and stores a DTC.

## MONITOR STRATEGY

Related DTCs	P0E6F (INF P0E6D11): Battery Charging System Precharge Contactor Control Circuit
Required sensors/components	Charge relay
Frequency of operation	Continuous
Duration	TMC's intellectual property
MIL operation	Immediately
Sequence of operation	None

## TYPICAL ENABLING CONDITIONS

The monitor will run whenever the following DTCs are not stored	TMC's intellectual property
Other conditions belong to TMC's intellectual property	-

## TYPICAL MALFUNCTION THRESHOLDS

TMC's intellectual property	-
-----------------------------	---

## COMPONENT OPERATING RANGE

Battery ECU assembly	DTC P0E6F (INF P0E6D11) is not detected
----------------------	---

## CONFIRMATION DRIVING PATTERN

### HINT:

- After repair has been completed, clear the DTC and then check that the vehicle has returned to normal by performing the following All Readiness check procedure.

[Click here](#) INFO

- When clearing the permanent DTCs, refer to the "CLEAR PERMANENT DTC" procedure.

[Click here](#) INFO

- Clear the DTCs (even if no DTCs are stored, perform the clear DTC procedure).
- Enter the following menus: Powertrain / Hybrid Control / Data List.[\*1]
- Check that "Hybrid/EV Battery SOC" shows 70% or less.[\*2]
- Turn the ignition switch off and wait for 2 minutes or more.[\*3]
- Connect the electric vehicle charger cable assembly, and plug-in charge the vehicle for at least 5 seconds.  
[\*4]

### HINT:

[\*1] to [\*4]: Normal judgment procedure.

The normal judgment procedure is used to complete DTC judgment and also used when clearing permanent DTCs.

- Enter the following menus: Powertrain / HV Battery / Utility / All Readiness.
- Check the DTC judgment result.

### HINT:

- If the judgment result shows NORMAL, the system is normal.
- If the judgment result shows ABNORMAL, the system has a malfunction.
- If the judgment result shows INCOMPLETE or N/A, perform the normal judgment procedure again.

## WIRING DIAGRAM

Refer to the wiring diagram for DTC P0D0A11.

[Click here](#) INFO

## CAUTION / NOTICE / HINT

### CAUTION:

Refer to the precautions before inspecting high voltage circuit.

[Click here](#) **INFO**

**NOTICE:**

- After the ignition switch is turned off, there may be a waiting time before disconnecting the auxiliary negative (-) battery terminal.

[Click here](#) **INFO**

- When disconnecting and reconnecting the auxiliary battery.

**HINT:**

When disconnecting and reconnecting the auxiliary battery, there is an automatic learning function that completes learning when the respective system is used.

[Click here](#) **INFO**

## PROCEDURE

<b>1.</b>	<b>CHECK CONNECTOR CONNECTION CONDITION (BATTERY ECU ASSEMBLY)</b>
-----------	--

[Click here](#) **INFO**

**NG**  **CONNECT SECURELY**

**OK**



<b>2.</b>	<b>CHECK HARNESS AND CONNECTOR (BATTERY ECU ASSEMBLY - BODY GROUND)</b>
-----------	---

**CAUTION:**

Be sure to wear insulated gloves and protective goggles.

Pre-procedure1

- (a) Check that the service plug grip is not installed.


**NOTICE:**

After removing the service plug grip, do not turn the ignition switch to ON (READY), unless instructed by the repair manual because this may cause a malfunction.

- (b) Disconnect the battery ECU assembly connector.

**NOTICE:**

Before disconnecting the connector, check that it is not loose or disconnected.



Procedure1

(c) Measure the resistance according to the value(s) in the tables below.

Standard Resistance:



[Click Location & Routing\(x4\).](#)

[Click Connector\(x4\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION	RESULT
x4-7 (CHRP) - Body ground	Ignition switch off	140 to 290 Ω	Ω

Post-procedure1

(d) Reconnect the battery ECU assembly connector.

**OK** ► REPLACE BATTERY ECU ASSEMBLY

**NG**



<b>3.</b>	<b>CHECK CONNECTOR CONNECTION CONDITION (NO. 1 TRACTION BATTERY DEVICE BOX ASSEMBLY)</b>
-----------	--

Click here [INFO](#)

**NG** ► CONNECT SECURELY

**OK**



## 4. CHECK HARNESS AND CONNECTOR (BATTERY ECU ASSEMBLY - NO. 1 TRACTION BATTERY DEVICE BOX ASSEMBLY)

### CAUTION:

Be sure to wear insulated gloves and protective goggles.

Pre-procedure1

(a) Check that the service plug grip is not installed.


### NOTICE:

After removing the service plug grip, do not turn the ignition switch to ON (READY), unless instructed by the repair manual because this may cause a malfunction.

(b) Disconnect the battery ECU assembly connector.

### NOTICE:


Before disconnecting the connector, check that it is not loose or disconnected.



(c) Disconnect the No. 1 traction battery device box assembly connector.

### NOTICE:

Before disconnecting the connector, check that it is not loose or disconnected.



Procedure1

(d) Measure the resistance according to the value(s) in the tables below.

Standard Resistance:



[Click Location & Routing\(x13,x4\)](#)

[Click Connector\(x13\)](#)[Click Connector\(x4\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION	RESULT
x13-2 (CHRP) and x4-7 (CHRP) - Body ground and other terminals	Ignition switch off	10 k $\Omega$ or higher	k $\Omega$

Post-procedure1

(e) Reconnect the No. 1 traction battery device box assembly connector.

(f) Reconnect the battery ECU assembly connector.

**OK** ► **REPLACE NO. 1 TRACTION BATTERY DEVICE BOX ASSEMBLY**

**NG** ► **REPAIR OR REPLACE HARNESS OR CONNECTOR**

