

Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM10000002BHV4
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [03/2023 -]
Title: HYBRID / BATTERY CONTROL: HYBRID BATTERY SYSTEM (for PHEV Model): P33EC16-P33EE16; (Extreme) Hybrid/EV Battery Stack 1 Cell Circuit Voltage Below Threshold; 2023 - 2024 MY Prius Prime [03/2023 -]		

DTC	P33EC16	(Extreme) Hybrid/EV Battery Stack 1 Cell Circuit Voltage Below Threshold
------------	----------------	---

DTC	P33ED16	(Extreme) Hybrid/EV Battery Stack 2 Cell Circuit Voltage Below Threshold
------------	----------------	---

DTC	P33EE16	(Extreme) Hybrid/EV Battery Stack 3 Cell Circuit Voltage Below Threshold
------------	----------------	---

DESCRIPTION

If the voltage of an HV battery cell is lower than the threshold for a certain amount of time, the battery ECU assembly will interpret this as a malfunction.

DTC NO.	DETECTION ITEM	DTC DETECTION CONDITION	TROUBLE AREA	MIL	WARNING INDICATE	DTC OUTPUT FROM	PRIORITY	NOTE
P33EC16	(Extreme) Hybrid/EV Battery Stack 1 Cell Circuit Voltage Below Threshold	The voltage of any cell of the No. 1 HV supply stack sub-assembly has decreased excessively. (1 trip detection logic)	<ul style="list-style-type: none"> No. 1 HV supply stack sub-assembly Battery voltage sensor 	Comes on	Master Warning: Comes on	HV Battery	A	SAE Code: P33EC
P33ED16	(Extreme) Hybrid/EV Battery Stack 2 Cell Circuit Voltage Below Threshold	The voltage of any cell of the No. 2 HV supply stack sub-assembly has decreased excessively. (1 trip detection logic)	<ul style="list-style-type: none"> No. 2 HV supply stack sub-assembly Battery voltage sensor 	Comes on	Master Warning: Comes on	HV Battery	A	SAE Code: P33ED

DTC NO.	DETECTION ITEM	DTC DETECTION CONDITION	TROUBLE AREA	MIL	WARNING INDICATE	DTC OUTPUT FROM	PRIORITY	NOTE
P33EE16	(Extreme) Hybrid/EV Battery Stack 3 Cell Circuit Voltage Below Threshold	The voltage of any cell of the No. 3 HV supply stack sub-assembly has decreased excessively. (1 trip detection logic)	<ul style="list-style-type: none"> No. 3 HV supply stack sub-assembly Battery voltage sensor 	Comes on	Master Warning: Comes on	HV Battery	A	SAE Code: P33EE

MONITOR DESCRIPTION

If the battery ECU assembly detects voltage drop in a battery module, the battery ECU assembly will illuminate the MIL and store a DTC.

MONITOR STRATEGY

Related DTCs	P33EC (INF P33EC16), P33ED (INF P33ED16), P33EE (INF P33EE16): Cell voltage too low
Required sensors/components	Battery ECU assembly
Frequency of operation	Continuous
Duration	TMC's intellectual property
MIL operation	1 driving cycle
Sequence of operation	None

TYPICAL ENABLING CONDITIONS

The monitor will run whenever the following DTCs are not stored	TMC's intellectual property
Other conditions belong to TMC's intellectual property	-

TYPICAL MALFUNCTION THRESHOLDS

TMC's intellectual property	-
-----------------------------	---

COMPONENT OPERATING RANGE

Battery ECU assembly	DTC P33EC (INF P33EC16) is not detected DTC P33ED (INF P33ED16) is not detected DTC P33EE (INF P33EE16) is not detected
----------------------	---

CONFIRMATION DRIVING PATTERN

HINT:

- After repair has been completed, clear the DTC and then check that the vehicle has returned to normal by performing the following All Readiness check procedure.

[Click here](#) **INFO**

- When clearing the permanent DTCs, refer to the "CLEAR PERMANENT DTC" procedure.

[Click here](#) **INFO**

1. Clear the DTCs (even if no DTCs are stored, perform the clear DTC procedure).
2. Turn the ignition switch off and wait for 2 minutes or more.
3. Drive the vehicle on urban roads for approximately 10 minutes.[*1]

HINT:

[*1]: Normal judgment procedure.

The normal judgment procedure is used to complete DTC judgment and also used when clearing permanent DTCs.

4. Enter the following menus: Powertrain / HV Battery / Utility / All Readiness.
5. Check the DTC judgment result.

HINT:

- If the judgment result shows NORMAL, the system is normal.
- If the judgment result shows ABNORMAL, the system has a malfunction.
- If the judgment result shows INCOMPLETE or N/A, perform the normal judgment procedure again.

WIRING DIAGRAM

Refer to the wiring diagram for DTC P1A001C.

[Click here](#) **INFO**

CAUTION / NOTICE / HINT

CAUTION:

Refer to the precautions before inspecting high voltage circuit.

[Click here](#) **INFO**

NOTICE:

- After the ignition switch is turned off, there may be a waiting time before disconnecting the auxiliary negative (-) battery terminal.

[Click here](#) **INFO**

- When disconnecting and reconnecting the auxiliary battery.

HINT:

When disconnecting and reconnecting the auxiliary battery, there is an automatic learning function that completes learning when the respective system is used.

[Click here](#) **INFO**

PROCEDURE

1.	CHECK DTC OUTPUT (HV BATTERY, HYBRID CONTROL)
-----------	--

Pre-procedure1

(a) None

Procedure1

(b) Check for DTCs.

Powertrain > HV Battery > Trouble Codes**Powertrain > Hybrid Control > Trouble Codes**

RESULT	PROCEED TO
"P33EC16, P33ED16 or P33EE16" only is output, or DTCs except the ones in the table below are also output.	A
DTCs of hybrid battery system in the table below are output.	B
DTCs of hybrid control system in the table below are output.	C

SYSTEM	RELEVANT DTC	
Hybrid battery system	P060A47	Hybrid/EV Battery Energy Control Module Monitoring Processor Watchdog / Safety MCU Failure
	P060B49	Hybrid/EV Battery Energy Control Module A/D Processing Internal Electronic Failure
	P060687	Hybrid/EV Battery Energy Control Module Processor to Monitoring Processor Missing Message
	P1AC413	Hybrid/EV Battery Stack 1 Current Interrupt Device Circuit Open
	P1AC513	Hybrid/EV Battery Stack 2 Current Interrupt Device Circuit Open
	P1AC613	Hybrid/EV Battery Stack 3 Current Interrupt Device Circuit Open
	P1AC713	Hybrid/EV Battery Stack 4 Current Interrupt Device Circuit Open
	P1AC49E	Hybrid/EV Battery Stack 1 Current Interrupt Device Stuck On
	P1AC59E	Hybrid/EV Battery Stack 2 Current Interrupt Device Stuck On
	P1AC69E	Hybrid/EV Battery Stack 3 Current Interrupt Device Stuck On
P1AC79E	Hybrid/EV Battery Stack 4 Current Interrupt Device Stuck On	
Hybrid control system	P0A1F94	Hybrid/EV Battery Energy Control Module Unexpected Operation

Post-procedure1

(c) Turn the ignition switch off.

B ► GO TO DTC CHART (HYBRID BATTERY SYSTEM)**C ► GO TO DTC CHART (HYBRID CONTROL SYSTEM)**

A

2.	CHECK DTC
-----------	------------------

(a) Check the DTCs that were output when the vehicle was brought to the workshop.

RESULT	PROCEED TO
"P33EC16" is also output.	A
"P33ED16" is also output.	B
"P33EE16" is also output.	C

B **GO TO STEP 8**

C **GO TO STEP 13**

A

3.	CHECK CONNECTOR CONNECTION CONDITION (BATTERY VOLTAGE SENSOR CONNECTOR)
-----------	--

CAUTION:

Be sure to wear insulated gloves and protective goggles.

Pre-procedure1

(a) Check that the service plug grip is not installed.

NOTICE:

After removing the service plug grip, do not turn the ignition switch to ON (READY), unless instructed by the repair manual because this may cause a malfunction.

Procedure1

(b) Check the connections of the battery voltage sensor connectors.


HINT:

Click here

OK:

The connector is connected securely and there are no contact problems.

Result:



RESULT		PROCEED TO
OK		A
Not connected securely	The terminals are not damaged or corroded	B
Connector is not connected securely	The terminals are damaged or corroded	C

Post-procedure1

(c) None

B ► CONNECT SECURELY

C ► REPLACE NO. 1 HV SUPPLY STACK SUB-ASSEMBLY

A
▼

4.	CHECK FREEZE FRAME DATA
-----------	--------------------------------

Pre-procedure1

(a) None

Procedure1

(b) Read the value of freeze frame data items "Hybrid/EV Battery Cell 1 voltage" through "Hybrid/EV Battery Cell 24 voltage" for DTC P33EC16 and make a note if the value of any is 1.6 V or less.

Powertrain > HV Battery > Trouble Codes

Post-procedure1

(c) Turn the ignition switch off.

NEXT
▼

5.	CHECK NO. 1 HV SUPPLY STACK SUB-ASSEMBLY (HYBRID BATTERY CELL 1 TO 24 VOLTAGE)
-----------	---

Click here [INFO](#)

RESULT	PROCEED TO
The voltage between the terminals is 1.6 V or less.	A
Other than above	B

B **REPLACE BATTERY VOLTAGE SENSOR**

A

6.	CHECK BATTERY VOLTAGE SENSOR (VA1 - VA24)
-----------	--

Click here [INFO](#)

RESULT	PROCEED TO
The resistance between the terminals is 50 kΩ or more.	A
Other than above	B

A **REPLACE NO. 1 HV SUPPLY STACK SUB-ASSEMBLY**

B

7.	REPLACE NO. 1 HV SUPPLY STACK SUB-ASSEMBLY
-----------	---

HINT:

Click here [INFO](#)

NEXT **REPLACE BATTERY VOLTAGE SENSOR**

8. CHECK CONNECTOR CONNECTION CONDITION (BATTERY VOLTAGE SENSOR CONNECTOR)

CAUTION:

Be sure to wear insulated gloves and protective goggles.

Pre-procedure1

(a) Check that the service plug grip is not installed.

NOTICE:

After removing the service plug grip, do not turn the ignition switch to ON (READY), unless instructed by the repair manual because this may cause a malfunction.

Procedure1

(b) Check the connections of the battery voltage sensor connectors.


HINT:

[Click here](#) INFO

OK:

The connector is connected securely and there are no contact problems.

Result:



RESULT		PROCEED TO
OK		A
Not connected securely	The terminals are not damaged or corroded	B
Not connected securely	The terminals are damaged or corroded	C

Post-procedure1

(c) None

B ▶ **CONNECT SECURELY**

C ▶ **REPLACE NO. 2 HV SUPPLY STACK SUB-ASSEMBLY**

A
▼

9. CHECK FREEZE FRAME DATA

Pre-procedure1

(a) None

Procedure1

(b) Read the value of freeze frame data items "Hybrid/EV Battery Cell 25 voltage" through "Hybrid/EV Battery Cell 48 voltage" for DTC P33ED16 and make a note if the value of any is 1.6 V or less.

Powertrain > HV Battery > Trouble Codes

Post-procedure1

(c) Turn the ignition switch off.

NEXT



10. CHECK NO. 2 HV SUPPLY STACK SUB-ASSEMBLY (HYBRID BATTERY CELL 25 TO 48 VOLTAGE)

Click here [INFO](#)

RESULT	PROCEED TO
The voltage between the terminals is 1.6 V or less.	A
Other than above	B

B **REPLACE BATTERY VOLTAGE SENSOR**

A



11. CHECK BATTERY VOLTAGE SENSOR (VA25 - VA48)

Click here [INFO](#)

RESULT	PROCEED TO
The resistance between the terminals is 50 kΩ or more.	A

RESULT	PROCEED TO
Other than above	B

A ▶ REPLACE NO. 2 HV SUPPLY STACK SUB-ASSEMBLY

B



12.	REPLACE NO. 2 HV SUPPLY STACK SUB-ASSEMBLY
------------	---

HINT:

Click here [INFO](#)

NEXT ▶ REPLACE BATTERY VOLTAGE SENSOR

13.	CHECK CONNECTOR CONNECTION CONDITION (BATTERY VOLTAGE SENSOR CONNECTOR)
------------	--

CAUTION:

Be sure to wear insulated gloves and protective goggles.

Pre-procedure1

(a) Check that the service plug grip is not installed.

NOTICE:

After removing the service plug grip, do not turn the ignition switch to ON (READY), unless instructed by the repair manual because this may cause a malfunction.

Procedure1

(b) Check the connections of the battery voltage sensor connectors.


HINT:

Click here [INFO](#)

OK:

The connector is connected securely and there are no contact problems.

Result:



RESULT	PROCEED TO
OK	A

RESULT		PROCEED TO
Not connected securely	The terminals are not damaged or corroded	B
Not connected securely	The terminals are damaged or corroded	C

Post-procedure1

(c) None

B ► **CONNECT SECURELY**

C ► **REPLACE NO. 3 HV SUPPLY STACK SUB-ASSEMBLY**

A



14.	CHECK FREEZE FRAME DATA
------------	--------------------------------

Pre-procedure1

(a) None

Procedure1

(b) Read the value of freeze frame data items "Hybrid/EV Battery Cell 49 voltage" through "Hybrid/EV Battery Cell 72 voltage" for DTC P33EE16 and make a note if the value of any is 1.6 V or less.

Powertrain > HV Battery > Trouble Codes

Post-procedure1

(c) Turn the ignition switch off.

NEXT



15.	CHECK NO. 3 HV SUPPLY STACK SUB-ASSEMBLY (HYBRID BATTERY CELL 49 TO 72 VOLTAGE)
------------	--

Click here 

RESULT	PROCEED TO
The voltage between the terminals is 1.6 V or less.	A
Other than above	B

B ► REPLACE BATTERY VOLTAGE SENSOR

A



16.	CHECK BATTERY VOLTAGE SENSOR (VA49 - VA72)
------------	---

Click here [INFO](#)

RESULT	PROCEED TO
The resistance between the terminals is 50 kΩ or more.	A
Other than above	B

A ► REPLACE NO. 3 HV SUPPLY STACK SUB-ASSEMBLY

B



17.	REPLACE NO. 3 HV SUPPLY STACK SUB-ASSEMBLY
------------	---

HINT:

Click here [INFO](#)

NEXT ► REPLACE BATTERY VOLTAGE SENSOR

