


Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM100000002B6JC
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [03/2023 -]
Title: NETWORKING: CAN COMMUNICATION SYSTEM (for PHEV Model): Check Bus 2 Line; 2023 - 2024 MY Prius Prime [03/2023 -]		


[Check Bus 2 Line](#)

DESCRIPTION

SYMPTOM	TROUBLE AREA
<p>There are ECUs or sensors that display a communication stop on the bus diagnostic screen. Or, there are ECUs or sensors that display communication stop history on the "Detail" screen.</p>	<ul style="list-style-type: none"> • CAN main bus line, CAN branch line or connector • Central gateway ECU (network gateway ECU) • Battery ECU assembly • Transmission floor shift assembly • Hybrid vehicle control ECU • Inverter with converter assembly • ECM • Solar energy control ECU assembly (w/ Solar Charging System) • Plugin charge control ECU assembly • No. 5 global CAN junction connector • No. 17 global CAN junction connector

WIRING DIAGRAM





CAUTION / NOTICE / HINT

CAUTION:

When performing the confirmation driving pattern, obey all speed limits and traffic laws.

NOTICE:

- Because the order of diagnosis is important to allow correct diagnosis, make sure to begin troubleshooting using How to Proceed with Troubleshooting when CAN communication system related DTCs are output.

Click here [INFO](#)

- Before measuring the resistance of the CAN bus, turn the ignition switch off and leave the vehicle for 1 minute or more without operating the key or any switches, or opening or closing the doors. After that, disconnect the cable from the negative (-) auxiliary battery terminal and leave the vehicle for 10 minutes or more before measuring the resistance.
- After the ignition switch is turned off, there may be a waiting time before disconnecting the negative (-) auxiliary battery terminal.

Click here [INFO](#)

- When disconnecting and reconnecting the auxiliary battery.

HINT:

When disconnecting and reconnecting the auxiliary battery, there is an automatic learning function that completes learning when the respective system is used.

Click here [INFO](#)

- Some parts must be initialized and set when replacing or removing and installing parts.

Click here [INFO](#)

- After performing repairs, perform the DTC check procedure and confirm that the DTCs are not output again.

DTC check procedure: Turn the ignition switch to ON and wait for 1 minute or more. Then operate the suspected malfunctioning system and drive the vehicle at 60 km/h (37 mph) or more for 5 minutes or more.

- After the repair, perform the CAN bus check and check that all the ECUs and sensors connected to the CAN communication system are displayed as normal.

Click here [INFO](#)

- Before replacing the hybrid vehicle control ECU, refer to Registration.

Click here [INFO](#)

HINT:

- Before disconnecting related connectors for inspection, push in on each connector body to check that the connector is not loose or disconnected.
- When a connector is disconnected, check that the terminals and connector body are not cracked, deformed or corroded.

PROCEDURE**1. CHECK FOR OPEN IN CAN MAIN BUS LINES**

(a) Disconnect the cable from the negative (-) auxiliary battery terminal.

(b) Measure the resistance according to the value(s) in the table below.


Standard Resistance:



[Click Location & Routing\(K78\)](#)

[Click Connector\(K78\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K78-26 (CA4H) - K78-25 (CA4L)	Cable disconnected from negative (-) auxiliary battery terminal	Below 70 Ω



*a	Component with harness connected (Central Gateway ECU (Network Gateway ECU))
----	--

NG **GO TO STEP 62**

OK

2.	CHECK FOR SHORT IN CAN BUS LINES
-----------	---

(a) Measure the resistance according to the value(s) in the table below.


Standard Resistance:



[Click Location & Routing\(K78\)](#)

[Click Connector\(K78\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K78-26 (CA4H) - K78-25 (CA4L)	Cable disconnected from negative (-) auxiliary battery terminal	54 Ω or higher



*a	Component with harness connected (Central Gateway ECU (Network Gateway ECU))
----	--


NG **GO TO STEP 43**

OK



3. CHECK FOR SHORT TO +B IN CAN BUS LINE

(a) Measure the resistance according to the value(s) in the table below.



*1	DLC3	-	-
*a	Component with harness connected (Central Gateway ECU (Network Gateway ECU))	-	-

Standard Resistance:



- [Click Location & Routing\(K78,K8\).](#)
- [Click Connector\(K78\).](#)
- [Click Connector\(K8\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K78-26 (CA4H) - K8-16 (BAT)	Cable disconnected from negative (-) auxiliary battery terminal	6 kΩ or higher
K78-25 (CA4L) - K8-16 (BAT)		


NG **GO TO STEP 24**

OK



4. CHECK FOR SHORT TO GND IN CAN BUS LINE

(a) Measure the resistance according to the value(s) in the table below.



*1	DLC3	-	-
*a	Component with harness connected (Central Gateway ECU (Network Gateway ECU))	-	-

Standard Resistance:



[Click Location & Routing\(K78,K8\)](#)

[Click Connector\(K78\)](#)

[Click Connector\(K8\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K78-26 (CA4H) - K8-4 (CG)	Cable disconnected from negative (-) auxiliary battery terminal	200 Ω or higher
K78-25 (CA4L) - K8-4 (CG)		

OK **REPLACE CENTRAL GATEWAY ECU (NETWORK GATEWAY ECU)**

NG



5. CHECK FOR SHORT TO GND IN CAN BUS LINE (NO. 17 GLOBAL CAN JUNCTION CONNECTOR - CENTRAL GATEWAY ECU (NETWORK GATEWAY ECU))

- (a) Disconnect the R93 No. 17 global CAN junction connector.
- (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(R93,K8\).](#)

[Click Connector\(R93\).](#)

[Click Connector\(K8\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
R93-4 (CANH) - K8-4 (CG)	Cable disconnected from negative (-) auxiliary battery terminal	200 Ω or higher
R93-8 (CANL) - K8-4 (CG)		

NG **GO TO STEP 10**

OK



6.	CHECK FOR SHORT TO GND IN CAN BUS LINE (NO. 17 GLOBAL CAN JUNCTION CONNECTOR - BATTERY ECU ASSEMBLY)
-----------	---

- (a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(R93,K8\).](#)

[Click Connector\(R93\).](#)

[Click Connector\(K8\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
R93-3 (CANH) - K8-4 (CG)	Cable disconnected from negative (-) auxiliary battery terminal	200 Ω or higher
R93-7 (CANL) - K8-4 (CG)		

NG **GO TO STEP 13**

OK



7.	CHECK VEHICLE TYPE
-----------	---------------------------

(a) Check vehicle type.

RESULT	PROCEED TO
w/ Solar Charging System	A
w/o Solar Charging System	B

B **GO TO STEP 9**

A

8.	CHECK FOR SHORT TO GND IN CAN BUS LINE (NO. 17 GLOBAL CAN JUNCTION CONNECTOR - SOLAR ENERGY CONTROL ECU ASSEMBLY)
-----------	--

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(R93,K8\).](#)

[Click Connector\(R93\).](#)

[Click Connector\(K8\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
R93-1 (CANH) - K8-4 (CG)	Cable disconnected from negative (-) auxiliary battery terminal	200 Ω or higher
R93-5 (CANL) - K8-4 (CG)		

NG **GO TO STEP 11**

OK

9.	CHECK FOR SHORT TO GND IN CAN BUS LINE (NO. 17 GLOBAL CAN JUNCTION CONNECTOR - PLUGIN CHARGE CONTROL ECU ASSEMBLY)
-----------	---

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(R93,K8\).](#)

[Click Connector\(R93\).](#)

[Click Connector\(K8\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
R93-2 (CANH) - K8-4 (CG)	Cable disconnected from negative (-) auxiliary battery terminal	200 Ω or higher
R93-6 (CANL) - K8-4 (CG)		

OK ► REPLACE NO. 17 GLOBAL CAN JUNCTION CONNECTOR

NG ► GO TO STEP 12

10.	CHECK FOR SHORT TO GND IN CAN BUS LINE (NO. 17 GLOBAL CAN JUNCTION CONNECTOR - CENTRAL GATEWAY ECU (NETWORK GATEWAY ECU))
------------	--

(a) Disconnect the K78 central gateway ECU (network gateway ECU) connector.

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(R93,K8\).](#)

[Click Connector\(R93\).](#)

[Click Connector\(K8\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
R93-4 (CANH) - K8-4 (CG)	Cable disconnected from negative (-) auxiliary battery terminal	200 Ω or higher
R93-8 (CANL) - K8-4 (CG)		

OK ► REPLACE CENTRAL GATEWAY ECU (NETWORK GATEWAY ECU)

NG ► REPAIR OR REPLACE CAN MAIN BUS LINE OR CONNECTOR (NO. 17 GLOBAL CAN JUNCTION CONNECTOR - CENTRAL GATEWAY ECU (NETWORK GATEWAY ECU))

11.	CHECK FOR SHORT TO GND IN CAN BUS LINE (NO. 17 GLOBAL CAN JUNCTION CONNECTOR - SOLAR ENERGY CONTROL ECU ASSEMBLY)
------------	--

- (a) Disconnect the R79 solar energy control ECU assembly connector.
- (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(R93,K8\)](#)

[Click Connector\(R93\)](#)

[Click Connector\(K8\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
R93-1 (CANH) - K8-4 (CG)	Cable disconnected from negative (-) auxiliary battery terminal	200 Ω or higher
R93-5 (CANL) - K8-4 (CG)		

OK ► REPLACE SOLAR ENERGY CONTROL ECU ASSEMBLY

NG ► REPAIR OR REPLACE CAN BRANCH LINE OR CONNECTOR (NO. 17 GLOBAL CAN JUNCTION CONNECTOR - SOLAR ENERGY CONTROL ECU ASSEMBLY)

12.	CHECK FOR SHORT TO GND IN CAN BUS LINE (NO. 17 GLOBAL CAN JUNCTION CONNECTOR - PLUGIN CHARGE CONTROL ECU ASSEMBLY)
------------	---

- (a) Disconnect the R62 plugin charge control ECU assembly connector.
- (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(R93,K8\)](#)

[Click Connector\(R93\)](#)

[Click Connector\(K8\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
R93-2 (CANH) - K8-4 (CG)	Cable disconnected from negative (-) auxiliary battery terminal	200 Ω or higher
R93-6 (CANL) - K8-4 (CG)		

OK ► REPLACE PLUGIN CHARGE CONTROL ECU ASSEMBLY

NG ► REPAIR OR REPLACE CAN BRANCH LINE OR CONNECTOR (NO. 17 GLOBAL CAN JUNCTION CONNECTOR - PLUGIN CHARGE CONTROL ECU ASSEMBLY)

13.	CHECK FOR SHORT TO GND IN CAN BUS LINE (BATTERY ECU ASSEMBLY - NO. 17 GLOBAL CAN JUNCTION CONNECTOR)
------------	---

- (a) Disconnect the x3 battery ECU assembly connector.
- (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



- [Click Location & Routing\(x3,K8\).](#)
- [Click Connector\(x3\).](#)
- [Click Connector\(K8\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
x3-10 (C2HB) - K8-4 (CG)	Cable disconnected from negative (-) auxiliary battery terminal	200 Ω or higher
x3-11 (C2LB) - K8-4 (CG)		

NG ► REPAIR OR REPLACE CAN MAIN BUS LINE OR CONNECTOR (BATTERY ECU ASSEMBLY - NO. 17 GLOBAL CAN JUNCTION CONNECTOR)

OK
▼

14.	CHECK FOR SHORT TO GND IN CAN BUS LINE (BATTERY ECU ASSEMBLY - NO. 5 GLOBAL CAN JUNCTION CONNECTOR)
------------	--

- (a) Measure the resistance according to the value(s) in the table below.
- Standard Resistance:



- [Click Location & Routing\(x3,K8\).](#)
- [Click Connector\(x3\).](#)
- [Click Connector\(K8\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
x3-12 (CA2H) - K8-4 (CG)	Cable disconnected from negative (-) auxiliary battery terminal	200 Ω or higher
x3-13 (CA2L) - K8-4 (CG)		

OK  **REPLACE BATTERY ECU ASSEMBLY**

NG



15.	CHECK FOR SHORT TO GND IN CAN BUS LINE (NO. 5 GLOBAL CAN JUNCTION CONNECTOR - BATTERY ECU ASSEMBLY)
------------	--

(a) Disconnect the K106 No. 5 global CAN junction connector.

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K106,K8\)](#)

[Click Connector\(K106\)](#)

[Click Connector\(K8\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K106-4 (CANH) - K8-4 (CG)	Cable disconnected from negative (-) auxiliary battery terminal	200 Ω or higher
K106-8 (CANL) - K8-4 (CG)		

NG  **REPAIR OR REPLACE CAN MAIN BUS LINE OR CONNECTOR (NO. 5 GLOBAL CAN JUNCTION CONNECTOR - BATTERY ECU ASSEMBLY)**

OK



16.	CHECK FOR SHORT TO GND IN CAN BUS LINE (NO. 5 GLOBAL CAN JUNCTION CONNECTOR - INVERTER WITH CONVERTER ASSEMBLY)
------------	--

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K106,K8\)](#)

[Click Connector\(K106\)](#)

[Click Connector\(K8\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K106-3 (CANH) - K8-4 (CG)	Cable disconnected from negative (-) auxiliary battery terminal	200 Ω or higher
K106-7 (CANL) - K8-4 (CG)		

NG **GO TO STEP 21**

OK



17.	CHECK FOR SHORT TO GND IN CAN BUS LINE (NO. 5 GLOBAL CAN JUNCTION CONNECTOR - HYBRID VEHICLE CONTROL ECU)
------------	--

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K106,K8\)](#)

[Click Connector\(K106\)](#)

[Click Connector\(K8\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K106-1 (CANH) - K8-4 (CG)	Cable disconnected from negative (-) auxiliary battery terminal	200 Ω or higher
K106-5 (CANL) - K8-4 (CG)		

NG **GO TO STEP 19**

OK



18.	CHECK FOR SHORT TO GND IN CAN BUS LINE (NO. 5 GLOBAL CAN JUNCTION CONNECTOR - TRANSMISSION FLOOR SHIFT ASSEMBLY)
------------	---

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K106,K8\)](#)

[Click Connector\(K106\)](#)

[Click Connector\(K8\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K106-2 (CANH) - K8-4 (CG)	Cable disconnected from negative (-) auxiliary battery terminal	200 Ω or higher
K106-6 (CANL) - K8-4 (CG)		

OK ► REPLACE NO. 5 GLOBAL CAN JUNCTION CONNECTOR

NG ► GO TO STEP 20

19.	CHECK FOR SHORT TO GND IN CAN BUS LINE (NO. 5 GLOBAL CAN JUNCTION CONNECTOR - HYBRID VEHICLE CONTROL ECU)
------------	--

(a) Disconnect the K11 hybrid vehicle control ECU connector.

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K106,K8\)](#)

[Click Connector\(K106\)](#)

[Click Connector\(K8\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K106-1 (CANH) - K8-4 (CG)	Cable disconnected from negative (-) auxiliary battery terminal	200 Ω or higher
K106-5 (CANL) - K8-4 (CG)		

OK ► REPLACE HYBRID VEHICLE CONTROL ECU

NG ► REPAIR OR REPLACE CAN BRANCH LINE OR CONNECTOR (NO. 5 GLOBAL CAN JUNCTION

CONNECTOR - HYBRID VEHICLE CONTROL ECU)

20.	CHECK FOR SHORT TO GND IN CAN BUS LINE (NO. 5 GLOBAL CAN JUNCTION CONNECTOR - TRANSMISSION FLOOR SHIFT ASSEMBLY)
------------	---

- (a) Disconnect the K53 transmission floor shift assembly connector.
- (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K106,K8\).](#)

[Click Connector\(K106\).](#)

[Click Connector\(K8\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K106-2 (CANH) - K8-4 (CG)	Cable disconnected from negative (-) auxiliary battery terminal	200 Ω or higher
K106-6 (CANL) - K8-4 (CG)		

OK ► **REPLACE TRANSMISSION FLOOR SHIFT ASSEMBLY**

NG ► **REPAIR OR REPLACE CAN BRANCH LINE OR CONNECTOR (NO. 5 GLOBAL CAN JUNCTION CONNECTOR - TRANSMISSION FLOOR SHIFT ASSEMBLY)**

21.	CHECK FOR SHORT TO GND IN CAN BUS LINE (INVERTER WITH CONVERTER ASSEMBLY - NO. 5 GLOBAL CAN JUNCTION CONNECTOR)
------------	--

- (a) Disconnect the A88 inverter with converter assembly connector.
- (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(A88,K8\).](#)

[Click Connector\(A88\).](#)

[Click Connector\(K8\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
A88-13 (CADH) - K8-4 (CG)	Cable disconnected from negative (-) auxiliary battery terminal	200 Ω or higher

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
A88-14 (CADL) - K8-4 (CG)		

NG  **REPAIR OR REPLACE CAN MAIN BUS LINE OR CONNECTOR (INVERTER WITH CONVERTER ASSEMBLY - NO. 5 GLOBAL CAN JUNCTION CONNECTOR)**

OK



22.	CHECK FOR SHORT TO GND IN CAN BUS LINE (INVERTER WITH CONVERTER ASSEMBLY - ECM)
------------	--

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(A88,K8\)](#)

[Click Connector\(A88\)](#)

[Click Connector\(K8\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
A88-5 (CANH) - K8-4 (CG)	Cable disconnected from negative (-) auxiliary battery terminal	200 Ω or higher
A88-6 (CANL) - K8-4 (CG)		

OK  **REPLACE INVERTER WITH CONVERTER ASSEMBLY**

NG



23.	CHECK FOR SHORT TO GND IN CAN BUS LINE (INVERTER WITH CONVERTER ASSEMBLY - ECM)
------------	--

(a) Disconnect the A92 ECM connector.

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(A88,K8\).](#)

[Click Connector\(A88\).](#)

[Click Connector\(K8\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
A88-5 (CANH) - K8-4 (CG)	Cable disconnected from negative (-) auxiliary battery terminal	200 Ω or higher
A88-6 (CANL) - K8-4 (CG)		

OK ► REPLACE ECM

NG ► REPAIR OR REPLACE CAN MAIN BUS LINE OR CONNECTOR (INVERTER WITH CONVERTER ASSEMBLY - ECM)

24.	CHECK FOR SHORT TO +B IN CAN BUS LINE (NO. 17 GLOBAL CAN JUNCTION CONNECTOR - CENTRAL GATEWAY ECU (NETWORK GATEWAY ECU))
------------	---

(a) Disconnect the R93 No. 17 global CAN junction connector.

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(R93,K8\).](#)

[Click Connector\(R93\).](#)

[Click Connector\(K8\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
R93-4 (CANH) - K8-16 (BAT)	Cable disconnected from negative (-) auxiliary battery terminal	6 k Ω or higher
R93-8 (CANL) - K8-16 (BAT)		

NG ► GO TO STEP 29

OK



25.	CHECK FOR SHORT TO +B IN CAN BUS LINE (NO. 17 GLOBAL CAN JUNCTION CONNECTOR - BATTERY ECU ASSEMBLY)
------------	--

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(R93,K8\).](#)

[Click Connector\(R93\).](#)

[Click Connector\(K8\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
R93-3 (CANH) - K8-16 (BAT)	Cable disconnected from negative (-) auxiliary battery terminal	6 kΩ or higher
R93-7 (CANL) - K8-16 (BAT)		

NG **GO TO STEP 32**

OK



26.	CHECK VEHICLE TYPE
------------	---------------------------

(a) Check vehicle type.

RESULT	PROCEED TO
w/ Solar Charging System	A
w/o Solar Charging System	B

B **GO TO STEP 28**

A



27.	CHECK FOR SHORT TO +B IN CAN BUS LINE (NO. 17 GLOBAL CAN JUNCTION CONNECTOR - SOLAR ENERGY CONTROL ECU ASSEMBLY)
------------	---

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(R93,K8\)](#)

[Click Connector\(R93\)](#)

[Click Connector\(K8\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
R93-1 (CANH) - K8-16 (BAT)	Cable disconnected from negative (-) auxiliary battery terminal	6 kΩ or higher
R93-5 (CANL) - K8-16 (BAT)		

NG **GO TO STEP 30**

OK



28.	CHECK FOR SHORT TO +B IN CAN BUS LINE (NO. 17 GLOBAL CAN JUNCTION CONNECTOR - PLUGIN CHARGE CONTROL ECU ASSEMBLY)
------------	--

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(R93,K8\)](#)

[Click Connector\(R93\)](#)

[Click Connector\(K8\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
R93-2 (CANH) - K8-16 (BAT)	Cable disconnected from negative (-) auxiliary battery terminal	6 kΩ or higher
R93-6 (CANL) - K8-16 (BAT)		

OK **REPLACE NO. 17 GLOBAL CAN JUNCTION CONNECTOR**

NG  **GO TO STEP 31**

29. CHECK FOR SHORT TO +B IN CAN BUS LINE (NO. 17 GLOBAL CAN JUNCTION CONNECTOR - CENTRAL GATEWAY ECU (NETWORK GATEWAY ECU))

- (a) Disconnect the K78 central gateway ECU (network gateway ECU) connector.
- (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(R93,K8\).](#)

[Click Connector\(R93\).](#)

[Click Connector\(K8\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
R93-4 (CANH) - K8-16 (BAT)	Cable disconnected from negative (-) auxiliary battery terminal	6 kΩ or higher
R93-8 (CANL) - K8-16 (BAT)		

OK  **REPLACE CENTRAL GATEWAY ECU (NETWORK GATEWAY ECU)**

NG  **REPAIR OR REPLACE CAN MAIN BUS LINE OR CONNECTOR (NO. 17 GLOBAL CAN JUNCTION CONNECTOR - CENTRAL GATEWAY ECU (NETWORK GATEWAY ECU))**

30. CHECK FOR SHORT TO +B IN CAN BUS LINE (NO. 17 GLOBAL CAN JUNCTION CONNECTOR - SOLAR ENERGY CONTROL ECU ASSEMBLY)

- (a) Disconnect the R79 solar energy control ECU assembly connector.
- (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(R93,K8\).](#)

[Click Connector\(R93\).](#)

[Click Connector\(K8\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
R93-1 (CANH) - K8-16 (BAT)	Cable disconnected from negative (-) auxiliary battery terminal	6 k Ω or higher
R93-5 (CANL) - K8-16 (BAT)		

OK ► REPLACE SOLAR ENERGY CONTROL ECU ASSEMBLY

NG ► REPAIR OR REPLACE CAN BRANCH LINE OR CONNECTOR (NO. 17 GLOBAL CAN JUNCTION CONNECTOR - SOLAR ENERGY CONTROL ECU ASSEMBLY)

31.	CHECK FOR SHORT TO +B IN CAN BUS LINE (NO. 17 GLOBAL CAN JUNCTION CONNECTOR - PLUGIN CHARGE CONTROL ECU ASSEMBLY)
------------	--

(a) Disconnect the R62 plugin charge control ECU assembly connector.

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(R93,K8\)](#)

[Click Connector\(R93\)](#)

[Click Connector\(K8\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
R93-2 (CANH) - K8-16 (BAT)	Cable disconnected from negative (-) auxiliary battery terminal	6 k Ω or higher
R93-6 (CANL) - K8-16 (BAT)		

OK ► REPLACE PLUGIN CHARGE CONTROL ECU ASSEMBLY

NG ► REPAIR OR REPLACE CAN BRANCH LINE OR CONNECTOR (NO. 17 GLOBAL CAN JUNCTION CONNECTOR - PLUGIN CHARGE CONTROL ECU ASSEMBLY)

32.	CHECK FOR SHORT TO +B IN CAN BUS LINE (BATTERY ECU ASSEMBLY - NO. 17 GLOBAL CAN JUNCTION CONNECTOR)
------------	--

(a) Disconnect the x3 battery ECU assembly connector.

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(x3,K8\)](#)

[Click Connector\(x3\)](#)

[Click Connector\(K8\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
x3-10 (C2HB) - K8-16 (BAT)	Cable disconnected from negative (-) auxiliary battery terminal	6 kΩ or higher
x3-11 (C2LB) - K8-16 (BAT)		

NG ► **REPAIR OR REPLACE CAN MAIN BUS LINE OR CONNECTOR (BATTERY ECU ASSEMBLY - NO. 17 GLOBAL CAN JUNCTION CONNECTOR)**

OK



33.	CHECK FOR SHORT TO +B IN CAN BUS LINE (BATTERY ECU ASSEMBLY - NO. 5 GLOBAL CAN JUNCTION CONNECTOR)
------------	---

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(x3,K8\)](#)

[Click Connector\(x3\)](#)

[Click Connector\(K8\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
x3-12 (CA2H) - K8-16 (BAT)	Cable disconnected from negative (-) auxiliary battery terminal	6 kΩ or higher
x3-13 (CA2L) - K8-16 (BAT)		

OK ► **REPLACE BATTERY ECU ASSEMBLY**

NG

**34.****CHECK FOR SHORT TO +B IN CAN BUS LINE (NO. 5 GLOBAL CAN JUNCTION CONNECTOR - BATTERY ECU ASSEMBLY)**

- (a) Disconnect the K106 No. 5 global CAN junction connector.
- (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:

[Click Location & Routing\(K106,K8\)](#)[Click Connector\(K106\)](#)[Click Connector\(K8\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K106-4 (CANH) - K8-16 (BAT)	Cable disconnected from negative (-) auxiliary battery terminal	6 kΩ or higher
K106-8 (CANL) - K8-16 (BAT)		

NG **REPAIR OR REPLACE CAN MAIN BUS LINE OR CONNECTOR (NO. 5 GLOBAL CAN JUNCTION CONNECTOR - BATTERY ECU ASSEMBLY)**

OK**35.****CHECK FOR SHORT TO +B IN CAN BUS LINE (NO. 5 GLOBAL CAN JUNCTION CONNECTOR - INVERTER WITH CONVERTER ASSEMBLY)**

- (a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:

[Click Location & Routing\(K106,K8\)](#)[Click Connector\(K106\)](#)[Click Connector\(K8\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K106-3 (CANH) - K8-16 (BAT)	Cable disconnected from negative (-) auxiliary battery terminal	6 k Ω or higher
K106-7 (CANL) - K8-16 (BAT)		

NG  **GO TO STEP 40**

OK



36.	CHECK FOR SHORT TO +B IN CAN BUS LINE (NO. 5 GLOBAL CAN JUNCTION CONNECTOR - HYBRID VEHICLE CONTROL ECU)
------------	---

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K106,K8\).](#)

[Click Connector\(K106\).](#)

[Click Connector\(K8\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K106-1 (CANH) - K8-16 (BAT)	Cable disconnected from negative (-) auxiliary battery terminal	6 k Ω or higher
K106-5 (CANL) - K8-16 (BAT)		

NG  **GO TO STEP 38**

OK



37.	CHECK FOR SHORT TO +B IN CAN BUS LINE (NO. 5 GLOBAL CAN JUNCTION CONNECTOR - TRANSMISSION FLOOR SHIFT ASSEMBLY)
------------	--

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K106,K8\)](#)

[Click Connector\(K106\)](#)

[Click Connector\(K8\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K106-2 (CANH) - K8-16 (BAT)	Cable disconnected from negative (-) auxiliary battery terminal	6 kΩ or higher
K106-6 (CANL) - K8-16 (BAT)		

OK ► REPLACE NO. 5 GLOBAL CAN JUNCTION CONNECTOR

NG ► GO TO STEP 39

38.	CHECK FOR SHORT TO +B IN CAN BUS LINE (NO. 5 GLOBAL CAN JUNCTION CONNECTOR - HYBRID VEHICLE CONTROL ECU)
------------	---

(a) Disconnect the K11 hybrid vehicle control ECU connector.

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K106,K8\)](#)

[Click Connector\(K106\)](#)

[Click Connector\(K8\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K106-1 (CANH) - K8-16 (BAT)	Cable disconnected from negative (-) auxiliary battery terminal	6 kΩ or higher
K106-5 (CANL) - K8-16 (BAT)		

OK ► REPLACE HYBRID VEHICLE CONTROL ECU

NG ► REPAIR OR REPLACE CAN BRANCH LINE OR CONNECTOR (NO. 5 GLOBAL CAN JUNCTION CONNECTOR - HYBRID VEHICLE CONTROL ECU)

39.	CHECK FOR SHORT TO +B IN CAN BUS LINE (NO. 5 GLOBAL CAN JUNCTION CONNECTOR - TRANSMISSION FLOOR SHIFT ASSEMBLY)
------------	--

- (a) Disconnect the K53 transmission floor shift assembly connector.
- (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K106,K8\).](#)

[Click Connector\(K106\).](#)

[Click Connector\(K8\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K106-2 (CANH) - K8-16 (BAT)	Cable disconnected from negative (-) auxiliary battery terminal	6 kΩ or higher
K106-6 (CANL) - K8-16 (BAT)		

OK ► REPLACE TRANSMISSION FLOOR SHIFT ASSEMBLY

NG ► REPAIR OR REPLACE CAN BRANCH LINE OR CONNECTOR (NO. 5 GLOBAL CAN JUNCTION CONNECTOR - TRANSMISSION FLOOR SHIFT ASSEMBLY)

40.	CHECK FOR SHORT TO +B IN CAN BUS LINE (INVERTER WITH CONVERTER ASSEMBLY - NO. 5 GLOBAL CAN JUNCTION CONNECTOR)
------------	---

- (a) Disconnect the A88 inverter with converter assembly connector.
- (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(A88,K8\).](#)

[Click Connector\(A88\).](#)

[Click Connector\(K8\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
A88-13 (CADH) - K8-16 (BAT)	Cable disconnected from negative (-) auxiliary battery terminal	6 kΩ or higher

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
A88-14 (CADL) - K8-16 (BAT)		

NG ▶ **REPAIR OR REPLACE CAN MAIN BUS LINE OR CONNECTOR (INVERTER WITH CONVERTER ASSEMBLY - NO. 5 GLOBAL CAN JUNCTION CONNECTOR)**

OK
▼

41.	CHECK FOR SHORT TO +B IN CAN BUS LINE (INVERTER WITH CONVERTER ASSEMBLY - ECM)
------------	---

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(A88,K8\).](#)

[Click Connector\(A88\).](#)

[Click Connector\(K8\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
A88-5 (CANH) - K8-16 (BAT)	Cable disconnected from negative (-) auxiliary battery terminal	6 kΩ or higher
A88-6 (CANL) - K8-16 (BAT)		

OK ▶ **REPLACE INVERTER WITH CONVERTER ASSEMBLY**

NG
▼

42.	CHECK FOR SHORT TO +B IN CAN BUS LINE (INVERTER WITH CONVERTER ASSEMBLY - ECM)
------------	---

(a) Disconnect the A92 ECM connector.

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(A88,K8\).](#)

[Click Connector\(A88\).](#)

[Click Connector\(K8\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
A88-5 (CANH) - K8-6 (BAT)	Cable disconnected from negative (-) auxiliary battery terminal	6 k Ω or higher
A88-6 (CANL) - K8-6 (BAT)		

OK ► REPLACE ECM

NG ► REPAIR OR REPLACE CAN MAIN BUS LINE OR CONNECTOR (INVERTER WITH CONVERTER ASSEMBLY - ECM)

43.	CHECK FOR SHORT IN CAN BUS LINES (NO. 17 GLOBAL CAN JUNCTION CONNECTOR - CENTRAL GATEWAY ECU (NETWORK GATEWAY ECU))
------------	--

(a) Disconnect the R93 No. 17 global CAN junction connector.

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(R93\).](#)

[Click Connector\(R93\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
R93-4 (CANH) - R93-8 (CANL)	Cable disconnected from negative (-) auxiliary battery terminal	108 to 132 Ω

NG ► GO TO STEP 48

OK



44.	CHECK FOR SHORT IN CAN BUS LINES (NO. 17 GLOBAL CAN JUNCTION CONNECTOR - BATTERY ECU ASSEMBLY)
------------	---

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(R93\)](#)

[Click Connector\(R93\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
R93-3 (CANH) - R93-7 (CANL)	Cable disconnected from negative (-) auxiliary battery terminal	108 to 132 Ω

NG **GO TO STEP 51**

OK



45.	CHECK VEHICLE TYPE
------------	---------------------------

(a) Check vehicle type.

RESULT	PROCEED TO
w/ Solar Charging System	A
w/o Solar Charging System	B

B **GO TO STEP 47**

A



46.	CHECK FOR SHORT IN CAN BUS LINES (NO. 17 GLOBAL CAN JUNCTION CONNECTOR - SOLAR ENERGY CONTROL ECU ASSEMBLY)
------------	--

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(R93\)](#)

[Click Connector\(R93\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
R93-1 (CANH) - R93-5 (CANL)	Cable disconnected from negative (-) auxiliary battery terminal	200 Ω or higher

NG  **GO TO STEP 49**

OK



47.	CHECK FOR SHORT IN CAN BUS LINES (NO. 17 GLOBAL CAN JUNCTION CONNECTOR - PLUGIN CHARGE CONTROL ECU ASSEMBLY)
------------	---

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(R93\)](#)

[Click Connector\(R93\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
R93-2 (CANH) - R93-6 (CANL)	Cable disconnected from negative (-) auxiliary battery terminal	200 Ω or higher

OK  **REPLACE NO. 17 GLOBAL CAN JUNCTION CONNECTOR**

NG  **GO TO STEP 50**

48.	CHECK FOR SHORT IN CAN BUS LINES (NO. 17 GLOBAL CAN JUNCTION CONNECTOR - CENTRAL GATEWAY ECU (NETWORK GATEWAY ECU))
------------	--

(a) Disconnect the K78 central gateway ECU (network gateway ECU) connector.

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(R93\)](#)

[Click Connector\(R93\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
R93-4 (CANH) - R93-8 (CANL)	Cable disconnected from negative (-) auxiliary battery terminal	1 MΩ or higher

OK ► **REPLACE CENTRAL GATEWAY ECU (NETWORK GATEWAY ECU)**

NG ► **REPAIR OR REPLACE CAN MAIN BUS LINES OR CONNECTOR (NO. 17 GLOBAL CAN JUNCTION CONNECTOR - CENTRAL GATEWAY ECU (NETWORK GATEWAY ECU))**

49.	CHECK FOR SHORT IN CAN BUS LINES (NO. 17 GLOBAL CAN JUNCTION CONNECTOR - SOLAR ENERGY CONTROL ECU ASSEMBLY)
------------	--

(a) Disconnect the R79 solar energy control ECU assembly connector.

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(R93\)](#)

[Click Connector\(R93\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
R93-1 (CANH) - R93-5 (CANL)	Cable disconnected from negative (-) auxiliary battery terminal	1 MΩ or higher

OK ► **REPLACE SOLAR ENERGY CONTROL ECU ASSEMBLY**

NG ► **REPAIR OR REPLACE CAN BRANCH LINES OR CONNECTOR (NO. 17 GLOBAL CAN JUNCTION CONNECTOR - SOLAR ENERGY CONTROL ECU ASSEMBLY)**

50.	CHECK FOR SHORT IN CAN BUS LINES (NO. 17 GLOBAL CAN JUNCTION CONNECTOR - PLUGIN CHARGE CONTROL ECU ASSEMBLY)
------------	---

(a) Disconnect the R62 plugin charge control ECU assembly connector.

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(R93\).](#)

[Click Connector\(R93\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
R93-2 (CANH) - R93-6 (CANL)	Cable disconnected from negative (-) auxiliary battery terminal	1 MΩ or higher

OK ► REPLACE PLUGIN CHARGE CONTROL ECU ASSEMBLY

NG ► REPAIR OR REPLACE CAN BRANCH LINES OR CONNECTOR (NO. 17 GLOBAL CAN JUNCTION CONNECTOR - PLUGIN CHARGE CONTROL ECU ASSEMBLY)

51.	CHECK FOR SHORT IN CAN BUS LINES (BATTERY ECU ASSEMBLY - NO. 17 GLOBAL CAN JUNCTION CONNECTOR)
------------	---

- (a) Reconnect the R93 No. 17 global CAN junction connector.
- (b) Disconnect the x3 battery ECU assembly connector.
- (c) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(x3\).](#)

[Click Connector\(x3\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
x3-10 (C2HB) - x3-11 (C2LB)	Cable disconnected from negative (-) auxiliary battery terminal	108 to 132 Ω

NG ► REPAIR OR REPLACE CAN MAIN BUS LINES OR CONNECTOR (BATTERY ECU ASSEMBLY - NO. 17 GLOBAL CAN JUNCTION CONNECTOR)



52.

CHECK FOR SHORT IN CAN BUS LINES (BATTERY ECU ASSEMBLY - NO. 5 GLOBAL CAN JUNCTION CONNECTOR)

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:

[Click Location & Routing\(x3\)](#)[Click Connector\(x3\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
x3-12 (CA2H) - x3-13 (CA2L)	Cable disconnected from negative (-) auxiliary battery terminal	108 to 132 Ω

OK **REPLACE BATTERY ECU ASSEMBLY****NG**

53.

CHECK FOR SHORT IN CAN BUS LINES (NO. 5 GLOBAL CAN JUNCTION CONNECTOR - BATTERY ECU ASSEMBLY)

(a) Reconnect the x3 battery ECU assembly connector.

(b) Disconnect the K106 No. 5 global CAN junction connector.

(c) Measure the resistance according to the value(s) in the table below.

Standard Resistance:

[Click Location & Routing\(K106\)](#)[Click Connector\(K106\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K106-4 (CANH) - K106-8 (CANL)	Cable disconnected from negative (-) auxiliary battery terminal	108 to 132 Ω

NG **REPAIR OR REPLACE CAN MAIN BUS LINES OR CONNECTOR (NO. 5 GLOBAL CAN JUNCTION CONNECTOR - BATTERY ECU ASSEMBLY)**

OK**54.****CHECK FOR SHORT IN CAN BUS LINES (NO. 5 GLOBAL CAN JUNCTION CONNECTOR - INVERTER WITH CONVERTER ASSEMBLY)**

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:

[Click Location & Routing\(K106\)](#)[Click Connector\(K106\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K106-3 (CANH) - K106-7 (CANL)	Cable disconnected from negative (-) auxiliary battery terminal	108 to 132 Ω

NG **GO TO STEP 59****OK****55.****CHECK FOR SHORT IN CAN BUS LINES (NO. 5 GLOBAL CAN JUNCTION CONNECTOR - HYBRID VEHICLE CONTROL ECU)**

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:

[Click Location & Routing\(K106\)](#)[Click Connector\(K106\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K106-1 (CANH) - K106-5 (CANL)	Cable disconnected from negative (-) auxiliary battery terminal	200 Ω or higher

NG **GO TO STEP 57****OK**

**56.****CHECK FOR SHORT IN CAN BUS LINES (NO. 5 GLOBAL CAN JUNCTION CONNECTOR - TRANSMISSION FLOOR SHIFT ASSEMBLY)**

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:

[Click Location & Routing\(K106\).](#)[Click Connector\(K106\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K106-2 (CANH) - K106-6 (CANL)	Cable disconnected from negative (-) auxiliary battery terminal	200 Ω or higher

OK ► **REPLACE NO. 5 GLOBAL CAN JUNCTION CONNECTOR****NG** ► **GO TO STEP 58****57.****CHECK FOR SHORT IN CAN BUS LINES (NO. 5 GLOBAL CAN JUNCTION CONNECTOR - HYBRID VEHICLE CONTROL ECU)**

(a) Disconnect the K11 hybrid vehicle control ECU connector.

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:

[Click Location & Routing\(K106\).](#)[Click Connector\(K106\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K106-1 (CANH) - K106-5 (CANL)	Cable disconnected from negative (-) auxiliary battery terminal	1 M Ω or higher

OK ► **REPLACE HYBRID VEHICLE CONTROL ECU****NG** ► **REPAIR OR REPLACE CAN BRANCH LINES OR CONNECTOR (NO. 5 GLOBAL CAN JUNCTION CONNECTOR - HYBRID VEHICLE CONTROL ECU)**

58.	CHECK FOR SHORT IN CAN BUS LINES (NO. 5 GLOBAL CAN JUNCTION CONNECTOR - TRANSMISSION FLOOR SHIFT ASSEMBLY)
------------	---

- (a) Disconnect the K53 transmission floor shift assembly connector.
- (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K106\)](#)

[Click Connector\(K106\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K106-2 (CANH) - K106-6 (CANL)	Cable disconnected from negative (-) auxiliary battery terminal	1 MΩ or higher

OK ► REPLACE TRANSMISSION FLOOR SHIFT ASSEMBLY

NG ► REPAIR OR REPLACE CAN BRANCH LINES OR CONNECTOR (NO. 5 GLOBAL CAN JUNCTION CONNECTOR - TRANSMISSION FLOOR SHIFT ASSEMBLY)

59.	CHECK FOR SHORT IN CAN BUS LINES (INVERTER WITH CONVERTER ASSEMBLY - NO. 5 GLOBAL CAN JUNCTION CONNECTOR)
------------	--

- (a) Reconnect the K106 No. 5 global CAN junction connector.
- (b) Disconnect the A88 inverter with converter assembly connector.
- (c) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(A88\)](#)

[Click Connector\(A88\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
A88-13 (CADH) - A88-14 (CADL)	Cable disconnected from negative (-) auxiliary battery terminal	108 to 132 Ω

NG ► REPAIR OR REPLACE CAN MAIN BUS LINES OR CONNECTOR (INVERTER WITH CONVERTER)

ASSEMBLY - NO. 5 GLOBAL CAN JUNCTION CONNECTOR)

OK



60. CHECK FOR SHORT IN CAN BUS LINES (INVERTER WITH CONVERTER ASSEMBLY - ECM)

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(A88\)](#)

[Click Connector\(A88\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
A88-5 (CANH) - A88-6 (CANL)	Cable disconnected from negative (-) auxiliary battery terminal	108 to 132 Ω

OK **REPLACE INVERTER WITH CONVERTER ASSEMBLY**

NG



61. CHECK FOR SHORT IN CAN BUS LINES (INVERTER WITH CONVERTER ASSEMBLY - ECM)

(a) Disconnect the A92 ECM connector.

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(A88\)](#)

[Click Connector\(A88\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
A88-5 (CANH) - A88-6 (CANL)	Cable disconnected from negative (-) auxiliary battery terminal	1 M Ω or higher

OK ► REPLACE ECM**NG** ► REPAIR OR REPLACE CAN MAIN BUS LINES OR CONNECTOR (INVERTER WITH CONVERTER ASSEMBLY - ECM)

62.	CHECK FOR OPEN IN CAN MAIN BUS LINES (CENTRAL GATEWAY ECU (NETWORK GATEWAY ECU))
------------	---

(a) Disconnect the K78 central gateway ECU (network gateway ECU) connector.

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K78\).](#)

[Click Connector\(K78\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K78-26 (CA4H) - K78-25 (CA4L)	Cable disconnected from negative (-) auxiliary battery terminal	108 to 132 Ω

OK ► REPLACE CENTRAL GATEWAY ECU (NETWORK GATEWAY ECU)**NG**

63.	CHECK FOR OPEN IN CAN MAIN BUS LINES (NO. 17 GLOBAL CAN JUNCTION CONNECTOR - CENTRAL GATEWAY ECU (NETWORK GATEWAY ECU))
------------	--

(a) Reconnect the K78 central gateway ECU (network gateway ECU) connector.

(b) Disconnect the R93 No. 17 global CAN junction connector.

(c) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(R93\).](#)

[Click Connector\(R93\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
R93-4 (CANH) - R93-8 (CANL)	Cable disconnected from negative (-) auxiliary battery terminal	108 to 132 Ω

NG ► **REPAIR OR REPLACE CAN MAIN BUS LINES OR CONNECTOR (NO. 17 GLOBAL CAN JUNCTION CONNECTOR - CENTRAL GATEWAY ECU (NETWORK GATEWAY ECU))**

OK



64.	CHECK FOR OPEN IN CAN MAIN BUS LINES (NO. 17 GLOBAL CAN JUNCTION CONNECTOR - BATTERY ECU ASSEMBLY)
------------	---

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(R93\)](#)

[Click Connector\(R93\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
R93-3 (CANH) - R93-7 (CANL)	Cable disconnected from negative (-) auxiliary battery terminal	108 to 132 Ω

OK ► **REPLACE NO. 17 GLOBAL CAN JUNCTION CONNECTOR**

NG



65.	CHECK FOR OPEN IN CAN MAIN BUS LINES (BATTERY ECU ASSEMBLY - NO. 17 GLOBAL CAN JUNCTION CONNECTOR)
------------	---

(a) Reconnect the R93 No. 17 global CAN junction connector.

(b) Disconnect the x3 battery ECU assembly connector.

(c) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(x3\)](#)

[Click Connector\(x3\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
x3-10 (C2HB) - x3-11 (C2LB)	Cable disconnected from negative (-) auxiliary battery terminal	108 to 132 Ω

NG ► **REPAIR OR REPLACE CAN MAIN BUS LINES OR CONNECTOR (BATTERY ECU ASSEMBLY - NO. 17 GLOBAL CAN JUNCTION CONNECTOR)**

OK



66.	CHECK FOR OPEN IN CAN MAIN BUS LINES (BATTERY ECU ASSEMBLY - NO. 5 GLOBAL CAN JUNCTION CONNECTOR)
------------	--

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(x3\)](#)

[Click Connector\(x3\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
x3-12 (CA2H) - x3-13 (CA2L)	Cable disconnected from negative (-) auxiliary battery terminal	108 to 132 Ω

OK ► **REPLACE BATTERY ECU ASSEMBLY**

NG



67.	CHECK FOR OPEN IN CAN MAIN BUS LINES (NO. 5 GLOBAL CAN JUNCTION CONNECTOR - BATTERY ECU ASSEMBLY)
------------	--

(a) Reconnect the x3 battery ECU assembly connector.

(b) Disconnect the K106 No. 5 global CAN junction connector.

(c) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K106\)](#)

[Click Connector\(K106\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K106-4 (CANH) - K106-8 (CANL)	Cable disconnected from negative (-) auxiliary battery terminal	108 to 132 Ω

NG ► **REPAIR OR REPLACE CAN MAIN BUS LINES OR CONNECTOR (NO. 5 GLOBAL CAN JUNCTION CONNECTOR - BATTERY ECU ASSEMBLY)**

OK



68.	CHECK FOR OPEN IN CAN MAIN BUS LINES (NO. 5 GLOBAL CAN JUNCTION CONNECTOR - INVERTER WITH CONVERTER ASSEMBLY)
------------	--

(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K106\)](#)

[Click Connector\(K106\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K106-3 (CANH) - K106-7 (CANL)	Cable disconnected from negative (-) auxiliary battery terminal	108 to 132 Ω

OK ► **REPLACE NO. 5 GLOBAL CAN JUNCTION CONNECTOR**

NG



69.

CHECK FOR OPEN IN CAN MAIN BUS LINES (INVERTER WITH CONVERTER ASSEMBLY - NO. 5 GLOBAL CAN JUNCTION CONNECTOR)

- (a) Reconnect the K106 No. 5 global CAN junction connector.
- (b) Disconnect the A88 inverter with converter assembly connector.
- (c) Measure the resistance according to the value(s) in the table below.

Standard Resistance:


[Click Location & Routing\(A88\)](#)
[Click Connector\(A88\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
A88-13 (CADH) - A88-14 (CADL)	Cable disconnected from negative (-) auxiliary battery terminal	108 to 132 Ω

NG ► **REPAIR OR REPLACE CAN MAIN BUS LINES OR CONNECTOR (INVERTER WITH CONVERTER ASSEMBLY - NO. 5 GLOBAL CAN JUNCTION CONNECTOR)**

OK



70.

CHECK FOR OPEN IN CAN MAIN BUS LINES (INVERTER WITH CONVERTER ASSEMBLY - ECM)

- (a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:


[Click Location & Routing\(A88\)](#)
[Click Connector\(A88\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
A88-5 (CANH) - A88-6 (CANL)	Cable disconnected from negative (-) auxiliary battery terminal	108 to 132 Ω

OK ► **REPLACE INVERTER WITH CONVERTER ASSEMBLY**

NG

71.	CHECK FOR OPEN IN CAN MAIN BUS LINES (ECM)
------------	---

- (a) Reconnect the A88 inverter with converter assembly connector.
- (b) Disconnect the A92 ECM connector.
- (c) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(A92\)](#)

[Click Connector\(A92\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
A92-7 (CFDH) - A92-8 (CFDL)	Cable disconnected from negative (-) auxiliary battery terminal	108 to 132 Ω

OK **REPLACE ECM**

NG **REPAIR OR REPLACE CAN MAIN BUS LINES OR CONNECTOR (ECM - INVERTER WITH CONVERTER ASSEMBLY)**

