

<b>Last Modified:</b> 12-04-2024	6.11:8.1.0	<b>Doc ID:</b> RM100000029X6H
<b>Model Year Start:</b> 2023	<b>Model:</b> Prius Prime	<b>Prod Date Range:</b> [12/2022 - ]
<b>Title:</b> WINDOW / GLASS: POWER WINDOW CONTROL SYSTEM: B231E96; P-Door P/W Motor Component Internal Failure; 2023 - 2024 MY Prius Prius Prime [12/2022 - ]		

<b>DTC</b>	<b>B231E96</b>	<b>P-Door P/W Motor Component Internal Failure</b>
------------	----------------	--


## DESCRIPTION

The main body ECU (multiplex network body ECU) communicates with the power window regulator motor assembly RH (for front passenger door) via LIN communication.

This DTC is stored when a power window regulator motor assembly RH (for front passenger door) is malfunctioning, or the ECU built into the power window regulator motor assembly RH (for front passenger door) determines that the fully closed power window position has deviated approximately 20 mm (0.787 in.) or more from the normal position.

DTC NO.	DETECTION ITEM	DTC DETECTION CONDITION	TROUBLE AREA	DTC OUTPUT FROM	PRIORITY
B231E96	P-Door P/W Motor Component Internal Failure	<p>Either condition is met:</p> <ol style="list-style-type: none"> <li>Power window regulator motor assembly (for front passenger door) is malfunctioning</li> <li>ECU in power window regulator motor assembly (for front passenger door) determines that fully closed power window position has deviated approx. 20 mm (0.787 in.) or more from normal position</li> </ol>	<ul style="list-style-type: none"> <li>Incorrect installation of power window components</li> <li>Overheated power window regulator motor assembly RH (for front passenger door)</li> <li>Power window regulator motor assembly RH (for front passenger door)</li> <li>Wire harness or connector</li> </ul>	Main Body	A

## WIRING DIAGRAM



## CAUTION / NOTICE / HINT

### NOTICE:

- Inspect the fuses for circuits related to this system before performing the following procedure.
- If a power window regulator motor assembly RH (for front passenger door) has been replaced with a new one, initialize the power window control system.

Click here [INFO](#)

- If a power window regulator motor assembly RH (for front passenger door) and door window regulator sub-assembly have been removed and installed, or if a power window regulator motor assembly RH (for front passenger door) was reused when a door glass or door glass run was replaced, initialize the power window control system.

[Click here](#) INFO

- The power window control system uses the LIN communication system. Inspect the communication function by following How to Proceed with Troubleshooting. Troubleshoot the power window control system after confirming that the communication system is functioning properly.

[Click here](#) INFO

## PROCEDURE

<b>1.</b>	<b>CLEAR DTC</b>
-----------	------------------

(a) Clear the DTCs.

**Body Electrical > Main Body > Clear DTCs**

### NEXT



<b>2.</b>	<b>CHECK FOR DTC</b>
-----------	----------------------

(a) Check for DTCs.

**Body Electrical > Main Body > Trouble Codes**

<b>Result</b>	PROCEED TO
B231E96 is output	A
B231E96 is not output	B

**B** **USE SIMULATION METHOD TO CHECK**

A



<b>3.</b>	<b>CHECK HARNESS AND CONNECTOR (POWER WINDOW REGULATOR MOTOR ASSEMBLY RH (for Front Passenger Door) - AUXILIARY BATTERY AND BODY GROUND)</b>
-----------	--

Pre-procedure1

(a) Disconnect the N4 power window regulator motor assembly RH (for front passenger door) connector.

Procedure1

(b) Measure the voltage and resistance according to the value(s) in the table below.

Standard Voltage:



[Click Location & Routing\(N4\)](#)

[Click Connector\(N4\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION	RESULT
N4-2 (B) - Body ground	Ignition switch off	11 to 14 V	V

Standard Resistance:



[Click Location & Routing\(N4\)](#)

[Click Connector\(N4\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION	RESULT
N4-1 (GND) - Body ground	Always	Below 1 $\Omega$	$\Omega$

Post-procedure1

(c) None

**NG** **REPAIR OR REPLACE HARNESS OR CONNECTOR**

**OK**



<b>4.</b>	<b>PERFORM ACTIVE TEST USING GTS</b>
-----------	--------------------------------------

(a) Perform the Active Test according to the display on the GTS.

**Body Electrical > Main Body > Active Test**

TESTER DISPLAY	MEASUREMENT ITEM	CONTROL RANGE	DIAGNOSTIC NOTE
P Door Power Window UP	Front passenger door power window up activate	OFF/ON	-
P Door Power Window DOWN	Front passenger door power window down activate	OFF/ON	-

**Body Electrical > Main Body > Active Test**

TESTER DISPLAY
P Door Power Window UP

**Body Electrical > Main Body > Active Test**

TESTER DISPLAY
P Door Power Window DOWN

**HINT:**

Up and down movement does not occur if the arrow is not pressed and held.

OK:

Front passenger door power window operates normally.

**NG**  **REPLACE POWER WINDOW REGULATOR MOTOR ASSEMBLY RH (for Front Passenger Door)** 

**OK**

<b>5.</b>	<b>PERFORM INITIALIZATION</b>
-----------	-------------------------------

(a) Initialize the power window regulator motor assembly RH (for front passenger door).

Click here 

**NEXT**

<b>6.</b>	<b>CHECK POWER WINDOW CONTROL SYSTEM</b>
-----------	--

(a) Check that the front passenger door power window operates normally by opening and closing it.

**HINT:**

Click here 

OK:

Front passenger door power window operates normally.

**NG**  **REPLACE POWER WINDOW REGULATOR MOTOR ASSEMBLY RH (for Front Passenger Door)** 

**OK****7. CHECK WHETHER PARTS HAVE BEEN INSTALLED CORRECTLY**

(a) Check that the front passenger door power window components are installed correctly.

OK:

Front passenger door power window components are installed correctly.

**OK ► END (OVERHEATED POWER WINDOW REGULATOR  
MOTOR ASSEMBLY RH (for Front Passenger Door)  
WAS DEFECTIVE)**

**NG ► INSTALL PARTS CORRECTLY**

