


Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM100000029B9S
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [12/2022 -]
Title: DOOR LOCK: POWER DOOR LOCK CONTROL SYSTEM: Only Back Door cannot be Opened; 2023 - 2024 MY Prius Prius Prime [12/2022 -]		

Only Back Door cannot be Opened

DESCRIPTION

The main body ECU (multiplex network body ECU) receives signals from the back door opener switch assembly. Then, the main body ECU (multiplex network body ECU) activates the back door lock motor.

WIRING DIAGRAM



CAUTION / NOTICE / HINT

NOTICE:

- When using the GTS with the vehicle ignition switch off, connect the GTS to the DLC3 and turn a door control switch of the multiplex network master switch assembly at intervals of 1.5 seconds or less until communication between the GTS and the vehicle begins.
- Inspect the fuses for circuits related to this system before performing the following procedure.
- The power door lock control system uses the CAN communication system. Inspect the communication function by following How to Proceed with Troubleshooting. Troubleshoot the power door lock control system after confirming that the communication systems are functioning properly.

Click here [INFO](#)

- If the main body ECU (multiplex network body ECU) is replaced, refer to registration.

[Click here](#) 

PROCEDURE

1. PERFORM ACTIVE TEST USING GTS (Trunk Lid / Back Door Open)

(a) Perform the Active Test according to the display on the GTS.

Body Electrical > Main Body > Active Test

TESTER DISPLAY	MEASUREMENT ITEM	CONTROL RANGE	DIAGNOSTIC NOTE
Trunk Lid / Back Door Open	Back door lock motor	OFF or ON	-

Body Electrical > Main Body > Active Test

TESTER DISPLAY
Trunk Lid / Back Door Open

OK:

The back door lock with courtesy light switch assembly unlatches when ON is selected.

OK  **GO TO SMART KEY SYSTEM (for Entry Function)**

NG



2. INSPECT BACK DOOR LOCK WITH COURTESY LIGHT SWITCH ASSEMBLY

[Click here](#) 

NG  **REPLACE BACK DOOR LOCK WITH COURTESY LIGHT SWITCH ASSEMBLY**

OK



3. CHECK HARNESS AND CONNECTOR (BACK DOOR LOCK WITH COURTESY LIGHT SWITCH ASSEMBLY - POWER DISTRIBUTION BOX ASSEMBLY AND BODY GROUND)

- (a) Disconnect the W20 back door lock with courtesy light switch assembly connector.
- (b) Disconnect the R17 power distribution box assembly connector.
- (c) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(W20,R17\).](#)

[Click Connector\(W20\).](#)

[Click Connector\(R17\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
W20-1 (ACT+) - R17-42	Always	Below 1 Ω
W20-3 (D+) - R17-2	Always	Below 1 Ω
W20-2 (ACT-) - Body ground	Always	Below 1 Ω
W20-1 (ACT+) or R17-42 - Other terminals and body ground	Always	10 kΩ or higher
W20-3 (D+) or R17-2 - Other terminals and body ground	Always	10 kΩ or higher

NG ► REPAIR OR REPLACE HARNESS OR CONNECTOR

OK
▼

4. INSPECT POWER DISTRIBUTION BOX ASSEMBLY


- (a) Remove the power distribution box assembly.

Click here

- (b) Remove the main body ECU (multiplex network body ECU) from the power distribution box assembly.

Click here

- (c) Measure the resistance according to the value(s) in the table below.



*a	Component without harness connected	-	-
----	-------------------------------------	---	---

(Power Distribution Box Assembly)		
-----------------------------------	--	--

Standard Resistance:



[Click Location & Routing\(z1,R17\)](#)

[Click Connector\(z1\)](#)

[Click Connector\(R17\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
z1-19 (BCTY) - R17-2	Always	Below 1 Ω

Click here



5.	CHECK HARNESS AND CONNECTOR (POWER DISTRIBUTION BOX ASSEMBLY - AUXILIARY BATTERY AND BODY GROUND)
-----------	--

(a) Disconnect the power distribution box assembly connectors.

(b) Measure the voltage according to the value(s) in the table below.

Standard Voltage:



[Click Location & Routing\(A15\)](#)

[Click Connector\(A15\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
A15-1 - Body ground	Always	11 to 14 V

(c) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K20,K21\)](#)

[Click Connector\(K20\)](#)

[Click Connector\(K21\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K20-36 - Body ground	Always	Below 1 Ω

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K21-41 - Body ground	Always	Below 1 Ω

NG ▶ REPAIR OR REPLACE HARNESS OR CONNECTOR

OK



6. CHECK POWER DISTRIBUTION BOX ASSEMBLY (DOOR BACK RELAY)


(a) Remove the power distribution box assembly.

Click here [INFO](#)

(b) Remove the main body ECU (multiplex network body ECU) from the power distribution box assembly.

Click here [INFO](#)

(c) Measure the resistance according to the value(s) in the table below.



*a	Component without harness connected (Power Distribution Box Assembly)	-	-
----	--	---	---

Standard Resistance:



[Click Location & Routing\(R17\).](#)

[Click Connector\(R17\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
R17-42 - Body ground	Auxiliary battery voltage applied to terminals A15-1 and z1-5 (TR+)	10 k Ω or higher
R17-42 - Body ground	Auxiliary battery voltage not applied to terminals A15-1 and z1-5 (TR+)	Below 1 Ω

(d) Measure the voltage according to the value(s) in the table below.

Standard Voltage:



[Click Location & Routing\(R17\).](#)

[Click Connector\(R17\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
R17-42 - Auxiliary battery negative (-) terminal	Auxiliary battery voltage applied to terminals A15-1 and z1-5 (TR+)	11 to 14 V

OK **REPLACE MAIN BODY ECU (MULTIPLEX NETWORK BODY ECU)**

NG **REPLACE POWER DISTRIBUTION BOX ASSEMBLY**

