

HOW TO PROCEED WITH TROUBLESHOOTING

HINT:

*: Use the intelligent tester.

1 VEHICLE BROUGHT TO WORKSHOP

NEXT

2 CUSTOMER PROBLEM ANALYSIS

NEXT

3 CONNECT INTELLIGENT TESTER TO DLC3*

HINT:

If the display indicates a communication fault in the tester, inspect the DLC3.

NEXT

4 CHECK DTC AND FREEZE FRAME DATA*

HINT:

Record or print DTCs and freeze frame data, if necessary.

NEXT

5 CLEAR DTC AND FREEZE FRAME DATA*

NEXT

6 CONDUCT VISUAL INSPECTION

NEXT

7 SET CHECK MODE DIAGNOSIS*

NEXT

ES

8 CONFIRM PROBLEM SYMPTOMS

HINT:

If the engine does not start, first perform the "CHECK DTC" procedures and "CONDUCT BASIC INSPECTION" procedures below.

Result	Proceed to
Malfunction does not occur	A
Malfunction occurs	B

B**GO TO STEP 10****A****9 SIMULATE SYMPTOMS****NEXT****10 CHECK DTC***

Result	Proceed to
Malfunction code	A
No code	B

B**GO TO STEP 12****A****11 REFER TO DTC CHART****NEXT****GO TO STEP 14****12 CONDUCT BASIC INSPECTION**

Result	Proceed to
Malfunctioning parts not confirmed	A
Malfunctioning parts confirmed	B

B**GO TO STEP 17****A**

13 REFER TO PROBLEM SYMPTOMS TABLE

Result	Proceed to
Malfunctioning circuit confirmed	A
Malfunctioning parts confirmed	B

B  **GO TO STEP 17****A** **14 CHECK ECM POWER SOURCE CIRCUIT****ES****NEXT** **15 CONDUCT CIRCUIT INSPECTION**

Result	Proceed to
Malfunction not confirmed	A
Malfunction confirmed	B

B  **GO TO STEP 18****A** **16 CHECK FOR INTERMITTENT PROBLEMS****NEXT** **GO TO STEP 18****17 CONDUCT PARTS INSPECTION****NEXT** **18 IDENTIFY PROBLEM****NEXT** **19 ADJUST AND/OR REPAIR****NEXT** 

20	CONDUCT CONFIRMATION TEST
----	---------------------------

NEXT

END
