


DTC	P1550	Battery Current Sensor Circuit
DTC	P1551	Battery Current Sensor Circuit Low
DTC	P1552	Battery Current Sensor Circuit High


DESCRIPTION



The battery current sensor installed on the positive (+) battery terminal detects the amount of current supplied from the generator.

The battery current sensor changes current to voltage (at the positive (+) battery terminal) and sends it to the ECM. The ECM controls the voltage of the generator based on the signals from the battery current sensor.

DTC No.	DTC Detection Condition	Trouble Area
P1550	The following condition continues for 10 seconds or more with the ignition switch ON (1 trip detection logic): Difference between the maximum and minimum current values of the battery current sensor is 1 A or less	- Open or short in battery current sensor circuit - Battery current sensor assembly - ECM
P1551	Battery current sensor output value is 0.2 V or less for 0.5 seconds or more with the ignition switch ON (1 trip detection logic):	- Short in battery current sensor circuit - Battery current sensor assembly - ECM
P1552	Battery current sensor output value is 4.8 V or more for 0.5 seconds or more with the ignition switch ON (1 trip detection logic):	- Open in battery current sensor circuit - Battery current sensor assembly - ECM


WIRING DIAGRAM**ES****INSPECTION PROCEDURE****HINT:**

- If different DTCs that are related to a different system are output simultaneously while terminal E2 is used as a ground terminal, terminal E2 may be open.
- Read freeze frame data using the intelligent tester. Freeze frame data records the engine conditions when malfunctions are detected. When troubleshooting, freeze frame data can help determine if the vehicle was running or stopped, if the engine was warmed up or not, if the air-fuel ratio was lean or rich, and other data from the time the malfunction occurred.

ES

1

INSPECT BATTERY CURRENT SENSOR ASSEMBLY



- (a) Disconnect the B29 battery current sensor connector.
(b) Measure the resistance of the battery current sensor.
Standard resistance

Tester Connection	Specified Condition
2 (VC5) - 4 (E2)	3 to 10 kΩ
2 (VC5) - 3 (IB)	Below 0.5 kΩ
3 (IB) - 4 (E2)	3 to 10 kΩ

HINT:
The resistance differs according to the tester type.


NG

REPLACE BATTERY CURRENT SENSOR ASSEMBLY

OK

2

CHECK HARNESS AND CONNECTOR (BATTERY CURRENT SENSOR - ECM)



- (a) Disconnect the B29 battery current sensor connector.
(b) Disconnect the B30 ECM connectors.
(c) Measure the resistance of the wire harness side connectors.

Standard resistance (Check for open)

Tester Connection	Specified Condition
B29-3 (IB) - B30-68 (IB)	Below 1 Ω
B29-2 (VC5) - B30-69 (VCIB)	Below 1 Ω
B29-4 (E2) - B30-92 (EIB)	Below 1 Ω
B29-1 (THB) - B30-120 (THB)	Below 1 Ω

Standard resistance (Check for short)

Tester Connection	Specified Condition
B29-3 (IB) or B30-68 (IB) - Body ground	10 kΩ or higher
B29-2 (VC5) or B30-69 (VCIB) - Body ground	10 kΩ or higher
B29-1 (THB) or B30-120 (THB) - Body ground	10 kΩ or higher

NG

REPAIR OR REPLACE HARNESS AND CONNECTOR

OK

REPLACE ECM