


(b) Remove the gasket from the exhaust manifold.









INSTALLATION

- 1. INSTALL FRONT EXHAUST PIPE ASSEMBLY
 - (a) Using a vernier caliper, measure the free length of the compression spring.

Minimum length:

41.5 mm (1.634 in.)


If the length is less than the minimum, replace the compression spring.


(b) Install a new gasket by hand so that its surface is flush with the exhaust manifold.

NOTICE:

- Make sure the gasket is facing the correct direction.
- · Do not reuse the removed gasket.
- Do not push in the gasket while installing the front exhaust pipe.
- (c) Install the front exhaust pipe with the 2 compression springs and 2 bolts.

Torque: 43 N*m (438 kgf*cm, 32 ft.*lbf)







2. INSTALL CENTER EXHAUST PIPE ASSEMBLY


- (a) Install a new gasket onto the front exhaust pipe.
- (b) Connect the 3 exhaust pipe supports, and install the center exhaust pipe.
- (c) Install the 2 bolts.

Torque: 43 N*m (438 kgf*cm, 32 ft.*lbf)









Gasket A133205E01

INSTALL TAILPIPE ASSEMBLY

(a) Using a vernier caliper, measure the free length of the compression spring.

Minimum length:

38.5 mm (1.516 in.)


If the length is less than the minimum, replace the compression spring.

(b) Install a new gasket by hand so that its surface is flush with the center exhaust pipe.

NOTICE:

- Make sure the gasket is facing the correct
- Do not reuse the removed gasket.
- · Do not push in the gasket while installing the
- (c) Connect the 2 exhaust pipe supports, and install the tailpipe.
- (d) Install the 2 compression springs and 2 bolts.

Torque: 43 N*m (438 kgf*cm, 32 ft.*lbf)



- **INSTALL HEATED OXYGEN SENSOR (for Bank 1** Sensor 2) (See page EC-24)
- **CONNECT CABLE TO NEGATIVE BATTERY TERMINAL**
- **CHECK FOR EXHAUST GAS LEAKS**

If gas is leaking, tighten the areas necessary to stop the leak. Replace damaged parts as necessary.

