

HOW TO USE THIS MANUAL

GENERAL INFORMATION

1. GENERAL DESCRIPTION

- (a) This manual is written in accordance with SAE J2008.
 - (1) Diagnosis
 - (2) Removing / Installing, Replacing, Disassembling / Reassembling, Checking and Adjusting
 - (3) Final Inspection
- (b) The following procedures are omitted from this manual. However, these procedures must be performed.
 - (1) Use a jack or lift to perform operations
 - (2) Clean all removed parts
 - (3) Perform a visual check

2. INDEX


- (a) An alphabetical INDEX section is provided at the end of the manual as a reference to help you find the item to be repaired.

3. PREPARATION

- (a) Use of Special Service Tools (SST) and Special Service Materials (SSM) may be required, depending on the repair procedure. Be sure to use SST and SSM when they are required and follow the working procedure properly. A list of SST and SSM is in the "Preparation" section of this manual.

4. REPAIR PROCEDURES

- (a) A component illustration is placed under the title where necessary.
- (b) Non-reusable parts, grease application areas, precoated parts and torque specifications are noted in the component illustrations.
The following illustration is an example.



- (c) Torque specifications, grease application areas and non-reusable parts are emphasized in the procedures.

HINT:

There are cases where such information can only be explained by using an illustration. In these cases, torque, oil and other information are described in the illustration.

- (d) Only items with key points are described in the text. What to do and other details are explained using illustrations next to the text. Both the text and illustrations are accompanied by standard values and notices.

Illustration	What to do and where to do it
Task heading	What work will be performed
Explanation text	How to perform the task Also has information such as specifications and warnings, which are written in boldface text

- (e) Illustrations of similar vehicle models are sometimes used. In these cases, minor details may be different from the actual vehicle.
- (f) Procedures are presented in a step-by-step format.

5. SERVICE SPECIFICATIONS

- (a) SPECIFICATIONS are presented in boldface text throughout the manual. The specifications are also found in the "Service Specifications" section for reference.

6. TERM DEFINITIONS

CAUTION	Possibility of injury to you or other people.
NOTICE	Possibility of damage to components being repaired.
HINT	Provides additional information to help you perform repairs.

7. INTERNATIONAL SYSTEM OF UNITS

- (a) The units used in this manual comply with the International System of Units (SI UNIT) standard. Units from the metric system and the English systems are also provided.

Example:

Torque: 30 N*m (310 kgf*cm, 22 ft.*lbf)

IN

IDENTIFICATION INFORMATION

VEHICLE IDENTIFICATION AND SERIAL NUMBERS

1. VEHICLE IDENTIFICATION NUMBER


- (a) The vehicle identification number is stamped on the vehicle body and on the certification label, as shown in the illustration.

A:

Vehicle Identification Number

B:


Certification Label




2. ENGINE SERIAL NUMBER AND TRANSAXLE SERIAL NUMBER

- (a) The engine serial number is stamped on the cylinder block of the engine as shown in the illustration.

2AZ-FE:




2GR-FE:



N

D100360E02



(b) The transaxle serial number is stamped on the housing as shown in the illustration.

A:

E351E Transaxle Serial Number

B:

U250E Transaxle Serial Number

C:

U660E Transaxle Serial Number

IN


REPAIR INSTRUCTION

PRECAUTION

1. BASIC REPAIR HINT

(a) HINTS ON OPERATIONS

IN



D025016E01

1	Attire	<ul style="list-style-type: none"> • Always wear a clean uniform. • Hat and safety shoes must be worn.
2	Vehicle protection	Prepare a grille cover, fender cover, seat cover and floor mat before starting the operation.
3	Safety operation	<ul style="list-style-type: none"> • When working with 2 or more persons, be sure to check safety for one another. • When working with the engine running, make sure to provide ventilation for exhaust fumes in the workshop. • If working on high temperature, high pressure, rotating, moving, or vibrating parts, wear appropriate safety equipment and take extra care not to injure yourself or others. • When jacking up the vehicle, be sure to support the specified location with a safety stand. • When lifting up the vehicle, use appropriate safety equipment.
4	Preparation of tools and measuring gauge	Before starting operation, prepare a tool stand, SST, gauge, oil and parts for replacement.
5	Removal and installation, disassembly and assembly operations	<ul style="list-style-type: none"> • Diagnose with a thorough understanding of proper procedures and of the reported problem. • Before removing the parts, check the general condition of the assembly and for deformation and damage. • When the assembly is complicated, take notes. For example, note the total number of electrical connections, bolts, or hoses removed. Add matchmarks to insure reassembly of components in the original positions. Temporarily mark hoses and their fittings if needed. • Clean and wash the removed parts if necessary and assemble them after a thorough check.


6	Removed parts	<ul style="list-style-type: none"> Place the removed parts in a separate box to avoid mixing them up with the new parts or contaminating the new parts. For non-reusable parts such as gaskets, O-rings, and self-locking nuts, replace them with new ones as instructed in this manual. Retain the removed parts for customer inspection, if requested.
---	---------------	---

(b) JACKING UP AND SUPPORTING VEHICLE

- Care must be taken when jacking up and supporting the vehicle. Be sure to lift and support the vehicle at the proper locations.

(c) PRECOATED PARTS

- Precoated parts are bolts and nuts that are coated with a seal lock adhesive at the factory.
- If a precoated part is retightened, loosened or moved in any way, it must be recoated with the specified adhesive.
- When reusing a precoated part, clean off the old adhesive and dry the part with compressed air. Then apply new seal lock adhesive appropriate to that part.
- Some seal lock agents harden slowly. You may have to wait for the seal lock adhesive to harden.



(d) GASKETS

- When necessary, use a sealer on gaskets to prevent leaks.

(e) BOLTS, NUTS AND SCREWS

- Carefully follow all the specifications for tightening torques. Always use a torque wrench.

(f) FUSES

- When inspecting a fuse, check that the wire of the fuse is not broken.
- When replacing fuses, be sure that the new fuse has the correct amperage rating. Do not exceed the rating or use one with a lower rating.












Illustration	Symbol	Part Name	Abbreviation
<p style="text-align: center; font-size: small;">N</p>	<p style="text-align: center; font-size: small;">N</p>	FUSE	FUSE

IN









Illustration	Symbol	Part Name	Abbreviation
 <p>N</p>	 <p>N</p>	MEDIUM CURRENT FUSE	M-FUSE
 <p>N</p>	 <p>N</p>	HIGH CURRENT FUSE	H-FUSE
 <p>N</p>	 <p>N</p>	FUSIBLE LINK	FL
 <p>N</p>	 <p>N</p>	CIRCUIT BREAKER	CB

(g) CLIPS





(1) The removal and installation methods of typical clips used for vehicle body parts are shown in the table below.

HINT:

If clips are damaged during work, always replace the damaged clip with a new one.

Shape (Example)	Removal/Installation
 <p data-bbox="289 520 310 548">N</p>	<p data-bbox="833 184 1214 212">Remove clips with clip remover or pliers.</p>  <p data-bbox="971 520 992 548">N</p>
 <p data-bbox="289 898 310 926">N</p>	<p data-bbox="833 560 1317 588">Remove fasteners with clip remover or screwdriver.</p>  <p data-bbox="971 898 992 926">N</p>
 <p data-bbox="289 1276 310 1304">N</p>	<p data-bbox="833 936 1377 963">Remove clips with wide scraper to prevent panel damage.</p>  <p data-bbox="971 1276 992 1304">N</p>
 <p data-bbox="289 1644 310 1671">N</p>	<p data-bbox="833 1312 1446 1339">Remove clips by pushing center pin through and prying out shell.</p>  <p data-bbox="971 1644 992 1671">N</p>

IN





Shape (Example)	Removal/Installation
 <p data-bbox="264 510 284 535">N</p>	<p data-bbox="805 178 1372 203">Remove clips by unscrewing center pin and prying out shell.</p>  <p data-bbox="933 516 953 541">N</p>
 <p data-bbox="264 877 284 903">N</p>	<p data-bbox="805 556 1339 581">Remove clips by prying out pin and then prying out shell.</p>  <p data-bbox="933 886 953 911">N</p>



(h) CLAWS


(1) The removal and installation methods of typical claws used for vehicle body parts are shown in the table below.

HINT:

If claws are damaged during a procedure, always replace the damaged claws with a new caps or covers.


Shape (Example)	Illustration	Procedures
		<p data-bbox="1032 1268 1430 1318">1. Using a screwdriver, detach the claws and remove the cap or covers.</p>
		<p data-bbox="1032 1642 1430 1692">1. Using a screwdriver, detach the claws and remove the cap or covers.</p>

Shape (Example)	Illustration	Procedures
		<p>1. Using a screwdriver, detach the claws and remove the cap or covers.</p>



(i) REMOVAL AND INSTALLATION OF VACUUM HOSES


(1) To disconnect a vacuum hose, pull and twist from the end of the hose. Do not pull from the middle of the hose as this may damage the hose.




(2) When disconnecting vacuum hoses, use tags to identify where they should be reconnected.

(3) After completing any hose related repairs, double check that the vacuum hoses are properly connected. The label under the hood shows the proper layout.

(4) When using a vacuum gauge, never force the hose onto a connector that is too large. If a hose has been stretched, air may leak. Use a step-down adapter if necessary.



(j) TORQUE WHEN USING TORQUE WRENCH WITH EXTENSION TOOL



- (1) Use the formula below to calculate special torque values for situations where SST or an extension tool is combined with the torque wrench.

Formula:

$$T' = L2 / (L1 + L2) * T$$

T'	Reading of torque wrench {N*m (kgf*cm, ft.*lbf)}
T	Torque {N*m (kgf*cm, ft.*lbf)}
L1	Length of SST or extension tool {cm (in.)}
L2	Length of torque wrench {cm (in.)}

NOTICE:

If an extension tool or SST is combined with a torque wrench and the wrench is used to tighten to a torque specification in this manual, the actual torque will be excessive and parts will be damaged.

2. FOR VEHICLES EQUIPPED WITH SRS AIRBAG AND SEAT BELT PRETENSIONER

The CAMRY is equipped with a Supplemental Restraint System (SRS).

CAUTION:

Failure to carry out the service operations in the correct sequence could cause the SRS to unexpectedly deploy during servicing and lead to serious injury. Furthermore, if a mistake is made when servicing SRS, it is possible that the SRS may fail to operate properly. Before servicing (including removal or installation of parts, inspection or replacement), be sure to read the following section carefully.

(a) GENERAL NOTICE

- (1) As malfunctions of the SRS are difficult to confirm, the Diagnostic Trouble Codes (DTCs) become the most important source of information when troubleshooting. When troubleshooting the SRS, always check the DTCs before disconnecting the battery.

- (2) Work must be started at least 90 seconds after the ignition switch is turned off and after the cable is disconnected from the negative (-) battery terminal.

The SRS is equipped with a back-up power source. If work is started within 90 seconds after turning the ignition switch off and disconnecting the cable from the negative (-) battery terminal, the SRS may deploy.

When the cable is disconnected from the negative (-) battery terminal, clock and audio system memory is erased. Before starting work, make a note of the settings of each memory system. When work is finished, reset the clock and audio system as before.

CAUTION:

Never use a back-up power source (battery or other) to avoid erasing the system memory. The back-up power source may inadvertently power the SRS and cause it to deploy.

- (3) In minor collisions where the SRS does not deploy, the steering pad, front passenger airbag assembly, driver side knee airbag assembly, front seat side airbag assembly, curtain shield airbag assembly and front seat outer belt assembly should be inspected before further use of the vehicle.

(See page [RS-352](#) for steering pad)

(See page [RS-399](#) for front passenger airbag assembly)

(See page [RS-371](#) for driver side knee airbag assembly)


(See page [RS-432](#) for front seat side airbag assembly)

(See page [RS-426](#) for curtain shield airbag assembly)

(See page [SB-23](#) for front seat outer belt assembly)

- (4) Never use SRS parts from another vehicle. When replacing parts, use new parts.
- (5) Before repairs, remove the airbag sensor assemblies if impacts are likely to be applied to the sensor during repairs.
- (6) Never disassemble and attempt to repair all airbag sensor assemblies and all airbag assemblies.
1. Steering pad
 2. Front passenger airbag assembly
 3. Driver side knee airbag assembly
 4. Front seat side airbag assembly
 5. Curtain shield airbag assembly
 6. Front seat outer belt assembly

- (7) Replace the airbag sensor assemblies and the airbag assemblies if: 1) damage has occurred from being dropped, or 2) cracks, dents or other defects in the case, bracket or connector are present.
- (8) Do not directly expose the airbag sensor assembly or airbag assembly to hot air or flames.
- (9) Use a voltmeter/ohmmeter with high impedance (minimum=10 k Ω) for troubleshooting electrical circuits.
- (10) Information labels are attached to the SRS components. Follow the instructions on the labels.
- (11) After work on the SRS is completed, check the SRS warning light.





(b) SPIRAL CABLE

- (1) The steering wheel must be fitted correctly to the steering column with the spiral cable at the neutral position, as cable disconnection and other problems may occur. Refer to the information about correct installation of the steering wheel (See page [RS-366](#)).

(c) STEERING PAD

- (1) Always place a removed or new steering pad surface upward as shown in the illustration. Placing the horn button with the pad surface facing down could cause a serious accident if the airbag inflates. Also, do not place anything on top of the horn button.


Example:




N

D100362E02


- (2) Never measure the resistance of the airbag squib. This may cause the airbag to inflate, which could cause serious injury.




- (3) Grease or detergents of any kind should not be applied to the horn button.
 - (4) Store the horn button assembly in an area where the ambient temperature is below 93°C (200°F), the humidity is not high and there is no electrical noise.
 - (5) When using electric welding anywhere on the vehicle, disconnect the airbag ECU connectors (4 pins). These connectors contain shorting springs. This feature reduces the possibility of the airbag deploying due to current entering the squib wiring.
 - (6) When disposing of the vehicle or the horn button assembly by itself, the airbag should be deployed using SST before disposal (See page RS-352). Activate the airbag in a safe place away from electrical noise.
- (d) FRONT PASSENGER AIRBAG ASSEMBLY
- (1) Always place a removed or new front passenger airbag assembly with the pad surface facing upward as shown in the illustration. Placing the airbag assembly with the airbag inflation direction facing down could cause a serious accident if the airbag inflates.




- (2) Never measure the resistance of the airbag squib. This may cause the airbag to inflate, which could cause serious injury.




- (3) Grease or detergents of any kind should not be applied to the front passenger airbag assembly.
- (4) Store the airbag assembly in an area where the ambient temperature is below 93°C (200°F), the humidity is not high and there is no electrical noise.
- (5) When using electric welding anywhere on the vehicle, disconnect the airbag ECU connectors (4 pins). These connectors contain shorting springs. This feature reduces the possibility of the airbag deploying due to current entering the squib wiring.
- (6) When disposing of the vehicle or the airbag assembly unit by itself, the airbag should be deployed using SST before disposal (See page [RS-399](#)). Activate the airbag in a safe place away from electrical noise.
- (e) DRIVER SIDE KNEE AIRBAG ASSEMBLY
- (1) Always place a removed or new knee airbag assembly with the airbag inflation direction facing upward. Placing the airbag assembly with the airbag inflation direction facing downward could cause a serious accident if the airbag inflates.



- (2) Never measure the resistance of the airbag squib. This may cause the airbag to inflate, which could cause serious injury.




- (3) Grease or detergents of any kind should not be applied to the knee airbag assembly.
- (4) Store the knee airbag assembly where the ambient temperature is below 93°C (200°F), the humidity is not high and there is no electrical noise.
- (5) When using electric welding anywhere on the vehicle, disconnect the airbag ECU connectors (2 pins). These connectors contain shorting springs. This feature reduces the possibility of the airbag deploying due to current entering the squib wiring.
- (6) When disposing of a vehicle or knee airbag assembly unit by itself, the airbag should be inflated using SST before disposal (See page [RS-371](#)). Activate the airbag in a safe place away from electrical noise.
- (f) FRONT SEAT SIDE AIRBAG ASSEMBLY
- (1) Always place a removed or new front seat side airbag assembly with the airbag inflation direction facing up.
- (2) Never measure the resistance of the airbag squib. This may cause the airbag to inflate, which could cause serious injury.



- (3) Grease or detergents of any kind should not be applied to the front seat side airbag assembly.
- (4) Store the airbag assembly in an area where the ambient temperature is below 93°C (200°F), the humidity is not high and there is no electrical noise.

- (5) When using electric welding anywhere on the vehicle, disconnect the airbag ECU connectors (2 pins). These connectors contain shorting springs. This feature reduces the possibility of the airbag deploying due to current entering the squib wiring.
- (6) When disposing of a vehicle or the airbag assembly unit by itself, the airbag should be deployed using SST before disposal (See page [RS-432](#)). Activate the airbag in a safe place away from electrical noise.
- (g) CURTAIN SHIELD AIRBAG ASSEMBLY
 - (1) Always place a removed or new curtain shield airbag assembly in a clear plastic bag, and keep it in a safe place.


**CAUTION:**

The plastic bag is not reusable.

NOTICE:


Never disassemble the curtain shield airbag assembly.

- (2) Never measure the resistance of the airbag squib. This may cause the airbag to inflate, which could cause serious injury.




- (3) Grease or detergents of any kind should not be applied to the curtain shield airbag assembly.
- (4) Store the airbag assembly in an area where the ambient temperature is below 93°C (200°F), the humidity is not high and there is no electrical noise.

- (5) When using electric welding anywhere on the vehicle, disconnect the airbag ECU connectors (4 pins). These connectors contain shorting springs. This feature reduces the possibility of the airbag deploying due to current entering the squib wiring.
- (6) When disposing of a vehicle or the airbag assembly unit by itself, the airbag should be deployed using SST before disposal (See page [RS-426](#)). Activate the airbag in a safe place away from electrical noise.
- (h) FRONT SEAT OUTER BELT ASSEMBLY AND REAR SEAT OUTER BELT ASSEMBLY (SEAT BELT PRETENSIONER)
 - (1) Never measure the resistance of the seat outer belt. This may cause the pretensioner of the seat belt to activate, which could cause serious injury.



- (2) Never disassemble the seat outer belt.
- (3) Never install the seat outer belt on another vehicle.
- (4) Store the seat outer belt in an area where the ambient temperature is below 80°C (176°F), the humidity is not high and there is no electrical noise.
- (5) When using electric welding anywhere on the vehicle, disconnect the airbag ECU connectors (2 pins). These connectors contain shorting springs. This feature reduces the possibility of the airbag deploying due to current entering the squib wiring.
- (6) When disposing of a vehicle or the seat outer belt unit by itself, the seat outer belt should be activated before disposal (See page [SB-23](#)). Activate the seat outer belt in a safe place away from electrical noise.
- (7) As the seat outer belt is hot after being activated, allow some time for it to cool down sufficiently before disposal. Never apply water to cool down the seat outer belt.
- (8) Grease, detergents, oil or water should not be applied to the front seat outer belt.

- (i) AIRBAG SENSOR ASSEMBLY
 - (1) Never reuse an airbag sensor assembly that has been involved in a collision where the SRS has deployed.
 - (2) The connectors to the airbag sensor assembly should be connected or disconnected with the sensor placed on the floor. If the connectors are connected or disconnected while the airbag sensor assembly is not placed on the floor, the SRS may activate.
 - (3) Work must be started at least 90 seconds after the ignition switch is turned off and the cable is disconnected from the negative (-) battery terminal, even if only loosening the set bolts of the airbag sensor assembly.
- (j) WIRE HARNESS AND CONNECTOR
 - (1) The SRS wire harness is integrated with the instrument panel wire harness assembly. All the connectors in the system are a standard yellow color. If the SRS wire harness becomes disconnected or the connector becomes broken, repair or replace it.



3. ELECTRONIC CONTROL

- (a) REMOVAL AND INSTALLATION OF BATTERY TERMINAL


NOTICE:

Certain systems need to be initialized after reconnecting the cable to the negative (-) battery terminal.

- (1) Before performing electronic work, disconnect the cable from the negative (-) battery terminal to prevent component and wire damage caused by accidental short circuits.
- (2) When disconnecting the cable, turn the ignition switch and headlight dimmer switch off and loosen the cable nut completely. Perform these operations without twisting or prying the cable. Then disconnect the cable.
- (3) Clock settings, radio settings, audio system memory, DTCs and other data are erased when the cable is disconnected from the negative (-) battery terminal. Write down any necessary data before disconnecting the cable.

- (b) HANDLING OF ELECTRONIC PARTS

- (1) Do not open the cover or case of the ECU unless absolutely necessary. If the IC terminals are touched, the IC may be rendered inoperative by static electricity.
- (2) Do not pull the wires when disconnecting electronic connectors. Pull the connector itself.
- (3) Do not drop electronic components, such as sensors or relays. If they are dropped on a hard surface, they should be replaced.



- (4) When cleaning the engine with steam, protect the electronic components, air filter and emission-related components from water.
- (5) Never use an impact wrench to remove or install temperature switches or temperature sensors.
- (6) When measuring the resistance between terminals of a wire connector, insert the tester probe carefully to prevent terminals from bending.


4. REMOVAL AND INSTALLATION OF FUEL CONTROL PARTS

(a) PLACE FOR REMOVING AND INSTALLING FUEL SYSTEM PARTS

- (1) Work in a location with good air ventilation that does not have welders, grinders, drills, electric motors, stoves, or any other ignition sources.
- (2) Never work in a pit or near a pit as vaporized fuel will collect in those places.


(b) REMOVING AND INSTALLING FUEL SYSTEM PARTS

- (1) Prepare a fire extinguisher before starting the operation.
- (2) To prevent static electricity, install a ground wire to the fuel changer, vehicle and fuel tank, do not spray the surrounding area with water. Be careful when performing work in this area, as the work surface will become slippery. Do not clean up gasoline spills with water, as this may cause the gasoline to spread, and possibly create a fire hazard.
- (3) Avoid using electric motors, working lights and other electric equipments that can cause sparks or high temperatures.
- (4) Avoid using iron hammers as they may create sparks.
- (5) Dispose of fuel-contaminated cloth separately using a fire resistant container.




5. REMOVAL AND INSTALLATION OF ENGINE INTAKE PARTS

- (a) If any metal particles enter inlet system parts, this may damage the engine.
- (b) When removing and installing inlet system parts, cover the openings of the removed parts and engine openings. Use gummed tape or other suitable materials.
- (c) When installing inlet system parts, check that no metal particles have entered the engine or the installed parts.



6. HANDLING OF HOSE CLAMPS

- (a) Before removing the hose, check the clamp position so that it can be reinstalled in the same position.
- (b) Replace any deformed or dented clamps with new ones.
- (c) When reusing a hose, attach the clamp on the clamp track portion of the hose.
- (d) For a spring type clamp, you may want to spread the tabs slightly after installation by pushing in the direction of the arrows as shown in the illustration.



7. FOR VEHICLES EQUIPPED WITH MOBILE COMMUNICATION SYSTEMS

- (a) Install the antenna far away from the ECU and sensors of the vehicle electronic systems as possible.
- (b) Install an antenna feeder at least 20 cm (7.87 in.) away from the ECU and sensors of the vehicle electronic systems. For details about ECU and sensors locations, refer to the section on the applicable components.
- (c) Keep the antenna and feeder separate from other wirings as much as possible. This will prevent signals sent from the communication equipment from affecting vehicle equipment and vice-versa.
- (d) Check that the antenna and feeder are correctly adjusted.
- (e) Do not install any high-powered mobile communication system.



8. FOR VEHICLES EQUIPPED WITH TRACTION CONTROL (TRAC) AND VEHICLE STABILITY CONTROL (VSC) SYSTEMS

When testing with a 2-wheel drum tester such as a speedometer tester, a combination tester for the speedometer and brake, a chassis dynamometer, or when jacking up the front wheels and turning the wheels, perform the following procedure to enter the inspection mode and stop the TRAC and VSC systems.

- (a) Activating inspection mode (Not using the intelligent tester)

HINT:

- Perform procedures "D" to "J" within 30 seconds.
 - Perform procedures "G" and "H" within 15 seconds each.
- (1) Ensure that the ignition switch is off and the engine is stopped (Procedure "A").
 - (2) Make sure that the shift lever is in the P position (Procedure "B").
 - (3) Start the engine (Procedure "C").
 - (4) Parking Brake Lever Type:
Apply the parking brake by pulling the parking brake lever (Procedure "D").



- (5) Parking Brake Pedal Type:
Apply the parking brake by depressing the parking brake pedal (Procedure "E").
- (6) Depress and release the brake pedal twice (Procedure "F").
- (7) While holding the brake pedal down, release and apply the parking brake twice (Procedure "G").
- (8) With the parking brake applied, depress and release the brake pedal twice (Procedure "H").
- (9) without Multi-information Display:
Check that the VSC warning light and SLIP indicator light come on (Procedure "I").

HINT:


- If the VSC warning light and SLIP indicator light do not come on in procedure "I", repeat the procedures from "A" to "I".
- Turning the ignition switch off ends inspection mode.

- (10)with Multi-information Display:
Check that the "CHECK VSC SYSTEM" message appears on the multi-information display and SLIP indicator light come on (Procedure "J").

HINT:


- If the "CHECK VSC SYSTEM" message appears on the multi-information display and SLIP indicator light do not come on in procedure "J", repeat the procedures from "A" to "J".
- Turning the ignition switch off ends inspection mode.

- (b) Activating inspection mode (Using the intelligent tester)
 - (1) Ensure that the ignition switch is off and the engine is stopped (Procedure "A").
 - (2) Make sure that the shift lever is in the P position (Procedure "B").
 - (3) Connect the intelligent tester to the DLC3 (Procedure "C").
 - (4) Start the engine (Procedure "D").
 - (5) Turn the intelligent tester main switch on (Procedure "E").
 - (6) Select the following menu items: ABS/INSPECTION MODE (Procedure "F").

without Multi-information Display:

H

D100379E01

with Multi-information Display:

H

D100380E02

- (7) without Multi-information Display:
Check that the VSC warning light and SLIP indicator light come on (Procedure "G").

HINT:

- If the VSC warning light and SLIP indicator light do not come on in procedure "G", repeat the procedures from "A" to "G".
- Turning the ignition switch off ends inspection mode.

- (8) with Multi-information Display:

Check that the "CHECK VSC SYSTEM" message appears on the multi-information display and SLIP indicator light come on (Procedure "H").

HINT:

- If the "CHECK VSC SYSTEM" message appears on the multi-information display and SLIP indicator light do not come on in procedure "H", repeat the procedures from "A" to "H".
- Turning the ignition switch off ends inspection mode.

9. FOR VEHICLES EQUIPPED WITH CATALYTIC CONVERTER

CAUTION:

If a large amount of unburned gasoline or gasoline vapors flow into the converter, it may cause overheating and create a fire hazard. To prevent this, observe the following precautions.

- Use only unleaded gasoline.
- Avoid idling the engine for more than 20 minutes.
- Avoid performing unnecessary spark jump tests.
 - Perform a spark jump test only when absolutely necessary. Perform this test as rapidly as possible.
 - While testing, never race the engine.
- Avoid a prolonged engine compression measurement. Engine compression measurements must be performed as rapidly as possible.
- Do not run the engine when the fuel tank is nearly empty. This may cause the engine to misfire and create an extra load on the converter.

VEHICLE LIFT AND SUPPORT LOCATIONS

1. NOTICE ABOUT VEHICLE CONDITION WHEN JACKING UP


- (a) As a rule, the vehicle must be unloaded when jacking up. Never jack up or lift up the vehicle loaded with things of heavy weight.
- (b) When removing any parts of heavy weight like the engine and transaxle, the center of gravity of the vehicle moves. Place a balance weight so as to keep it from rolling, or hold the jacking support location using the mission jack.

2. NOTICE FOR USING 4 POST LIFT

- (a) Follow the instruction manual for a safety operation.
- (b) Do not damage tires or wheels with a free wheel beam.
- (c) Using a wheel stopper, fix the vehicle.


3. NOTICE FOR USING JACK AND SAFETY STAND

- (a) Work in the flat place using a wheel stopper at all times.
- (b) Use a safety stand with a rubber attachment, as shown in the illustration.
- (c) Support the specified location with a jack and safety stand accurately.
- (d) When jacking up the front wheels, release the parking brake and place wheel stoppers only behind the rear wheels. When jacking up the rear wheels, place wheel stoppers only in front of the front wheels.
- (e) Do not work or leave the vehicle supported only by a jack. Be sure to support the vehicle with a safety stand.
- (f) When jacking up only the front wheels or only the rear wheels, place wheel stoppers to both sides of the wheels that contact ground.



- (g) When jacking down the vehicle with its front wheels jacked up, release the parking brake and place wheel stoppers only in front of the rear wheels. When jacking down the vehicle with its rear wheels jacked up, place wheel stoppers only behind the front wheels.

IN



P

D100366E01

4. NOTICE FOR USING SWING ARM TYPE LIFT

- (a) Follow the instruction manual of the lift for a safety operation.
- (b) Use a cradle with a rubber attachment, as shown in the illustration.
- (c) Set in the vehicle so as to make its center of gravity as close as possible to the center of the lift.
- (d) Place the vehicle horizontally by adjusting the height of the cradle, and match the groove of the cradle and the safety stand support location accurately.
- (e) Be sure to lock the swing arm during the operation.
- (f) Lift the vehicle up until the tires float, and shake the vehicle to make sure that the vehicle is stable.

5. NOTICE FOR USING PLATE TYPE LIFT

- (a) Follow the instruction manual of the lift for a safety operation.
- (b) Use a plate lift attachment.
- (c) Be sure to set the vehicle to the specified position.

Right and left set position	<ul style="list-style-type: none"> • Place the vehicle over the center of the lift.
Front and rear set position	<ul style="list-style-type: none"> • Align the cushion gum ends of the plate with the attachment lower ends (A and C). • Align the attachment upper end (B) with the rocker flange front side notch.

IN

- (d) Lift the vehicle up until the tires float a bit, and shake the vehicle to make sure that the vehicle is stable.

IN

Swing Arm Type Lift:





Plate Type Lift:



CUSTOMIZE PARAMETERS

1. AIR CONDITIONING SYSTEM

HINT:

The following items can be customized.

NOTICE:

- **When the customer requests a change in a function, first make sure that the function can be customized.**
- **Be sure to make a note of the current settings before customizing.**
- **When troubleshooting a function, first make sure that the function is set to the default setting.**

AIR CONDITIONER (AUTO A/C)

DISPLAY (ITEM)	DEFAULT	CONTENTS	SETTING
SET TEMP SHIFT (Set Temperature Shift)	NORMAL	To shift the temperature against the displayed temperature	+2 C / +1 C / NORMAL / -1 C / -2 C
AIR INLET MODE (Air Inlet Mode)	AUTO	In case of turning the A/C ON when you desire to make the compartment cool down quickly, this is the function to change the mode automatically to RECIRCULATION mode	MANUAL / AUTO
COMPRESSOR MODE (Compressor Mode)	AUTO	Function to turn the A/C ON automatically by pressing the AUTO button when the blower is ON and the A/C is OFF	MANUAL / AUTO
COMPRS / DEF OPER (Compressor / Air Inlet DEF Operation)	LINK	Function to turn the A/C ON automatically linked with the FRONT DEF button when the A/C is OFF	NORMAL / LINK
EVAP CTRL (Evaporator Control)	AUTO	Function to set the evaporator control to the AUTOMATIC position (AUTO) to save power, or to the coldest position (MANUAL) to dehumidify the air and to prevent the windows from fogging up	MANUAL / AUTO
FOOT / DEF MODE (Foot / DEF auto mode)	ON	Function to turn the airflow from FOOT / DEF ON automatically when AUTO MODE is ON	OFF / ON
AUTO BLOW UP (Foot / DEF automatic blower up function)	ON	Function to change the blower level automatically when the defroster is ON	OFF / ON
AMBIENT TMP SFT (Ambient Temperature Shift)	NORMAL	Function to shift the ambient temperature against the displayed ambient temperature	+3 C / +2 C / +1 C / NORMAL / -1 C / -2 C / -3 C

2. THEFT DETERRENT SYSTEM (w/o Smart Key System)

HINT:

The following items can be customized.

NOTICE:

- **After confirming whether the items requested by the customer are applicable or not for customization, perform customizing operations.**
- **Be sure to record the current settings before customization.**
- **When troubleshooting, make sure that the item in question is not set to "OFF" as a result of customization (Example: For the system, "the wireless function does not operate", first check that the wireless function is not set to "OFF", then perform troubleshooting).**

THEFT DETERRENT SYSTEM

DISPLAY (ITEM)	DEFAULT	CONTENTS	SETTING
PASSIVE MODE (Passive Arming Mode)	OFF	PASSIVE MODE is a function that switches theft deterrent system from arming preparation state to armed state 30 seconds after key is not in the key cylinder and all doors, engine hood and luggage compartment door are closed, even if doors are not locked by wireless or door key lock operation In PASSIVE MODE, if you do not perform following operations within 14 seconds after door is opened during armed state, theft deterrent system will judge that condition as a theft and switch to alarm sounding state <ul style="list-style-type: none"> - Unlock any door by key or wireless operation - Turn the ignition switch ON - Open luggage compartment door by key or wireless operation 	ON/OFF
WARN BY HORN (Warning by horn)	ON	Function that makes vehicle horn and theft deterrent horn be able to be used as a warning device	ON/OFF
ENTRY DELAY (Entry delay time)	14 s	Function that changes entry delay time (time before warning starts) for PASSIVE MODE	0 s/14 s/30 s

3. THEFT DETERRENT SYSTEM (w/ Smart Key System)**HINT:**

The following items can be customized.

NOTICE:

- **After confirming whether the items requested by the customer are applicable or not for customization, perform customizing operations.**
- **Be sure to record the current settings before customization.**
- **When troubleshooting, make sure that the item in question is not set to "OFF" as a result of customization (Example: For the system, "the wireless function does not operate", first check that the wireless function is not set to "OFF", then perform troubleshooting).**

THEFT DETERRENT SYSTEM

DISPLAY (ITEM)	DEFAULT	CONTENTS	SETTING
PASSIVE MODE (Passive Arming Mode)	OFF	PASSIVE MODE is a function that switches theft deterrent system from arming preparation state to armed state 30 seconds after key is not in the actuation area and all doors, engine hood and luggage compartment door are closed, even if doors are not locked by wireless or door key lock operation In PASSIVE MODE, if you do not perform following operations within 14 seconds after door is opened during armed state, theft deterrent system will judge that condition as a theft and switch to alarm sounding state <ul style="list-style-type: none"> - Unlock any door by key or wireless operation - Turn the engine switch on (IG) - Open luggage compartment door by key or wireless operation 	ON/OFF
WARN BY HORN (Warning by horn)	ON	Function that makes vehicle horn and theft deterrent horn be able to be used as a warning device	ON/OFF
ENTRY DELAY (Entry delay time)	14 s	Function that changes entry delay time (time before warning starts) for PASSIVE MODE	0 s/14 s/30 s

4. LIGHTING SYSTEM**HINT:**

The followings are the possible items to be customized.

NOTICE:

- Before attempting to customize vehicle settings, confirm whether it is possible to make the change that the customer has requested.
- Be sure to record the current value before customizing.
- In case of performing the troubleshooting, pay attention because there is a possibility that the function has been disabled by customizing. (Example: In case of the symptom in which "The wireless operation does not function", check that the wireless operation has not been disabled by customizing, then perform the troubleshooting.)

IN

ILLUMINATED ENTRY:

Display	Default	Contents	Setting
LIGHTING TIME	15 s	Changes the lighting time of the interior light and ignition key cylinder light.	7.5 s / 15 s / 30 s
I/L ON / UNLOCK	ON	Lights up the interior light and ignition key cylinder light when a door is unlocked.	ON / OFF
I/L ON / ACC OFF	ON	Lights up the interior light and ignition key cylinder light when the ignition switch is turned from on (ACC) to off	ON / OFF


LIGHT CONTROL:

Display	Default	Contents	Setting
LIGHT OFF DELAY	30 s	Keeps the headlights on for a certain period of time after turning the ignition switch off and closing all the doors with the headlights on.	OFF / 30 s / 60 s / 90 s
SENSITIVITY	NORMAL	Adjusts the sensitivity of the automatic light control system. *1	LIGHT 2 / LIGHT 1 / NORMAL / DARK 1 / DARK 2
DISP EX ON SEN	NORMAL	Changes the ambient brightness level required to dim the clock display illumination. *1	LIGHT 2 / LIGHT 1 / NORMAL / DARK 1 / DARK 2
DISP EX OFF SEN	NORMAL	Changes the ambient brightness level required to cancel the dimming of the clock display illumination.	LIGHT 2 / LIGHT 1 / NORMAL / DARK 1 / DARK 2

HINT:

Sensitivity adjustment can hardly be confirmed. Check by driving the customer's vehicle.

Illustration *1



**5. POWER DOOR LOCK CONTROL SYSTEM
CUSTOMIZING FUNCTION WITH INTELLIGENT
TESTER**

HINT:

The following items can be customized.

NOTICE:

- Before attempting to customize vehicle settings, confirm whether it is possible to make the change that the customer has requested.
- Be sure to record the current settings before customizing.
- When troubleshooting, make sure that the item in question has not been disabled using the customizing function.

DOOR LOCK:

Display (Item)	Default	Contents	Setting
UNLOCK/PARK (Unlock w/ engine switch on (IG), shift P, speed 0 km/h (0 mph))	A/T: ON M/T: OFF (Cannot be changed)	Function that unlocks doors when the shift lever is moved to the P position from any other position while the ignition switch is on (IG)	ON/OFF
ALL UNLK/OPN-CL (All unlock w/ D door open-close)	A/T: OFF M/T: ON	Function that unlocks all other doors when opening driver side door within 10 seconds after turning the ignition switch off from on (IG)	ON/OFF
UNLK/KEY TWICE (Unlock w/ 2 times D key operation)	ON	<ul style="list-style-type: none"> • Function that unlocks only the driver side door when the driver side door key cylinder is turned to unlock once and unlocks all the doors when it is turned to unlock twice • In the OFF setting, turning it once unlocks all doors 	ON/OFF
AUTO LOCK/SHIFT (Auto lock/shift not P)	A/T: ON M/T: OFF (Cannot be changed)	Function that locks doors when the shift lever is moved from the P position to any other position	ON/OFF
AUTO LOCK	OFF	Function that locks doors when vehicle reaches a vehicle speed 20 km/h (13 mph)	ON/OFF

WIRELESS D LOCK:

Display (Item)	Default	Contents	Setting
AUTO LOCK DELAY	60s	Function that selects AUTO LOCK time (30 sec. or 60 sec.)	30s/60s

6. WIRELESS DOOR LOCK CONTROL SYSTEM (w/ Smart Key System)**HINT:**

The following items can be customized.

NOTICE:

- When the customer requests a change in a function, first make sure that customization of the function(s) is possible.
- Be sure to record the current settings before customizing.
- When troubleshooting a function, first make sure that the function is not set to OFF.

WIRELESS DOOR LOCK CONTROL SYSTEM

Display (item)	Default	Function	Setting
WIRELESS OPER (Wireless door lock control function)	ON	Function that turns wireless door lock function ON/OFF	ON/OFF

Display (item)	Default	Function	Setting
HAZARD ANS BACK (Hazard answer-back for wireless door lock control)	ON	<ul style="list-style-type: none"> When the doors are locked by wireless operation, the hazard warning lights flash once. When the doors are unlocked by wireless operation, the hazard warning lights flash twice. 	ON/OFF
OPEN DOOR WARN (Door ajar warning)	ON	The buzzer sounds when LOCK is pressed when any of the doors are ajar.	ON/OFF
AUTO LOCK DELAY (Auto lock time)	60 s	This function regulates the interval between unlocking and automatic relocking of doors.	30 s/60 s
UNLOCK /2OPER (Wireless unlock operated twice)	ON	This function unlocks the driver's door when the UNLOCK switch is pressed once, and unlocks all doors when pressed twice within 3 seconds. If set to OFF, pressing UNLOCK once unlocks all doors.	ON/OFF
ALARM FUNCTION (Panic function)	ON	This function operates the theft deterrent system when PANIC is pressed and held for 0.8 seconds.	ON/OFF
WIRLS BUZZ RESP (Wireless buzzer answer-back)	ON	Wireless door lock buzzer response/ON or OFF	ON/OFF
TRUNK LID OPER (Wireless trunk opener function setting)	0.6 s PR ON	This function changes operation method of transmitter to open luggage compartment door. 1 TIME: Push 1 time 2 TIMES: Push 2 times 0.6 s PR: Push 0.6 seconds OFF: Does not operate	1 TIME/2 TIMES/0.6 s PR/OFF

7. WIRELESS DOOR LOCK CONTROL SYSTEM (w/o Smart Key System)

HINT:

The following items can be customized.

NOTICE:

- When the customer requests a change in a function, first make sure that customization of the function(s) is possible.
- Be sure to record the current settings before customizing.
- When troubleshooting a function, first make sure that the function is not set to OFF.

WIRELESS DOOR LOCK CONTROL SYSTEM:

Display (item)	Default	Function	Setting
WIRELESS OPER (Wireless door lock control function)	ON	Function that turns wireless door lock function ON/OFF	ON/OFF
HAZARD ANS BACK (Hazard answer-back for wireless door lock control)	ON	<ul style="list-style-type: none"> When the doors are locked by wireless operation, the hazard warning lights flash once. When the doors are unlocked by wireless operation, the hazard warning lights flash twice. 	ON/OFF
OPEN DOOR WARN (Door ajar warning)	ON	The buzzer sounds when LOCK is pressed when any of the doors are ajar.	ON/OFF
AUTO LOCK DELAY (Auto lock time)	60 s	This function regulates the interval between unlocking and automatic relocking of doors.	30 s/60 s

Display (item)	Default	Function	Setting
UNLOCK /2OPER (Wireless unlock operated twice)	ON	This function unlocks the driver's door when the UNLOCK switch is pressed once, and unlocks all doors when pressed twice within 3 seconds. If set to OFF, pressing UNLOCK once unlocks all doors.	ON/OFF
ALARM FUNCTION (Panic function)	ON	This function operates the theft deterrent system when PANIC is pressed and held for 0.8 seconds.	ON/OFF
WIRLS BUZZ RESP (Wireless buzzer answer-back)	ON	Wireless door lock buzzer response/ON or OFF	ON/OFF
TRUNK LID OPER (Wireless trunk opener function setting)	0.6 s ON	This function changes operation method of transmitter to open luggage compartment door. 1 TIME: Push 1 time 2 TIMES: Push 2 times 0.6 s PR: Push 0.6 seconds OFF: Does not operate	1 TIME/2 TIMES/0.6 s PR/ OFF

8. SMART KEY SYSTEM (Door Lock)

(a) CUSTOMIZING FUNCTION WITH INTELLIGENT TESTER

HINT:

The items in the table below can be customized.

NOTICE:

- When the customer requests a change in a function, first make sure that the function can be customized.
- Be sure to make a note of the current setting before customizing.
- When troubleshooting a function, first make sure that the function is set to the default setting.

HINT:

The following functions' default settings are ON. Part of these functions can be customized.

SMART:

Display (Item)	Default	Contents	Setting
PARK WAIT TIME (Wait time to permit opening door after locking)	2.5s	Function that sets waiting time to permit opening door after door is locked with entry lock function.	0.5s / 1.5s / 2.5s / 5.0s
SMART UNLOCK	D_DOOR	Function that switches the entry unlock detection area.	ALL / D_DOOR
SMART IGNITION (SMART ignition available area)	ALL	Function to choose the available area for electrical key to start E/G and cancel the steering lock.	FRONT / ALL
SMART TRUNK (Luggage compartment opening operation)	ON	Function to open a luggage compartment when the driver has the electrical key and presses the luggage open button.	ON / OFF

WIRELESS DOOR LOCK:

Display (Item)	Default	Contents	Setting
ALARM FUNCTION (Panic function)	ON	Function to operate the theft deterrent system by keeping pressing the lock button of the transmitter for 2.5 seconds. If there is a panic button, press the panic button instead of the lock button.	ON / OFF

WARNING:

Display (Item)	Default	Contents	Setting
KEY LOW-BATT WRN	ON	Function to set a warning function for the time when a key battery becomes weak.	ON / OFF

(b) Entry Unlock Mode Switching Function

- (1) To change the vehicle to entry unlock mode switching function, make sure the vehicle power is off and simultaneously press and hold the electrical key's LOCK switch and another electrical key switch for 4.5 seconds. When the switches are pressed and held for 4.5seconds, the entry door unlock mode changes in the following order: driver door mode, all door mode.





NOTICE:


After pressing and holding the switches for 4.5 seconds, wait 5 seconds before performing the same procedure again.

- Driver door unlock mode:
When the driver door's touch sensor is touched, only the driver door unlocks. When another touch sensor is touched, all doors unlock.
 - All door unlock mode:
When the touch sensor is touched, all doors unlock.
- (2) The certification ECU receives this signal from the entry door control receiver and changes the smart key system to the entry unlock mode.

(3) The certification ECU sounds the buzzers of the wireless door lock buzzer and combination meter to inform the user that the mode has been switched.

IN

Mode	Wireless Door Lock Buzzer	Combination Meter		
		Multi-information Display		Buzzer
Driver Door (Default)	ON OFF  Sounds 3 times	 Displayed for 5 sec.	Passenger, rear LH and RH door "open" indication	Sounds once
All Doors (Customized)	ON OFF  Sounds 2 times	 Displayed for 5 sec.	All door "open" indication	Sounds once



N

B137954E01

HINT:

The function only changes the entry unlock mode of the smart key system. It does not switch the unlocking of the wireless door lock control.

(c) **Electrical Key Cancel**

The electrical key cancel operation disables the following functions:

- Entry Ignition
- Entry Unlock/Lock
- Entry Luggage Compartment Open
- Electrical Key Lock-in Prevention
- Warning

- Memory Call
- (1) The operation procedures are as follows:
- Precondition:
Engine switch off, driver side door closed and unlocked.
1. Unlock the driver side door once with the UNLOCK switch of the electrical key.
 2. Open the driver door within 5 seconds.
 3. Unlock the driver side door twice with the UNLOCK switch of the electrical key within 5 seconds.
 4. Repeat open → close twice for the driver door within 30 seconds, and open again.
(Driver door: Open → Close → Open → Close → Open)
 5. Unlock the driver side door twice with the UNLOCK switch of the electrical key within 5 seconds.
 6. Repeat open → close once for the driver door within 30 seconds, and open again.
(Driver door: Open → Close → Open)
 7. Close the driver door within 5 seconds.
When electrical key cancel is activated, the wireless door lock buzzer sounds twice.
To return to the original condition, perform the procedures again. When the original condition is returned, the wireless door lock buzzer sounds once.

9. KEY REMINDER WARNING SYSTEM PARAMETERS (USING INTELLIGENT TESTER)

HINT:

The following items can be customized.

NOTICE:

- **Be sure to record current values before customizing.**
- **When performing troubleshooting, be aware that the functions may be set to OFF by customizing. (Example: In case of the symptom in which "The wireless operation does not function", check that the wireless operation is not set to OFF by customizing, then perform the troubleshooting.)**

METER:

Display (Item)	Default	Contents	Setting
KEY REMND VOLUM	LARGE	Function to change volume of the key reminder warning buzzer.	LARGE/MEDIUM/SMALL
KEY REMND SOUND	NORMAL	Function to change cycle of the key reminder warning buzzer.	FAST/NORMAL/SLOW

10. METER/GAUGE SYSTEM COMBINATION METER ASSEMBLY

NOTICE:

Be sure to record the current value before customizing.

HINT:

The following items can be customized using intelligent tester.

METER:

Display (Item)	Default	Contents	Setting
KEY REMND VOLUM	LARGE	Function to change the volume of the key remind warning buzzer	LARGE, MEDIUM, SMALL
KEY REMND SOUND	NORMAL	Function to change the cycle of the key remind warning buzzer	FAST, NORMAL, SLOW
SEAT-BELT WARN	D/P ON	Function to change the setting of the seat belt buzzer.	D/P on, D ON, P on, D/P off

HINT:

This setting is only valid for the buzzer which sounds at the 5 km/h (3 mph) or more.

(a) SEAT BELT BUZZER ON/OFF SETTING
(Procedure "A")

The seat belt buzzer ON/OFF setting, which is a setting of the buzzer function of the combination meter, can disable the driver and front passenger side seat belt buzzers.

NOTICE:

- **These buzzers should be on for safe driving. Perform these procedures only if it is necessary to set the buzzer off (disabled).**
- **When either the battery cable or the combination meter connector is disconnected, these buzzers are set on (enabled).**
- **Odometer returns to 0 after starting this procedure, although it is not displayed.**

HINT:

"b-oFF" indicates that the buzzer is OFF. "b-on" indicates that the buzzer is ON. The seat belt buzzer ON/OFF setting will be finished (the odometer will display "ODO") if the ODO/TRIP switch is not operated for 10 seconds or more. In this case, perform step 11 to check that the buzzer ON/OFF setting is complete. If it is not complete, start from step 1 again.

(1) Driver and front passenger side seat belt buzzers

1. Turn the ignition switch on (IG).
2. Press the ODO/TRIP switch until the odometer displays "ODO".
3. Ignition switch off.
4. Turn the ignition switch on (IG).
5. Press the ODO/TRIP switch immediately (within 6 seconds) and hold it down for 10 seconds or more.
6. Continue holding down the ODO/TRIP switch and fasten the driver side seat belt.
7. Check that the odometer displays either "b-on" or "b-oFF".
8. Press the ODO/TRIP switch to change the display to "b-oFF".

9. Ignition switch off.
 10. Turn the ignition switch on (IG).
 11. Check that no buzzer sounds.
- (2) Front passenger side seat belt buzzer
1. Turn the ignition switch on (IG).
 2. Press the ODO/TRIP switch until the odometer displays "ODO".
 3. Ignition switch off.
 4. Turn the ignition switch on (IG).
 5. Sit in the front passenger seat. Press the ODO/TRIP switch immediately (within 6 seconds) and hold it down for 10 seconds or more.
 6. Sit in the front passenger seat. Continue holding down the ODO/TRIP switch and fasten the front passenger side seat belt.
 7. Check that the odometer displays either "b-on" or "b-oFF".
 8. Press the ODO/TRIP switch to change the display to "b-oFF".
 9. Ignition switch off.
 10. Turn the ignition switch on (IG).
 11. Check that no buzzer sounds.

HOW TO TROUBLESHOOT ECU CONTROLLED SYSTEMS

GENERAL INFORMATION

A large number of ECU controlled systems are used in the CAMRY. In general, ECU controlled systems are considered to be very intricate, requiring a high level of technical knowledge to troubleshoot. However, most problem checking procedures only involve inspecting the ECU controlled system's circuits one by one. An adequate understanding of the system and a basic knowledge of electricity is enough to perform effective troubleshooting, accurate diagnoses and necessary repairs.

FOR USING INTELLIGENT TESTER


- Before using the intelligent tester, read the tester operator's manual thoroughly.
- If the tester cannot communicate with the ECU controlled systems when the tester is connected to the DLC3 with the ignition switch on and the tester turned on, there is a problem on the vehicle side or tester side.
 - (1) If communication is normal when the tester is connected to another vehicle, inspect the diagnosis data link line (Bus (+) line) or ECU power circuit of the vehicle.
 - (2) If communication is still not possible when the tester is connected to another vehicle, the problem is probably in the tester itself. Perform the Self Test procedures outlined in the tester operator's manual.

ELECTRONIC CIRCUIT INSPECTION PROCEDURE

1. BASIC INSPECTION

(a) WHEN MEASURING RESISTANCE OF ELECTRONIC PARTS

- (1) Unless otherwise stated, all resistance measurements should be made at an ambient temperature of 20°C (68°F). Resistance measurements may be inaccurate if measured at high temperatures, i.e. immediately after the vehicle has been running. Measurements should be made after the engine has cooled down.




(b) HANDLING CONNECTORS

- (1) When disconnecting a connector, first squeeze the mating connector housing halves tightly together to release the lock, and then press the lock claw and separate the connector.
- (2) When disconnecting a connector, do not pull on the harnesses. Grasp the connector directly and separate it.
- (3) Before connecting a connector, check that there are no deformations, damage, looseness or missing terminals.
- (4) When connecting a connector, press firmly until it locks with a "click" sound.
- (5) If checking a connector with a TOYOTA electrical tester, check the connector from the backside (harness side) using a mini test lead.





NOTICE:

- **As a waterproof connector cannot be checked from the backside, check it by connecting a sub-harness.**
- **Do not damage the terminals by moving the inserted tester needle.**



(c) CHECKING CONNECTORS

- (1) Checking when a connector is disconnected: Squeeze the connector together to confirm that they are fully connected and locked.
- (2) Checking when a connector is disconnected: Check by pulling the wire harness lightly from the backside of the connector. Look for unlatched terminals, missing terminals, loose crimps or broken conductor wires. Check visually for corrosion, metallic or foreign matter and water, and bent, rusted, overheated, contaminated, or deformed terminals.



- (3) Checking the contact pressure of the terminal:
Prepare a spare male terminal. Insert it into a female terminal, and check for ample tension when inserting and after full engagement.

NOTICE:

When testing a gold-plated female terminal, always use a gold-plated male terminal.

(d) REPAIR METHOD OF CONNECTOR TERMINAL


- (1) If there is any foreign matter on the terminal, clean the contact point with compressed air or a cloth. Never rub the contact point using sandpaper as the plating may come off.
- (2) If there is abnormal contact pressure, replace the female terminal. If the male terminal is gold-plated (gold color), use a gold-plated female terminal; if it is silver-plated (silver color), use a silver-plated female terminal.
- (3) Damaged, deformed, or corroded terminals should be replaced. If the terminal does not lock into the housing, the housing may have to be replaced.

(e) HANDLING OF WIRE HARNESS

- (1) If removing a wire harness, check the wiring and clamping before proceeding so that it can be restored in the same way.
- (2) Never twist, pull or slacken the wire harness more than necessary.
- (3) The wire harness should never come into contact with a high temperature part, or rotating, moving, vibrating or sharp-edged parts. Avoid contact with panel edges, screw tips and other sharp items.
- (4) When installing parts, never pinch the wire harness.
- (5) Never cut or break the cover of the wire harness. If it is cut or broken, replace it or repair it with vinyl tape.

2. CHECK FOR OPEN CIRCUIT

- (a) For an open circuit in the wire harness in Fig. 1, the resistance or voltage, as described below.



- (b) Check the resistance.
 (1) Disconnect connectors A and C and measure the resistance between the terminals of the connectors.

Standard resistance (Fig. 2)


Tester Connection	Specified Condition
Connector A terminal 1 - Connector C terminal 1	10 kΩ or higher
Connector A terminal 2 - Connector C terminal 2	Below 1 Ω

HINT:

Measure the resistance while lightly shaking the wire harness vertically and horizontally. If the results match the examples above, an open circuit exists between terminal 1 of connector A and terminal 1 of connector C.


- (2) Disconnect connector B and measure the resistance between the terminals of the connectors.

Standard resistance (Fig. 3)



Tester Connection	Specified Condition
Connector A terminal 1 - Connector B1 terminal 1	Below 1 Ω
Connector B2 terminal 2 - Connector C terminal 2	10 kΩ or higher

If the results match the examples above, an open circuit exists between terminal 1 of connector B2 and terminal 1 of connector C.




- (c) Check the voltage.
 (1) In a circuit in which voltage is applied to the ECU connector terminal, an open circuit can be checked by conducting a voltage check. With each connector still connected, measure the voltage between the body ground and these terminals (in this order): 1) terminal 1 of connector A, 2) terminal 1 of connector B, and 3) terminal 1 of connector C.

Standard voltage (Fig. 4)

Tester Connection	Specified Condition
Connector A terminal 1 - Body ground	5 V
Connector B terminal 1 - Body ground	5 V
Connector C terminal 1 - Body ground	Below 1 V


If the results match the examples above, an open circuit exists in the wire harness between terminal 1 of connector B and terminal 1 of connector C.

IN



3. CHECK FOR SHORT CIRCUIT

(a) If the wire harness is ground shorted (Fig. 5), locate the section by conducting a resistance check with the body ground (below).



(b) Check the resistance with the body ground.
 (1) Disconnect connectors A and C and measure the resistance.

Standard resistance (Fig. 6)


Tester Connection	Specified Condition
Connector A terminal 1 - Body ground	Below 1 Ω
Connector A terminal 2 - Body ground	10 kΩ or higher

HINT:

Measure the resistance while lightly shaking the wire harness vertically and horizontally. If your results match the examples above, an open circuit exists between terminal 1 of connector A and terminal 1 of connector C.

(2) Disconnect connector B and measure the resistance.

Standard resistance (Fig. 7)



Tester Connection	Specified Condition
Connector A terminal 1 - Body ground	10 kΩ or higher
Connector B2 terminal 2 - Body ground	Below 1 Ω



If the results match the examples above, a short circuit exists between terminal 1 of connector B2 and terminal 1 of connector C.

4. CHECK AND REPLACE ECU

NOTICE:

- The connector should not be disconnected from the ECU. Perform the inspection from the backside of the connector on the wire harness side.
- When no measuring condition is specified, perform the inspection with the engine stopped and the ignition switch on.
- Check that the connectors are fully seated. Check for loose, corroded or broken wires.

IN



(a) First, check the ECU ground circuit. If it is faulty, repair it. If it is normal, the ECU could be faulty. Temporarily replace the ECU with a normally functioning one and check if the symptoms occur. If the trouble symptoms disappear, replace the original ECU.

(1) Measure the resistance between the ECU ground terminal and body ground.

Standard resistance:

Below 1 Ω

(2) Disconnect the ECU connector. Check the ground terminal on the ECU side and wire harness side for bending, corrosion or foreign matter. Lastly, check the contact pressure of the female terminals.

HOW TO PROCEED WITH TROUBLESHOOTING

1. OPERATION FLOW

HINT:

Perform troubleshooting in accordance with the procedures below. The following is an outline of basic troubleshooting procedures. Confirm the troubleshooting procedures for the circuit you are working on before beginning troubleshooting.

1 VEHICLE BROUGHT TO WORKSHOP

NEXT

2 CUSTOMER PROBLEM ANALYSIS

- (a) Ask the customer about the conditions and environment when the problem occurred.

NEXT

3 INSPECT BATTERY VOLTAGE

Standard voltage:

11 to 14 V

If the voltage is below 11 V, recharge or replace the battery before proceeding.

NEXT

4 SYMPTOM CONFIRMATION AND DTC (AND FREEZE FRAME DATA) CHECK

- (a) Visually check the wire harnesses, connectors and fuses for open and short circuits.
 (b) Warm up the engine to the normal operating temperature.
 (c) Confirm the problem symptoms and conditions, and check for DTCs

Result

Result	Proceed to
DTC is output	A
DTC is not output	B

B

Go to step 6

A

5 DTC CHART

- (a) Check the results obtained in step 4. Then find the output DTC in the DTC chart. Look at the "Trouble Area" column for a list of potentially malfunctioning circuits and/or parts.

NEXT**Go to step 7****6 PROBLEM SYMPTOMS CHART**

- (a) Check the results obtained in step 4. Then find the problem symptoms in the problem symptoms table. Look at the "Suspected Area" column for a list of potentially malfunctioning circuits and/or parts.

NEXT**7 CIRCUIT INSPECTION OR PARTS INSPECTION**

- (a) Identify the malfunctioning circuit or part.

NEXT**8 ADJUST, REPAIR OR REPLACE**

- (a) Adjust, repair or replace the malfunctioning circuit or parts.

NEXT**9 CONFIRMATION TEST**

- (a) After the adjustment, repairs or replacement, confirm that the malfunction no longer exists. If the malfunction does not reoccur, perform a confirmation test under the same conditions and in the same environment as when the malfunction occurred the first time.

NEXT**END****2. CUSTOMER PROBLEM ANALYSIS**

HINT:

- In troubleshooting, confirm that the problem symptoms have been accurately identified. Preconceptions should be discarded in order to make an accurate judgment. To clearly understand what the problem symptoms are, it is extremely important to ask the customer about the problem and the conditions at the time the malfunction occurred.
- Gather as much information as possible for reference. Past problems that seem unrelated may also help in some cases.
- The following 5 items are important points in the problem analysis:

What	Vehicle model, system name
When	Date, time, occurrence frequency
Where	Road conditions
Under what conditions?	Running conditions, driving conditions, weather conditions
How did it happen?	Problem symptoms

3. SYMPTOM CONFIRMATION AND DIAGNOSTIC TROUBLE CODE

HINT:

The diagnostic system in the CAMRY has various functions.

- The first function is the Diagnostic Trouble Code (DTC) check. A DTC is a code stored in the ECU memory whenever a malfunction in the signal circuits to the ECU occurs. In a DTC check, a previous malfunction's DTC can be checked by a technician during troubleshooting.
- Another function is the Input Signal Check, which checks if the signals from various switches are sent to the ECU correctly.

By using these functions, the problem areas can be narrowed down and troubleshooting is more effective. Diagnostic functions are incorporated in the following system in the CAMRY.

System	DTC Check (Normal Mode)	DTC Check (Check Mode)	Sensor Check/Test Mode (Input Signal Check)	Data List	Active Test
2AZ-FE SFI System	○	○		○	○
2GR-FE SFI System	○	○		○	○
Smart Key System (Starting)	○			○	○
U250E Automatic Transaxle System	○	○		○	○
U660E Automatic Transaxle System	○	○		○	○
Tire Pressure Warning System	○		○	○	
Anti-lock Brake System	○		○	○	○
Vehicle Stability Control System (for BOSCH made)	○		○	○	○

System	DTC Check (Normal Mode)	DTC Check (Check Mode)	Sensor Check/Test Mode (Input Signal Check)	Data List	Active Test
Vehicle Stability Control System (for ADVICS made)	○		○	○	○
Electric Steering Lock	○			○	○
Air Conditioning System	○			○	○
Airbag System	○	○		○	
Occupant Classification System	○			○	
Seat Belt Warning System					○
Theft Deterrent System (w/ Smart Key System)				○	○
Theft Deterrent System (w/o Smart Key System)				○	○
Engine Immobilizer System (w/ Smart Key System)	○			○	○
Engine Immobilizer System (w/o Smart Key System)	○			○	○
Cruise Control System	○			○	
Lighting System	○			○	○
Power Door Lock Control System	○			○	○
Wireless Door Lock Control System (w/ Smart Key System)	○			○	○
Wireless Door Lock Control System (w/o Smart Key System)	○			○	○
Smart Key System (Door Lock)	○			○	○
Key Reminder Warning System				○	○
Meter/Gauge System	○			○	○
Audio and Visual System	○				
Navigation System	○				
Power Window Control System	○			○	○
Window Defogger System					○
Sliding Roof System	○			○	○

IN

- In the DTC check, it is very important to determine whether the problem indicated by the DTC either: 1) still occurs, or 2) occurred in the past but has returned to normal. In addition, the DTC should be compared to the problem symptom to see if they are related. For this reason, DTCs should be checked before and after confirmation of symptoms (i.e., whether or not problem symptoms exist) to determine current system conditions, as shown in the flowchart below.
- Never skip the DTC check. Failing to check DTCs may, depending on the case, result in unnecessary troubleshooting for systems operating normally or lead to repairs not related to the problem. Follow the procedures listed in the flowchart in the correct order.
- The following flowchart shows how to proceed with troubleshooting using the DTC check. Directions from the flowchart will indicate how to proceed either to DTC troubleshooting or to the troubleshooting of each problem symptom.

1 DTC CHECK

NEXT

2 MAKE A NOTE OF DTCS DISPLAYED AND THEN CLEAR MEMORY

NEXT

3 SYMPTOM CONFIRMATION

Result

Result	Proceed to
No symptoms exist	A
Symptoms exist	B

B **Go to step 5**

A

4 SIMULATION TEST USING SYMPTOM SIMULATION METHODS

NEXT

5 DTC CHECK

Result

Result	Proceed to
DTC is not output	A

Result	Proceed to
DTC is output	B

B → **TROUBLESHOOTING OF PROBLEM INDICATED BY DTC**

A

IN

6 SYMPTOM CONFIRMATION

Result

Result	Proceed to
No symptoms exist	A
Symptoms exist	B

If a DTC was displayed in the initial DTC check, the problem may have occurred in a wire harness or connector in that circuit in the past. Check the wire harness and connectors.

B → **SYSTEM NORMAL**

A

TROUBLESHOOTING OF EACH PROBLEM SYMPTOM

The problem still occurs in a place other than the diagnostic circuit (the DTC displayed first is either for a past problem or a secondary problem).

4. SYMPTOM SIMULATION



HINT:

The most difficult case in troubleshooting is when no problem symptoms occur. In such a case, a thorough problem analysis must be carried out. A simulation of the same or similar conditions and environment in which the problem occurred in the customer's vehicle should be carried out. No matter how much skill or experience a technician has, troubleshooting without confirming the problem symptoms will lead to important repairs being overlooked and mistakes or delays.

For example:

With a problem that only occurs when the engine is cold or as a result of vibration caused by the road during driving, the problem can never be determined if the symptoms are being checked on a stationary vehicle or a vehicle with a warmed-up engine. Vibration, heat or water penetration (moisture) are difficult to reproduce. The symptom simulation tests below are effective substitutes for the conditions and can be applied to a stationary vehicle. Important points in the symptom simulation test:

In the symptom simulation test, the problem symptoms as well as the problem area or parts must be confirmed. First, narrow down the possible problem circuits according to the symptoms. Then, connect the tester and carry out the symptom simulation test, judging whether the circuit being tested is defective or normal. Also, confirm the problem symptoms at the same time. Refer to the problem symptoms table for each system to narrow down the possible causes.



(a) **VIBRATION METHOD:** When a malfunction seems to occur as a result of vibration.

(1) **PART AND SENSOR**

Apply slight vibration with a finger to the part of the sensor suspected to be the cause of the problem, and check whether the malfunction occurs.

NOTICE:

Applying strong vibration to relays may open relays.

(2) **CONNECTORS**

Slightly shake the connector vertically and horizontally.

(3) **WIRE HARNESS**

Slightly shake the wire harness vertically and horizontally.

HINT:

The connector joint and fulcrum of the vibration are the major areas that should be checked thoroughly.

(b) **HEAT METHOD:** When a malfunction seems to occur when the area in question is heated.

(1) Heat the component that is the possible cause of the malfunction with a hair dryer or similar device. Check if the malfunction occurs.

NOTICE:

- **Do not heat to more than 60°C (140°F). Exceeding this temperature may damage the components.**
- **Do not apply heat directly to the parts in the ECU.**

(c) **WATER SPRINKLING METHOD:** When a malfunction seems to occur on a rainy day or in high-humidity.


(1) Sprinkle water onto the vehicle and check if the malfunction occurs.

NOTICE:

- **Never sprinkle water directly into the engine compartment. Indirectly change the temperature and humidity by spraying water onto the front of the radiator.**
- **Never apply water directly onto the electronic components.**

HINT:

If the vehicle has or had a water leakage problem, the leakage may have damaged the ECU or connections. Look for evidence of corrosion or short circuits. Proceed with caution during water tests.



(d) **HIGH ELECTRICAL LOAD METHOD:** When a malfunction seems to occur when an electrical load is excessive.

- (1) Turn on the heater blower, headlight, rear window defogger and all other electrical loads. Check if the malfunction reoccurs.

5. DIAGNOSTIC TROUBLE CODE CHART

Look for output Diagnostic Trouble Codes (DTCs) (from the DTC checks) in the appropriate section's Diagnostic Trouble Code Chart. Use the chart to determine the trouble area and the proper inspection procedure. A description of each of the chart's columns is shown in the table below.

Item	Description
DTC No.	Indicates the diagnostic trouble code
Detection Item	Indicates the system or details of the problem
Trouble Area	Indicates the suspected areas of the problem
See Page	Indicates the page where the inspection procedures for each circuit is to be found, or gives instruction for checking and repairs.

6. PROBLEM SYMPTOMS TABLE

When a "Normal" code is output during a DTC check but the problem still occurs, use the Problem Symptoms Table. The suspected areas (circuits or parts) for each problem symptoms are in the table. The suspected areas are listed in order of probability. A description of each of the chart's columns is shown in the table below.

HINT:

In some cases, the problem is not detected by the diagnostic system even though a problem symptom occurs. It is possible that the problem occurs outside the detection range of the diagnostic system, or that the problem occurs in a completely different system.

Item	Description
Problem Symptom	-
Circuit Inspection, Inspection Order	Indicates the order in which the circuits need to be checked
Circuit or Part Name	Indicates the circuit or part which needs to be checked
See Page	Indicates the page where the flowchart for each circuit is located

7. CIRCUIT INSPECTION

A description of the main areas of each circuit inspection is shown in the table below.

Item	Description
Circuit Description	The major role, operation of the circuit and its component parts are explained.
Diagnostic Trouble Code No. and Detection Item	Indicates the diagnostic trouble codes, diagnostic trouble code settings and suspected areas for a problem

Item	Description
Wiring Diagram	<p>This shows a wiring diagram of the circuit.</p> <p>Use this diagram together with ELECTRICAL WIRING DIAGRAM to thoroughly understand the circuit.</p> <p>Wire colors are indicated by an alphabetical code. B = Black, L = Blue, R = Red, BR = Brown, LG = Light Green, V = Violet, G = Green, O = Orange, W = White, GR = Gray, P = Pink, Y = Yellow, SB = Sky Blue</p> <p>The first letter indicates the basic wire color and the second letter indicates the color of the stripe.</p>
Inspection Procedures	<p>Use the inspection procedures to determine if the circuit is normal or abnormal. If abnormal, use the inspection procedures to determine whether the problem is located in the sensors, actuators, wire harnesses or ECU.</p>
Indicates the condition of the connector of the ECU during the check	<p>Connector being checked is connected.</p> <p>Connections of tester are indicated by (+) or (-) after the terminal name.</p> <p>Connector being checked is disconnected.</p> <p>The inspections between a connector and body ground, information about the body ground is not shown in the illustration.</p>

TERMS**ABBREVIATIONS USED IN MANUAL**

Abbreviations	Meaning
ABS	Anti-Lock Brake System
A/C	Air Conditioner
AC	Alternating Current
ACC	Accessory
ACIS	Acoustic Control Induction System
ACM	Active Control Engine Mount
ACSD	Automatic Cold Start Device
A.D.D	Automatic Disconnecting Differential
A/F	Air-Fuel Ratio
AHC	Active Height Control Suspension
ALR	Automatic Locking Retractor
ALT	Alternator
AMP	Amplifier
ANT	Antenna
APPROX.	Approximately
ASSY	Assembly
A/T, ATM	Automatic Transmission (Transaxle)
ATF	Automatic Transmission Fluid
AUTO	Automatic
AUX	Auxiliary
AVG	Average
AVS	Adaptive Variable Suspension
AWD	All Wheel Drive Vehicle
B+	Battery Voltage
BA	Brake Assist
BACS	Boost Altitude Compensation System
BAT	Battery
BDC	Bottom Dead Center
B/L	Bi-Level
B/S	Bore-Stroke Ratio
BTDC	Before Top Dead Center
BVS	Bimetallic Vacuum Switching Valve
CAN	Controller Area Network
CB	Circuit Breaker
CCo	Catalytic Converter For Oxidation
CCV	Canister Closed Valve
CD	Compact Disc
CF	Cornering Force
CG	Center of Gravity
CH	Channel
CKD	Complete Knock Down
COMB.	Combination
CPE	Coupe
CPS	Combustion Pressure Sensor
CPU	Central Processing Unit
CRS	Child Restraint System

Abbreviations	Meaning
CTR	Center
C/V	Check Valve
CV	Control Valve
CW	Curb Weight
DC	Direct Current
DEF	Defogger
DFL	Deflector
DIFF.	Differential
DIFF. LOCK	Differential Lock
D/INJ	Direct Injection
DLC	Data Link Connector
DLI	Distributorless Ignition
DOHC	Double Overhead Camshaft
DP	Dash Pot
DS	Dead Soak
DSP	Digital Signal Processor
DTC	Diagnostic Trouble Code
DVD	Digital Versatile Disc
EBD	Electric Brake Force Distribution
EC	Electrochromic
ECAM	Engine Control And Measurement System
ECD	Electronically Controlled Diesel
ECDY	Eddy Current Dynamometer
ECT	Electronic Controlled Automatic Transmission
ECU	Electronic Control Unit
ED	Electro-Deposited Coating
EDU	Electronic Driving Unit
EDIC	Electric Diesel Injection Control
EFI	Electronic Fuel Injection
E/G	Engine
EGR	Exhaust Gas Recirculation
EGR-VM	EGR-Vacuum Modulator
ELR	Emergency Locking Retractor
EPS	Electric Power Steering
ENG	Engine
ES	Easy & Smooth
ESA	Electronic Spark Advance
ETCS-i	Electronic Throttle Control System-intelligent
EVAP	Evaporative Emission Control
EVP	Evaporator
E-VRV	Electric Vacuum Regulating Valve
EX	Exhaust
FE	Fuel Economy
FF	Front-Engine-Front-Wheel-Drive
F/G	Fuel Gauge
FIPG	Formed In Place Gasket
FL	Fusible Link
F/P	Fuel Pump
FPU	Fuel Pressure Up

Abbreviations	Meaning
FR	Front
F/W	Flywheel
FW/D	Flywheel Damper
FWD	Front-Wheel-Drive
GAS	Gasoline
GND	Ground
GPS	Global Positioning System
GSA	Gear Shift Actuator
HAC	High Altitude Compensator
H/B	Hatchback
H-FUSE	High Current Fuse
HI	High
HID	High Intensity Discharge (Headlight)
HPU	Hydraulic Power Unit
HSG	Housing
HT	Hard Top
HV	Hybrid Vehicle
HWS	Heated Windshield System
IC	Integrated Circuit
IDI	Indirect Diesel Injection
IFS	Independent Front Suspension
IG	Ignition
IIA	Integrated Ignition Assembly
IN	Intake (Manifold, Valve)
INT	Intermittent
I/P	Instrument Panel
IRS	Independent Rear Suspension
ISC	Idle Speed Control
J/B	Junction Block
J/C	Junction Connector
KD	Kick-Down
LAN	Local Area Network
LB	Liftback
LCD	Liquid Crystal Display
LED	Light Emitting Diode
LH	Left-Hand
LHD	Left-Hand Drive
LIN	Local Interconnect Network
L/H/W	Length, Height, Width
LLC	Long-Life Coolant
LNG	Liquefied Natural Gas
LO	Low
LPG	Liquefied Petroleum Gas
LSD	Limited Slip Differential
LSP & BV	Load Sensing Proportioning and Bypass Valve
LSPV	Load Sensing Proportioning Valve
MAP	Manifold Absolute Pressure
MAX.	Maximum
MIC	Microphone

Abbreviations	Meaning
MIL	Malfunction Indicator Lamp
MIN.	Minimum
MG1	Motor Generator No. 1
MG2	Motor Generator No. 2
MMT	Multi-mode Manual Transmission
MP	Multipurpose
MPI	Multipoint Electronic Injection
MPX	Multiplex Communication System
M/T, MTM	Manual Transmission (Transaxle)
MT	Mount
MTG	Mounting
N	Neutral
NA	Natural Aspiration
NO.	Number
O2S	Oxygen Sensor
OC	Oxidation Catalyst
OCV	Oil Control Valve
O/D	Overdrive
OEM	Original Equipment Manufacturing
OHC	Overhead Camshaft
OHV	Overhead Valve
OPT	Option
ORVR	On-board Refilling Vapor Recovery
O/S	Oversize
P & BV	Proportioning and Bypass Valve
PBD	Power Back Door
PCS	Power Control System
PCV	Positive Crankcase Ventilation
PKB	Parking Brake
PPS	Progressive Power Steering
PROM	Programmable Read Only Memory
PS	Power Steering
PSD	Power Slide Door
PTC	Positive Temperature Coefficient
PTO	Power Take-Off
PZEV	Partial Zero Emission Vehicle
P/W	Power Window
R & P	Rack and Pinion
RAM	Random Access Memory
R/B	Relay Block
RBS	Recirculating Ball Type Steering
R/F	Reinforcement
RFS	Rigid Front Suspension
RH	Right-Hand
RHD	Right-Hand Drive
RLY	Relay
ROM	Read Only Memory
RR	Rear
RRS	Rigid Rear Suspension

Abbreviations	Meaning
RSE	Rear Seat Entertainment
RWD	Rear-Wheel Drive
SC	Supercharger
SCV	Swirl Control Valve
SDN	Sedan
SEN	Sensor
SICS	Starting Injection Control System
SOC	State Of Charge
SOHC	Single Overhead Camshaft
SPEC	Specification
SPI	Single Point Injection
SRS	Supplemental Restraint System
SSM	Special Service Materials
SST	Special Service Tools
STD	Standard
STJ	Cold-Start Fuel Injection
SW	Switch
SYS	System
T/A	Transaxle
TACH	Tachometer
TBI	Throttle Body Electronic Fuel Injection
TC	Turbocharger
TCCS	TOYOTA Computer-Controlled System
TCM	Transmission Control Module
TCV	Timing Control Valve
TDC	Top Dead Center
TEMP.	Temperature
TFT	TOYOTA Free-Tronic
TIS	Total Information System for Vehicle Development
T/M	Transmission
TMC	TOYOTA Motor Corporation
TMMIN	PT. TOYOTA Motor Manufacturing Indonesia
TMMK	TOYOTA Motor Manufacturing Kentucky, Inc.
TMT	TOYOTA Motor Thailand Co. Ltd.
TRAC/TRC	Traction Control System
TURBO	Turbocharge
TVIP	TOYOTA Vehicle Instruction Protection
TWC	Three-Way Catalyst
U/D	Underdrive
U/S	Undersize
VCV	Vacuum Control Valve
VDIM	Vehicle Dynamics Integrated Management
VENT	Ventilator
VIM	Vehicle Interface Module
VGRS	Variable Gear Ratio Steering
VIN	Vehicle Identification Number
VPS	Variable Power Steering
VSC	Vehicle Skid Control
VSV	Vacuum Switching Valve

Abbreviations	Meaning
VTV	Vacuum Transmitting Valve
VVT-i	Variable Valve Timing-intelligent
W/	With
WGN	Wagon
W/H	Wire Harness
W/O	Without
1ST	First
2ND	Second
2WD	Two Wheel Drive Vehicle (4 x 2)
3RD	Third
4TH	Fourth
4WD	Four Wheel Drive Vehicle (4 x 4)
4WS	Four Wheel Steering System
5TH	Fifth

GLOSSARY OF SAE AND TOYOTA TERMS

This glossary lists all SAE-J1930 terms and abbreviations used in this manual in compliance with SAE recommendations, as well as their TOYOTA equivalents.

SAE ABBREVIATIONS	SAE TERMS	TOYOTA TERMS ()-ABBREVIATIONS
A/C	Air Conditioning	Air Conditioner
ACL	Air Cleaner	Air Cleaner, A/CL
AIR	Secondary Air Injection	Air Injection (AI)
AP	Accelerator Pedal	-
B+	Battery Positive Voltage	+B, Battery Voltage
BARO	Barometric Pressure	HAC
CAC	Charge Air Cooler	Intercooler
CARB	Carburetor	Carburetor
CFI	Continuous Fuel Injection	-
CKP	Crankshaft Position	Crank Angle
CL	Closed Loop	Closed Loop
CMP	Camshaft Position	Cam Angle
CPP	Clutch Pedal Position	-
CTOX	Continuous Trap Oxidizer	-
CTP	Closed Throttle Position	LL ON, Idle ON
DFI	Direct Fuel Injection	Direct Injection (DI./INJ)
DI	Distributor Ignition	-
DLC3	Data Link Connector 3	OBD II Diagnostic Connector
DTC	Diagnostic Trouble Code	Diagnostic Trouble Code
DTM	Diagnostic Test Mode	-
ECL	Engine Coolant Level	-
ECM	Engine Control Module	Engine Electronic Control Unit (ECU)
ECT	Engine Coolant Temperature	Coolant Temperature, Water Temperature (THW)
EEPROM	Electrically Erasable Programmable Read Only Memory	Electrically Erasable Programmable Read Only Memory (EEPROM), Erasable Programmable Read Only Memory (EPROM)
EFE	Early Fuel Evaporation	Cold Mixture Heater (CMH), Heat Control Valve (HCV)
EGR	Exhaust Gas Recirculation	Exhaust Gas Recirculation (EGR)
EI	Electronic Ignition	Distributorless Ignition (DLI)
EM	Engine Modification	Engine Modification (EM)
EPROM	Erasable Programmable Read Only Memory	Programmable Read Only Memory (PROM)
EVAP	Evaporative Emission	Evaporative Emission Control (EVAP)
FC	Fan Control	-
FEEPROM	Flash Electrically Erasable Programmable Read Only Memory	-
FEPROM	Flash Erasable Programmable Read Only Memory	-
FF	Flexible Fuel	-
FP	Fuel Pump	Fuel Pump
GEN	Generator	Alternator
GND	Ground	Ground (GND)
HO2S	Heated Oxygen Sensor	Heated Oxygen Sensor (HO ₂ S)
IAC	Idle Air Control	Idle Speed Control (ISC)
IAT	Intake Air Temperature	Intake or Inlet Air Temperature
ICM	Ignition Control Module	-

SAE ABBREVIATIONS	SAE TERMS	TOYOTA TERMS ()-ABBREVIATIONS
IFI	Indirect Fuel Injection	Indirect Injection (IDL)
IFS	Inertia Fuel-Shutoff	-
ISC	Idle Speed Control	-
KS	Knock Sensor	Knock Sensor
MAF	Mass Airflow	Air Flow Meter
MAP	Manifold Absolute Pressure	Manifold Pressure Intake Vacuum
MC	Mixture Control	Electric Bleed Air Control Valve (EBCV) Mixture Control Valve (MCV) Electric Air Control Valve (EACV)
MDP	Manifold Differential Pressure	-
MFI	Multiport Fuel Injection	Electronic Fuel Injection (EFI)
MIL	Malfunction Indicator Light	Check Engine Light
MST	Manifold Surface Temperature	-
MVZ	Manifold Vacuum Zone	-
NVRAM	Non-Volatile Random Access Memory	-
O2S	Oxygen Sensor	Oxygen Sensor, O ₂ Sensor (O ₂ S)
OBD	On-Board Diagnostic	On-Board Diagnostic System (OBD)
OC	Oxidation Catalytic Converter	Oxidation Catalytic Convert (OC), CCo
OL	Open Loop	Open Loop
PAIR	Pulsed Secondary Air Injection	Air Suction (AS)
PCM	Powertrain Control Module	-
PNP	Park/Neutral Position	-
PROM	Programmable Read Only Memory	-
PSP	Power Steering Pressure	-
PTOX	Periodic Trap Oxidizer	Diesel Particulate Filter (DPF) Diesel Particulate Trap (DPT)
RAM	Random Access Memory	Random Access Memory (RAM)
RM	Relay Module	-
ROM	Read Only Memory	Read Only Memory (ROM)
RPM	Engine Speed	Engine Speed
SC	Supercharger	Supercharger
SCB	Supercharger Bypass	E-ABV
SFI	Sequential Multiport Fuel Injection	Electronic Fuel Injection (EFI), Sequential Injection
SPL	Smoke Puff Limiter	-
SRI	Service Reminder Indicator	-
SRT	System Readiness Test	-
ST	Scan Tool	-
TB	Throttle Body	Throttle Body
TBI	Throttle Body Fuel Injection	Single Point Injection Central Fuel Injection (Ci)
TC	Turbocharger	Turbocharger
TCC	Torque Converter Clutch	Torque Converter
TCM	Transmission Control Module	Transmission ECU, ECT ECU
TP	Throttle Position	Throttle Position
TR	Transmission Range	-
TVV	Thermal Vacuum Valve	Bimetallic Vacuum Switching Valve (BVSV) Thermostatic Vacuum Switching Valve (TVSV)
TWC	Three-Way Catalytic Converter	Three-Way Catalytic (TWC) Manifold Converter CC _{RO}

SAE ABBREVIATIONS	SAE TERMS	TOYOTA TERMS ()-ABBREVIATIONS
TWC+OC	Three-Way + Oxidation Catalytic Converter	CC _R + CCo
VAF	Volume Airflow	Air Flow Meter
VR	Voltage Regulator	Voltage Regulator
VSS	Vehicle Speed Sensor	Vehicle Speed Sensor
WOT	Wide Open Throttle	Full Throttle
WU-OC	Warm Up Oxidation Catalytic Converter	-
WU-TWC	Warm Up Three-Way Catalytic Converter	-
3GR	Third Gear	-
4GR	Fourth Gear	-