

<b>Last Modified:</b> 12-04-2024	6.11:8.1.0	<b>Doc ID:</b> RM100000028X34
<b>Model Year Start:</b> 2023	<b>Model:</b> Prius Prime	<b>Prod Date Range:</b> [12/2022 - ]
<b>Title:</b> BRAKE CONTROL / DYNAMIC CONTROL SYSTEMS: ELECTRONICALLY CONTROLLED BRAKE SYSTEM: C050614; Right Front Wheel Speed Sensor Circuit Short to Ground or Open; 2023 - 2024 MY Prius Prius Prime [12/2022 - ]		

<b>DTC</b>	<b>C050614</b>	<b>Right Front Wheel Speed Sensor Circuit Short to Ground or Open</b>
------------	----------------	-----------------------------------------------------------------------

## DESCRIPTION

Refer to DTC C050612.

Click here [INFO](#)

DTC NO.	DETECTION ITEM	DTC DETECTION CONDITION	TROUBLE AREA	MIL	DTC OUTPUT FROM	PRIORITY	NOTE
C050614	Right Front Wheel Speed Sensor Circuit Short to Ground or Open	An open in the speed sensor signal circuit continues for 0.5 seconds or more.	<ul style="list-style-type: none"> <li>Front speed sensor RH</li> <li>Wire harness and connector</li> <li>No. 2 skid control ECU (brake actuator assembly)</li> </ul>	Comes on	Brake/EPB	A	<ul style="list-style-type: none"> <li>SAE Code: C0508</li> <li>Output ECU: No. 2 skid control ECU (brake actuator assembly)</li> </ul>

## MONITOR DESCRIPTION

The No. 2 skid control ECU (brake actuator assembly) monitors the output of the speed sensor. When the output current of the speed sensor is excessively low, the MIL is illuminated and a DTC is stored.

## MONITOR STRATEGY

Related DTCs	C0508: Wheel speed sensor (FR) voltage circuit open
Required Sensors/Components(Main)	Speed sensor
Required Sensors/Components(Related)	No. 2 skid control ECU (brake actuator assembly)
Frequency of Operation	Continuous
Duration	0.528 seconds
MIL Operation	Immediately
Sequence of Operation	None

## TYPICAL ENABLING CONDITIONS

<p>Monitor runs whenever the following DTCs are not stored</p>	<p>C0501 (Case 1): Wheel speed sensor (FL) range/performance (correlation A)  C0501 (Case 2): Wheel speed sensor (FL) range/performance (2 wheels)  C0501 (Case 3): Wheel speed sensor (FL) range/performance (correlation B)  C0501 (Case 4): Wheel speed sensor (FL) range/performance (pulse output high)  C0503: Wheel speed sensor (FL) voltage circuit high  C0507 (Case 1): Wheel speed sensor (FR) range/performance (correlation A)  C0507 (Case 2): Wheel speed sensor (FR) range/performance (2 wheels)  C0507 (Case 3): Wheel speed sensor (FR) range/performance (correlation B)  C0507 (Case 4): Wheel speed sensor (FR) range/performance (pulse output high)  C0509: Wheel speed sensor (FR) voltage circuit high  C050D (Case 1): Wheel speed sensor (RL) range/performance (correlation A)  C050D (Case 2): Wheel speed sensor (RL) range/performance (2 wheels)  C050D (Case 3): Wheel speed sensor (RL) range/performance (correlation B)  C050D (Case 4): Wheel speed sensor (RL) range/performance (pulse output high)  C050F: Wheel speed sensor (RL) voltage circuit high  C0513 (Case 1): Wheel speed sensor (RR) range/performance (correlation A)  C0513 (Case 2): Wheel speed sensor (RR) range/performance (2 wheels)  C0513 (Case 3): Wheel speed sensor (RR) range/performance (correlation B)  C0513 (Case 4): Wheel speed sensor (RR) range/performance (pulse output high)  C0515: Wheel speed sensor (RR) voltage circuit high  C137D: Brake system voltage circuit high  C14E1 (Case 1): Wheel speed sensor (FL) voltage circuit low  C14E1 (Case 2): Wheel speed sensor (FL) voltage circuit low (continuation)  C14E4 (Case 1): Wheel speed sensor (FR) voltage circuit low  C14E4 (Case 2): Wheel speed sensor (FR) voltage circuit low (continuation)  C14E7 (Case 1): Wheel speed sensor (RL) voltage circuit low  C14E7 (Case 2): Wheel speed sensor (RL) voltage circuit low (continuation)  C14EA (Case 1): Wheel speed sensor (RR) voltage circuit low  C14EA (Case 2): Wheel speed sensor (RR) voltage circuit low (continuation)</p>
<p>All of the following conditions are met</p>	<p>A, B, C, D, E, F, G and H</p>

A. Following condition is met	More than 0.22 seconds
+BS voltage	17.4 V or less
B. Following condition is met	More than 0.22 seconds
+BS voltage	8.5 V or higher
C. Command to wheel speed sensor power supply	On
D. Following condition is met	More than 0.204 seconds
Wheel speed sensor power supply voltage low signal (IC Data)	Off
E. Wheel speed sensor overcurrent signal (IC Data)	Off
F. +BS voltage	9.5 V or higher
G. IGR voltage	Higher than 10 V
H. IGP voltage	Higher than 10 V

## TYPICAL MALFUNCTION THRESHOLDS

Wheel speed sensor open circuit signal (IC Data)	On
--------------------------------------------------	----

## COMPONENT OPERATING RANGE

Wheel speed sensor open circuit signal (IC Data)	Off
--------------------------------------------------	-----

## CONFIRMATION DRIVING PATTERN

### NOTICE:

When performing the normal judgment procedure, make sure that the driver door is closed and is not opened at any time during the procedure.

### HINT:

- After repair has been completed, clear the DTC and then check that the vehicle has returned to normal by performing the following All Readiness check procedure.
- When clearing the permanent DTCs, refer to the "CLEAR PERMANENT DTC" procedure.

- Connect the GTS to the DLC3.
- Turn the ignition switch to ON and turn the GTS on.
- Clear the DTCs (even if no DTCs are stored, perform the clear DTC procedure).
- Turn the ignition switch off.
- Turn the ignition switch to ON (READY) and turn the GTS on.
- Wait for 2 seconds or more. [\*]

### HINT:

[\*]: Normal judgment procedure.

The normal judgment procedure is used to complete DTC judgment and also used when clearing permanent DTCs.

- Enter the following menus: Chassis / Brake/EPB\* / Utility / All Readiness.

\*: Electric Parking Brake System

- Check the DTC judgment result.

**HINT:**

- If the judgment result shows **NORMAL**, the system is normal.
- If the judgment result shows **ABNORMAL**, the system has a malfunction.
- If the judgment result shows **INCOMPLETE**, perform driving pattern again.

**WIRING DIAGRAM**

Refer to DTC C050612.

Click here [INFO](#)

**PROCEDURE**

<b>1.</b>	<b>READ VALUE USING GTS (MOMENTARY INTERRUPTION)</b>
-----------	------------------------------------------------------

Pre-procedure1

(a) Select the line graph display on the GTS.

Procedure1

(b) Check for any momentary interruption in the wire harness and connector.

**Chassis > Brake/EPB > Data List**

TESTER DISPLAY	MEASUREMENT ITEM	RANGE	NORMAL CONDITION	DIAGNOSTIC NOTE
FR Speed Open	Front speed sensor RH open detection	Normal / Under intermittent	Normal: Normal Under intermittent: Momentary interruption	-
FR Speed Sensor Voltage Open	Front speed sensor RH voltage open detection	Normal / Under intermittent	Normal: Normal Under intermittent: Momentary interruption	-

**Chassis > Brake/EPB > Data List**

TESTER DISPLAY
FR Speed Open
FR Speed Sensor Voltage Open

OK:

Normal (There are no momentary interruptions.)

**NOTICE:**

Perform the above inspection before removing the sensor and connector.

Post-procedure1

(c) None

**OK**  **USE SIMULATION METHOD TO CHECK**

**NG**



**2. CHECK HARNESS AND CONNECTOR (FRONT SPEED SENSOR RH - BRAKE ACTUATOR ASSEMBLY)**

Pre-procedure1

(a) Turn the ignition switch off.

Procedure1

(b) Make sure that there is no looseness at the locking part and the connecting part of the connectors.

OK:

The connector is securely connected.

Pre-procedure2

(c) Disconnect the A9 front speed sensor RH connector.

(d) Disconnect the A4 No. 2 skid control ECU (brake actuator assembly) connector.

Procedure2

(e) Check both the connector case and the terminals for deformation and corrosion.

OK:

No deformation or corrosion.

Procedure3

(f) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(A9,A4\).](#)

[Click Connector\(A9\).](#)

[Click Connector\(A4\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION	RESULT
A9-2 (FR+) - A4-7 (FR+)	Always	Below 1 Ω	Ω
A9-2 (FR+) or A4-7 (FR+) - Body ground	Always	10 kΩ or higher	kΩ
A9-1 (FR-) - A4-6 (FR-)	Always	Below 1 Ω	Ω
A9-1 (FR-) or A4-6 (FR-) - Body ground	Always	10 kΩ or higher	kΩ

Post-procedure1

(g) None

**NG**  **REPAIR OR REPLACE HARNESS OR CONNECTOR**

**OK**



**3. INSPECT BRAKE ACTUATOR ASSEMBLY (SENSOR POWER SOURCE CIRCUIT)**

Pre-procedure1

- (a) Reconnect the A4 No. 2 skid control ECU (brake actuator assembly) connector.
- (b) Turn the ignition switch to ON.

Procedure1

- (c) Measure the voltage according to the value(s) in the table below.

Standard Voltage:



[Click Location & Routing\(A9\).](#)

[Click Connector\(A9\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION	RESULT
A9-2 (FR+) - Body ground	Ignition switch ON	11 to 14 V	V

Post-procedure1

(d) None

**OK**  **REPLACE FRONT SPEED SENSOR RH**

**NG**  **REPLACE BRAKE ACTUATOR ASSEMBLY** 

