

Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM10000002BHWO
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [03/2023 -]
Title: HYBRID / BATTERY CONTROL: HYBRID BATTERY SYSTEM (for PHEV Model): P2BE41C; Hybrid/EV Battery Pack Current Sensor "C" Circuit Range/Performance Circuit Voltage Out of Range; 2023 - 2024 MY Prius Prime [03/2023 -]		

DTC	P2BE41C	Hybrid/EV Battery Pack Current Sensor "C" Circuit Range/Performance Circuit Voltage Out of Range
------------	----------------	---

DESCRIPTION

Refer to the description for DTC P0ABF11.

Click here [INFO](#)

DTC NO.	DETECTION ITEM	DTC DETECTION CONDITION	TROUBLE AREA	MIL	WARNING INDICATE	DTC OUTPUT FROM	PRIORITY	NOTE
P2BE41C	Hybrid/EV Battery Pack Current Sensor "C" Circuit Range/Performance Circuit Voltage Out of Range	A battery current sensor is malfunctioning.*1 (1 trip detection logic)	<ul style="list-style-type: none"> No. 1 traction battery device box assembly Battery ECU assembly Wire harness or connector 	Comes on	Master Warning: Comes on	HV Battery	A	SAE Code: P2BE5

*1: The difference in output of the main and low battery current sensors is large.

MONITOR DESCRIPTION

If the battery ECU assembly detects a malfunction in the battery current sensor, the battery ECU assembly illuminates the MIL and stores a DTC.

MONITOR STRATEGY

Related DTCs	P2BE5 (INF P2BE41C): Hybrid/EV Battery Pack Current sensor malfunction (offset)
Required sensors/components	Battery current sensor
Frequency of operation	Continuous
Duration	TMC's intellectual property
MIL operation	1 driving cycle
Sequence of operation	None

TYPICAL ENABLING CONDITIONS

The monitor will run whenever the following DTCs are not stored	TMC's intellectual property
Other conditions belong to TMC's intellectual property	-

TYPICAL MALFUNCTION THRESHOLDS

TMC's intellectual property	-
-----------------------------	---

COMPONENT OPERATING RANGE

Battery ECU assembly	DTC P2BE5 (INF P2BE41C) is not detected
----------------------	---

CONFIRMATION DRIVING PATTERN

HINT:

- After repair has been completed, clear the DTC and then check that the vehicle has returned to normal by performing the following All Readiness check procedure.

[Click here](#) INFO

- When clearing the permanent DTCs, refer to the "CLEAR PERMANENT DTC" procedure.

[Click here](#) INFO

- Clear the DTCs (even if no DTCs are stored, perform the clear DTC procedure).
- Turn the ignition switch off and wait for 2 minutes or more.
- Drive the vehicle on urban roads for approximately 10 minutes.[*1]

HINT:

[*1]: Normal judgment procedure.

The normal judgment procedure is used to complete DTC judgment and also used when clearing permanent DTCs.

- Enter the following menus: Powertrain / HV Battery / Utility / All Readiness.
- Check the DTC judgment result.

HINT:

- If the judgment result shows NORMAL, the system is normal.
- If the judgment result shows ABNORMAL, the system has a malfunction.
- If the judgment result shows INCOMPLETE or N/A, perform the normal judgment procedure again.

WIRING DIAGRAM

Refer to the wiring diagram for P0ABF11.

[Click here](#) INFO

CAUTION / NOTICE / HINT

CAUTION:

Refer to the precautions before inspecting high voltage circuit.

[Click here](#) INFO

NOTICE:

- After the ignition switch is turned off, there may be a waiting time before disconnecting the auxiliary negative (-) battery terminal.

[Click here](#) INFO

- When disconnecting and reconnecting the auxiliary battery.

HINT:

When disconnecting and reconnecting the auxiliary battery, there is an automatic learning function that completes learning when the respective system is used.

[Click here](#) INFO

PROCEDURE

1.	CHECK DTC OUTPUT (HV BATTERY, HYBRID CONTROL)
-----------	--

Pre-procedure1

(a) None

Procedure1

(b) Check for DTCs.

Powertrain > HV Battery > Trouble Codes

Powertrain > Hybrid Control > Trouble Codes

RESULT	PROCEED TO
"P2BE41C" only is output, or DTCs except the ones in the table below are also output.	A
DTCs of hybrid battery system in the table below are output.	B
DTCs of hybrid control system in the table below are output.	C

SYSTEM	RELEVANT DTC	
Hybrid battery system	P060A47	Hybrid/EV Battery Energy Control Module Monitoring Processor Watchdog / Safety MCU Failure
	P060B49	Hybrid/EV Battery Energy Control Module A/D Processing Internal Electronic Failure
	P060687	Hybrid/EV Battery Energy Control Module Processor to Monitoring Processor Missing Message
Hybrid control system	P0A1F94	Hybrid/EV Battery Energy Control Module Unexpected Operation

Post-procedure1

(c) Turn the ignition switch off.

B [**GO TO DTC CHART \(HYBRID BATTERY SYSTEM\)**](#)

C ► **GO TO DTC CHART (HYBRID CONTROL SYSTEM)**

A
▼

2. CHECK HARNESS AND CONNECTOR (BATTERY ECU ASSEMBLY - NO. 1 TRACTION BATTERY DEVICE BOX ASSEMBLY)

CAUTION:

Be sure to wear insulated gloves and protective goggles.

Pre-procedure1

(a) Check that the service plug grip is not installed.


NOTICE:

After removing the service plug grip, do not turn the ignition switch to ON (READY), unless instructed by the repair manual because this may cause a malfunction.

(b) Disconnect the battery ECU assembly connector.

NOTICE:

Before disconnecting the connector, check that it is not loose or disconnected.



(c) Disconnect the battery current sensor connector from the No. 1 traction battery device box assembly.

NOTICE:

Before disconnecting the connector, check that it is not loose or disconnected.



Procedure1

(d) Measure the resistance according to the value(s) in the tables below.

Standard Resistance (Check for Open):



[Click Location & Routing\(x11,x4\)](#)

[Click Connector\(x11\)](#)

[Click Connector\(x4\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
x11-1 (IBL) - x4-15 (IBL)	Ignition switch off	Below 1 Ω
x11-5 (IB1) - x4-17 (IB1)	Ignition switch off	Below 1 Ω
x11-4 (GIB) - x4-14 (GIB)	Ignition switch off	Below 1 Ω
x11-3 (IB0) - x4-16 (IB0)	Ignition switch off	Below 1 Ω
x11-2 (VIB) - x4-4 (VIB)	Ignition switch off	Below 1 Ω

Standard Resistance (Check for Short):



[Click Location & Routing\(x11,x4\)](#)

[Click Connector\(x11\)](#)

[Click Connector\(x4\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
x11-1 (IBL) or x4-15 (IBL) - Body ground and other terminals	Ignition switch off	10 k Ω or higher
x11-5 (IB1) or x4-17 (IB1) - Body ground and other terminals	Ignition switch off	10 k Ω or higher
x11-4 (GIB) or x4-14 (GIB) - Body ground and other terminals	Ignition switch off	10 k Ω or higher
x11-3 (IB0) or x4-16 (IB0) - Body ground and other terminals	Ignition switch off	10 k Ω or higher
x11-2 (VIB) or x4-4 (VIB) - Body ground and other terminals	Ignition switch off	10 k Ω or higher

Post-procedure1

(e) Reconnect the battery current sensor connector to the No. 1 traction battery device box assembly.

(f) Reconnect the battery ECU assembly connector.

NG ► REPAIR OR REPLACE HARNESS OR CONNECTOR

OK



3.	REPLACE NO. 1 TRACTION BATTERY DEVICE BOX ASSEMBLY
-----------	---

HINT:

[Click here](#) **NEXT****4. CLEAR DTC (HV BATTERY)**

Pre-procedure1

(a) None

Procedure1

(b) Clear the DTCs and freeze frame data.

Powertrain > HV Battery > Clear DTCs

Post-procedure1

(c) Perform a road test.

NEXT**5. CHECK DTC OUTPUT (HV BATTERY)**

(a) Check for DTCs.

Powertrain > HV Battery > Trouble Codes

RESULT	PROCEED TO
DTCs are not output.	A
P2BE41C is also output.	B

A  **END****B**  **REPLACE BATTERY ECU ASSEMBLY**