


<b>Last Modified:</b> 12-04-2024	6.11:8.1.0	<b>Doc ID:</b> RM10000002BI1K
<b>Model Year Start:</b> 2023	<b>Model:</b> Prius Prime	<b>Prod Date Range:</b> [03/2023 - ]
<b>Title:</b> HYBRID / BATTERY CONTROL: HYBRID CONTROL SYSTEM (for PHEV Model): ECU Power Source Circuit; 2023 - 2024 MY Prius Prime [03/2023 - ]		

## ECU Power Source Circuit

## DESCRIPTION

If the ignition switch is ON, the hybrid vehicle control ECU applies current to the MREL terminal to turn the IGCT SCENE relay on. This supplies power to the +B1 and +B2 terminal.

## WIRING DIAGRAM



## CAUTION / NOTICE / HINT

### NOTICE:

- After the ignition switch is turned off, there may be a waiting time before disconnecting the negative (-) auxiliary battery terminal.

[Click here](#) **INFO**

- When disconnecting and reconnecting the auxiliary battery

### HINT:


When disconnecting and reconnecting the auxiliary battery, there is an automatic learning function that completes learning when the respective system is used.

[Click here](#) **INFO**

## PROCEDURE

**1. CHECK HYBRID VEHICLE CONTROL ECU (+B1, +B2 VOLTAGE)**

- (a) Turn the ignition switch to ON.
- (b) Measure the voltage according to the value(s) in the table below.



*a	Component with harness connected (Hybrid Vehicle Control ECU)	-	-
----	---	---	---

Standard Voltage:



- [Click Location & Routing\(K11,A57\).](#)
- [Click Connector\(K11\).](#)
- [Click Connector\(A57\).](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K11-8 (+B1) - Body ground	Ignition switch ON	11 to 14 V
A57-10 (+B2) - Body ground	Ignition switch ON	11 to 14 V

- (c) Turn the ignition switch off.

**NG** **GO TO STEP 3**

**OK**

**2. CHECK HARNESS AND CONNECTOR (HYBRID VEHICLE CONTROL ECU - BODY GROUND)**

- (a) Disconnect the hybrid vehicle control ECU connectors.
- (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(A57,K11\)](#)

[Click Connector\(A57\)](#)

[Click Connector\(K11\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
A57-12 (E01) - Body ground	Always	Below 1 Ω
A57-24 (E12) - Body ground	Always	Below 1 Ω
K11-1 (E1) - Body ground	Always	Below 1 Ω

(c) Reconnect the hybrid vehicle control ECU connectors.


**OK** ► [GO TO PROBLEM SYMPTOMS TABLE](#)

**NG** ► [REPAIR OR REPLACE HARNESS OR CONNECTOR](#)

<b>3.</b>	<b>CHECK HYBRID VEHICLE CONTROL ECU (MREL TERMINAL VOLTAGE)</b>
-----------	---

(a) Turn the ignition switch to ON.

(b) Measure the voltage according to the value(s) in the table below.



*a	Component with harness connected (Hybrid Vehicle Control ECU)	-	-
----	---	---	---

Standard Voltage:



[Click Location & Routing\(K11\)](#)

[Click Connector\(K11\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K11-10 (MREL) - Body ground	Ignition switch ON	11 to 14 V

(c) Turn the Ignition switch off.

**NG**  **REPLACE HYBRID VEHICLE CONTROL ECU**

**OK**



<b>4.</b>	<b>CHECK FUSE (PM IGCT-PHV)</b>
-----------	---------------------------------

(a) Remove the PM IGCT-PHV fuse from the fuse block assembly.

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
PM IGCT-PHV fuse	Always	Below 1 Ω

(c) Install the PM IGCT-PHV fuse.

**NG**  **GO TO STEP 10**

**OK**



<b>5.</b>	<b>INSPECT RELAY (IGCT SCENE)</b>
-----------	-----------------------------------


(a) Remove the IGCT SCENE relay from the No. 3 relay block.

(b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
3 - 5	Auxiliary battery voltage not applied between terminals 1 and 2	10 kΩ or higher

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
	Auxiliary battery voltage applied between terminals 1 and 2	Below 1 Ω



\*1 IGCT-MAIN NO. 1 Relay

(c) Install the IGCT SCENE relay.

**NG** ▶ REPLACE RELAY (IGCT SCENE)

**OK**  
▼

**6. CHECK HARNESS AND CONNECTOR (HYBRID VEHICLE CONTROL ECU - FUSE BLOCK ASSEMBLY)**

- (a) Disconnect the hybrid vehicle control ECU connector.
- (b) Remove the PM IGCT-PHV fuse from the fuse block assembly.
- (c) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K11\)](#)  
[Click Connector\(K11\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K11-8 (+B1) - 3 (PM IGCT-PHV fuse holder)	Always	Below 1 Ω

- (d) Install the PM IGCT-PHV fuse.
- (e) Reconnect the hybrid vehicle control ECU connector.

**NG** ▶ REPAIR OR REPLACE HARNESS OR CONNECTOR



**7. CHECK HARNESS AND CONNECTOR (RELAY BLOCK NO.3 - FUSE BLOCK ASSEMBLY)**

- (a) Remove the PM IGCT-PHV fuse from the No. 3 relay block.
- (b) Remove the IGCT SCENE relay from the fuse block assembly.
- (c) Measure the resistance according to the value(s) in the table below.

Standard Resistance:

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
3 (IGCT SCENE relay holder) - 1 (PM IGCT-PHV fuse holder)	Always	Below 1 Ω

- (d) Install the IGCT SCENE relay.
- (e) Install the PM IGCT-PHV fuse.

**NG** **REPAIR OR REPLACE HARNESS OR CONNECTOR**



**8. CHECK HARNESS AND CONNECTOR (HYBRID VEHICLE CONTROL ECU - NO.3 RELAY BLOCK)**

- (a) Disconnect the hybrid vehicle control ECU connector.
- (b) Remove the IGCT SCENE relay from the No. 3 relay block.
- (c) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K11\)](#)  
[Click Connector\(K11\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K11-10 (MREL) - 1 (IGCT SCENE relay holder)	Always	Below 1 Ω
K11-10 (MREL) or 1 (IGCT SCENE relay holder) - Body ground and other terminals	Always	10 kΩ or higher

- (d) Install the IGCT- SCENE relay.
- (e) Reconnect the hybrid vehicle control ECU connector.

**NG**  **REPAIR OR REPLACE HARNESS OR CONNECTOR**

**OK**



**9. CHECK HARNESS AND CONNECTOR (NO.3 RELAY BLOCK)**

- (a) Remove the IGCT SCENE relay from the No. 3 relay block.
- (b) Measure the resistance according to the value(s) in the table below.

Standard Resistance:

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
2 (IGCT SCENE relay holder) - Body ground	Always	Below 1 Ω

- (c) Install the IGCT SCENE relay.

**OK**  **CHECK FOR INTERMITTENT PROBLEMS**

**NG**  **REPAIR OR REPLACE HARNESS OR CONNECTOR**

**10. CHECK HARNESS AND CONNECTOR (HYBRID VEHICLE CONTROL ECU - FUSE BLOCK ASSEMBLY)**

- (a) Remove the PM IGCT-PHV fuse from the fuse block assembly.
- (b) Disconnect the hybrid vehicle control ECU connector.
- (c) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(K11\)](#)  
[Click Connector\(K11\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
K11-8 (+B1) or 3 (PM IGCT-PHV fuse holder) - Body ground and other terminals	Always	10 kΩ or higher

- (d) Reconnect the hybrid vehicle control ECU connector.

(e) Install the PM IGCT-PHV fuse.

**OK**  **REPLACE FUSE (PM IGCT-PHV)**

**NG**



<b>11.</b>	<b>REPAIR OR REPLACE HARNESS OR CONNECTOR</b>
------------	---

**NEXT**  **REPLACE FUSE (PM IGCT-PHV)**

