

<b>Last Modified:</b> 12-04-2024	6.11:8.1.0	<b>Doc ID:</b> RM10000002BI11
<b>Model Year Start:</b> 2023	<b>Model:</b> Prius Prime	<b>Prod Date Range:</b> [03/2023 - ]
<b>Title:</b> HYBRID / BATTERY CONTROL: HYBRID CONTROL SYSTEM (for PHEV Model): P1C2D62; Hybrid/EV Battery "A" Voltage Sensor/Boosting Converter Voltage Sensor "A" Signal Compare Failure; 2023 - 2024 MY Prius Prime [03/2023 - ]		

<b>DTC</b>	<b>P1C2D62</b>	<b>Hybrid/EV Battery "A" Voltage Sensor/Boosting Converter Voltage Sensor "A" Signal Compare Failure</b>
------------	----------------	--

## DTC SUMMARY

### MALFUNCTION DESCRIPTION

The hybrid vehicle control ECU detects a VB sensor or VL sensor malfunction.

The cause of this malfunction may be one of the following:

#### **Inverter voltage (VB or VL) sensor internal circuit malfunction**

- Voltage sensor malfunction
- Motor generator control ECU (MG ECU) malfunction
- Communication (wire harness) malfunction

#### **High voltage system malfunction**

- HV battery malfunction
- No. 1 traction battery device box assembly malfunction
- Inverter with converter assembly malfunction
- High-voltage wire harness malfunction
- High-voltage connector or connection malfunction

### Inspection Overview

INSPECTION CONTENT	REASON (NARROW DOWN IN ORDER USING INSPECTION PROCEDURES BELOW)
Check for DTCs (hybrid control, motor generator, HV battery)	Output DTCs
Check for DTCs (check voltage sensor malfunction locations) Check for DTCs (drive test)	Ignition switch ON (READY) (vehicle stopped or being driven) and then check whether DTCs are output again.
Read value using GTS (data list)	Data List value
Check freeze frame data	Freeze Frame Data
Read value using GTS (data list)	Accelerator and brake pedal simultaneously depressed Data List value

## DESCRIPTION

For a description of the boost converter.

Click here [INFO](#)

The MG ECU uses a voltage sensor (VL) that is built into the boost converter to detect the high voltage before it is boosted. The ECU also uses the battery ECU assembly to detect HV battery voltage (VB).

DTC NO.	DETECTION ITEM	DTC DETECTION CONDITION	TROUBLE AREA	MIL	WARNING INDICATE	DTC OUTPUT FROM	PRIORITY	NOTE
P1C2D62	Hybrid/EV Battery "A" Voltage Sensor/Boosting Converter Voltage Sensor "A" Signal Compare Failure	Voltages from HV battery voltage (VB) sensor and boost converter voltage (VL) sensor deviate:  Difference between "VL-Voltage before Boosting" and "Hybrid/EV Battery Voltage" is large when the boosting request is given. (1 trip detection logic)	<ul style="list-style-type: none"> <li>Inverter with converter assembly</li> <li>Battery ECU assembly</li> </ul>	Comes on	Master Warning:  Comes on	Hybrid Control	A	SAE Code:  P1C2D

## MONITOR DESCRIPTION

The hybrid vehicle control ECU monitors signals of HV battery voltage (VB) and boost converter voltage (VL) sensors. When a large difference occurs between the voltages from the VB and VL sensors, the hybrid vehicle control ECU interprets this as a failure of either of the sensors. The hybrid vehicle control ECU will illuminate the MIL and store a DTC.

## MONITOR STRATEGY

Related DTCs	P1C2D (INF P1C2D62): Hybrid / EV battery voltage / DC/DC converter voltage correlation
Required sensors/components	Boost converter
Frequency of operation	-
Duration	TMC's intellectual property
MIL operation	1 driving cycle
Sequence of operation	None

## TYPICAL ENABLING CONDITIONS

The monitor will run whenever the following DTCs are not stored	TMC's intellectual property
Other conditions belong to TMC's intellectual property	-

## TYPICAL MALFUNCTION THRESHOLDS

TMC's intellectual property	-
-----------------------------	---

## COMPONENT OPERATING RANGE

Hybrid vehicle control ECU	DTC P1C2D (INF P1C2D62) is not detected
----------------------------	---

## CONFIRMATION DRIVING PATTERN

### HINT:

- After repair has been completed, clear the DTC and then check that the vehicle has returned to normal by performing the following All Readiness check procedure.

Click here [INFO](#)

- When clearing the permanent DTCs, refer to the "CLEAR PERMANENT DTC" procedure.

Click here [INFO](#)

- Clear the DTCs (even if no DTCs are stored, perform the clear DTC procedure).
- Turn the ignition switch off and wait for 2 minutes or more.
- Turn the ignition switch to ON (READY). [\*1]
- With the shift lever in D, depress both the accelerator pedal and brake pedal at the same time to raise the "Hybrid/EV Battery SOC" to a sufficient level. [\*2]
- Move the shift lever to P, check that the engine is stopped and move the shift lever to N. [\*3]
- Set the A/C for maximum cooling. [\*4]
- Leave the vehicle for a few minutes. [\*5]

### HINT:

- When the accelerator pedal is not depressed with the ignition switch ON (READY) and shift lever in P, if "VL-Voltage before Boosting" and the "Hybrid/EV Battery Voltage" is approximately the same after repair, the condition is judged as normal.
- [\*1] to [\*5] : Normal judgment procedure.

The normal judgment procedure is used to complete DTC judgment and also used when clearing permanent DTCs.

- Enter the following menus: Powertrain / Hybrid Control / Utility / All Readiness.
- Check the DTC judgment result.

### HINT:

- If the judgment result shows NORMAL, the system is normal.
- If the judgment result shows ABNORMAL, the system has a malfunction.
- If the judgment result shows INCOMPLETE, perform the normal judgment procedure again.

## CAUTION / NOTICE / HINT

### HINT:

- P1C2D62 may be output as a result of the malfunction indicated by the DTCs in table below.
  - The chart above is listed in inspection order of priority.
  - Check DTCs that are output at the same time by following the listed order. (The main cause of the malfunction can be determined without performing unnecessary inspections.)

MALFUNCTION CONTENT	SYSTEM	RELEVANT DTC	
Microcomputer malfunction	Hybrid Control System	P060647	Hybrid/EV Powertrain Control Module Processor Watchdog / Safety MCU Failure
		P0A1B49	Drive Motor "A" Control Module Internal Electronic Failure
		P060B49	Hybrid/EV Powertrain Control Module A/D Processing Internal Electronic Failure
		P060687	Hybrid/EV Powertrain Control Module Processor to Monitoring Processor Missing Message
		P060A47	Hybrid/EV Powertrain Control Module Monitoring Processor Watchdog / Safety MCU Failure
		P060A87	Hybrid/EV Powertrain Control Module Processor from Monitoring Processor Missing Message
	Motor Generator Control System	P0A1A47	Generator Control Module Watchdog / Safety $\mu$ C Failure
		P0A1A49	Generator Control Module Internal Electronic Failure
		P0A1B1F	Generator Control Module Circuit Intermittent
		P1C2A1C	Generator A/D Converter Circuit Voltage Out of Range
		P1C2A49	Generator A/D Converter Circuit Internal Electronic Failure
		P313383	Communication Error from Generator to Drive Motor "A" Value of Signal Protection Calculation Incorrect
	Hybrid Battery System	P313386	Communication Error from Generator to Drive Motor "A" Signal Invalid
		P060B49	Hybrid/EV Battery Energy Control Module A/D Processing Internal Electronic Failure
		P060687	Hybrid/EV Battery Energy Control Module Processor to Monitoring Processor Missing Message
		P060A47	Hybrid/EV Battery Energy Control Module Monitoring Processor Watchdog / Safety MCU Failure
		P060A87	Hybrid/EV Battery Energy Control Module Processor from Monitoring Processor Missing Message
		P060B16	Hybrid/EV Battery Energy Control Module A/D Processing Circuit Voltage Below Threshold
Power source circuit malfunction	Motor Generator Control System	P06D61C	Generator Control Module Offset Power Circuit Voltage Out of Range
Communication system malfunction	Hybrid Control System	U011187	Lost Communication with Hybrid/EV Battery Energy Control Module "A" Missing Message
	Motor Generator Control System	P313387	Communication Error from Generator to Drive Motor "A" Missing Message

MALFUNCTION CONTENT	SYSTEM	RELEVANT DTC	
Sensor and actuator circuit malfunction	Hybrid Battery System	P301A1C	Hybrid Battery Stack 1 Cell Voltage Detection Voltage Out of Range
		P1A001C	Hybrid Battery Stack 2 Cell Voltage Detection Voltage Out of Range
		P1AFD1C	Flying Capacitor/Internal Control Module Hybrid/EV Battery Monitor Voltage Out of Range
System malfunction	Motor Generator Control System	P0E3116	DC/DC Converter Voltage Sensor "A" (VL) Circuit Voltage Below Threshold
		P0E3117	DC/DC Converter Voltage Sensor "A" (VL) Circuit Voltage Above Threshold

## PROCEDURE

### 1. CHECK DTC OUTPUT (HYBRID CONTROL, MOTOR GENERATOR, HV BATTERY)

(a) Check for DTCs.

**Powertrain > Hybrid Control > Trouble Codes**

**Powertrain > Motor Generator > Trouble Codes**

**Powertrain > HV Battery > Trouble Codes**

RESULT	PROCEED TO
<b>One of the following applies:</b> <ul style="list-style-type: none"> <li>Only P1C2D62 is output.</li> <li>One or more DTCs other than P0E311C, P0CA300, P0B231C, and DTCs in the table below are also output.</li> </ul>	A
P1C2D62 and P0E311C or P0CA300 are output at the same time.	B
P1C2D62 and P0B231C are output at the same time.	C
DTCs of hybrid control system in the tables below are output.	D
DTCs of motor generator control system in the tables below are output.	E
DTCs of hybrid battery system in the tables below are output.	F

MALFUNCTION CONTENT	SYSTEM	RELEVANT DTC	
Microcomputer malfunction	Hybrid Control System	P060647	Hybrid/EV Powertrain Control Module Processor Watchdog / Safety MCU Failure

MALFUNCTION CONTENT	SYSTEM	RELEVANT DTC	
		P0A1B49	Drive Motor "A" Control Module Internal Electronic Failure
		P060B49	Hybrid/EV Powertrain Control Module A/D Processing Internal Electronic Failure
		P060687	Hybrid/EV Powertrain Control Module Processor to Monitoring Processor Missing Message
		P060A47	Hybrid/EV Powertrain Control Module Monitoring Processor Watchdog / Safety MCU Failure
	Motor Generator Control System	P060A87	Hybrid/EV Powertrain Control Module Processor from Monitoring Processor Missing Message
		P0A1A47	Generator Control Module Watchdog / Safety $\mu$ C Failure
		P0A1A49	Generator Control Module Internal Electronic Failure
		P0A1B1F	Generator Control Module Circuit Intermittent
		P1C2A1C	Generator A/D Converter Circuit Circuit Voltage Out of Range
		P1C2A49	Generator A/D Converter Circuit Internal Electronic Failure
		P313383	Communication Error from Generator to Drive Motor "A" Value of Signal Protection Calculation Incorrect
		P313386	Communication Error from Generator to Drive Motor "A" Signal Invalid
	P313387	Communication Error from Generator to Drive Motor "A" Missing Message	
	Hybrid Battery System	P060B49	Hybrid/EV Battery Energy Control Module A/D Processing Internal Electronic Failure
		P060687	Hybrid/EV Battery Energy Control Module Processor to Monitoring Processor Missing Message
P060A47		Hybrid/EV Battery Energy Control Module Monitoring Processor Watchdog / Safety MCU Failure	
P060A87		Hybrid/EV Battery Energy Control Module Processor from Monitoring Processor Missing Message	
P060B16		Hybrid/EV Battery Energy Control Module A/D Processing Circuit Voltage Below Threshold	
P0E2D00		Hybrid/EV Battery Energy Control Module Hybrid/EV Battery Monitor Performance	
Power source circuit malfunction	Motor Generator Control System	P06D61C	Generator Control Module Offset Power Circuit Voltage Out of Range
Communication system malfunction	Hybrid Control System	U011187	Lost Communication with Hybrid/EV Battery Energy Control Module "A" Missing Message
		P312387	Lost Communication with Drive Motor Control Module "A" from Hybrid/EV Control Module Missing Message

MALFUNCTION CONTENT	SYSTEM	RELEVANT DTC	
Sensor and actuator circuit malfunction	Hybrid Battery System	P301A1C	Hybrid Battery Stack 1 Cell Voltage Detection Voltage Out of Range
		P1A001C	Hybrid Battery Stack 2 Cell Voltage Detection Voltage Out of Range
		P1A051C	Hybrid Battery Stack 3 Cell Voltage Detection Voltage Out of Range
		P1AFD1C	Flying Capacitor/Internal Control Module Hybrid/EV Battery Monitor Voltage Out of Range
System malfunction	Motor Generator Control System	P0E3116	DC/DC Converter Voltage Sensor "A" (VL) Circuit Voltage Below Threshold
		P0E3117	DC/DC Converter Voltage Sensor "A" (VL) Circuit Voltage Above Threshold

**HINT:**

- P1C2D62 may be output as a result of the malfunction indicated by the DTCs above.
  - a. The chart above is listed in inspection order of priority.
  - b. Check DTCs that are output at the same time by following the listed order. (The main cause of the malfunction can be determined without performing unnecessary inspections.)

(b) Turn the ignition switch off.

**B** ► REPLACE INVERTER WITH CONVERTER ASSEMBLY

**C** ► REPLACE BATTERY ECU ASSEMBLY

**D** ► GO TO DTC CHART (HYBRID CONTROL SYSTEM)

**E** ► GO TO DTC CHART (MOTOR GENERATOR CONTROL SYSTEM)

**F** ► GO TO DTC CHART (HYBRID BATTERY SYSTEM)

**A**



**2. CLEAR DTC**

Click here 

**NEXT**



### 3. CHECK DTC OUTPUT (CHECK FAILURE PART)

Pre-procedure1

(a) Apply the parking brake and secure the wheels using chocks.

**NOTICE:**

Perform this test with the AUTO function (shift-linked function) of the electric parking brake system off.

**HINT:**

When the parking brake indicator (red) is illuminated after the electric parking brake switch assembly has been pulled to the lock side, the maximum amount of braking force is applied if the electric parking brake switch assembly is pulled to the lock side one more time.

(b) Connect the GTS to the DLC3. \*1

(c) Turn the ignition switch to ON (READY). \*2

(d) Read the Data List. \*3

**Powertrain > Hybrid Control > Data List**

TESTER DISPLAY
Hybrid/EV Battery SOC
Hybrid/EV Battery Current

(e) If the value of "Hybrid/EV Battery SOC" is less than 55%, move the shift lever to D and charge the HV battery by depressing the accelerator pedal and brake pedal simultaneously until the value reaches 55% or more. \*4

(f) Move the shift lever to P. \*5

(g) Set the air conditioning to MAX COOL and turn the headlights on. \*6

(h) Confirm that "Hybrid/EV Battery Current" is more than 3 A. \*7

(i) With the engine stopped and the conditions of steps \*5, \*6 and \*7 satisfied, leave the vehicle for 15 seconds. \*8

(j) Enter the following menus: Powertrain / Hybrid Control, Motor Generator / Trouble codes. \*9

Procedure1

(k) Check for DTCs. \*10

**Powertrain > Hybrid Control > Trouble Codes**

**Powertrain > Motor Generator > Trouble Codes**

**Powertrain > HV Battery > Trouble Codes**

**NOTICE:**

If the low HV battery information comes on, move the shift lever to P and start the engine to charge the HV battery. After the engine stops, perform steps \*1 through \*10 again.

RESULT	PROCEED TO
No DTCs are output, or DTCs except the following are output.	A
P0E311C or P0CA300 are output.	B
P0B231C or P1C8349 are output.	C
P300000 is output.	D

Post-procedure1

(I) Turn the ignition switch off.

**B** ▶ REPLACE INVERTER WITH CONVERTER ASSEMBLY

**C** ▶ REPLACE BATTERY ECU ASSEMBLY

**D** ▶ LEAVE VEHICLE WITH SHIFT LEVER IN P, AND CHARGE HV BATTERY BY IDLING UNTIL IDLING STOPS (PERFORM STEPS \*1 THROUGH \*10)

**A**  
▼

<b>4.</b>	<b>READ VALUE USING GTS (DATA LIST)</b>
-----------	---

Pre-procedure1

(a) If the value of "Hybrid/EV Battery SOC" is less than 70%.

**Powertrain > Hybrid Control > Data List**

TESTER DISPLAY
Hybrid/EV Battery SOC

**HINT:**

If "Hybrid/EV Battery SOC" is 70% or more, reduce it to below 70% by leaving the hybrid system on with neutral (N) selected.

(b) Turn the ignition switch off and wait for 2 minutes or more.

(c) Connect the electric vehicle charger cable assembly, and plug-in charge the vehicle.

(d) When charge is completed within 20 seconds:

- (1) Disconnect the electric vehicle charger cable assembly and wait for 2 minutes or more.
- (2) Check for DTCs.

**Powertrain > Hybrid Control > Trouble Codes**

- (3) Turn the ignition switch off.

Procedure1

- (e) When charge is not completed within 20 seconds:

- (1) If the value of "Hybrid/EV Battery Voltage" and "Charging Voltage for Hybrid/EV Battery".

**Powertrain > Hybrid Control > Data List**

TESTER DISPLAY
Hybrid/EV Battery Voltage
Charging Voltage for Hybrid/EV Battery

RESULT		PROCEED TO
When charge is completed within 20 seconds:	P1C2D62 and P0D4C1C only is output.	A
	Except above	B
When charge is not completed within 20 seconds:	Difference between "Hybrid/EV Battery Voltage" and "Charging Voltage for Hybrid/EV Battery" is less than 33 V.	C
	Difference between "Hybrid/EV Battery Voltage" and "Charging Voltage for Hybrid/EV Battery" is 33 V or more.	A

Post-procedure1

- (f) Turn the ignition switch off.

**A** ► REPLACE BATTERY ECU ASSEMBLY

**B** ► GO TO DTC CHART (HYBRID CONTROL SYSTEM)

**C** ► REPLACE INVERTER WITH CONVERTER ASSEMBLY

