2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

#### 2000-06 TRANSMISSION

### **Continuously Variable Transmission (CVT) - Insight**

# CVT

### SPECIAL TOOLS

Ref. No.	Tool Number	Description	Qty
1	07GAB-PF50101 or 07GAB-PF50100	Mainshaft Holder	1
2	07GAD-SD40101	Attachement, 78 x 90 mm	1
3	07GAE-PG40200 or 07GAE-PG4020A	Clutch Spring Compressor Bolt Assembly	1
4	07HAC-PK40102	Housing Puller	1
(5)	07HAJ-PK40201	Preload Inspection Tool	1
6	07JAB-001020A	Holder Handle	1
(i)	07JAD-PH80101	Oil Seal Driver Attachment	1
8	07JAF-SJ80110	Installer Shaft, 14 x 165 mm	1
9	07JAF-SJ80120	Installer Nut, 14 mm	2
10	07KAF-PS30120	Bearing Installer Attachment	1
(1)	07KAF-PS30200	Bearing Separator	1
(12)	07LAD-PW50601	Attachment, 40 x 50 mm	2
(13)	07LAE-PX40100	Clutch Spring Compressor Attachment	1
14	07LAF-PZ70110	Bearing Installer Attachment	1
(15)	07MAJ-PY4011A	A/T Pressure Hose, 2,210 mm	3
(16)	07MAJ-PY40120	A/T Pressure Hose Adapter	3
1	07QAD-P0A0100	Attachment, 42 mm I.D.	1
(18)	07RAB-TB4010A or 07RAB-TB4010B	Companion Flange Holder	2
(19)	07SAZ-001000A	Backprobe Set	2
20	07ZAE-PRP0100	Clutch Compressor Attachment	1

(4): If the top arm is too short, replace it with 07SAC-P0Z1001.

(1): 07HAE-PL50101 may also be used to substitute one of these tools.



2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# Fig. 1: Special Tools Specifications Courtesy of AMERICAN HONDA MOTOR CO., INC.

### GENERAL TROUBLESHOOTING INFORMATION

How to Check for DTCs with the Honda Diagnostic System

When the transmission control module (TCM) senses an abnormality in the input or output systems, the D indicator (A) in the gauge assembly (B) will usually blink.



G03681700

# **Fig. 2: Identifying Illumination Of D Indicator In Gauge Assembly Courtesy of AMERICAN HONDA MOTOR CO., INC.**

When the data link connector (DLC) (A) (located under the driver's side of the dashboard) is connected to the Honda diagnostic system (HDS), it will indicate the

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

diagnostic trouble code (DTC) when the ignition switch is turned ON (II) and the appropriate menu is selected.



G03681701

# **Fig. 3: Identifying Data Link Connector** Courtesy of AMERICAN HONDA MOTOR CO., INC.

If the D indicator or malfunction indicator lamp (MIL) has been reported on, or if a driveability problem is suspected, follow this procedure:

- 1. Connect the HDS to the DLC. (See the HDS user's manual for specific instructions.)
- 2. Turn the ignition switch ON (II), select A/T system, and observe the DTC in

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

the DTCs MENU on the HDS screen.

- 3. Record all fuel and emissions DTCs, A/T DTCs, and freeze data.
- 4. If there is a fuel and emissions DTC, first check the fuel and emissions system as indicated by the DTC (except for DTC P0700, DTC P0700 means there is one or more A/T DTCs, and no problems were detected in the fuel and emissions circuit of the ECM).
- 5. Clear the DTC and data.
- 6. Drive the vehicle for several minutes under the same conditions as those indicated by the freeze data, and then recheck for a DTC. If the A/T DTC returns, go to the <u>DTC TROUBLESHOOTING INDEX</u>. If the DTC does not return, there was an intermittent problem within the circuit. Make sure all pins and terminals in the circuit are tight.

Symptom Troubleshooting Versus DTC Troubleshooting

Some symptoms will not trigger diagnostic trouble codes (DTCs) or cause the D indicator to blink. If the malfunction indicator lamp (MIL) was reported ON or the D indicator has been blinking, check for DTCs. If the vehicle has an abnormal symptom, and there are no DTCs stored, go to the <u>SYMPTOM</u> <u>TROUBLESHOOTING INDEX</u>. Check the list of probable cause(s) for the symptom, in the sequence listed, until you find the problem.

How to Check for DTCs with the SCS Mode (retrieving the flash codes)

# NOTE: The preferred method is to use the HDS to retrieve the DTCs.

When the TCM senses an abnormality in the input or output system, the D indicator (A) in the gauge assembly (B) will usually blink.

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03681702

# **Fig. 4: Identifying Illumination Of D Indicator In Gauge Assembly** Courtesy of AMERICAN HONDA MOTOR CO., INC.

When the D indicator has been reported on, connect the HDS to the DLC (A) (located under the dash behind the center console). Turn the ignition switch ON (II), select SCS mode, then the D indicator will indicate (blink) the DTC.

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03681703

# **Fig. 5: Identifying Data Link Connector** Courtesy of AMERICAN HONDA MOTOR CO., INC.

If the D indicator and the MIL come on at the same time, or if a driveability problem is suspected, follow this procedures:

- 1. Connect the HDS to the DLC. (See the HDS user's manual for specific instructions.)
- 2. Turn the ignition switch ON (II), select SCS mode, then observe the D indicator in the gauge assembly. Codes 1 through 9 are indicated by individual short blinks. Codes 10 and above are indicated by a series of long and short blinks. One long blink equals 10 short blinks. Add the long and short blinks

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

together to determine the code.

# **Example: DTC 1**



# **Fig. 6: Blinking Pattern Of MIL (Example DTC 1)** Courtesy of AMERICAN HONDA MOTOR CO., INC.

# Example: DTC 15



# **Fig. 7: Blinking Pattern Of MIL (Example DTC 15)** Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 3. Record all fuel and emissions DTCs and A/T DTCs.
- 4. If there is a fuel and emissions DTC, first check the fuel and emissions system as indicated by the DTC (except DTC 70, DTC 70 means there is one or more A/T DTCs, and no problems were detected in the fuel and emissions circuit of the ECM).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

- 5. Clear the DTC and data.
- 6. Drive the vehicle for several minutes under the same conditions as those indicated by the freeze data, and then recheck for DTC. If the A/T DTC returns, go to the <u>DTC TROUBLESHOOTING INDEX</u>. If the DTC does not return, there was an intermittent problem within the circuit. Make sure all pins and terminals in the circuit are tight.

How to Troubleshoot Circuit at the TCM

# **Special Tools Required**

Backprobe set 07SAZ-001000A (two required)

- 1. Remove the passenger's carpet, then remove the right kick panel.
- 2. Remove the mounting bolts securing the EPS control unit, but do not disconnect EPS control unit connectors, then remove the TCM cover (A).



G03681706

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# **Fig. 8: Identifying Loosening Torque Of EPS Control Unit Mounting Bolts Courtesy of AMERICAN HONDA MOTOR CO., INC.**

- 3. Remove the TCM (B).
- 4. Connect the backprobe adapters (A) to the stacking patch cords (B), and connect the cords to a multimeter (C).



G03681707

# **Fig. 9: Connecting Backprobe Adapters To Stacking Patch Cords, And To** <u>Multimeter</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 5. Using the wire insulation as a guide for the contoured tip of the backprobe adapter, gently slide the tip into the connector from the wire side until it touches the end of the wire terminal.
- 6. If you cannot get to the wire side of the connector or the wire side is sealed, disconnect the connector and use the tester probe to probe the connectors from the terminal side. Do not force the probe into the connector.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

Clear A/T DTCs, and TCM Reset Procedures

1. Connect the HDS to the DLC (A).



G03681708

# **Fig. 10: Identifying Data Link Connector** Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 2. Turn the ignition switch ON (II).
- 3. Clear the DTC(s) on the HDS screen.

#### **TCM Reset Procedures**

1. Get the audio (and navigation) anti-theft codes, and write down the presets.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

- 2. Turn the ignition switch OFF.
- 3. Use one of these methods to reset the TCM memory:
  - Use the Scan Tool or the HDS, then go to step 7.
  - Remove the No. 18 (7.5 A) fuse (A) in the under-dash fuse/relay box (B) for more than 10 seconds. Then go to step 3.



### G03681709

# **Fig. 11: Removing Number 18 (7.5A) Fuse** Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 4. Remove the No. 15 (40 A) fuse from the under-hood fuse/relay box.
- 5. If the IMA battery level gauge (BAT) displays no segments, start the engine, and hold it between 3,500 RPM and 4,000 RPM without load (in the P or N

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

position) until the BAT displays at least three segments.

- 6. Reinstall the No. 15 (40 A) fuse to the under-hood fuse/relay box.
- 7. Do the ECM idle learn procedure (see ECM IDLE LEARN PROCEDURE ).
- 8. Do the start clutch calibration procedure (see <u>START CLUTCH</u> <u>CALIBRATION PROCEDURES</u>).

How to End a Troubleshooting Session

This procedure must be done after any troubleshooting.

- 1. Turn the ignition switch OFF.
- 2. Reset the TCM. Use the HDS, then disconnect HDS from the DLC (A).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03681710

# **Fig. 12: Identifying Data Link Connector** Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 3. Turn the ignition switch ON (II).
- 4. Enter the anti-theft codes, then enter the customer's audio presets, and set the clock.
- 5. To verify that the problem is repaired, test-drive the vehicle for several minutes at speeds over 30 mph (50 km/h).
- 6. Do the Start Clutch Calibration Procedures (see <u>START CLUTCH</u> <u>CALIBRATION PROCEDURES</u>).

#### DTC TROUBLESHOOTING INDEX

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

2001-2004 Models

# NOTE: Record all freeze data and review General Troubleshooting Information (see <u>GENERAL TROUBLESHOOTING</u> <u>INFORMATION</u>) before you troubleshoot.

# DTC TROUBLESHOOTING INDEX

DTC (1)	D Indicator	MIL	<b>Detection Item</b>	Page
P0725 (11-1) (2)	Blinks	ON	Engine speed input circuit	(see DTC P0725: PROBLEM IN ENGINE SPEED INPUT CIRCUIT )
P1630 (0-2) <sup>(2)</sup>	Blinks	ON	Transmission control module (TCM)	(see DTC P0725: PROBLEM IN ENGINE SPEED INPUT <u>CIRCUIT</u> )
P1655 (37-1) (2)	Blinks	OFF	Communication lines (TMA and TMB) between ECM and TCM	(see DTC P1655: PROBLEM IN TCM-TO-ECM COMMUNICATION LINES )
P1705 (5-1) <sup>(2)</sup>	Blinks	ON	Transmission range switch (short to ground)	(see DTC P1705: SHORT IN TRANSMISSION RANGE SWITCH CIRCUIT )
P1706 (6-1) <sup>(2)</sup>	OFF	ON	Transmission range switch (open)	(see DTC P1706: OPEN IN TRANSMISSION RANGE SWITCH CIRCUIT )
P1790 (3-3, 3- 4) <sup>(2)</sup>	Blinks	ON	Throttle position sensor circuit	(see DTC P1790: PROBLEM IN THROTTLE POSITION SENSOR CIRCUIT )
P1791 (4-1) <sup>(2)</sup>	Blinks	OFF	Vehicle speed sensor	(see DTC P1791: PROBLEM IN VEHICLE SPEED SENSOR CIRCUIT )
P1792 (10-3,	Blinks	OFF	Engine coolant temperature sensor	(see DTC P1792: PROBLEM IN ENGINE COOLANT TEMPERATURE SENSOR

$10-4)^{(2)}$			circuit	<u>CIRCUIT</u> )
P1793 (12-3, 12-4) <sup>(2)</sup>	Blinks	ON	Manifold absolute pressure sensor circuit	(see DTC P1793: PROBLEM IN MANIFOLD ABSOLUTE PRESSURE SENSOR CIRCUIT )
P1799 (92-3, 92-4) <sup>(2)</sup>	Blinks	OFF	Intake air temperature sensor circuit	(see DTC P1799: PROBLEM IN INTAKE AIR TEMPERATURE SENSOR CIRCUIT )
P1850 (90-1) (2)	Blinks	OFF	Creep aid system solenoid valve A	(see DTC P1850: PROBLEM IN CREEP AID SYSTEM SOLENOID VALVE A <u>CIRCUIT</u> )
P1851 (91-1) (2)	Blinks	OFF	Creep aid system solenoid valve B	(see DTC P1851: PROBLEM IN CREEP AID SYSTEM SOLENOID VALVE B CIRCUIT )
P1879 (32-1) (2)	Blinks	ON	CVT start clutch pressure control valve circuit	(see DTC P1879: PROBLEM IN CVT START CLUTCH PRESSURE CONTROL VALVE CIRCUIT )
P1882 (33-1) (2)	Blinks	OFF	Inhibitor solenoid	(see DTC P1882: PROBLEM IN INHIBITOR SOLENOID CIRCUIT )
P1885 (34-1) (2)	Blinks	ON	CVT input shaft (drive pulley) speed sensor	(see DTC P1885: PROBLEM IN CVT INPUT SHAFT (DRIVE PULLEY) SPEED SENSOR CIRCUIT )
P1886 (35-1) (2)	Blinks	ON	CVT output shaft (driven pulley) speed sensor	(see DTC P1886: PROBLEM IN CVT OUTPUT SHAFT (DRIVEN PULLEY) SPEED SENSOR CIRCUIT )
P1888				(see DTC P1888: PROBLEM

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

(36-1) (2)	Blinks	ON	CVT speed sensor	IN CVT SPEED SENSOR <u>CIRCUIT</u> )
P1890 (42-1)	Blinks	ON	Shift control system	(see DTC P1890: PROBLEM IN SHIFT CONTROL SYSTEM )
P1891 (43-1)	Blinks	ON	Start clutch control system	(see DTC P1891: PROBLEM IN START CLUTCH CONTROL SYSTEM)
P1894 (38-1) (2)	Blinks	ON	CVT drive pulley pressure control valve circuit	(see DTC P1894: PROBLEM IN CVT DRIVE PULLEY PRESSURE CONTROL VALVE CIRCUIT )
P1895 (39-1) (2)	Blinks	ON	CVT driven pulley pressure control valve circuit	(see DTC P1895: PROBLEM IN CVT DRIVEN PULLEY PRESSURE CONTROL VALVE CIRCUIT )

#### NOTE:

(1) The DTC in parenthesis is the Honda code that you will see when you use the HDS. The first number(s) before the - (hyphen) is the flash code the D indicator indicates when the data link connector (DLC) is connected to the HDS, and the HDS in SCS mode.

(2) This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.

2005-2006 Models

# NOTE: Record all freeze data and review General Troubleshooting Information (see <u>GENERAL TROUBLESHOOTING</u> <u>INFORMATION</u>) before you troubleshoot.

# **MODELS DESCRIPTION**

DTC (1)	D Indicator	MIL	<b>Detection Item</b>	Page
P0501 (4-5) (2)	Blinks	ON	Vehicle speed sensor circuit (range/performance)	(see <u>DTC P0501:</u> RANGE/PERFORMANCE PROBLEM IN VEHICLE

				<b>SPEED SENSOR CIRCUIT</b> )
P0502 (4-3) (2)	Blinks	ON	Vehicle speed sensor circuit (no signal input)	(see DTC P0502: PROBLEM IN VEHICLE SPEED SENSOR CIRCUIT (NO SIGNAL INPUT) )
P0603 (0-3) (2)	Blinks	ON	Transmission control module (TCM)	(see DTC P0603: PROBLEM IN TCM )
P0705 (5-2) (2)	Blinks	ON	Transmission range switch circuit (short to ground) (multiple shift-position input)	(see DTC P0705: SHORT IN TRANSMISSION RANGE SWITCH CIRCUIT (MULTIPLE SHIFT- POSITION INPUT))
P0706 (6-2) (2)	Not blinks	ON	Transmission range switch circuit (open)	(see DTC P0706: OPEN IN TRANSMISSION RANGE SWITCH CIRCUIT )
P0716 (34-5) (2)	Blinks	ON	CVT input shaft (drive pulley) speed sensor circuit (range/performance)	(see DTC P0716: RANGE/PERFORMANCE PROBLEM IN CVT INPUT SHAFT (DRIVE PULLEY) SPEED SENSOR CIRCUIT)
P0717 (34-3) (2)	Blinks	ON	CVT input shaft (drive pulley) speed sensor circuit (no signal input)	(see DTC P0717: PROBLEM IN CVT INPUT SHAFT (DRIVE PULLEY) SPEED SENSOR CIRCUIT (NO SIGNAL INPUT) )
P0721 (35-5) (2)	Blinks	ON	CVT output shaft (driven pulley) speed sensor circuit (range/performance)	(see DTC P0721: RANGE/PERFORMANCE PROBLEM IN CVT OUTPUT SHAFT (DRIVEN PULLEY) SPEED SENSOR CIRCUIT )
P0722 (35-3)	Blinks	ON	CVT output shaft (driven pulley) speed	(see DTC P0722: PROBLEM IN CVT OUTPUT SHAFT (DRIVEN PULLEY) SPEED

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

(2)			sensor circuit (no signal input)	SENSOR CIRCUIT (NO SIGNAL INPUT) )
P0726 (11-5) (2)	Blinks	ON	Engine RPM signal input circuit (range/ performance)	(see DTC P0726: RANGE/PERFORMANCE PROBLEM IN ENGINE RPM SIGNAL INPUT CIRCUIT )
P0727 (11-3) (2)	Blinks	ON	Engine RPM signal input circuit (no signal input)	(see DTC P0727: PROBLEM IN ENGINE RPM SIGNAL INPUT CIRCUIT (NO SIGNAL INPUT) )

#### NOTE:

(1) The DTC in parenthesis is the Honda code that you will see when you use the HDS. The first number(s) before the - (hyphen) is the flash code the D indicator indicates when the data link connector (DLC) is connected to the HDS, and the HDS in SCS mode.

(2) This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.

2005-2006 Models

# NOTE: Record all freeze data and review General Troubleshooting Information (see <u>GENERAL TROUBLESHOOTING</u> <u>INFORMATION</u>) before you troubleshoot.

# **MODELS DESCRIPTION**

DTC (1)	D Indicator	MIL	Detection Item	Page
P0780 (42-2)	Blinks	ON	Shift control system	(see DTC P0780: PROBLEM IN SHIFT CONTROL SYSTEM )
P0801 (33-2) (2)	Blinks	OFF	Inhibitor solenoid circuit	(see DTC P0801: PROBLEM IN INHIBITOR SOLENOID CIRCUIT )
P0811 (43-2)	Blinks	ON	Start clutch control system	(see DTC P0811: PROBLEM IN START CLUTCH CONTROL SYSTEM )
i				

P0962 (38-3) (2)	Blinks	ON	CVT drive pulley pressure control valve circuit low	(see DTC P0962: CVT DRIVE PULLEY PRESSURE CONTROL VALVE CIRCUIT LOW VOLTAGE )
P0963 (38-4) (2)	Blinks	ON	CVT drive pulley pressure control valve circuit high	(see DTC P0963: CVT DRIVE PULLEY PRESSURE CONTROL VALVE <u>CIRCUIT HIGH</u> <u>VOLTAGE</u> )
P0966 (39-3) (2)	Blinks	ON	CVT driven pulley pressure control valve circuit low	(see DTC P0966: CVT DRIVEN PULLEY PRESSURE CONTROL VALVE CIRCUIT LOW <u>VOLTAGE</u> )
P0967 (39-4) (2)	Blinks	ON	CVT driven pulley pressure control valve circuit high	(see DTC P0967: CVT DRIVEN PULLEY PRESSURE CONTROL VALVE CIRCUIT HIGH VOLTAGE)
P0970 (32-3) (2)	Blinks	ON	CVT start clutch pressure control valve circuit low	(see DTC P0970: CVT START CLUTCH PRESSURE CONTROL VALVE CIRCUIT LOW VOLTAGE)
P0971 (32-4) (2)	Blinks	ON	CVT start clutch pressure control valve circuit high	(see DTC P0971: CVT START CLUTCH PRESSURE CONTROL VALVE CIRCUIT HIGH VOLTAGE)
P1655 (37-1) (2)	Blinks	OFF	Transmisison control module (TCM)-to- engine control module (ECM) communication circuit	(see DTC P1655: PROBLEM IN TCM-TO-ECM COMMUNICATION LINES )

P1782 (3-11) (2)	Blinks	ON	Throttle position (TP) sensor circuit low	(see DTC P1782: TP SENSOR CIRCUIT LOW VOLTAGE )
P1783 (3-12) (2)	Blinks	ON	Throttle position (TP) sensor circuit high	(see DTC P1783: TP SENSOR CIRCUIT HIGH VOLTAGE )
P1784 (12- 11) <sup>(2)</sup>	Blinks	ON	Manifold absolute pressure (MAP) sensor circuit low	(see DTC P1784: MAP SENSOR CIRCUIT LOW VOLTAGE )
P1785 (12- 12) <sup>(2)</sup>	Blinks	ON	Manifold absolute pressure (MAP) sensor circuit high	(see DTC P1785: MAP SENSOR CIRCUIT HIGH VOLTAGE )
P1792 (10-3, 10-4) (2)	Blinks	OFF	Engine coolant temperature (ECT) sensor circuit	(see DTC P1792: PROBLEM IN ENGINE COOLANT TEMPERATURE SENSOR <u>CIRCUIT</u> )
P1799 (92-3, 92-4) (2)	Blinks	OFF	Intake air temperature (IAT) sensor circuit	(see DTC P1799: PROBLEM IN INTAKE AIR TEMPERATURE SENSOR <u>CIRCUIT</u> )
P1850 (90-1) (2)	Blinks	OFF	Creep aid system solenoid valve A	(see DTC P1850: PROBLEM IN CREEP AID SYSTEM SOLENOID VALVE A <u>CIRCUIT</u> )
P1851 (91-1) (2)	Blinks	OFF	Creep aid system solenoid valve B	(see DTC PI851: PROBLEM IN CREEP AID SYSTEM SOLENOID VALVE B <u>CIRCUIT</u> )
P2159 (36-9) (2)	Blinks	ON	CVT speed sensor circuit (range/performance)	(see DTC P2159: RANGE/PERFORMANCE PROBLEM IN CVT SPEED SENSOR CIRCUIT )

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

P2160 (36-7) (2)	Blinks	ON	CVT speed sensor circuit (no signal input)	(see DTC P2160: PROBLEM IN CVT SPEED SENSOR CIRCUIT (NO SIGNAL INPUT))
------------------------	--------	----	--	---

#### NOTE:

- (1) The DTC in parenthesis is the Honda code that you will see when you use the HDS. The first number(s) before the - (hyphen) is the flash code the D indicator indicates when the data link connector (DLC) is connected to the HDS, and the HDS in SCS mode.
- (2) This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.

### SYMPTOM TROUBLESHOOTING INDEX

# SYMPTOM TROUBLESHOOTING

Symptom	Probable cause(s)	Notes
When you turn the ignition switch ON (II), the D indicator comes on and stays on in all shift lever positions, or it never comes on at all	A problem in the D indicator circuit	Check the D indicator circuit (see <u>D</u> <u>INDICATOR CIRCUIT</u> <u>TROUBLESHOOTING</u> ).
Transmission does not shift into S mode when pressing the S mode button, or does not return to D mode from S mode	A problem in the mode switch circuit	Check the mode switch circuit (see <u>MODE SWITCH CIRCUIT</u> <u>TROUBLESHOOTING</u> ).
S indicator does not come on	A problem in the S	Check the S indicator circuit (see <u>S</u> INDICATOR CIRCUIT

when the S mode is selected	indicator circuit	TROUBLESHOOTING ).
Vehicle feels like the brakes drag	A problem in the creep aid system	Check the creep aid system solenoid valves A and B circuit (see <u>CREEP</u> <u>AID SYSTEM SOLENOID VALVE</u> <u>A AND B TROUBLESHOOTING</u> ).
Shift lever cannot be moved from P while you are pressing on the brake pedal	A problem in the shift lock system (interlock system)	Check the interlock system - shift lock system circuit (see <u>SHIFT LOCK</u> <u>SYSTEM CIRCUIT</u> <u>TROUBLESHOOTING</u> ).
Ignition switch cannot be moved from ACC (I) to LOCK (0) (key is pushed in, shift lever in P)	A problem in the key interlock system (interlock system)	Check the interlock system - key interlock system circuit (see <u>KEY</u> <u>INTERLOCK SYSTEM CIRCUIT</u> <u>TROUBLESHOOTING</u> ).
	<ol> <li>Low CVT Fluid level</li> <li>ATF pump worn, binding, or foreign materials in ATF pump</li> <li>ATF pump</li> <li>ATF pump chain or ATF pump sprocket worn or damaged</li> <li>Input shaft worn or</li> </ol>	<ul> <li>Check the CVT Fluid level, and check the ATF cooler lines for leakage and loose connections. If necessary, clean the ATF cooler lines.</li> <li>Inspect the differential pinion gears for wear. If the differential pinion gears are worn, replace the differential assembly, replace the ATF strainer, thoroughly clean the transmission, cooler and cooler lines.</li> <li>Check that the ATF strainer is in good condition, if the ATF strainer is clogged with particles of steel or aluminum, inspect the ATF pump. If the ATF pump is OK, find the</li> </ul>

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

damaged components that caused the debris.

• Inspect the planetary carrier, drive pulley shaft, ATF pump drive sprocket, and flywheel. If any part is worn or damaged, replace it.

• Inspect the drive pulley pressure, driven pulley pressure, and forward clutch feed pipes for wear, damage and out of round. If the drive pulley pressure feed pipe is scored, replace the end cover. If the forward clutch feed pipe is scored, replace the O-ring under the feed pipe guide.

• Replace the start clutch assembly if the secondary drive gear is worn or damaged. Inspect the secondary gear shaft thrust clearance if the secondary driven gear is worn or damaged.

- Inspect the input shaft splines and flywheel housing input shaft oil seal for wear and damage.
- Check the forward clutch pressure.
  - Inspect the forward clutch piston, clutch piston check valve, and Orings. Check the spring retainer for wear and damage. Inspect the clutch end-plate-to-top-disc
     clearance. If the clearance is out of tolerance, inspect the clutch discs and plates for wear and damage. If the discs and plates are worn or

damaged

- 5. Sun gear worn or damaged
  - 6. Final driven gear worn or damaged
- 7. Secondary drive gear and secondary driven gear worn or damaged
  - 8. Flywheel and drive plate worn or damaged
  - 9. Intermediate housing assembly worn or damaged
- 10. Forward clutch defective
  - 11. Start clutch defective
- 12. ATF strainer and ATF filter clogged
- 13. Lower valve body assembly defective
- 14. CVT drive pulley pressure control valve defective

Engine runs, but vehicle does not move in any position

	<ul> <li>15. CVT driven pulley pressure pulley pressure control valve defective</li> <li>16. CVT start clutch pressure control valve defective</li> <li>17. Manual valve body defective</li> </ul>	<ul> <li>damaged, replace them as a set. If they are OK, adjust the clearance with the clutch end-plate.</li> <li>Inspect the forward clutch feed pipe for wear, damage, and out of round. If the feed pipe is scored, replace it and the O-ring under the feed pipe guide.</li> <li>Calibrate the start clutch control system after replacing the start clutch.</li> <li>Check for a stored DTC, and check for loose solenoid harness connector.</li> </ul>
Vehicle moves in R, but not in D and L	<ol> <li>Forward clutch defective</li> <li>Shift cable broken or out of adjustment, or shift cable end removed</li> <li>Manual valve lever and lever pin defective</li> <li>Start clutch defective</li> <li>Manual valve body defective</li> </ol>	<ul> <li>Check the forward clutch pressure.</li> <li>Inspect the clutch piston, clutch piston check valve, and O-rings. Check the spring retainer for wear and damage. Inspect the clutch end-plate-to-top-disc clearance. If the clearance is out of tolerance, inspect the clutch discs and plates for wear and damage. If the discs and plates are worn or damaged, replace them as a set. If they are OK, adjust the clearance with the clutch end-plate.</li> <li>Inspect the forward clutch feed pipe for wear, damage, and out of round. If the feed pipe is scored, replace it and the O-ring under the feed pipe guide.</li> <li>Check for a loose shift cable at the shift lever and the transmission</li> </ul>

2000-06 TRANSMISSION Continuously	Variable Transmission (CVT) - Insigh
-----------------------------------	--------------------------------------

		control lever. • Calibrate the start clutch control system after replacing the start clutch.
Vehicle moves in D and L, but not in R	<ol> <li>Sun gear worn or damaged</li> <li>Forward clutch defective</li> <li>Shift cable broken or out of adjustment, or shift cable end removed</li> <li>Manual valve lever and lever pin defective</li> <li>Reverse brake defective</li> <li>Reverse brake defective</li> <li>Reverse brake defective</li> <li>Reverse brake defective</li> <li>Reverse brake defective</li> <li>Reverse brake defective</li> <li>Reverse brake piston and related parts stuck, worn or damaged</li> <li>Planetary carrier worn or damaged</li> </ol>	<ul> <li>Check the forward clutch pressure.</li> <li>Inspect the clutch piston, clutch piston check valve, and O-rings. Check the spring retainer for wear and damage. Inspect the clutch end-plate-to-top-disc clearance. If the clearance is out of tolerance, inspect the clutch discs and plates for wear and damage. If the discs and plates are worn or damaged, replace them as a set. If they are OK, adjust the clearance with the clutch end-plate.</li> <li>Inspect the forward clutch feed pipe for wear, damage, and out of round. If the feed pipe guide.</li> <li>Check for a loose shift cable at the shift lever and the transmission control lever.</li> <li>Check the reverse brake pressure.</li> <li>Inspect the brake piston and O-rings. Check the spring retainer and return spring assembly for wear and damage. Inspect the brake end-plate-to-top-disc clearance. If the clearance is out of tolerance, inspect the brake discs and plates for wear and damage. Inspect the brake discs and plates for wear and damage. If the clearance is out of tolerance, inspect the brake discs and plates for wear and damage. If the clearance is out of tolerance, inspect the brake discs and plates for wear and damage. If the clearance is out of tolerance, inspect the brake discs and plates for wear and damage. If the clearance is out of tolerance, inspect the brake discs and plates for wear and damage. If the clearance is out of tolerance, inspect the brake discs and plates for wear and damage. If the clearance is out of tolerance, inspect the brake discs and plates for wear and damage. If the clearance is out of tolerance, is plate to the brake discs and plates for wear and damage. If the clearance is out of tolerance, inspect the brake discs and plates for wear and damage. If the clearance is out of tolerance, inspect the brake discs and plates for wear and damage. If the clearance is out of tolerance, inspect the brake discs and plates for wear and damage.</li> </ul>

	8. Manual valve body defective	discs and plates are worn or damaged, replace them as a set. If they are OK, adjust the clearance with the brake end-plate. • Inspect the reverse brake piston, piston O-rings, return spring and spring retainer assembly, discs and plates for wear and damage.
No shift to higher ratio or lower ratio	<ol> <li>Intermediate housing assembly worn or damaged</li> <li>Pulley pressure feed pipe damaged or out of round</li> <li>CVT input shaft (drive pulley) speed sensor and CVT output shaft (driven pulley) speed sensor defective</li> <li>CVT speed sensor defective</li> <li>TCM defective</li> <li>Lower valve body assembly defective 7. CVT drive pulley pressure control valve defective</li> <li>CVT driven</li> </ol>	<ul> <li>Inspect the drive pulley pressure feed pipe. If the feed pipe is scored, replace the end cover.</li> <li>Replace the input shaft if the bushing for the drive pulley pressure feed pipe is loose or damaged.</li> <li>Inspect the driven pulley pressure feed pipe. If the feed pipe is scored, replace it and the O-ring under the feed pipe guide.</li> <li>Replace the drive pulley shaft with the intermediate housing assembly if the bushing for the driven pulley pressure feed pipe is loose or damaged.</li> <li>Check the drive pulley and driven pulley pressure, and lubrication pressure. If low or no pressure, check the ATF pump, pump chain, and sprockets.</li> <li>Check for a stored DTC, and check</li> </ul>

	pulley pressure control valve defective 8. Solenoid harness worn or damaged	for loose connectors. • Check the speed sensors installation.
Poor acceleration	<ol> <li>Intermediate housing assembly worn or damaged</li> <li>Pulley pressure feed pipe damaged or out of round</li> <li>CVT input shaft (drive pulley) speed sensor and CVT output shaft (driven pulley) speed sensor defective</li> <li>CVT speed sensor defective</li> <li>TCM defective</li> <li>Start clutch defective</li> <li>Start clutch defective</li> <li>IMA motor defective</li> <li>Lower valve body assembly defective 9. CVT drive pulley pressure</li> </ol>	<ul> <li>Inspect the drive pulley pressure feed pipe. If the feed pipe is scored, replace the end cover.</li> <li>Replace the input shaft if the bushing for the drive pulley pressure feed pipe is loose or damaged.</li> <li>Inspect the driven pulley pressure feed pipe. If the feed pipe is scored, replace it and the O-ring under the feed pipe guide.</li> <li>Replace the drive pulley shaft with the intermediate housing assembly if the bushing for the driven pulley pressure feed pipe is loose or damaged.</li> <li>Check the drive pulley and driven pulley pressure, and lubrication pressure. If low or no pressure, check the ATF pump, pump chain, and sprockets. Check for a stored DTC, and check for loose</li> </ul>

	control valve defective 9. CVT driven pulley pressure control valve defective 10. CVT start clutch pressure control valve defective 11. Solenoid harness worn or damaged	connectors. • Check the speed sensors installation. • Calibrate the start clutch control system after replacing the start clutch.
Flares while driving	<ol> <li>Intermediate housing assembly worn or damaged</li> <li>Forward clutch defective</li> <li>TCM defective</li> <li>Start clutch defective</li> <li>Start clutch feed pipe damaged or out of round</li> <li>Lower valve body assembly defective</li> <li>CVT drive pulley pressure control valve defective</li> <li>CVT drive</li> </ol>	<ul> <li>Check the forward clutch pressure.</li> <li>Inspect the clutch piston, clutch piston check valve, and O-rings. Check the spring retainer for wear and damage. Inspect the clutch end-plate-to-top-disc clearance. If the clearance is out of tolerance, inspect the clutch discs and plates for wear and damage. If the discs and plates are worn or damaged, replace them as a set. If they are OK, adjust the clearance with the clutch end-plate.</li> <li>Inspect the forward clutch feed pipe for wear, damage, and out of round. If the feed pipe is scored, replace it and the O-ring under the feed pipe guide.</li> </ul>

	pulley pressure	• Check for a stored DTC and check
	control valve	for loose connectors.
	defective	• Calibrate the start clutch control
	9. CVT start	system after replacing the start
	clutch pressure	clutch.
	control valve	• Inspect the start clutch feed pipe. If
	defective	the feed pipe is scored, replace the
	10. Solenoid	end cover.
	harness worn or	• Replace the drive pulley shaft with
	damaged	the intermediate housing assembly.
	11. Start clutch	if the bushing for the start clutch
	control system	feed pipes are loose or damaged.
	memory in	
	TCM defective	
	1 Intermediate	
	1. Interneturate	• Check the forward clutch pressure.
	assembly worn	• Inspect the clutch piston, clutch
	or damaged	piston check valve, and O-rings.
	2 Forward alutah	Check the spring retainer for wear
	2. Forward crutch	and damage. Inspect the clutch
		end-plate-to-top-disc clearance. If
	3. ICM defective	the clearance is out of tolerance,
Excessive shock	4. Start clutch	inspect the clutch discs and plates
when	defective	for wear and damage. If the discs
accelerating and	5. Start clutch feed	and plates are worn or damaged,
decelerating	pipe damaged	replace them as a set. If they are
	or out of round	OK, adjust the clearance with the
	6. Lower valve	clutch end-plate.
	body assembly	<ul> <li>Inspect the forward clutch feed</li> </ul>
	defective	pipe for wear, damage, and out of
	7. CVT drive	round. If the feed pipe is scored,
	pulley pressure	replace it and the O-ring under the
	control valve	feed pipe guide.
	defective	• Check for a stored DTC, and check

	<ul> <li>8. CVT driven pulley pressure control valve defective</li> <li>9. CVT start clutch pressure control valve defective</li> <li>10. Start clutch control system memory in TCM defective</li> </ul>	<ul> <li>for loose connectors.</li> <li>Calibrate the start clutch control system after replacing the start clutch.</li> <li>Inspect the start clutch feed pipe. If the feed pipe is scored, replace the end cover.</li> <li>Replace the drive pulley shaft with the intermediate housing assembly, if the bushing for the start clutch feed pipes are loose or damaged.</li> </ul>
No engine braking	<ol> <li>Intermediate housing assembly worn or damaged</li> <li>TCM defective</li> <li>Start clutch defective</li> <li>Start clutch feed pipe damaged or out of round</li> <li>IMA motor defective</li> <li>Lower valve body assembly defective</li> <li>CVT drive pulley pressure control valve defective</li> <li>CVT driven pulley pressure</li> </ol>	<ul> <li>Check for a stored DTC, and check for loose connectors.</li> <li>Calibrate the start clutch control system after replacing the start clutch.</li> <li>Inspect the start clutch feed pipe. If the feed pipe is scored, replace the end cover.</li> <li>Replace the drive pulley shaft with the intermediate housing assembly, if the bushing for the start clutch feed pipes are loose or damaged.</li> </ul>

	control valve defective 9. CVT start clutch pressure control valve defective 1. Intermediate housing	
Vehicle does not accelerate in R	<ul> <li>assembly worn or damaged</li> <li>2. TCM defective</li> <li>3. Reverse brake defective</li> <li>4. Reverse brake piston and related parts stuck, worn or damaged</li> <li>5. Planetary carrier worn or damaged</li> <li>6. Start clutch defective</li> <li>7. IMA motor defective</li> <li>8. Lower valve body assembly defective</li> <li>9. CVT drive pulley pressure control valve defective</li> <li>10. CVT driven</li> </ul>	<ul> <li>Check for a stored DTC, and check for loose connectors.</li> <li>Check the reverse brake pressure.</li> <li>Inspect the brake piston and O- rings. Check the spring retainer and return spring assembly for wear and damage. Inspect the brake end-plate-to-top-disc clearance. If the clearance is out of tolerance, inspect the brake discs and plates for wear and damage. If discs and plates are worn or damaged, replace them as a set. If they are OK, adjust the clearance with the brake end-plate.</li> <li>Inspect the reverse brake piston, piston O-rings, return spring and spring retainer assembly, discs and plates for wear and damage.</li> <li>Calibrate start clutch control system after replacing the start</li> </ul>

	pulley pressure control valve defective 11. CVT start clutch pressure control valve defective	clutch.
Vehicle does not creep on a flat road in D	<ol> <li>TCM defective</li> <li>Start clutch defective</li> <li>Start clutch feed pipe damaged or out of round</li> <li>Lower valve body assembly defective</li> <li>CVT drive pulley pressure control valve defective</li> <li>CVT driven pulley pressure control valve defective</li> <li>CVT driven pulley pressure control valve defective</li> <li>Solenoid harness worn or damaged</li> <li>Start clutch control system memory in TCM defective</li> </ol>	<ul> <li>Check for a stored DTC, and check for loose connectors.</li> <li>Calibrate start clutch control system after replacing the start clutch.</li> <li>Inspect the start clutch feed pipe. If the feed pipe is scored, replace the end cover.</li> <li>Replace the drive pulley shaft with the intermediate housing assembly if the bushing for the start clutch feed pipes are loose or damaged.</li> </ul>
		<ul> <li>Check the forward clutch pressure.</li> <li>Inspect the clutch piston, clutch</li> </ul>

#### piston check valve, and O-rings. Check the spring retainer for wear and damage. Inspect the clutch 1. Forward clutch end-plate-to-top-disc clearance. If defective the clearance is out of tolerance, 2. Start clutch inspect the clutch discs and plates defective for wear and damage. If the discs 3. Reverse brake and plates are worn or damaged. Vehicle moves return spring or replace them as a set. If they are in N, shift cable spring retainer OK, adjust the clearance with the is properly worn or clutch end-plate. adjusted damaged • Inspect the forward clutch feed 4. Manual valve pipe for wear, damage and out of lever and lever round. If the feed pipe is scored, pin defective replace it and the O-ring under the 5. Manual valve feed pipe guide. body defective • Calibrate the start clutch control system after replacing the start clutch. • Check the forward clutch pressure. • Inspect the clutch piston, clutch piston check valve, and O-rings. 1. Forward clutch Check the spring retainer for wear defective and damage. Inspect the clutch 2. Shift cable end-plate-to-top-disc clearance. If Late shift after broken or out of the clearance is out of tolerance, shifting from N adjustment, or inspect the clutch discs and plates to D shift cable end for wear and damage. If the discs removed and plates are worn or damaged, 3. Manual valve replace them as a set. If they are OK, adjust the clearance with the lever and lever pin defective clutch end-plate. 4. Clutch end-• Inspect the forward clutch feed plate clearance pipe for wear, damage, and out of

#### 2006 Honda Insight

	5. Manual valve body defective	<ul> <li>round. If the feed pipe is scored, replace it and O-ring under the feed pipe guide.</li> <li>Check for a loose shift cable at the shift lever and the transmission control lever.</li> </ul>
Late shift after shifting from N to R	<ol> <li>Shift cable broken or out of adjustment, or shift cable end removed</li> <li>Manual valve lever and lever pin defective</li> <li>Reverse brake defective</li> <li>Reverse brake piston and related parts stuck, worn or damaged</li> <li>Clutch end- plate clearance incorrect</li> <li>Manual valve body defective</li> </ol>	<ul> <li>Check for a loose shift cable at the shift lever and the transmission control lever.</li> <li>Check the reverse brake pressure.</li> <li>Inspect the brake piston and Orings. Check the spring retainer and return spring assembly for wear and damage. Inspect the brake end-plate-to-top-disc clearance. If the clearance is out of tolerance, inspect the brake discs and plates for wear and damage. If discs and plates are worn or damaged, replace them as a set. If they are OK, adjust the clearance with the brake end-plate.</li> <li>Inspect the clutch end-plate-to-top-disc clearance. If the clearance with the brake end-plate.</li> <li>Inspect the clutch end-plate to-top-disc clearance. If the clearance with the brake end-plate.</li> </ul>
	1. Intermediate housing assembly worn	^ 

200	0-06 TRANSMISSION Continue	ously Variable Transmission (CVT) - Insight
Engine stops when shifted to D from N	or damaged 2. Forward clutch defective 3. TCM defective 4. Start clutch defective 5. Lower valve body assembly defective 6. CVT drive pulley pressure control valve defective 7. CVT driven pulley pressure control valve defective 8. CVT start clutch pressure control valve defective 9. Start clutch control system memory in TCM defective	<ul> <li>Check the forward clutch pressure.</li> <li>Inspect the clutch piston, clutch piston check valve, and O-rings. Check the spring retainer for wear and damage. Inspect the clutch end-plate-to-top-disc clearance. If the clearance is out of tolerance, inspect the clutch discs and plates for wear and damage. If the discs and plates are worn or damaged, replace them as a set. If they are OK, adjust the clearance with the clutch end-plate.</li> <li>Inspect the forward clutch feed pipe for wear, damage, and out of round. If the feed pipe guide.</li> <li>Check for a stored DTC, and check for loose connectors.</li> <li>Calibrate start clutch control system after replacing the start clutch.</li> </ul>
	<ol> <li>Intermediate housing assembly worn or damaged</li> <li>TCM defective</li> <li>Reverse brake piston and</li> </ol>	

related parts

# 2006 Honda Insight

Engine stops when shifted to R from N	<ul> <li>damaged</li> <li>4. Planetary carrier worn or damaged</li> <li>5. Start clutch defective</li> <li>6. Lower valve body assembly defective</li> <li>7. CVT drive pulley pressure control valve defective</li> <li>8. CVT driven pulley pressure control valve defective</li> <li>9. CVT start clutch pressure control valve defective</li> <li>10. Start clutch control system memory in TCM defective</li> </ul>	<ul> <li>Check for a stored DTC, and check for loose connectors.</li> <li>Inspect the reverse brake piston, piston O-rings, return spring and spring retainer assembly, discs and plates for wear and damage.</li> <li>Calibrate start clutch control system after replacing the start clutch.</li> <li>Check for a stored DTC, and check for loose solenoid harness connector.</li> </ul>
Noise from transmission in R	<ol> <li>Sun gear worn or damaged</li> <li>Reverse brake defective</li> <li>Reverse brake piston and related parts</li> </ol>	<ul> <li>Check the reverse brake pressure.</li> <li>Inspect the brake piston and O- rings. Check the spring retainer and return spring assembly for wear and damage. Inspect the brake end-plate-to-top-disc clearance. If the clearance is out of</li> </ul>
	stuck, worn or damaged 4. Planetary carrier worn or damaged	tolerance, inspect the brake discs and plates for wear and damage. If discs and plates are worn or damaged, replace them as a set. If they are OK, adjust the clearance with the brake end-plate.
--------------------------	--	--
Engine idle vibration	<ol> <li>ATF pump worn, binding, or foreign materials in ATF pump</li> <li>ATF pump</li> <li>ATF pump chain or ATF pump sprocket worn or damaged</li> <li>Flywheel and drive plate worn or damaged</li> <li>Engine output low</li> <li>IMA motor defective</li> <li>Flywheel assembly defective</li> </ol>	<ul> <li>Inspect the differential pinion gears for wear. If the differential pinion gears are worn, replace the differential assembly and the ATF strainer, and thoroughly clean the transmission, cooler and cooler lines.</li> <li>Check that the ATF strainer is in good condition. If the ATF strainer is clogged with particles of steel or aluminum, inspect the ATF pump. If the ATF pump is OK, find the damaged components that caused the debris.</li> <li>Inspect the input shaft splines and flywheel housing input shaft oil seal for wear and damage.</li> </ul>
	<ol> <li>ATF pump worn, binding, or foreign materials in ATF pump</li> <li>ATF pump</li> <li>ATF pump chain or ATF</li> </ol>	• Inspect the differential pinion gear for wear. If the differential pinion gears are worn, replace the differential assembly and the ATF

		strain on and the new shire aloon the
	worn or damaged	transmission, cooler and cooler lines.
	<ol> <li>Planetary carrier worn or damaged</li> <li>Input shaft</li> </ol>	• Check that the ATF strainer is in good condition. If the ATF strainer is clogged with particles of steel or aluminum, inspect the ATF pump.
transmission in N and P	needle bearing seized up, worn or damaged	If the ATF pump is OK, find the damaged components that caused debris.
	5. Transmission range switch defective	• Check for a stored DTC, and check for loose transmission range switch connectors.
	6. Flywheel assembly defective	
Unstable RPM while driving	<ol> <li>TCM defective</li> <li>Lower valve body assembly defective</li> <li>CVT drive pulley pressure control valve defective</li> <li>CVT driven pulley pressure control valve defective</li> <li>CVT start clutch pressure control valve defective</li> </ol>	Check for a stored DTC, and check for loose connectors.
	1. Flywheel and	

Excessive vibration in all shift lever positions	drive plate worn or damaged 2. Flywheel assembly defective	Inspect the input shaft splines and flywheel housing input shaft oil seal for wear and damage.
Shift lever does not operate smoothly	<ol> <li>Shift cable broken or out of adjustment, or shift cable end removed</li> <li>Control lever worn or damaged</li> <li>Manual valve lever and lever pin defective</li> <li>Manual valve body defective</li> </ol>	Check for loose shift cable at the shift lever and the transmission control lever.
Transmission will not shift into P, or transmission cannot shift out of P	<ol> <li>Shift cable broken or out of adjustment, or shift cable end removed</li> <li>Control lever worn or damaged</li> <li>Park pawl and pawl shaft worn or damaged</li> <li>Detent lever worn or damaged</li> <li>Park gear worn</li> </ol>	Check for a loose shift cable at the shift lever and the transmission control lever.

Vehicle does not accelerate after a certain speed has been exceeded	<ul> <li>6. Park pawl spring worn or damaged</li> <li>1. Intermediate housing assembly worn or damaged</li> <li>2. Forward clutch defective</li> <li>3. CVT input shaft (drive pulley) speed sensor and CVT output shaft (driven pulley) speed sensor defective</li> <li>4. CVT speed sensor defective</li> <li>5. TCM defective</li> <li>6. Start clutch defective</li> <li>7. Lower valve body assembly defective</li> <li>8. CVT drive pulley pressure control valve defective</li> <li>9. CVT driven pulley pressure control valve</li> </ul>	<ul> <li>Check the forward clutch pressure.</li> <li>Inspect the clutch piston, clutch piston check valve, and O-rings. Check the spring retainer for wear and damage. Inspect the clutch end-plate-to-top-disc clearance. If the clearance is out of tolerance, inspect the clutch discs and plates for wear and damage. If the discs and plates are worn or damaged, replace them as a set. If they are OK, adjust the clearance with the clutch end-plate.</li> <li>Inspect the forward clutch feed pipe for wear, damage, and out of round. If the feed pipe is scored, replace it and the O-ring under the feed pipe guide.</li> <li>Check for a stored DTC, and check for loose connectors.</li> <li>Check the speed sensors installation.</li> <li>Calibrate the start clutch control system after replacing the start clutch.</li> </ul>
--	---	--

Excessive shock when starting off	<ol> <li>CVT start clutch pressure control valve defective</li> <li>Start clutch control system memory in TCM defective</li> </ol>	<ul> <li>Check for a stored DTC, and check for a loose solenoid harness connector.</li> <li>Calibrate start clutch control system.</li> </ul>
Flares while accelerating at low vehicle speed	<ol> <li>Start clutch defective</li> <li>Start clutch feed pipe damaged or out of round</li> <li>CVT start clutch pressure control valve defective</li> <li>Start clutch control system memory in TCM defective</li> </ol>	<ul> <li>Calibrate the start clutch control system after replacing the start clutch.</li> <li>Inspect the start clutch feed pipe. If the feed pipe is scored, replace the end cover.</li> <li>Replace the drive pulley shaft with the intermediate housing assembly if the bushing for the start clutch feed pipes are loose or damaged.</li> <li>Check for a stored DTC, and check for a loose solenoid harness connector.</li> </ul>
Excessive vibration at idle when shifted to R, D, and L	<ol> <li>Start clutch defective</li> <li>Start clutch feed pipe damaged or out of round</li> <li>IMA motor defective</li> <li>CVT start clutch pressure control valve defective</li> <li>Start clutch</li> </ol>	<ul> <li>Calibrate the start clutch control system after replacing the start clutch.</li> <li>Inspect the start clutch feed pipe. If the feed pipe is scored, replace the end cover.</li> <li>Replace the drive pulley shaft with the intermediate housing assembly if the bushing for the start clutch feed pipes are loose or damaged.</li> <li>Check for a stored DTC, and check</li> </ul>

	control system memory in TCM defective	for a loose solenoid harness connector.
Excessive engine RPM drop-off when shifted to R, D, and L	<ol> <li>TCM defective</li> <li>Start clutch defective</li> <li>Start clutch feed pipe damaged or out of round</li> <li>CVT start clutch pressure control valve defective</li> <li>Start clutch control system memory in TCM defective</li> </ol>	<ul> <li>Check for a stored DTC, and check for loose connectors.</li> <li>Calibrate the start clutch control system after replacing the start clutch.</li> <li>Inspect the start clutch feed pipe. If the feed pipe is scored, replace the end cover.</li> <li>Replace the drive pulley shaft with the intermediate housing assembly if the bushing for the start clutch feed pipes are loose or damaged.</li> </ul>
Stall speed high	<ol> <li>Forward clutch defective</li> <li>Start clutch defective</li> <li>CVT start clutch pressure control valve defective</li> </ol>	<ul> <li>Check the forward clutch pressure.</li> <li>Inspect the clutch piston, clutch piston check valve, and O-rings. Check the spring retainer for wear and damage. Inspect the clutch end-plate-to-top-disc clearance. If the clearance is out of tolerance, inspect the clutch discs and plates for wear and damage. If the discs and plates are worn or damaged, replace them as a set. If they are OK, adjust the clearance with the clutch end-plate.</li> <li>Inspect the forward clutch feed pipe for wear, damage, and out of round. If the feed pipe is scored.</li> </ul>

2006 Honda Insight	
--------------------	--

		<ul> <li>replace it and the O-ring under the feed pipe guide.</li> <li>Calibrate the start clutch control system after replacing the start clutch.</li> <li>Check for a stored DTC, and check for loose solenoid harness connector.</li> </ul>
Stall speed low	<ol> <li>Intermediate housing assembly worn or damaged</li> <li>Start clutch defective</li> <li>IMA motor defective</li> <li>IMA motor defective</li> <li>CVT drive pulley pressure control valve defective</li> <li>CVT driven pulley pressure control valve defective</li> <li>CVT driven pulley pressure control valve defective</li> <li>CVT start clutch pressure control valve defective</li> </ol>	<ul> <li>Calibrate the start clutch control system after replacing the start clutch.</li> <li>Check for a stored DTC, and check for a loose solenoid harness connector.</li> </ul>
Judder when starting off	<ol> <li>Start clutch defective</li> <li>CVT Fluid deteriorated</li> </ol>	<ul> <li>Calibrate the start clutch control system after replacing the start clutch.</li> <li>Replace CVT Fluid.</li> </ul>

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

A/T gear position indicator does not indicate shift lever positions	<ul> <li>broken or out of adjustment, or shift cable end removed</li> <li>2. Transmission range switch defective</li> <li>3. Control lever worn or damaged</li> </ul>	<ul> <li>Check for a loose shift cable at the shift lever and the transmission control lever.</li> <li>Check for a stored DTC, and check for a loose transmission range switch connectors.</li> </ul>
---	---	---

#### SYSTEM DESCRIPTION

#### **General Operation**

The continuously variable transmission (CVT) is an electronically controlled automatic transmission with drive and driven pulleys, and steel belt. The CVT provides non-stage speeds forward and one reverse.

#### Transmission

Around the outside of the flywheel is a ring gear which meshes with the starter pinion when the engine is being started. The transmission has four parallel shafts: the input shaft, the drive pulley shaft, the driven pulley shaft, and the secondary gear shaft. The input shaft is connected to the flywheel, which is connected to the motor rotor. This is connected to the end of the engine crankshaft. The drive pulley shaft and driven pulley shaft consists of movable and fixed face pulleys. Both pulleys are linked by the steel belt.

The input shaft includes the sun gear and planetary gears with carrier. The drive pulley shaft includes the drive pulley and forward clutch. The driven pulley shaft includes the driven pulley, start clutch, and the secondary drive gear, which is integral with the park gear. The secondary gear shaft is positioned between the secondary drive gear and the final driven gear. The secondary gear shaft includes the secondary driven gear and the final drive gear, which serves to change the rotation direction, because the drive pulley shaft and driven pulley shaft rotate the same direction. When certain conditions of the planetary gears in the transmission

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

are engaged by the forward clutch and the reverse brake, power is transmitted from the drive pulley shaft to the driven pulley shaft to provide the L, D, and R positions.

#### **Electronic Control**

The electronic control system consists of the transmission control module (TCM), sensors, and solenoid valves. Shifting is electronically controlled for comfortable driving under all conditions. The TCM is located below the dashboard, behind the kick panel on the passenger's side.

#### Hydraulic Control

The lower valve body assembly includes the main valve body, the secondary valve body, the CVT driven pulley pressure control valve, the CVT drive pulley pressure control valve, the CVT start clutch pressure control valve, and the inhibitor solenoid valve. These valve bodies are positioned on the lower portion of the transmission housing. The manual valve body is bolted on the intermediate housing.

The main valve body contains the start clutch shift valve, the shift inhibitor valve, and the lubrication valve. The secondary valve body contains the pressure high (PH) regulator valve, the pressure high control (PHC) shift valve B, the start clutch back-up valve, the clutch reducing valve, and the start clutch accumulator. The CVT driven pulley pressure control valve contains the pulley control valve A and the driven pulley control valve with the solenoid. The CVT drive pulley pressure control valve B and the drive pulley control valve with the solenoid. The CVT drive pulley control valve with the solenoid. The CVT drive pulley control valve with the solenoid. The CVT drive pulley control valve with the solenoid. The CVT drive pulley control valve with the solenoid. The CVT start clutch pressure control valve consists of the start clutch pressure control valve and the solenoid. These solenoids are controlled by the TCM. The manual valve body contains the manual valve and the reverse inhibitor valve.

The ATF pump is located on the transmission housing, and it is linked with the input shaft by the sprockets and the sprocket chain. The pulleys, forward clutch, and start clutch receive fluid from their respective feed pipes, and the reverse brake receives fluid from internal hydraulic circuit.

#### Shift Control

The TCM controls the shift pulley ratio through the solenoids, while receiving input

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

signal from the various sensors and switches located throughout the vehicle. The TCM actuates the pulley control solenoids to control the pulley control valves A and B. Drive pulley pressure, regulated at pulley control valve B, is applied to the drive pulley; driven pulley pressure, regulated at pulley control valve A, is applied to the driven pulley; and the pulley ratio is changed to their directed ratio.

Gear Selection

The shift lever has five positions; P: PARK, R: REVERSE, N: NEUTRAL, D: DRIVE, and L: LOW.

Position	Description
P: PARK	Front wheels locked; park pawl engaged with the park gear on the secondary drive gear. The start clutch and forward clutch released.
R: REVERSE	Reverse; reverse brake engaged.
N: NEUTRAL	Neutral; the start clutch and forward clutch released.
D: DRIVE	D position has two modes; Drive mode and Second mode with switching the mode switch on the steering wheel.
	• Drive mode
	General driving; the transmission automatically adjusts to keep the engine at the best speed for driving conditions.
	Second mode
	For rapid acceleration; the transmission selects a wider range of the ratios to give better acceleration.
L: LOW	For engine braking and power for climbing; the transmission shifts into the lowest range of the ratios.

# **GEAR POSITION AND DESCRIPTION**

Starting is possible only in the P and N positions through the use of a slide-type, neutral-safety switch.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

#### Automatic Transmission (A/T) Gear Position Indicator

The A/T gear position indicator in the instrument panel shows what shift lever position has been selected without looking down at the console.

#### Clutches/Reverse Brake/Planetary Gear/Pulleys

#### Clutches/Reverse Brake

The CVT uses the hydraulic-actuated clutches and brake to engage and disengage the transmission gears. When hydraulic pressure is introduced into the clutch drum and the reverse brake piston cavity, the clutch piston and the reverse brake piston move. This presses the friction discs and steel plate together, locking them so they do not slip. Power is then transmitted through the engaged clutch pack to its hubmounted gear, and through the engaged ring gear to the pinion gears.

Likewise, when the hydraulic pressure is bled from the clutch pack and reverse brake piston cavity, the piston releases the friction discs and the steel plates, and they are free to slide past each other. This allows the gear to spin independently on its shaft, transmitting no power.

#### Start Clutch

The start clutch engages/disengages the secondary drive gear, and is located at the end of the driven pulley shaft. The start clutch is supplied hydraulic pressure by its ATF feed pipe within the driven pulley shaft.

#### Forward Clutch

The forward clutch engages/disengages the sun gear, and is located at the end of the drive pulley shaft. The forward clutch is supplied hydraulic pressure by its ATF feed pipe within the drive pulley shaft.

#### Reverse Brake

The reverse brake locks the planetary carrier in the R position, and is located inside the intermediate housing around the planetary carrier. The reverse brake discs are mounted to the planetary carrier and the reverse brake plates are mounted on the intermediate housing. The reverse brake is supplied hydraulic pressure by a circuit connected to the internal hydraulic circuit.

#### **Planetary Gear**

The planetary gear consists of the sun gear, planetary pinion gears, and ring gear. The sun gear is connected to the input shaft with splines. The pinion gears are mounted on the planetary carrier. The planetary carrier is located on the end of the input shaft, over the sun gear. The ring gear is located in the planetary carrier, and connected to the forward clutch drum. The sun gear inputs the engine power via the input shaft to the planetary gears, and the ring gear outputs the engine power. The planetary gear mechanism is only used for switching the rotation direction of the pulley shafts. In the D and L positions (forward range), the pinion gears do not rotate and revolve around the sun gear, so the carrier rotates. In the R position (reverse range), the reverse brake locks the planetary carrier, and the sun gear drives the pinion gears to rotate. The pinion gears rotate, but do not revolve around the sun gear. The pinion gears drive the ring gear in the opposite direction from the rotation direction of the sun gear.

#### Pulleys

Each pulley consists of a movable face and a fixed face, and the effective pulley ratio changes with engine speed. The drive pulley and the driven pulley are linked by the steel belt.

To achieve a low pulley ratio, high hydraulic pressure works on the movable face of the driven pulley and reduces the effective diameter of the drive pulley, and a lower hydraulic pressure works on the movable face of the driven pulley to eliminate the steel belt slippage. To achieve a high pulley ratio, high hydraulic pressure works on the movable face of the drive pulley and reduces the effective diameter of the driven pulley, and low hydraulic pressure works on the movable face of the driven pulley to eliminate the steel belt slippage.

#### **Power Flow**

**Transmission Cutaway View** 

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03681714

# **Fig. 13: Transmission Cutaway View** Courtesy of AMERICAN HONDA MOTOR CO., INC.

P Position

Hydraulic pressure is not applied to the start clutch, forward clutch, and reverse brake. Power is not transmitted to the secondary drive gear. The secondary drive gear is locked by the park pawl interlocking with the park gear.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

#### N Position

Engine power transmitted from the flywheel drives the input shaft, but the hydraulic pressure is not applied to the forward clutch and reverse brake. Power is not transmitted to the drive pulley shaft. Also hydraulic pressure is not applied to the start clutch.



G03681715

# **Fig. 14: Identifying Transmission Power Flow - P And N Positions** Courtesy of AMERICAN HONDA MOTOR CO., INC.

D and L Position (Forward Range)

- Forward clutch: engaged
- Reverse brake: released
- Start clutch: engaged
- Hydraulic pressure is applied to the forward clutch and start clutch, and the sun gear drives the forward clutch.
- The forward clutch drives the drive pulley shaft, which drives the driven pulley shaft linked by the steel belt.
- The driven pulley shaft drives the secondary drive gear via the start clutch.
- Power is transmitted to the secondary driven gear and final drive gear, which in turn drives the final driven gear.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03681716

# **Fig. 15: Identifying Transmission Power Flow - D And L Position** (Forward Range) Courtesy of AMERICAN HONDA MOTOR CO., INC.

**R** Position (Reverse Range)

- Forward clutch: released
- Reverse brake: engaged
- Start clutch: engaged
- Hydraulic pressure is applied to the reverse brake and the start clutch, and the

planetary carrier locks with the reverse brake.

- The sun gear drives the pinion gears to rotate, and the pinion gears drive the ring gear in the opposite direction from the rotation direction of the sun gear.
- The ring gear drives the drive pulley shaft via the forward clutch drum, and drive pulley shaft drives the driven pulley shaft linked by the steel belt.
- The driven pulley shaft drives the secondary drive gear via the start clutch.
- Power is transmitted to the secondary driven gear and final drive gear, which in turn drives the final driven gear.



Fig. 16: Identifying Transmission Power Flow - R Position (Reverse

# **<u>Range</u>**) Courtesy of AMERICAN HONDA MOTOR CO., INC.

**Electronic Control System** 

Functional Diagram

The electronic control system consists of the transmission control module (TCM), sensors, switches, and solenoid valves. Shifting is electronically controlled for comfortable driving under all conditions.

The TCM receives input signals from the ECM, sensors and switches, perform processing data, and outputs signals for automatic transmission control system. The A/T control system, which includes the shift control, pulley pressure control, start clutch pressure control, reverse inhibitor control, and creep aid control, is stored in the TCM.

The TCM actuates the pulley control solenoids to control the pulley control valves A and B shifting transmission pulley ratios.

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



# **Fig. 17: Electronic Control System Functional Diagram** Courtesy of AMERICAN HONDA MOTOR CO., INC.

Pulley Pressure Control/Shift Control

To reduce belt slippage and increase belt life, the TCM calculates signals from the sensors and switches, and actuates the pulley pressure control valves to maintain optimum pulley pressure. When the pulley ratio is low (low vehicle speed), high hydraulic pressure works on the movable face of the driven pulley and reduces the effective diameter of the driven pulley, and a lower hydraulic pressure works on the movable face of the steel belt slippage. When the pulley ratio is high (high vehicle speed), high hydraulic pressure works on the

movable face of the drive pulley and reduces the effective diameter of the drive pulley, and a lower hydraulic pressure works on the movable face of the driven pulley to eliminate the steel belt slippage.

The TCM compares actual driving conditions with memorized driving conditions to control shifting, and instantly determines a drive pulley ratio from various signals sent from sensors and switches. The TCM activates the CVT drive pulley pressure control valve to control pulley pressure to the pulleys. The drive pulley drives the driven pulley via a steel belt at varying ratios ranging from 2.441 to 0.407 in the D position.



2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# **Fig. 18: Pulley Pressure Control/Shift Control Functional Diagram** Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Start Clutch Control

The hydraulic-controlled start clutch controls smooth starting-off and creeping in the D, L, and R positions like a torque converter. The TCM receives input signals from the ECM, sensors switches actuates the start clutch pressure control valve to regulate the clutch reducing pressure, and the clutch reducing pressure controls the start clutch.



2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# **Fig. 19: Start Clutch Control Functional Diagram** Courtesy of AMERICAN HONDA MOTOR CO., INC.

**Creep Aid Control** 

The Creep Aid System prevents the vehicle from moving backwards when the vehicle starts off on an ascending slope after the brake pedal is released.

When the vehicle comes to a stop, the engine is stopped by the auto-stop system under certain conditions. The start clutch is released because the ATF pump does not operate when the engine is stopped.

With the auto-stop system, when the vehicle comes to a stop with the brakes applied on an ascending slope, the TCM turns the creep-aid system solenoid valves A and B ON. This maintains the brake pressure, applied during the stop, to the brakes. When the engine restarts, the TCM turns the creep-aid system solenoid valves A and B OFF releasing the brake system pressure, allowing the vehicle to creep.



# Fig. 20: Creep Aid Control Functional Diagram

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### **Electronic Controls Location**



# **Fig. 21: Identifying Electronic Controls Location** Courtesy of AMERICAN HONDA MOTOR CO., INC.

**TCM Electrical Connection** 

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



## **Fig. 22: TCM Electrical Connection Diagram Courtesy of AMERICAN HONDA MOTOR CO., INC.**

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

**TCM Inputs and Outputs** 

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

#### TCM Connector Terminal Locations



A (26P)

B (22P)

#### TCM CONNECTOR A (26P)

Terminal Number	Wire Color	Signal	Description	Measuring Conditions/Terminal Voltage
A1	PNK/BLU	SC LS-	CVT start clutch pressure control valve power supply negative electrode	With ignition switch ON (II): Current control
A2	PNK/BLK	DN LS-	CVT driven pulley pressure control valve power supply negative electrode	With ignition switch ON (II): Current control
A3	GRN/YEL	DR LS-	CVT drive pulley pressure control valve power supply negative electrode	With ignition switch ON (II): Current control
A4	BRN/BLK	LG1	Ground	Less than 1.0 V at all times
A5	BLU	NEP	Engine speed signal input	With engine running: Pulsing signal
A7	BLU	ATP L	Transmission range switch L position input	In the L position: 0 V In other than the L position: About 10 V
A9	PNK	ATP D	Transmission range switch D position input	In the D position: 0 V In other than the D position: About 5 V
A10	LT GRN	ATP NP	Transmission range switch P and N positions input	In the P and N positions: 0 V In other than the P and N positions: About 5 V
A11	GRN/BLK	ATP R	Transmission range switch R position input	In the R position: 0 V In other than the R position: About 10 V
A12	BLK/YEL	IG1	Power supply circuit	With ignition switch ON (II): Battery voltage With ignition switch OFF: 0 V
A13	BLK	PG1	Ground	Less than 1.0 V at all times
A14	YEL	SC LS+	CVT start clutch pressure control valve power supply positive electrode	With ignition switch ON (II): Current control
A15	GRN/WHT	DN LS+	CVT driven pulley pressure control valve power supply positive electrode	With ignition switch ON (II): Current control
A16	BLU/WHT	DR LS+	CVT drive pulley pressure control valve power supply positive electrode	With ignition switch ON (II): Current control
A17	BRN/BLK	LG2	Ground	Less than 1.0 V at all times
A18	LT GRN	SPO IND	S mode indicator output	In S mode (S mode indicator comes on): About 10 V In drive mode (S mode indicator turns off):
A19	RED/WHT	ECT	Engine coolant temperature sensor signal input	Ignition switch ON (II): About 0.1—4.8 V (depending on engine coolant temperature)
A20	GRN/BLK	DIND	D indicator control	When ignition switch is first turned ON (II): About 10 V In the D position: About 10 V
A21	YEL	SPO SW	Sport mode switch signal input	With Sport mode switch ON: 0 V With Sport mode switch OFF: About 5 V
A23	WHT/BLU	VBU	Back-up power supply	Always battery voltage
A24	BLU	DSW	Drive mode switch signal input	With Drive mode switch ON: 0 V With Drive mode switch OFF: About 5 V
A25	BLK/YEL	IG2	Power supply circuit	With ignition switch ON (II): Battery voltage With ignition switch OFF: 0 V
A26	BLK	PG2	Ground	Less than 10 V at all times

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# **Fig. 23: TCM Inputs And Outputs - Connector A (26P)** Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### **TCM Connector Terminal Locations**



A (26P)

B (22P)

#### TCM CONNECTOR B (22P)

Terminal Number	Wire Color	Signal	Description	Measuring Conditions/Terminal Voltage
B1	GRN/BLK	INH SOL	Inhibitor solenoid control	With inhibitor solenoid ON: Battery voltage With inhibitor solenoid OFF: 0 V
B2	RED/GRN	MAP (PB)	Manifold absolute pressure sensor signal input	With ignition switch ON (II): About 3.0 V With engine idling: About 1.0 V (depending on engine speed)
B3	YEL/RED	VCC1	Power supply for sensors	With ignition switch ON (II): About 5 V With ignition switch OFF: 0 V
B4	RED/BLK	TPS	Throttle position sensor signal input	With ignition switch ON (II) and throttle fully open: About 4.5 V With ignition switch ON (II) and throttle fully closed: About 0.5 V
B5	BLU/WHT	VSS	Vehicle speed sensor signal input	With ignition switch ON (II) and rotating front wheels: 0 V or about 5 V
B6	PNK	ТМВ	Data communication line: transmission control data output to ECM	With ignition switch ON (II): Pulsing signal
B7	GRY	TMA	Data communication line: Engine control data input from ECM	With ignition switch ON (II): Pulsing signal
B8	RED/WHT	NDN SG	CVT output shaft (driven pulley) speed sensor ground	Less than 1.0 V at all times
B9	WHT	NDN	CVT output shaft (driven pulley) speed sensor signal input	Ignition switch ON (II): 0 V or about 5 V With engine idling 1.5—3.5 V

G03681725

# **Fig. 24: TCM Inputs And Outputs - Connector B (22P) (1 Of 2)** Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

Terminal Number	Wire Color	Signal	Description	Measuring Conditions/Terminal Voltage
B10	RED/BLU	NDR	CVT input shaft (drive pulley) speed sensor signal input	Ignition switch ON (II): 0 V or about 5 V With engine idling 1.5—3.5 V
B11	WHT/RED	CAS SOL A	Creep aid system solenoid valve A control	Creep aid system solenoid valve A ON: Battery voltage Creep aid system solenoid valve A OFF: 0 V
B12	GRN/WHT	BK SW	Brake pedal position switch signal input	With brake pedal pressed: Battery voltage With brake pedal released: 0 V
B13	LT BLÜ	DIAG-H (TXD/RXD)	Data communication line; Diagnostic trouble code output	With ignition switch ON (II): About 5 V
B14	BRN	SCS	Service check signal	With ignition switch ON (II) and SCS line open: About 5 V With ignition switch ON (II) and SCS line short-circuited: About 0 V
B15	WHT/RED	VEL	CVT speed sensor signal input	Ignition switch ON (II): 0 V or about 5 V With vehicle running (front wheels rotating): 1.5—3.5 V
B16	BLK/WHT	VEL SG	CVT speed sensor ground	Less than 1.0 V at all times
B17	GRN	NDR SG	CVT input shaft (drive pulley) speed sensor ground	Less than 1.0 V at all times
B18	BLU/WHT	CAS SOL B	Creep aid system solenoid valve B control	Creep aid system solenoid valve B ON: Battery voltage Creep aid system solenoid valve B OFF: 0 V
B19	RED/YEL	IAT	Intake air temperature sensor signal input	With ignition switch ON (II): 0.1–4.8 V (depending on intake air temperature)
B20	WHT/RED	VREF	+5 V reference	With ignition switch ON (II): About 5 V With ignition switch OFF: 0 V
B21	YEL/GRN	VCC3	Power supply for sensors	With ignition switch ON (II): About 5 V With ignition switch OFF: 0 V
B22	YEL/BLU	VCC2	Power supply for sensors	With ignition switch ON (II): About 5 V With ignition switch OFF: 0 V

G03681726

# Fig. 25: TCM Inputs And Outputs - Connector B (22P) (2 Of 2) Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### **Hydraulic Control**

The hydraulic control system is controlled by the ATF pump, the valves, and the solenoids. The ATF pump is driven by the input shaft. The ATF pump and the input shaft are linked by the ATF pump drive chain and the sprockets. Fluid from the ATF pump flows through the pressure high (PH) regulator valve to maintain specified pressure to the drive pulley, the driven pulley, and the manual valve.

The lower valve body assembly includes the main valve body, the secondary valve body, the CVT driven pulley pressure control valve, the CVT start clutch pressure control valve, and the CVT drive pulley pressure control valve. The manual valve body is bolted on the intermediate housing, and houses the manual valve which switches hydraulic pressure to meet with the shift lever position.

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

Main Valve Body

The main valve body contains the start clutch shift valve, the shift inhibitor valve, and the lubrication valve.

• Start Clutch Shift Valve

When a control system malfunction occurs, the start clutch shift valve receives shift inhibitor pressure (SI) and covers the port of lubrication pressure by-pass circuit.

• Shift Inhibitor Valve

The shift inhibitor valve switches the fluid passage to switch the start clutch control from electronic control to hydraulic control when the electronic control system is faulty.

• Lubrication Valve

The lubrication valve stabilizes the lubrication pressure to the internal circuit.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



# **Fig. 26: Identifying Main Valve Body Components** Courtesy of AMERICAN HONDA MOTOR CO., INC.

Secondary Valve Body

The secondary valve body contains the pressure high (PH) regulator valve, the pressure high control (PHC) shift valve B, the start clutch back-up valve, the clutch reducing valve, and the start clutch accumulator.

# • PH Regulator Valve

The PH regulator valve maintains hydraulic pressure supplied from the ATF pump, and supplies PH pressure to the hydraulic control circuit and the lubrication circuit. PH pressure is regulated at the PH regulator valve by the PH control pressure (PHC) from PHC shift valve B.

• PHC Shift Valve

The PHC shift valve supplies PH control pressure (PHC) to the PH regulator valve to regulate PH pressure in accordance with the drive pulley control pressure (DRC) or driven pulley pressure (DNC).

• Start Clutch Back-up Valve

When a control system malfunction occurs, the start clutch back-up valve supplies start clutch control B pressure (CCB) based on shift inhibitor pressure (SI) to the start clutch.

• Clutch Reducing Valve

The clutch reducing valve receives PH pressure from the PH regulator valve and regulates clutch reducing pressure (CR).

• Start Clutch Accumulator

The start clutch accumulator stabilizes the hydraulic pressure that is supplied to the start clutch.



# **Fig. 27: Identifying Secondary Valve Body Components Courtesy of AMERICAN HONDA MOTOR CO., INC.**

#### **CVT Driven Pulley Pressure Control Valve**

The CVT driven pulley pressure control valve contains the driven pulley control valve with the solenoid and the pulley control valve A. The driven pulley control valve controls the position of the pulley control valve A to applying driven pulley pressure (DN) to the driven pulley.

#### CVT Drive pulley pressure Control Valve

The CVT drive pulley pressure control valve contains the drive pulley control valve with the solenoid and the pulley control valve B. The drive pulley control valve controls the position of the pulley control valve B to applying drive pulley pressure (DR) to the drive pulley. The combination of the CVT driven pulley pressure control valve and the CVT drive pulley pressure speed change control valve applying pulley control pressures to the respective pulley provides a power transfer completely, to eliminate steel belt slippage and to make long belt life.

#### **CVT Start Clutch Pressure Control Valve**

The CVT start clutch pressure control valve consists of the start clutch pressure control valve and the solenoid. The CVT start clutch pressure control valve controls start clutch engagement according to the throttle opening.

# 2006 Honda Insight 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



# Fig. 28: Identifying CVT Start Clutch Pressure Control Valve Components Courtesy of AMERICAN HONDA MOTOR CO., INC.

Manual Valve Body

The manual valve body contains the manual valve and the reverse inhibitor valve. The manual valve body is bolted on the intermediate housing.

• Manual Valve

The manual valve mechanically uncovers/covers the fluid passage according to the shift lever position.

- Reverse Inhibitor Valve
- The reverse inhibitor valve is controlled by reverse inhibitor (Rl) pressure from the reverse inhibitor solenoid. The reverse inhibitor valve intercepts the hydraulic pressure flowing to the reverse brake while the vehicle is moving

forward at speeds over about 6 mph (10 km/h).



# **Fig. 29: Identifying Manual Valve Body Components** Courtesy of AMERICAN HONDA MOTOR CO., INC.

**Hydraulic Flow** 

As the engine turns, the ATF pump starts to operate. Continuously variable transmission fluid (CVTF) is drawn through the ATF strainer and discharge into the hydraulic circuit. Then, CVTF flowing from the ATF pump flows to the PH regulator valve and becomes pressure high (PH) pressure. PH pressure flows to the pulley control valves and then to the pulleys. The TCM actuates the solenoids to control hydraulic pressure shifting pulley ratio and engaging the start clutch.

Hydraulic pressure at the port is as follows:

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# HYDRAULIC PRESSURE DESCRIPTION

Port	Description of Hydraulic Pressure	Port	Description of Hydraulic Pressure
CC	Start Clutch Control	LUB'	Lubrication
CCB	Start Clutch Control B	PH	Pressure High
COL	ATF Cooler	PHC	Pressure High Control
CR	Clutch Reducing	RCC	Recirculation
DN	Driven Pulley	R1	Reverse Inhibitor
DNC	Driven Pulley Control	RVS	Reverse Brake
DR	Drive Pulley	RVS'	Reverse Brake
DRC	Drive Pulley Control	SC	Start Clutch
FWD	Forward Clutch	SI	Shift Inhibitor
LUB	Lubrication	X	Drain

General Chart Of Hydraulic Pressure



2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# **Fig. 30: Hydraulic Pressure General Chart** Courtesy of AMERICAN HONDA MOTOR CO., INC.

N Position

Fluid from the ATF pump is regulated to high pressure at the PH regulator valve, and flows to the pulley control valves. The CVT driven pulley pressure control valve and the CVT drive pulley pressure control valve control the pulley control valves A and B to apply pressure to the pulleys. The driven pulley receives pressure higher than pressure drive pulley receives, but hydraulic pressure to the forward clutch is intercepted by the manual valve and to the start clutch is intercepted by the CVT start clutch pressure control valve. Under this condition, hydraulic pressure is not applied to the start and forward clutches.



G03681732

# **Fig. 31: Hydraulic Circuit - N Position (2001-2003 Models)** Courtesy of AMERICAN HONDA MOTOR CO., INC.
#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

#### D Position, at low speed range

The manual valve is shifted into D position, and uncovers the port leading forward clutch pressure (FWD) to the forward clutch. The forward clutch pressure (FWD) flows to the forward clutch, the forward clutch is engaged and drives the input shaft and drive pulley shaft. The drive pulley receives low pressure, and driven pulley receives high pressure. The TCM actuates the CVT start clutch pressure control valve to control start clutch pressure. The start clutch control pressure (CC) from the CVT start clutch pressure control valve becomes the start clutch pressure (SC) at the shift inhibitor valve, and flows to the start clutch. The start clutch is engaged, and the vehicle moves.



## Fig. 32: Hydraulic Circuit - D Position, At Low Speed Range (2001-2003 Models) Courtesy of AMERICAN HONDA MOTOR CO., INC.

D Position, at middle speed range

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

As the speed of the vehicle reaches the prescribed value, the TCM controls the CVT driven pulley pressure control valve and the CVT drive pulley pressure control valve to provide about the same hydraulic pressure to the pulleys. The diameter contacted with the steel belt on the drive and driven pulleys become nearly equal, and the pulley ratio is in middle. Hydraulic pressure remains to apply to the start and forward clutches.



G03681734

### Fig. 33: Hydraulic Circuit - D Position, At Middle Speed Range (2001-2003 Models) Courtesy of AMERICAN HONDA MOTOR CO., INC.

D Position, at high speed range

Vehicle speed is further increased, the TCM controls the CVT driven pulley pressure control valve and the CVT drive pulley pressure control valve to apply hydraulic pressure to the drive pulley high and to the driven pulley low. The drive

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

pulley receives high pressure and the driven pulley receives low. The drive pulley provides the steel belt to large-diameter contact and the driven pulley provides to small-diameter contact, and the pulley ratio is in high. Hydraulic pressure remains to apply to the start and forward clutches.



### Fig. 34: Hydraulic Circuit - D Position, At High Speed Range (2001-2003 Models) Courtesy of AMERICAN HONDA MOTOR CO., INC.

**R** Position

The manual valve is shifted into the R position, and uncovers the port leading reverse brake pressure (RVS) to the reverse inhibitor valve. The reverse inhibitor solenoid is turned OFF by the TCM, and reverse inhibitor pressure (Rl) is applied to the right end of the reverse inhibitor valve. The reverse inhibitor valve is moved to the left side, and uncovers the port leading reverse brake pressure (RVS') to the reverse brake. Clutch reducing pressure (CR) becomes reverse brake pressure

(RVS), and flows to the reverse brake via the reverse inhibitor valve. The reverse brake is engaged, and it locks the planetary carrier.

# NOTE: When used, "left" or "right" indicates direction on the hydraulic circuit.



G03681736

## Fig. 35: Hydraulic Circuit - R Position (2001-2003 Models) Courtesy of AMERICAN HONDA MOTOR CO., INC.

**R** Position

## Reverse Inhibitor Control

If the R position is selected while the vehicle is moving forward at speeds over 6 mph (10 km/h), the TCM outputs signal to turn ON the reverse inhibitor solenoid, and reverse inhibitor pressure (RI) in the right end of the reverse inhibitor valve is released. The reverse inhibitor valve is moved to the right side, and uncovers the

port to stop reverse brake pressure to the reverse brake from the manual valve. Reverse brake pressure (RVS) is not applied to the reverse brake, and power is not transmitted to the reverse direction.

# NOTE: When used, "left" or "right" indicates direction on the hydraulic circuit.



G03681737

## Fig. 36: Hydraulic Circuit - R Position (2001-2003 Models) Courtesy of AMERICAN HONDA MOTOR CO., INC.

**P** Position

The manual valve is shifted into the P position, the manual valve intercepts hydraulic pressure to the forward clutch. Hydraulic pressure is not applied to the start and forward clutches, and power is not transmitted to the drive pulley shaft.

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03681738

## Fig. 37: Hydraulic Circuit - P Position (2001-2003 Models) Courtesy of AMERICAN HONDA MOTOR CO., INC.

D Position, when an electronic control system malfunction occurs.

When an electronic control system malfunction occurs, the CVT start clutch pressure control valve cannot operate to control the start clutch pressure circuit, and the transmission creates the temporary circuit of the start clutch pressure control to allow the vehicle to be driven.

The CVT start clutch control valve covers the port leading start clutch control pressure (CC) to the shift inhibitor valve, and the shift inhibitor valve is moved to the left side by drive pulley control pressure (DRC). Clutch reducing pressure (CR) becomes shift inhibitor pressure (SI) at the shift inhibitor valve, flows to the left side of the start clutch back-up valve, and becomes start clutch control B pressure (CCB). Start clutch control B pressure (SC) at

the shift inhibitor valve, and flows to the start clutch. Clutch reducing pressure (CR) also flows to the manual valve, and becomes to forward clutch pressure (FWD). The start clutch and the forward clutch are engaged, and the vehicle will move.

#### NOTE: When used, "left" or "right" indicates direction on the hydraulic circuit.



G03681739

## Fig. 38: Hydraulic Circuit - D Position (2001-2003 Models) **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

R Position, when an electronic control system malfunction occurs.

When an electronic control system malfunction occurs, the CVT start clutch pressure control valve cannot operate to control the start clutch pressure circuit, and the transmission creates the temporary circuit of the start clutch pressure control to allow the vehicle to be driven.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

The CVT start clutch control valve covers the port leading start clutch control pressure (CC) to the shift inhibitor valve, and the shift inhibitor valve is moved to the left side by drive pulley control pressure (DRC). Clutch reducing pressure (CR) becomes shift inhibitor pressure (SI) at the shift inhibitor valve, flows to the left side of the start clutch back-up valve, and becomes start clutch control B pressure (CCB). Start clutch control B pressure (CCB) becomes start clutch pressure (SC) at the shift inhibitor valve, and flows to the start clutch. Clutch reducing pressure (CR) also flows to the manual valve, and becomes to reverse brake pressure (RVS). The start clutch and the reverse brake are engaged, and the vehicle will reverse.

## NOTE: When used, "left" or "right" indicates direction on the hydraulic circuit.



G03681740

## **Fig. 39: Hydraulic Circuit - R Position (2001-2003 Models)** Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

#### N Position

Fluid from the ATF pump is regulated to high pressure at the PH regulator valve, and flows to the pulley control valves. The CVT driven pulley pressure control valve and the CVT drive pulley pressure control valve control the pulley control valves A and B to apply pressure to the pulleys. The driven pulley receives pressure higher than pressure drive pulley receives, but hydraulic pressure to the forward clutch is intercepted by the manual valve and to the start clutch is intercepted by the CVT start clutch pressure control valve. Under this condition, hydraulic pressure is not applied to the start and forward clutches.



G03681741

## **Fig. 40: Hydraulic Circuit - N Position (2004-2006 Models)** Courtesy of AMERICAN HONDA MOTOR CO., INC.

D Position, at low speed range

The manual valve is shifted into the D position, and uncovers the port leading

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

forward clutch pressure (FWD) to the forward clutch. The forward clutch pressure (FWD) flows to the forward clutch, the forward clutch is engaged and drives the input shaft and drive pulley shaft. The drive pulley receives low pressure, and driven pulley receives high pressure. The TCM actuates the CVT start clutch pressure control valve to control start clutch pressure. The start clutch control pressure (CC) from the CVT start clutch pressure control valve becomes the start clutch pressure (SC) at the shift inhibitor valve, and flows to the start clutch. The start clutch is engaged, and the vehicle moves.



G03681742

## Fig. 41: Hydraulic Circuit - D Position At Low Speed Range (2004-2006 Models) Courtesy of AMERICAN HONDA MOTOR CO., INC.

D Position, at middle speed range

As the speed of the vehicle reaches the prescribed value, the TCM controls the CVT

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

driven pulley pressure control valve and the CVT drive pulley pressure control valve to provide about the same hydraulic pressure to the pulleys. The diameter contacted with the steel belt on the drive and driven pulleys become nearly equal, and the pulley ratio is in middle. Hydraulic pressure remains to apply to the start and forward clutches.



G03681743

## Fig. 42: Hydraulic Circuit - D Position, At Middle Speed Range (2004-2006 Models) Courtesy of AMERICAN HONDA MOTOR CO., INC.

D Position, at high speed range

Vehicle speed is further increased, the TCM controls the CVT driven pulley pressure control valve and the CVT drive pulley pressure control valve to apply hydraulic pressure to the drive pulley high and to the driven pulley low. The drive pulley receives high pressure and the driven pulley receives low. The drive pulley

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

provides the steel belt to large-diameter contact and the driven pulley provides to small-diameter contact, and the pulley ratio is in high. Hydraulic pressure remains to apply to the start and forward clutches.



G03681744

## Fig. 43: Hydraulic Circuit - D Position, At High Speed Range (2004-2006 Models) Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### **R** Position

The manual valve is shifted into the R position, and uncovers the port leading reverse brake pressure (RVS) to the reverse inhibitor valve. The reverse inhibitor solenoid is turned OFF by the TCM, and reverse inhibitor pressure (RI) is applied to the right end of the reverse inhibitor valve. The reverse inhibitor valve is moved to the left side, and uncovers the port leading reverse brake pressure (RVS') to the reverse brake. Clutch reducing pressure (CR) becomes reverse brake pressure

(RVS), and flows to the reverse brake via the reverse inhibitor valve. The reverse brake is engaged, and it locks the planetary carrier.

# NOTE: When used, "left" or "right" indicates direction on the hydraulic circuit.



G03681745

## Fig. 44: Hydraulic Circuit - R Position (2004-2006 Models) (1 Of 2) Courtesy of AMERICAN HONDA MOTOR CO., INC.

**R** Position

## Reverse Inhibitor Control

If the R position is selected while the vehicle is moving forward at speeds over 6 mph (10 km/h), the TCM outputs signal to turn ON the reverse inhibitor solenoid, and reverse inhibitor pressure (RI) in the right end of the reverse inhibitor valve is released. The reverse inhibitor valve is moved to the right side, and uncovers the

port to stop reverse brake pressure to the reverse brake from the manual valve. Reverse brake pressure (RVS) is not applied to the reverse brake, and power is not transmitted to the reverse direction.

# NOTE: When used, "left" or "right" indicates direction on the hydraulic circuit.



G03681746

## Fig. 45: Hydraulic Circuit - R Position (2004-2006 Models) (2 Of 2) Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### P Position

The manual valve is shifted into the P position, the manual valve intercepts hydraulic pressure to the forward clutch. Hydraulic pressure is not applied to the start and forward clutches, and power is not transmitted to the drive pulley shaft.

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03681747

## Fig. 46: Hydraulic Circuit - P Position (2004-2006 Models) Courtesy of AMERICAN HONDA MOTOR CO., INC.

D Position, when an electronic control system malfunction occurs.

When an electronic control system malfunction occurs, the CVT start clutch pressure control valve cannot operate to control the start clutch pressure circuit, and the transmission creates the temporary circuit of the start clutch pressure control to allow the vehicle to be driven.

The CVT start clutch control valve covers the port leading start clutch control pressure (CC) to the shift inhibitor valve, and the shift inhibitor valve is moved to the left side by drive pulley control pressure (DRC). Clutch reducing pressure (CR) becomes shift inhibitor pressure (SI) at the shift inhibitor valve, flows to the left side of the start clutch back-up valve, and becomes start clutch control B pressure (CCB). Start clutch control B pressure (SC) at

the shift inhibitor valve, and flows to the start clutch. Clutch reducing pressure (CR) also flows to the manual valve, and becomes to forward clutch pressure (FWD). The start clutch and the forward clutch are engaged, and the vehicle will move.

## NOTE: When used, "left" or "right" indicates direction on the hydraulic circuit.



G03681748

## Fig. 47: Hydraulic Circuit - D Position, When Electronic Control System Malfunction Occurs (2004-2006 Models) Courtesy of AMERICAN HONDA MOTOR CO., INC.

R Position, when an electronic control system malfunction occurs.

When an electronic control system malfunction occurs, the CVT start clutch pressure control valve cannot operate to control the start clutch pressure circuit, and the transmission creates the temporary circuit of the start clutch pressure control to

## 2006 Honda Insight 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

allow the vehicle to be driven.

The CVT start clutch control valve covers the port leading start clutch control pressure (CC) to the shift inhibitor valve, and the shift inhibitor valve is moved to the left side by drive pulley control pressure (DRC). Clutch reducing pressure (CR) becomes shift inhibitor pressure (SI) at the shift inhibitor valve, flows to the left side of the start clutch back-up valve, and becomes start clutch control B pressure (CCB). Start clutch control B pressure (CCB) becomes start clutch pressure (SC) at the shift inhibitor valve, and flows to the start clutch. Clutch reducing pressure (CR) also flows to the manual valve, and becomes to reverse brake pressure (RVS). The start clutch and the reverse brake are engaged, and the vehicle will reverse.

# NOTE: When used, "left" or "right" indicates direction on the hydraulic circuit.



G03681749

## Fig. 48: Hydraulic Circuit - R Position, When Electronic Control System

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

## **Malfunction Occurs (2004-2006 Models)** Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Park Mechanism

The park mechanism locks the transmission by engaging the park pawl with the park gear which is integral with the secondary drive gear. The secondary drive gear engages with the secondary driven gear which is integral with the final drive gear, and the final drive gear engages the final driven gear.

Shifting to the P position causes the park cone (installed at the end of the park rod) to press the park pawl onto the park gear. Even if the end of the park pawl rides on the top of the park gear teeth, slight movement of the vehicle will cause the park pawl and park gear to mesh with each other completely because the park cone receives the tension from the park rod spring. The park pawl receives the tension (which acts to separate the park pawl from the park gear) from the park pawl spring.



2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

## **Fig. 49: Identifying Park Mechanism** Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### **Circuit Diagram**



G03681751

## **Fig. 50: CVT Circuit Diagram (1 Of 2)** Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03681752

## **Fig. 51: CVT Circuit Diagram (2 Of 2)** Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### DTC TROUBLESHOOTING

#### **DTC INDEX**

• • •	
DTC	Description
DTC P0725	Problem in Engine Speed Input Circuit
DTC P1630	Problem in TCM
DTC P1655	Problem in TCM-to-ECM

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

	Communication Lines
DTC P1705	Short in Transmission Range Switch
	Circuit
<u>DTC P1706</u>	Open in Transmission Range Switch
	Circuit
<u>DTC P1790</u>	Problem in Throttle Position Sensor
	Circuit
<u>DTC P1791</u>	Problem in Vehicle Speed Sensor Circuit
<u>DTC P1792</u>	Problem in Engine Coolant Temperature
	Sensor Circuit
<u>DTC P1793</u>	Problem in Manifold Absolute Pressure
	Dechter in Letzlandin Tennenstein Sensor Circuit
<u>DIC P1/99</u>	Problem in Intake Air Temperature Sensor
DTC D1950	Drohlam in Croon Aid System Solanoid
	Valve A Circuit
DTC P1851	Problem in Creen Aid System Solenoid
	Valve B Circuit
DTC P1879	Problem in CVT Start Clutch Pressure
	Control Valve Circuit
DTC P1882	Problem in Inhibitor Solenoid Circuit
DTC P1885	Problem in CVT Input Shaft (Drive
	Pulley) Speed Sensor Circuit
DTC P1886	Problem in CVT Output Shaft (Driven
	Pulley) Speed Sensor Circuit
DTC P1888	Problem in CVT Speed Sensor Circuit
<u>DTC P1890</u>	Problem in Shift Control System
DTC P1891	Problem in Start Clutch Control System
<u>DTC P1894</u>	Problem in CVT Drive Pulley Pressure
	Control Valve Circuit
<u>DTC P1895</u>	Problem in CVT Driven Pulley Pressure
	Control Valve Circuit
<u>DTC P0501</u>	Range/Performance Problem in Vehicle

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

	Speed Sensor Circuit
DTC P0502	Problem in Vehicle Speed Sensor Circuit
	(No Signal Input)
DTC P0603	Problem in TCM
DTC P0705	Short in Transmission Range Switch
	Circuit (Multiple Shift-position Input)
DTC P0706	Open in Transmission Range Switch
	Circuit
<u>DTC P0716</u>	Range/Performance Problem in CVT
	Input Shaft (Drive Pulley) Speed Sensor
	Circuit
<u>DTC P0717</u>	Problem in CVT Input Shaft (Drive
	Pulley) Speed Sensor Circuit (No Signal
DTC D0701	Input)
<u>DTC P0/21</u>	Cutput Sheft (Driven Pulley) Speed
	Sensor Circuit
DTC P0722	Problem in CVT Output Shaft (Driven
	Pulley) Speed Sensor Circuit (No Signal
	Input)
DTC P0726	Range/Performance Problem in Engine
	RPM Signal Input Circuit
DTC P0727	Problem in Engine RPM Signal Input
	Circuit (No Signal Input)
DTC P0780	Problem in Shift Control System
DTC P0801	Problem in Inhibitor Solenoid Circuit
DTC P0811	Problem in Start Clutch Control System
DTC P0962	CVT Drive Pulley Pressure Control Valve
	Circuit Low Voltage
DTC P0963	CVT Drive Pulley Pressure Control Valve
	Circuit High Voltage
DTC P0966	CVT Driven Pulley Pressure Control
	Valve Circuit Low Voltage

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

<u>DTC P0967</u>	CVT Driven Pulley Pressure Control Valve Circuit High Voltage
<u>DTC P0970</u>	CVT Start Clutch Pressure Control Valve Circuit Low Voltage
DTC P0971	CVT Start Clutch Pressure Control Valve Circuit High Voltage
<u>DTC P1655</u>	Problem in TCM-to-ECM Communication Lines
DTC P1782	TP Sensor Circuit Low Voltage
DTC P1783	TP Sensor Circuit High Voltage
DTC P1784	MAP Sensor Circuit Low Voltage
DTC P1785	MAP Sensor Circuit High Voltage
DTC P1792	Problem in Engine Coolant Temperature Sensor Circuit
DTC P1799	Problem in Intake Air Temperature Sensor Circuit
<u>DTC P1850</u>	Problem in Creep Aid System Solenoid Valve A Circuit
DTC P2159	Range/Performance Problem in CVT
	Speed Sensor Circuit
DTC P2160	Problem in CVT Speed Sensor Circuit
	(No Signal Input)

DTC P0725: Problem in Engine Speed Input Circuit

2001-2004 Models

NOTE:

- Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.
  - This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

1. Start the engine, and check the tachometer for proper operation.

Does the tachometer operate properly?

**YES** -Go to step 2.

**NO** -Check the wire between gauge assembly connector terminal A5 and ECM connector terminal A19. If the wire is OK, check the gauge assembly or ECM.

- 2. Turn the ignition switch OFF.
- 3. Disconnect TCM connector A (26P).
- 4. Start the engine.
- 5. Measure the voltage between TCM connector terminals A5 and A4.

## **TCM CONNECTOR A (26P)**



## Wire side of female terminals

G03681753

## **Fig. 52: Measuring Voltage Between TCM Connector A (26P) Terminals** A5 And A4

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

## **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there voltage?

**YES** -Check for loose terminal fit in the TCM connectors. If necessary, substitute a known-good TCM (see <u>HOW TO TROUBLESHOOT</u> <u>CIRCUIT AT THE TCM</u>) and recheck.

**NO** -Repair an open in the wire between TCM connector terminal A5 and ignition coil.

DTC P1630: Problem in TCM

2001-2004 Models

- NOTE:
- Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.
  - This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
- 1. Turn the ignition switch ON (II).
- 2. Shift to the P or N position.
- 3. Turn the ignition switch OFF.
- 4. Disconnect TCM connector A (26P) for more than 5 seconds, then reconnect the connector.
- 5. Turn the ignition switch ON (II), and wait for more than 5 seconds.
- 6. Check that DTC P1630 recurs.

Is DTC P1630 indicated?

**YES** -Update the TCM if it does not have the latest software, or substitute a known-good TCM (see <u>HOW TO TROUBLESHOOT CIRCUIT AT</u> <u>THE TCM</u>), then recheck. If the symptom/indication goes away with a known-good TCM, replace the original TCM.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

**NO** -Intermittent failure, the system is OK at this time. Check for poor connections or loose terminals at TCM.

DTC P1655: Problem in TCM-to-ECM Communication Lines

2001-2004 Models

- NOTE:
- Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.
  - This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
- 1. Turn the ignition switch OFF.
- 2. Disconnect TCM connector B (22P) and ECM connector C (31P).
- 3. Check for continuity between TCM connector terminal B7 and ECM connector terminal C15.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

## TCM CONNECTOR B (22P) ECM CONNECTOR C (31P)



Wire side of female terminals

G03681754

## Fig. 53: Checking Continuity Between TCM Connector Terminal B7 And ECM Connector Terminal C15 Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** -Go to step 4.

**NO** -Repair an open in the wire between TCM connector terminal B7 and ECM connector terminal C15.

4. Check for continuity between TCM connector terminal B7 and body ground, or between ECM connector terminal C15 and body ground.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



Wire side of female terminals

G03681755

## Fig. 54: Checking Continuity Between TCM Connector Terminal B7 And Body Ground, Or Between ECM Connector Terminal C15 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** -Repair a short to ground in the wire between TCM connector terminal B7, ECM connector terminal C15, and body ground. **NO** -Go to step 5.

- 5. Connect TCM connector B (22P).
- 6. Turn the ignition switch ON (II).
- 7. Measure the voltage between ECM connector terminal C15 and body ground.



Wire side of female terminals

G03681756

## **Fig. 55: Measuring Voltage Between ECM Connector C (31P) Terminal** <u>C15 And Body Ground</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there about 10 V?

## YES -Go to step 8.

**NO** -Check for loose terminal fit in the TCM connectors. If necessary, substitute a known-good TCM (see <u>HOW TO TROUBLESHOOT</u> <u>CIRCUIT AT THE TCM</u>) and recheck.

- 8. Turn the ignition switch OFF.
- 9. Connect ECM connector C (31P).

- 10. Turn the ignition switch ON (II).
- 11. Measure the voltage between ECM connector terminal C15 and body ground.

## ECM CONNECTOR C (31P)



Wire side of female terminals

G03681757

## **Fig. 56: Measuring Voltage Between ECM Connector C (31P) Terminal** <u>C15 And Body Ground</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there battery voltage?

**YES** -Go to step 12. **NO** -Replace the ECM.

12. Turn the ignition switch OFF.

- 13. Disconnect TCM connector B (22P) and ECM connector C (31P).
- 14. Check for continuity between TCM connector terminal B6 and ECM connector terminal C11.

## TCM CONNECTOR B (22P) ECM CONNECTOR C (31P)



Wire side of female terminals

G03681758

## **Fig. 57: Checking Continuity Between TCM Connector Terminal B6 And** <u>ECM Connector Terminal C11</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

YES -Go to step 15.

**NO** -Repair an open in the wire between TCM connector terminal B6 and ECM connector terminal C11.

15. Check for continuity between TCM connector terminal B6 and body ground, or between ECM connector terminal C11 and body ground.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



Wire side of female terminals

G03681759

### Fig. 58: Checking Continuity Between TCM Connector Terminal B6 And Body Ground, Or Between ECM Connector Terminal C11 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** -Repair a short to ground in the wire between TCM connector terminal B6, ECM connector terminal C11, and ground.

**NO** -Go to step 16.

- 16. Connect ECM connector C (31P).
- 17. Turn the ignition switch ON (II).
- 18. Measure the voltage between TCM connector terminal B6 and body ground.



Wire side of female terminals

G03681760

## **Fig. 59: Measuring Voltage Between TCM Connector B (22P) Terminal B6 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there about 10 V?

**YES** -Go to step 19.

**NO** -Check for loose terminal fit in the ECM connectors. If necessary, substitute a known-good ECM (see <u>HOW TO SUBSTITUTE THE</u> <u>ECM</u>) and recheck.

- 19. Turn the ignition switch OFF.
- 20. Connect TCM connector B (22P).
- 21. Turn the ignition switch ON (II).

22. Measure the voltage between TCM connector terminal B6 and body ground.

## TCM CONNECTOR B (22P)



Wire side of female terminals

G03681761

## Fig. 60: Measuring Voltage Between TCM Connector B (22P) Terminal B6 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there battery voltage?

YES -Substitute a known-good TCM (see <u>HOW TO</u> <u>TROUBLESHOOT CIRCUIT AT THE TCM</u>) and recheck. If the check results are same, replace the ECM. NO -Replace the TCM.

DTC P1705: Short in Transmission Range Switch Circuit

2001-2004 Models

## NOTE:

- Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.
  - This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
- 1. Turn the ignition switch ON (II).
- 2. Observe the A/T gear position indicator, and shift to each position.

Do any indicators stay on when the shift lever is not in that position?

YES -Go to step 3.

NO -Go to step 4.

3. Clear the DTC, test-drive the vehicle, and recheck for DTC P1705.

Does the scan tool or the HDS indicate code P1705?

**YES** -Review the freeze data. If the freeze data indicates more than one gear position indicator on at one time, go to step 4.

**NO** -Intermittent failure; wiggle the wire harness and check for an intermittent short to ground.

4. Disconnect the transmission range switch connector.

Do all gear position indicators go out?

**YES** -Replace the transmission range switch.

**NO** -Turn the ignition switch OFF, then go to step 5.

- 5. Connect the transmission range switch connector.
- 6. Turn the ignition switch ON (II).
- 7. Shift to any position other than the R position.
- 8. Measure the voltage between TCM connector terminals A11 and A4.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

## TCM CONNECTOR A (26P)



Wire side of female terminals

G03681762

## **Fig. 61: Measuring Voltage Between TCM Connector A (26P) Terminals** <u>A11 And A4</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there about 10 V?

**YES** -Go to step 9.

**NO** -Check for short in the wire between TCM connector terminal A11 and the transmission range switch or A/T gear position indicator, and check for an open in the wires between TCM connector terminals A4, and ground (G101). If the wires are OK, check for loose terminal fit in the TCM connectors. If necessary, substitute a known-good TCM (see <u>HOW</u> <u>TO TROUBLESHOOT CIRCUIT AT THE TCM</u>) and recheck.

- 9. Shift to any position other than the P and N positions.
- 10. Measure the voltage between TCM connector terminals A10 and A4.
2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# TCM CONNECTOR A (26P)



Wire side of female terminals

G03681763

#### **Fig. 62: Measuring Voltage Between TCM Connector A (26P) Terminals** <u>A10 And A4</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there about 5 V?* 

**YES** -Go to step 11.

**NO** -Check for short in the wire between TCM connector terminal A10 and the A/T gear position indicator, and check for short in the P and N position wires between the gauge assembly and the transmission range switch. If the wires are OK, check for loose terminal fit in the TCM connectors. If necessary, substitute a known-good TCM (see <u>HOW TO</u> **TROUBLESHOOT CIRCUIT AT THE TCM**) and recheck.

- 11. Shift to any position other than the D position.
- 12. Measure the voltage between TCM connector terminals A9 and A4.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# TCM CONNECTOR A (26P)



## Wire side of female terminals

G03681764

#### **Fig. 63: Measuring Voltage Between TCM Connector A (26P) Terminals** <u>A9 And A4</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there about 5 V?* 

**YES** -Go to step 13.

**NO** -Check for short in the wire between TCM connector terminal A9 and the transmission range switch. If the wire is OK, check for loose terminal fit in the TCM connectors. If necessary, substitute a known-good TCM (see **HOW TO TROUBLESHOOT CIRCUIT AT THE TCM**) and recheck.

- 13. Shift to any position other than the L position.
- 14. Measure the voltage between TCM connector terminals A7 and A4.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# TCM CONNECTOR A (26P)



Wire side of female terminals

G03681765

#### **Fig. 64: Measuring Voltage Between TCM Connector A (26P) Terminals** <u>A7 And A4</u> **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there about 10 V?

**YES** -Check for loose terminal fit in the TCM connectors. If necessary, substitute a known-good TCM and recheck.

**NO** -Check for short in the wire between TCM connector terminal A7 and the transmission range switch or A/T gear position indicator. If the wire is OK, check for loose terminal fit in the TCM connectors. If necessary, substitute a known-good TCM (see <u>HOW TO TROUBLESHOOT</u> <u>CIRCUIT AT THE TCM</u>) and recheck.

DTC P1706: Open in Transmission Range Switch Circuit

2001-2004 Models

- NOTE: Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.
  - This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
  - 1. Test the transmission range switch (see <u>TRANSMISSION RANGE</u> <u>SWITCH TEST</u> ).

Is the switch OK?

YES -Go to step 2.

**NO** -Replace the transmission range switch.

- 2. Connect the transmission range switch connector.
- 3. Check for continuity between TCM connector terminal A4 and body ground, and between A17 and body ground.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



Wire side of female terminals

G03681766

## **Fig. 65: Checking Continuity Between TCM Connector A (26P) Terminal** <u>A4, A17 And Body Ground</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

YES -Go to step 4.

**NO** -Repair an open in the wires between TCM connector terminals A4, A17, and ground (G101), or repair poor ground (G10D.

- 4. Turn the ignition switch ON (II).
- 5. Shift to the R position.
- 6. Measure the voltage between TCM connector terminals A11 and A4.

TCM CONNECTOR A (26P)

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# TCM CONNECTOR A (26P)



## Wire side of female terminals

G03681767

## **Fig. 66: Measuring Voltage Between TCM Connector A (26P) Terminals** <u>A11 And A4</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there about 10 V?

**YES** -Repair an open in the wire between TCM connector terminal A11 and the transmission range switch.

NO -Go to step 7.

- 7. Shift to the P or N position.
- 8. Measure the voltage between TCM connector terminals A10 and A4.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

## **TCM CONNECTOR A (26P)**



Wire side of female terminals

G03681768

#### Fig. 67: Measuring Voltage Between TCM Connector A (26P) Terminals A10 And A4 Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there about 5 V?* 

**YES** -Repair an open in the wire between TCM connector terminal A10 and the A/T gear position indicator.

NO -Go to step 9.

- 9. Shift to the D position.
- 10. Measure the voltage between TCM connector terminals A9 and A4.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# TCM CONNECTOR A (26P)



Wire side of female terminals

G03681769

#### **Fig. 68: Measuring Voltage Between TCM Connector A (26P) Terminals** <u>A9 And A4</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there about 5 V?* 

**YES** -Repair an open in the wire between TCM connector terminal A9 and the transmission range switch.

**NO** -Go to step 11.

- 11. Shift to the L position.
- 12. Measure the voltage between TCM connector terminals A7 and A4.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# TCM CONNECTOR A (26P)



## Wire side of female terminals

G03681770

#### **Fig. 69: Measuring Voltage Between TCM Connector A (26P) Terminals** A7 And A4 Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there about 10 V?* 

**YES** -Repair an open in the wire between TCM connector terminal A7 and the transmission range switch.

**NO** -Check for loose terminal fit in the TCM connectors. If necessary, substitute a known-good TCM (see <u>HOW TO TROUBLESHOOT</u> <u>CIRCUIT AT THE TCM</u>) and recheck.

DTC P1790: Problem in Throttle Position Sensor Circuit

2001-2004 Models

# NOTE: • Record all freeze data and review General

Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.

- This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
- 1. Turn the ignition switch ON (II).
- 2. Check whether the scan tool or the HDS indicates code for the throttle position (TP) sensor.

Does the scan tool or the HDS indicate code for TP sensor?

**YES** -Do the DTC Troubleshooting for the TP sensor circuit low voltage (see **DTC P0122: TP SENSOR CIRCUIT LOW VOLTAGE**), and the TP sensor circuit high voltage (see **DTC P0123: TP SENSOR CIRCUIT HIGH VOLTAGE**). Recheck for DTC P1790 after troubleshooting. NO -Turn the ignition switch OFF, then go to step 3.

- 3. Disconnect TCM connectors A (26P) and B (22P).
- 4. Turn the ignition switch ON (II).
- 5. Measure the voltage between TCM connector terminals B20 and A4.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# TCM CONNECTORS



## Wire side of female terminals

G03681771

## **Fig. 70: Measuring Voltage Between TCM Connector Terminals B20 And** <u>A4</u> **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

*Is there about 5 V?* 

YES -Go to step 6.

**NO** -Repair an open or short in VREF wire between TCM connector terminals B20 and the ECM.

- 6. Close the throttle fully.
- 7. Measure the voltage between TCM connector terminals B4 and A4.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

## **TCM CONNECTORS**



Wire side of female terminals

G03681772

#### **Fig. 71: Measuring Voltage Between TCM Connector Terminals B4 And** <u>A4</u> **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

*Is there about 0.5 V?* 

**YES** -Check for loose terminal fit in the TCM connectors. If necessary, substitute a known-good TCM (see <u>HOW TO TROUBLESHOOT</u> <u>CIRCUIT AT THE TCM</u>) and recheck.

**NO** -Repair an open or short in the wire between TCM connector terminal B4 and the TP sensor.

DTC P1791: Problem in Vehicle Speed Sensor Circuit

2001-2004 Models

NOTE:

 Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u>

TROUBLESHOOTING INFORMATION ) before you troubleshoot.

- This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
- 1. Apply the parking brake, and block both rear wheels securely.
- 2. Raise the front of the vehicle, and make sure it is securely supported.
- 3. Shift to the N position.
- 4. Disconnect TCM connectors A (26P) and B (22P).
- 5. Turn the ignition switch ON (II).
- 6. Measure the voltage between TCM connector terminals B5 and A4 while rotating the front wheel slowly by hand.

## **TCM CONNECTORS**



Wire side of female terminals

G03681773

#### **Fig. 72: Measuring Voltage Between TCM Connector Terminals B5 And** <u>A4</u> **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

*Is there 0 V or about 5 V?* 

**YES** -Check for loose terminal fit in the TCM connectors. If necessary, substitute a known-good TCM (see <u>HOW TO TROUBLESHOOT</u> <u>CIRCUIT AT THE TCM</u>) and recheck.

**NO** -Check for an open or a short in the wire between TCM connector terminal B5 and the vehicle speed sensor (VSS). If the wire is OK, replace the VSS.

DTC P1792: Problem in Engine Coolant Temperature Sensor Circuit

2001-2004 Models

- NOTE: 1. Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.
  - 2. This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
  - 1. Turn the ignition switch ON (II).
- 2. Check whether the scan tool or the HDS indicates code for the engine coolant temperature (ECT) sensor.

Does the scan tool or the HDS indicate code for ECT sensor?

**YES** -Do the DTC Troubleshooting for the ECT sensor circuit low voltage (see **DTC P0117: ECT SENSOR CIRCUIT LOW VOLTAGE**), and the ECT sensor circuit high voltage (see **DTC P0118: ECT SENSOR CIRCUIT HIGH VOLTAGE**). Recheck for DTC P1792 after troubleshooting.

**NO** -Turn the ignition switch OFF, then go to step 3.

- 3. Disconnect TCM connectors A (26P) and B (22P).
- 4. Turn the ignition switch ON (II).
- 5. Measure the voltage between TCM connector terminals B20 and A4.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# TCM CONNECTORS



Wire side of female terminals

G03681774

#### **Fig. 73: Measuring Voltage Between TCM Connector Terminals B20 And** <u>A4</u> **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

*Is there about 5 V?* 

**YES** -Go to step 6.

**NO** -Repair an open or short in VREF wire between TCM connector terminals B20 and the ECM.

6. Measure the voltage between TCM connector terminals A19 and A4.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# TCM CONNECTOR A (26P)



Wire side of female terminals

G03681775

#### **Fig. 74: Measuring Voltage Between TCM Connector A (26P) Terminals** <u>A19 And A4</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there 0.1 - 4.8 V?* 

**YES** -Check for loose terminal fit in the TCM connectors. If necessary, substitute a known-good TCM (see <u>HOW TO TROUBLESHOOT</u> <u>CIRCUIT AT THE TCM</u>) and recheck.

**NO** -Repair an open or short in the wire between TCM connector terminal A19 and the ECT sensor.

DTC P1793: Problem in Manifold Absolute Pressure Sensor Circuit

2001-2004 Models

NOTE:

## Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u>

TROUBLESHOOTING INFORMATION ) before you troubleshoot.

- This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
- 1. Turn the ignition switch ON (II).
- 2. Check whether the scan tool or the HDS indicates code for the manifold absolute pressure (MAP) sensor.

Does the scan tool or the HDS indicate code for MAP sensor?

YES -Do the DTC Troubleshooting for the MAP sensor circuit low voltage (see <u>DTC P0107: MAP SENSOR CIRCUIT LOW</u> <u>VOLTAGE</u>), and the MAP sensor circuit high voltage (see <u>DTC P0108:</u> <u>MAP SENSOR CIRCUIT HIGH VOLTAGE</u>). Recheck for DTC P1793 after troubleshooting.

**NO** -Turn the ignition switch OFF, then go to step 3.

- 3. Disconnect TCM connectors A (26P) and B (22P).
- 4. Turn the ignition switch ON (II).
- 5. Measure the voltage between TCM connector terminals B20 and A4.

# TCM CONNECTORS



## Wire side of female terminals

G03681776

## **Fig. 75: Measuring Voltage Between TCM Connector Terminals B20 And** <u>A4</u> **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there about 5 V?

YES -Go to step 6.

**NO** -Repair an open or short in VREF wire between TCM connector terminals B20and the ECM.

6. Measure the voltage between TCM connector terminals B2 and A4.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

## **TCM CONNECTORS**



## Wire side of female terminals

G03681777

#### **Fig. 76: Measuring Voltage Between TCM Connector Terminals B2 And** <u>A4</u> **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there about 3 V?

**YES** -Check for loose terminal fit in the TCM connectors. If necessary, substitute a known-good TCM (see <u>HOW TO TROUBLESHOOT</u> <u>CIRCUIT AT THE TCM</u>) and recheck.

**NO** -Repair an open or short in the wire between TCM connector terminal B2 and the MAP sensor.

DTC P1799: Problem in Intake Air Temperature Sensor Circuit

2001-2004 Models

NOTE:

## Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u>

TROUBLESHOOTING INFORMATION ) before you troubleshoot.

- This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
- 1. Turn the ignition switch ON (II).
- 2. Check whether the scan tool or the HDS indicates code for the intake air temperature (IAT) sensor.

Does the scan tool or the HDS indicate code for IAT sensor?

**YES** -Do the DTC Troubleshooting for the IAT sensor circuit low voltage (see **DTC P0112: IAT SENSOR CIRCUIT LOW VOLTAGE**), and the IAT sensor circuit high voltage (see **DTC P0113: IAT SENSOR CIRCUIT HIGH VOLTAGE**). Recheck for DTC P1799 after troubleshooting.

**NO** -Turn the ignition switch OFF, then go to step 3.

- 3. Disconnect TCM connectors A (26P) and B (22P).
- 4. Turn the ignition switch ON (II).
- 5. Measure the voltage between TCM connector terminals B20 and A4.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# TCM CONNECTORS



## Wire side of female terminals

G03681778

## **Fig. 77: Measuring Voltage Between TCM Connector Terminals B20 And** <u>A4</u> **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

•

*Is there about 5 V?* 

**YES** -Go to step 6.

**NO** -Repair an open or short in VREF wire between TCM connector terminals B20 and the ECM.

6. Measure the voltage between TCM connector terminals B19 and A4.

# TCM CONNECTORS



Wire side of female terminals

G03681779

# Fig. 78: Measuring Voltage Between TCM Connector Terminals B19 And A4

**Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

Is there 0.1 - 4.8 V?

**YES** -Check for loose terminal fit in the TCM connectors. If necessary, substitute a known-good TCM (see <u>HOW TO TROUBLESHOOT</u> <u>CIRCUIT AT THE TCM</u>) and recheck.

**NO** -Repair an open or short in the wire between TCM connector terminal B19 and the IAT sensor.

DTC P1850: Problem in Creep Aid System Solenoid Valve A Circuit

2001-2004 Models

# NOTE: • Record all freeze data and review General

Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.

- This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
- 1. Turn the ignition switch OFF.
- 2. Disconnect TCM connectors A (26P) and B (22P).
- 3. Turn the ignition switch ON (II).
- 4. Measure the voltage between TCM connector terminals B11 and A4.

## **TCM CONNECTORS**



Wire side of female terminals

G03681780

**Fig. 79: Measuring Voltage Between TCM Connector Terminals B11 And** <u>A4</u> **Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

Is there voltage?

**YES** -Repair a short to power in the wire between TCM connector terminal B11 and the creep aid system solenoid valve A. **NO** -Go to step 5.

- 5. Turn the ignition switch OFF.
- Disconnect the 4P connector from the creep aid system solenoid valves A and B.
- 7. Check for continuity between TCM connector terminals B11 and A4.

## **TCM CONNECTORS**



Wire side of female terminals

G03681781

## **Fig. 80: Checking Continuity Between TCM Connector Terminals B11** <u>And A4</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

**YES** -Repair a short to ground in the wire between TCM connector terminal B11 and the creep aid system solenoid valve A.

**NO** -Go to step 8.

- 8. Connect the creep aid system solenoid valves A and B connector.
- 9. Measure the resistance between TCM connector terminals B11 and A4.

## **TCM CONNECTORS**



Wire side of female terminals

G03681782

## **Fig. 81: Measuring Resistance Between TCM Connector Terminals B11** <u>And A4</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there 8 - 24 ohm ?* 

**YES** -Check for loose terminal fit in the TCM connectors. If necessary, substitute a known-good TCM (see <u>HOW TO TROUBLESHOOT</u> <u>CIRCUIT AT THE TCM</u>) and recheck.

NO -Check for an open in the wire between TCM connector terminal B11

and the creep aid system solenoid valve A. If the wire is OK, replace the creep aid system solenoid valves A and B.

DTC P1851: Problem in Creep Aid System Solenoid Valve B Circuit

2001-2004 Models

- NOTE:
- Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.
  - This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
- 1. Turn the ignition switch OFF.
- 2. Disconnect TCM connectors A (26P) and B (22P).
- 3. Turn the ignition switch ON (II).
- 4. Measure the voltage between TCM connector terminals B18 and A4.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# **TCM CONNECTORS**



Wire side of female terminals

G03681783

#### **Fig. 82: Measuring Voltage Between TCM Connector Terminals B18 And** <u>A4</u> **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there voltage?

**YES** -Repair a short to power in the wire between TCM connector terminal B18 and the creep aid system solenoid valve B.

**NO** -Go to step 5.

- 5. Turn the ignition switch OFF.
- 6. Disconnect the 4P connector from the creep aid system solenoid valves A and B.
- 7. Check for continuity between TCM connector terminals B18 and A4.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# **TCM CONNECTORS**



Wire side of female terminals

G03681784

#### **Fig. 83: Checking Continuity Between TCM Connector Terminals B18** <u>And A4</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** -Repair a short to ground in the wire between TCM connector terminal B18 and the creep aid system solenoid valve B.

NO -Go to step 8.

- 8. Connect the creep aid system solenoid valves A and B connector.
- 9. Measure the resistance between TCM connector terminals B18 and A4.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# TCM CONNECTORS



Wire side of female terminals

G03681785

## **Fig. 84: Measuring Resistance Between TCM Connector Terminals B18** <u>And A4</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there 8 - 24 ohm ?* 

**YES** -Check for loose terminal fit in the TCM connectors. If necessary, substitute a known-good TCM (see <u>HOW TO TROUBLESHOOT</u> <u>CIRCUIT AT THE TCM</u>) and recheck.

**NO** -Check for an open in the wire between TCM connector terminal B18 and the creep aid system solenoid valve B. If the wire is OK, replace the creep aid system solenoid valves A and B.

DTC P1879: Problem in CVT Start Clutch Pressure Control Valve Circuit

2001-2004 Models

## NOTE: • Record all freeze data and review General

Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.

- This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
- 1. Turn the ignition switch OFF.
- 2. Disconnect the solenoid harness connector (8P).
- 3. Measure the resistance between solenoid harness connector (8P) terminals No. 4 and No. 8.

# **SOLENOID HARNESS CONNECTOR (8P)**



# Terminal side of male terminals

G03681786

## **Fig. 85: Measuring Resistance Between Solenoid Harness Connector (8P) Terminals 4 And 8 Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is the resistance 3.8-6.8 ohm?

**YES** -Go to step 4.

**NO** -Replace the lower valve body assembly.

- 4. Disconnect TCM connector A (26P).
- 5. Check for continuity between TCM connector terminal A1 and body ground, and between A14 and body ground.



## Fig. 86: Checking Continuity Between TCM Connector A (26P) Terminal A1, A14 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** -Repair a short to ground in the wire between TCM connector terminal A1 or A14 and the solenoid harness connector (8P).

NO -Go to step 6.

- 6. Connect the solenoid harness connector (8P).
- 7. Measure the resistance between TCM connector terminals A1 and A14.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# TCM CONNECTOR A (26P)



Wire side of female terminals

G03681788

## Fig. 87: Measuring Resistance Between TCM Connector A (26P) Terminals A1 And A14 Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there 3.8- 6.8 ohm?* 

**YES** -Check for loose terminal fit in the TCM connectors. If necessary, substitute a known-good TCM (see <u>HOW TO TROUBLESHOOT</u> <u>CIRCUIT AT THE TCM</u>) and recheck.

**NO** -Repair an open in the wire between TCM connector terminal A1 or A14 and the solenoid harness connector (8P).

DTC P1882: Problem in Inhibitor Solenoid Circuit

2001-2004 Models

# NOTE: • Record all freeze data and review General

Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.

- This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
- 1. Turn the ignition switch OFF.
- 2. Disconnect the solenoid harness connector (8P).
- Measure the resistance between solenoid harness connector (8P) terminals No.
  5 and body ground.

# SOLENOID HARNESS CONNECTOR (8P)



Terminal side of male terminals

G03681789

## **Fig. 88: Measuring Resistance Between Solenoid Harness Connector (8P) Terminals 5 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is the resistance 11.7-21.0 ohm?

**YES** -Go to step 4.

**NO** -Replace the lower valve body assembly.

- 4. Disconnect TCM connector B (22P).
- 5. Check for continuity between TCM connector terminal B1 and body ground.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# TCM CONNECTOR B (22P)

# SOL INH (GRN/BLK)



Wire side of female terminals

G03681790

#### **Fig. 89: Checking Continuity Between TCM Connector B (22P) Terminal B1 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there continuity?

**YES** -Repair a short to ground in the wire between TCM connector terminal B1 and the solenoid harness connector (8P). **NO** -Go to step 6.

- 6. Connect the solenoid harness connector (8P).
- 7. Measure the resistance between TCM connector terminal B1 and body ground.
### TCM CONNECTOR B (22P)

### SOL INH (GRN/BLK)



Wire side of female terminals

G03681791

#### **Fig. 90: Measuring Resistance Between TCM Connector B (22P) Terminal B1 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there 11.7-21.0 ohm?

**YES** -Check for loose terminal fit in the TCM connectors. If necessary, substitute a known-good TCM (see <u>HOW TO TROUBLESHOOT</u> <u>CIRCUIT AT THE TCM</u>) and recheck.

**NO** -Repair an open in the wire between TCM connector terminal B1 and the solenoid harness connector (8P).

DTC P1885: Problem in CVT Input Shaft (Drive Pulley) Speed Sensor Circuit

2006 Honda I	nsight
--------------	--------

- NOTE: Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.
  - This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
  - 1. Turn the ignition switch OFF.
- 2. Disconnect CVT input shaft (drive pulley) speed sensor connector.
- 3. Turn the ignition switch ON (II).
- 4. Measure the voltage between CVT input shaft (drive pulley) speed sensor connector terminal No. 1 and body ground.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

### CVT INPUT SHAFT (DRIVE PULLEY) SPEED SENSOR CONNECTOR



# Wire side of female terminals

G03681792

**Fig. 91: Measuring Voltage Between CVT Input Shaft (Drive Pulley) Speed Sensor Connector Terminal 1 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

*Is there about 5 V?* 

YES -Go to step 5. NO -Go to step 11.

5. Turn the ignition switch OFF.

6. Check for continuity between CVT input shaft (drive pulley) speed sensor connector terminal No. 2 and body ground.

# CVT INPUT SHAFT (DRIVE PULLEY) SPEED SENSOR CONNECTOR



# Wire side of female terminals

G03681793

**Fig. 92: Checking Continuity Between CVT Input Shaft (Drive Pulley) Speed Sensor Connector Terminal 2 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

Is there continuity?

**YES** -Repair a short to ground in the wire between TCM connector terminal B10 and the CVT input shaft (drive pulley) speed sensor. **NO** -Go to step 7.

7. Check for continuity between CVT input shaft (drive pulley) speed sensor connector terminal No. 3 and body ground.

### CVT INPUT SHAFT (DRIVE PULLEY) SPEED SENSOR CONNECTOR



# Wire side of female terminals

G03681794

**Fig. 93: Checking Continuity Between CVT Input Shaft (Drive Pulley) Speed Sensor Connector Terminal 3 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

Is there continuity?

YES -Go to step 8.

**NO** -Repair loose terminal or open in the wire between TCM connector terminal B17 and the CVT input shaft (drive pulley) speed sensor.

- 8. Turn the ignition switch ON (II).
- 9. Measure the voltage between CVT input shaft (drive pulley) speed sensor connector terminals No. 2 and No. 3.

### CVT INPUT SHAFT (DRIVE PULLEY) SPEED SENSOR CONNECTOR



### Wire side of female terminals

G03681795

**Fig. 94: Measuring Voltage Between CVT Input Shaft (Drive Pulley) Speed Sensor Connector Terminals 2 And 3** 

### Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there about 5 V?

YES -Go to step 15.

NO -Go to step 10.

10. Measure the voltage between TCM connector terminals B10and B17.

### TCM CONNECTOR B (22P)



Wire side of female terminals

G03681796

**Fig. 95: Measuring Voltage Between TCM Connector B (22P) Terminals B10 And B17 Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

*Is there about 5 V?* 

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

**YES** -Repair an open in the wire between TCM connector terminal B10 and the CVT input shaft (drive pulley) speed sensor.

**NO** -Check for loose terminal fit in the TCM connectors. If necessary, substitute a known-good TCM (see <u>HOW TO TROUBLESHOOT</u> <u>CIRCUIT AT THE TCM</u>) and recheck.

11. Measure the voltage between TCM connector terminals B17 and B22.

### TCM CONNECTOR B (22P)



Wire side of female terminals

G03681797

#### **Fig. 96: Measuring Voltage Between TCM Connector B (22P) Terminals B17 And B22 Courtesy of AMERICAN HONDA MOTOR CO., INC.**

*Is there about 5 V?* 

**YES** -Repair an open in the wire between TCM connector terminal B22

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

and the CVT input shaft (drive pulley) speed sensor.

NO -Go to step 12.

- 12. Turn the ignition switch OFF.
- 13. Disconnect TCM connector B (22P).
- 14. Check for continuity between TCM connector terminal B22 and body ground.

# TCM CONNECTOR B (22P)



G03681798

**Fig. 97: Checking Continuity Between TCM Connector B (22P) Terminal B22 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

Is there continuity?

**YES** -Repair a short to ground in the wire between TCM connector terminal B22 and the CVT input shaft (drive pulley) speed sensor.

**NO** -Check for loose terminal fit in the TCM connectors. If necessary, substitute a known-good TCM (see <u>HOW TO TROUBLESHOOT</u> <u>CIRCUIT AT THE TCM</u>) and recheck.

- 15. Turn the ignition switch OFF.
- 16. Connect CVT input shaft (drive pulley) speed sensor connector.
- 17. Turn the ignition switch ON (II).
- 18. Measure the voltage between TCM connector terminals B10 and B17.

### TCM CONNECTOR B (22P)



Wire side of female terminals

G03681799

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

#### **Fig. 98: Measuring Voltage Between TCM Connector B (22P) Terminals B10 And B17 Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there 0 V or about 5 V?

YES -Go to step 17.

**NO** -Replace the CVT input shaft (drive pulley) speed sensor.

- 19. Apply the parking brake, and block both rear wheels securely.
- 20. Raise the front of the vehicle, and make sure it is securely supported.
- 21. Start the engine, then shift to the D position and drive the vehicle at engine idling.
- 22. Measure the voltage between TCM connector terminals B10and B17.



Wire side of female terminals

G03681800

### **Fig. 99: Measuring Voltage Between TCM Connector B (22P) Terminals B10 And B17 Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there 1.5-3.5 V?

**YES** -Check for loose terminal fit in the TCM connectors. If necessary, substitute a known-good TCM (see <u>HOW TO TROUBLESHOOT</u> <u>CIRCUIT AT THE TCM</u>) and recheck.

NO -Replace the CVT input shaft (drive pulley) speed sensor.

DTC P1886: Problem in CVT Output Shaft (Driven Pulley) Speed Sensor Circuit

2001-2004 Models

- NOTE: Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.
  - This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
  - 1. Turn the ignition switch OFF.
- 2. Disconnect CVT output shaft (driven pulley) speed sensor connector.
- 3. Turn the ignition switch ON (II).
- 4. Measure the voltage between CVT output shaft (driven pulley) speed sensor connector terminal No. 1 and body ground.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

### CVT OUTPUT SHAFT (DRIVEN PULLEY) SPEED SENSOR CONNECTOR



Wire side of female terminals

G03681801

### **Fig. 100:** Measuring Voltage Between CVT Output Shaft (Driven Pulley) Speed Sensor Connector Terminal 1 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there about 5 V?* 

**YES** -Go to step 5. **NO** -Go to step 11.

- 5. Turn the ignition switch OFF.
- 6. Check for continuity between CVT output shaft (driven pulley) speed sensor connector terminal No. 2 and body ground.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

### CVT OUTPUT SHAFT (DRIVEN PULLEY) SPEED SENSOR CONNECTOR



Wire side of female terminals

G03681802

### **Fig. 101: Checking Continuity Between CVT Output Shaft (Driven Pulley) Speed Sensor Connector Terminal 2 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there continuity?

**YES** -Repair a short to ground in the wire between TCM connector terminal B9 and the CVT output shaft (driven pulley) speed sensor. **NO** -Go to step 7.

7. Check for continuity between CVT output shaft (driven pulley) speed sensor connector terminal No. 3 and body ground.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

### CVT OUTPUT SHAFT (DRIVEN PULLEY) SPEED SENSOR CONNECTOR



Wire side of female terminals

G03681803

#### **Fig. 102: Checking Continuity Between CVT Output Shaft (Driven Pulley) Speed Sensor Connector Terminal 3 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there continuity?

YES -Go to step 8.

**NO** -Repair loose terminal or open in the wire between TCM connector terminal B8 and the CVT output shaft (driven pulley) speed sensor.

- 8. Turn the ignition switch ON (II).
- 9. Measure the voltage between CVT output shaft (driven pulley) speed sensor connector terminals No. 2 and No. 3.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

### CVT OUTPUT SHAFT (DRIVEN PULLEY) SPEED SENSOR CONNECTOR



Wire side of female terminals

G03681804

**Fig. 103: Measuring Voltage Between CVT Output Shaft (Driven Pulley) Speed Sensor Connector Terminals 2 And 3 Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

*Is there about 5 V?* 

**YES** -Go to step 15 . **NO** -Go to step 10.

10. Measure the voltage between TCM connector terminals B8 and B9.



Wire side of female terminals

G03681805

#### **Fig. 104: Measuring Voltage Between TCM Connector B (22P) Terminals B8 And B9 Courtesy of AMERICAN HONDA MOTOR CO., INC.**

*Is there about 5 V?* 

**YES** -Repair an open in the wire between TCM connector terminal B9 and the CVT output shaft (driven pulley) speed sensor.

**NO** -Check for loose terminal fit in the TCM connectors. If necessary, substitute a known-good TCM (see <u>HOW TO TROUBLESHOOT</u> <u>CIRCUIT AT THE TCM</u>) and recheck.

11. Measure the voltage between TCM connector terminals B8 and B21.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# TCM CONNECTOR B (22P)



Wire side of female terminals

G03681806

#### Fig. 105: Measuring Voltage Between TCM Connector B (22P) Terminals B8 And B21 Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there about 5 V?* 

**YES** -Repair an open in the wire between TCM connector terminal B21 and the CVT output shaft (driven pulley) speed sensor.

**NO** -Go to step 12.

- 12. Turn the ignition switch OFF.
- 13. Disconnect TCM connector B (22P).
- 14. Check for continuity between TCM connector terminal B21 and body ground.

#### TCM CONNECTOR B (22P)

### VCC3 (YEL/GRN)

### Wire side of female terminals

G03681807

### **Fig. 106: Checking Continuity Between TCM Connector B (22P) Terminal B21 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there continuity?

**YES** -Repair a short to ground in the wire between TCM connector terminal B21 and the CVT output shaft (driven pulley) speed sensor.

**NO** -Check for loose terminal fit in the TCM connectors. If necessary, substitute a known-good TCM (see <u>HOW TO TROUBLESHOOT</u> <u>CIRCUIT AT THE TCM</u>) and recheck.

- 15. Connect CVT output shaft (driven pulley) speed sensor connector.
- 16. Turn the ignition switch ON (II).
- 17. Measure the voltage between TCM connector terminals B8 and B9.

### **TCM CONNECTOR B (22P)**



### Wire side of female terminals

G03681808

### **Fig. 107: Measuring Voltage Between TCM Connector B (22P) Terminals B8 And B9 Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there O V or about 5 V?

**YES** -Go to step 17.

**NO** -Replace the CVT output shaft (driven pulley) speed sensor.

18. Apply the parking brake, and block both rear wheels securely.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

- 19. Raise the front of the vehicle, and make sure it is securely supported.
- 20. Start the engine, then shift to the D position and drive the vehicle at engine idling.
- 21. Measure the voltage between TCM connector terminals B8 and B9.

### **TCM CONNECTOR B (22P)**



Wire side of female terminals

G03681809

#### **Fig. 108: Measuring Voltage Between TCM Connector B (22P) Terminals B8 And B9 Courtesy of AMERICAN HONDA MOTOR CO., INC.**

*Is there 1.5-3.5 V?* 

**YES** -Check for loose terminal fit in the TCM connectors. If necessary, substitute a known-good TCM (see **<u>HOW TO TROUBLESHOOT</u>** 

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

### CIRCUIT AT THE TCM ) and recheck.

**NO** -Replace the CVT output shaft (driven pulley) speed sensor.

DTC P1888: Problem in CVT Speed Sensor Circuit

2001-2004 Models

- NOTE:
- Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.
  - This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
- 1. Turn the ignition switch OFF.
- 2. Disconnect CVT speed sensor connector.
- 3. Turn the ignition switch ON (II).
- 4. Measure the voltage between CVT speed sensor connector terminal No. 1 and body ground.

# **CVT SPEED SENSOR CONNECTOR**



# Wire side of female terminals

G03681810

**Fig. 109: Measuring Voltage Between CVT Speed Sensor Connector Terminal 1 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

*Is there about 5 V?* 

**YES** -Go to step 5. **NO** -Go to step 11.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

- 5. Turn the ignition switch OFF.
- 6. Check for continuity between CVT speed sensor connector terminal No. 2 and body ground.

# **CVT SPEED SENSOR CONNECTOR**



# Wire side of female terminals

G03681811

**Fig. 110: Checking Continuity Between CVT Speed Sensor Connector Terminal 2 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

Is there continuity?

**YES** -Repair a short to ground in the wire between TCM connector terminal B15and the CVT speed sensor.

**NO** -Go to step 7.

7. Check for continuity between CVT speed sensor connector terminal No. 3 and body ground.

### **CVT SPEED SENSOR CONNECTOR**



Wire side of female terminals

G03681812

**Fig. 111: Checking Continuity Between CVT Speed Sensor Connector Terminal 3 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

Is there continuity?

YES -Go to step 8.

**NO** -Repair loose terminal or open in the wire between TCM connector terminal B16 and the CVT speed sensor.

- 8. Turn the ignition switch ON (II).
- Measure the voltage between CVT speed sensor connector terminals No. 2 and No. 3.

### **CVT SPEED SENSOR CONNECTOR**



Wire side of female terminals

G03681813

**Fig. 112: Measuring Voltage Between CVT Speed Sensor Connector** <u>Terminals 2 And 3</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there about 5 V?* 

YES -Go to step 15.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

**NO** -Go to step 10.

10. Measure the voltage between TCM connector terminals B15 and B16.

### TCM CONNECTOR B (22P)



Wire side of female terminals

G03681814

### **Fig. 113: Measuring Voltage Between TCM Connector B (22P) Terminals B15 And B16 Courtesy of AMERICAN HONDA MOTOR CO., INC.**

*Is there about 5 V?* 

**YES** -Repair an open in the wire between TCM connector terminal B15 and the CVT speed sensor.

**NO** -Check for loose terminal fit in the TCM connectors. If necessary, substitute a known-good TCM (see <u>HOW TO TROUBLESHOOT</u> <u>CIRCUIT AT THE TCM</u>) and recheck.

11. Measure the voltage between TCM connector terminals B3 and B16.

### TCM CONNECTOR B (22P)



VEL SG (BLK/WHT)

Wire side of female terminals

G03681815

### **Fig. 114: Measuring Voltage Between TCM Connector B (22P) Terminals B3 And B16 Courtesy of AMERICAN HONDA MOTOR CO., INC.**

*Is there about 5 V?* 

**YES** -Repair an open in the wire between TCM connector terminal B3 and the CVT speed sensor.

NO -Go to step 12.

- 12. Turn the ignition switch OFF.
- 13. Disconnect TCM connector B (22P).

14. Check for continuity between TCM connector terminal B3 and body ground.

### TCM CONNECTOR B (22P)



Wire side of female terminals

G03681816

### **Fig. 115: Checking Continuity Between TCM Connector B (22P) Terminal B3 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there continuity?

**YES** -Repair a short to ground in the wire between TCM connector terminal B3 and the CVT speed sensor.

**NO** -Check for loose terminal fit in the TCM connectors. If necessary, substitute a known-good TCM (see <u>HOW TO TROUBLESHOOT</u> <u>CIRCUIT AT THE TCM</u>) and recheck.

15. Connect CVT speed sensor connector.

- 16. Turn the ignition switch ON (II).
- 17. Measure the voltage between TCM connector terminals B15 and B16.

### TCM CONNECTOR B (22P)



Wire side of female terminals

G03681817

### **Fig. 116: Measuring Voltage Between TCM Connector B (22P) Terminals B15 And B16 Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there O V or about 5 V?

**YES** -Go to step 17.

**NO** -Replace the CVT speed sensor.

- 18. Apply the parking brake, and block both rear wheels securely.
- 19. Raise the front of the vehicle, and make sure it is securely supported.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

- 20. Start the engine, then shift to the D position and drive the vehicle at engine idling.
- 21. Measure the voltage between TCM connector terminals B15 and B16.



### TCM CONNECTOR B (22P)

Wire side of female terminals

G03681818

### **Fig. 117: Measuring Voltage Between TCM Connector B (22P) Terminals B15 And B16 Courtesy of AMERICAN HONDA MOTOR CO., INC.**

*Is there 1.5-3.5 V?* 

**YES** -Check for loose terminal fit in the TCM connectors. If necessary, substitute a known-good TCM (see <u>HOW TO TROUBLESHOOT</u> <u>CIRCUIT AT THE TCM</u>) and recheck.

**NO** -Replace the CVT speed sensor.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

DTC P1890: Problem in Shift Control System

2001-2004 Models

### NOTE: Record all freeze data and review General Troubleshooting Information (see <u>GENERAL TROUBLESHOOTING</u> <u>INFORMATION</u>) before you troubleshoot.

1. Check whether the scan tool or the HDS indicates another code.

Does the scan tool or the HDS indicate another code?

**YES** -Do the DTC Troubleshooting for the indicated code(s). Recheck for DTC P1890 after troubleshooting.

NO -Go to step 2.

2. Measure the stall speed RPM in the D position (see <u>STALL SPEED TEST</u>).

Is the stall speed over 3,500 RPM?

**YES** -Replace the transmission.

**NO** -If the stall speed is below 2,000 RPM, replace the lower valve body assembly. If the stall speed is 2,000-3,500 RPM, go to step 3.

3. Drive the vehicle at 37 mph (60 km/h), and check the engine speed with respect to vehicle speed and throttle position (see **<u>ROAD TEST</u>**).

Is the engine speed within specification?

**YES** -Replace the lower valve body assembly. **NO** -Replace the transmission.

DTC P1891: Problem in Start Clutch Control System

2001-2004 Models

NOTE: Record all freeze data and review General Troubleshooting Information (see <u>GENERAL TROUBLESHOOTING</u> <u>INFORMATION</u>) before you troubleshoot

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

1. Check whether the scan tool or the HDS indicates another code.

Does the scan tool or the HDS indicate the another code?

**YES** -Do the DTC Troubleshooting for the indicated code(s). Recheck for DTC P1891 after troubleshooting.

**NO** -Go to step 2.

- 2. Warm up the engine to normal operating temperature (the radiator fan comes on), if necessary.
- 3. Turn the ignition switch OFF.
- 4. Disconnect solenoid harness connector (8P).
- 5. Start the engine, and shift to the D position.
- 6. Check whether the vehicle moves.

Does the vehicle move?

**YES** -Go to step 7.

**NO** -Replace the start clutch.

- 7. Turn the ignition switch OFF.
- 8. Connect solenoid harness connector (8P).
- 9. Start the engine, and shift to the D position.
- 10. Check whether the vehicle creeps and check the creeping speed on level ground.

Does the vehicle creep and is the creeping speed about 3 mph (5 km/h)?

**YES** -Go to step 11.

**NO** -Replace the lower valve body assembly.

11. Measure the stall speed RPM in the D position.

Is the stall speed over 3,500 RPM?

YES -Replace the start clutch or transmission.

NO -The system is OK at this time. If necessary, substitute a known-good

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

TCM (see  $\underline{HOW \ TO \ TROUBLESHOOT \ CIRCUIT \ AT \ THE \ TCM}$  ) and recheck.

DTC P1894: Problem in CVT Drive Pulley Pressure Control Valve Circuit

2001-2004 Models

- NOTE:
- Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.
  - This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
- 1. Turn the ignition switch OFF.
- 2. Disconnect the solenoid harness connector (8P).
- Measure the resistance between solenoid harness connector (8P) terminals No. 3 and No. 7.

# **SOLENOID HARNESS CONNECTOR (8P)**



# Terminal side of male terminals

G03681819

### **Fig. 118: Measuring Resistance Between Solenoid Harness Connector (8P)** <u>Terminals 3 And 7</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is the resistance 3.8-6.8 ohm?

**YES** -Go to step 4.

**NO** -Replace the lower valve body assembly.

- 4. Disconnect TCM connector A (26P).
- 5. Check for continuity between TCM connector terminal A3 and body ground, and between A16 and body ground.
2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03681820

### **Fig. 119: Checking Continuity Between TCM Connector Terminal A3,** <u>A16 And Body Ground</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** -Repair a short to ground in the wire between TCM connector terminal A3 or A16 and the solenoid harness connector (8P). **NO** -Go to step 6.

- 6. Connect the solenoid harness connector (8P).
- 7. Measure the resistance between TCM connector terminals A3 and A16.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

### TCM CONNECTOR A (26P)

## DR LS- (GRN/YEL)



DR LS+ (BLU/WHT)

Wire side of female terminals

G03681821

### **Fig. 120:** Measuring Resistance Between TCM Connector A (26P) <u>Terminals A3 And A16</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there 3.8-6.8 ohm?

**YES** -Check for loose terminal fit in the TCM connectors. If necessary, substitute a known-good TCM (see <u>HOW TO TROUBLESHOOT</u> <u>CIRCUIT AT THE TCM</u>) and recheck.

**NO** -Repair an open in the wire between TCM connector terminal A3 or A16 and the solenoid harness connector (8P).

DTC P1895: Problem in CVT Driven Pulley Pressure Control Valve Circuit

2001-2004 Models

### NOTE: • Record all freeze data and review General

Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.

- This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
- 1. Turn the ignition switch OFF.
- 2. Disconnect the solenoid harness connector (8P).
- Measure the resistance between solenoid harness connector (8P) terminals No. 2 and No. 6.

## **SOLENOID HARNESS CONNECTOR (8P)**



## Terminal side of male terminals

G03681822

### **Fig. 121: Measuring Resistance Between Solenoid Harness Connector (8P)** <u>Terminals 2 And 6</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is the resistance 3.8-6.8 ohm?

**YES** -Go to step 4.

**NO** -Replace the lower valve body assembly.

- 4. Disconnect TCM connector A (26P).
- 5. Check for continuity between TCM connector terminal A2 and body ground, and between A15 and body ground.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03681823

### Fig. 122: Checking Continuity Between TCM Connector Terminal A2, A15 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** -Repair a short to ground in the wire between TCM connector terminal A2 or A15 and the solenoid harness connector (8P).

**NO** -Go to step 6.

- 6. Connect the solenoid harness connector (8P).
- 7. Measure the resistance between TCM connector terminals A2 and A15.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

### TCM CONNECTOR A (26P)

### DN LS- (PNK/BLK)



DN LS+ (GRN/WHT)

Wire side of female terminals

G03681824

### **Fig. 123: Measuring Resistance Between TCM Connector A (26P)** <u>Terminals A2 And A15</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there 3.8-6.8 ohm?

**YES** -Check for loose terminal fit in the TCM connectors. If necessary, substitute a known-good TCM (see <u>HOW TO TROUBLESHOOT</u> <u>CIRCUIT AT THE TCM</u>) and recheck.

**NO** -Repair an open in the wire between TCM connector terminal A2 or A15 and the solenoid harness connector (8P).

DTC P0501: Range/Performance Problem in Vehicle Speed Sensor Circuit

2005-2006 Models

### NOTE: • Record all freeze data and review General

Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.

- This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
- 1. Raise the front of the vehicle, make sure it is securely supported, and allow the front wheels to rotate freely.
- 2. Start the engine, and shift into the D position. Push on the accelerator pedal until the rotational speed of the SECONDARY SHAFT SPEED is the same speed as indicated by the freeze data.
- 3. Monitor the SECONDARY SHAFT SPEED and VEHICLE SPEED SENSOR with the HDS in the data list.

Do the SECONDARY SHAFT SPEED and VEHICLE SPEED SENSOR signals fluctuate with the same speed?

**YES** -Intermittent failure, the system is OK at this time. Check for poor connections or loose terminals at the vehicle speed sensor and TCM.

**NO** -Go to step 4.

- 4. Turn the ignition switch OFF.
- 5. Check for continuity between TCM connector terminals A4 and body ground, and between A17 and body ground.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



Wire side of female terminals

G03681825

### **Fig. 124:** Checking Continuity Between TCM Connector A (26P) Terminals A4, A17 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

YES -Go to step 6.

**NO** -Repair an open in the wires between TCM connector terminals A4, A17, and ground (G101), or repair poor ground (G101).

- 6. Disconnect vehicle speed sensor connector.
- 7. Turn the ignition switch ON (II).
- 8. Check for voltage between vehicle speed sensor connector terminal No. 3 and body ground.

## **VEHICLE SPEED SENSOR CONNECTOR**



Wire side of female terminals

G03681826

### **Fig. 125: Checking Voltage Between Vehicle Speed Sensor Connector Terminal 3 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

*Is there about 5 V?* 

YES -Go to step 15.

- **NO** -Go to step 9.
- 9. Turn the ignition switch OFF.
- 10. Disconnect TCM connector B (22P).
- 11. Check for continuity between vehicle speed sensor connector terminal No. 3

and body ground.

## **VEHICLE SPEED SENSOR CONNECTOR**



Wire side of female terminals

G03681827

### **Fig. 126: Checking Continuity Between Vehicle Speed Sensor Connector Terminal 3 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there continuity?

**YES** -Repair a short to ground in the wire between TCM connector terminal B5 and the vehicle speed sensor.

**NO** -Go to step 12.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

- 12. Connect TCM connector B (22P).
- 13. Turn the ignition switch ON (II).
- 14. Measure the voltage between TCM connector terminals B5 and A4.

### **TCM CONNECTORS**



Wire side of female terminals

G03681828

### **Fig. 127: Measuring Voltage Between TCM Connector Terminals B5 And** <u>A4</u> **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there about 5 V?

**YES** -Repair an open in the wire between TCM connector terminal B5 and the vehicle speed sensor.

**NO** -Check for loose or poor connections at TCM connector terminal B5. If the connection is OK, substitute a known-good TCM (see <u>HOW TO</u> <u>**TROUBLESHOOT CIRCUIT AT THE TCM**</u>), then recheck. If the symptom/indication goes away with a known-good TCM, replace the original TCM.

15. Measure the voltage between vehicle speed sensor connector terminal No. 2 and body ground.

## **VEHICLE SPEED SENSOR CONNECTOR**



## Wire side of female terminals

G03681829

### **Fig. 128: Measuring Voltage Between Vehicle Speed Sensor Connector** <u>Terminal 2 And Body Ground</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there battery voltage?* 

**YES** -Go to step 16.

**NO** -A short or an open in the wire between the under-dash fuse/relay box

and vehicle speed sensor.

16. Measure the voltage between vehicle speed sensor connector terminals No. 1 and No. 2.

## **VEHICLE SPEED SENSOR CONNECTOR**



## Wire side of female terminals

G03681830

### **Fig. 129: Measuring Voltage Between Vehicle Speed Sensor Connector Terminals 1 And 2 Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there battery voltage?

YES -Replace the vehicle speed sensor (see SPEED SENSOR

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

### **<u>REPLACEMENT</u>** ), then go to step 17.

**NO** -Repair an open in the wire between the vehicle speed sensor and ground (G101), or repair poor ground (G101).

- 17. Clear the DTC with the HDS.
- 18. Test-drive the vehicle for several minutes under the same conditions as those indicated by the freeze data.
- 19. Check that DTC P0501 recurs.

Is DTC P0501 indicated?

**YES** -Return to step 1 . and recheck. **NO** -Troubleshooting is complete.

DTC P0502: Problem in Vehicle Speed Sensor Circuit (No Signal Input)

2005-2006 Models

- NOTE: Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.
  - This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
  - 1. Raise the front of the vehicle, make sure it is securely supported, and allow the front wheels to rotate freely.
- 2. Start the engine, run the vehicle in the D position with engine speed 2,000 RPM or higher for more than 10 seconds, then slow down and stop the wheels.
- 3. Check the VEHICLE SPEED SENSOR with the HDS in the data list.

Is the VEHICLE SPEED SENSOR 2 km/h or less?

**YES** -Go to step 4.

**NO** -Intermittent failure, the system is OK at this time. Check for poor connections or loose terminals at the vehicle speed sensor and TCM.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

- 4. Turn the ignition switch OFF.
- 5. Check for continuity between TCM connector terminals A4 and body ground, and between A17 and body ground.



Wire side of female terminals

G03681831

### **Fig. 130:** Checking Continuity Between TCM Connector A (26P) Terminals A4, A17 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** -Go to step 6.

**NO** -Repair an open in the wires between TCM connector terminals A4, A17, and ground (G101), or repair poor ground (G10D).

- 6. Disconnect vehicle speed sensor connector.
- 7. Turn the ignition switch ON (II).

8. Check for voltage between vehicle speed sensor connector terminal No. 3 and body ground.

## **VEHICLE SPEED SENSOR CONNECTOR**



Wire side of female terminals

G03681832

**Fig. 131: Checking Voltage Between Vehicle Speed Sensor Connector Terminal 3 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

*Is there about 5 V?* 

**YES** -Go to step 15. **NO** -Go to step 9.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

- 9. Turn the ignition switch OFF.
- 10. Disconnect TCM connector B (22P).
- 11. Check for continuity between vehicle speed sensor connector terminal No. 3 and body ground.

## **VEHICLE SPEED SENSOR CONNECTOR**



## Wire side of female terminals

G03681833

**Fig. 132: Checking Continuity Between Vehicle Speed Sensor Connector Terminal 3 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

Is there continuity?

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

**YES** -Repair a short to ground in the wire between TCM connector terminal B5 and the vehicle speed sensor.

**NO** -Go to step 12.

- 12. Connect TCM connector B (22P).
- 13. Turn the ignition switch ON (II).
- 14. Measure the voltage between TCM connector terminals B5 and A4.

### **TCM CONNECTORS**



Wire side of female terminals

G03681834

#### **Fig. 133: Measuring Voltage Between TCM Connector Terminals B5 And** <u>A4</u> **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

*Is there about 5 V?* 

**YES** -Repair an open in the wire between TCM connector terminal B5 and the vehicle speed sensor.

**NO** -Check for loose or poor connections at TCM connector terminal B5. If the connection is OK, substitute a known-good TCM (see **<u>HOW TO</u>** 

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

**TROUBLESHOOT CIRCUIT AT THE TCM** ), then recheck. If the symptom/indication goes away with a known-good TCM, replace the original TCM.

15. Measure the voltage between vehicle speed sensor connector terminal No. 2 and body ground.

## **VEHICLE SPEED SENSOR CONNECTOR**



## Wire side of female terminals

G03681835

**Fig. 134: Measuring Voltage Between Vehicle Speed Sensor Connector Terminal 2 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

*Is there battery voltage?* 

**YES** -Go to step 16.

**NO** -A short or an open in the wire between the under-dash fuse/relay box and vehicle speed sensor.

16. Measure the voltage between vehicle speed sensor connector terminals No. 1 and No. 2.

## **VEHICLE SPEED SENSOR CONNECTOR**



## Wire side of female terminals

G03681836

**Fig. 135: Measuring Voltage Between Vehicle Speed Sensor Connector Terminals 1 And 2 Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

Is there battery voltage?

**YES** -Replace an the vehicle speed sensor (see **SPEED SENSOR <u>REPLACEMENT</u>**), then go to step 17.

**NO** -Repair an open in the wire between the vehicle speed sensor and ground (G101), or repair poor ground (G101).

- 17. Clear the DTC with the HDS.
- 18. Test-drive the vehicle for several minutes under the same conditions as those indicated by the freeze data.
- 19. Check that DTC P0502 recurs.

Is DTC P0502 indicated?

**YES** -Return to step 1 . and recheck.

**NO** -Troubleshooting is complete.

DTC P0603: Problem in TCM

2005-2006 Models

- NOTE:
- Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.
  - This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
- 1. Turn the ignition switch ON (II).
- 2. Shift to the P or N position.
- 3. Turn the ignition switch OFF.
- 4. Disconnect TCM connector A (26P) for more than 5 seconds, then reconnect the connector.
- 5. Turn the ignition switch ON (II), and wait for more than 5 seconds.
- 6. Check that DTC P0603 recurs.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

Is DTC P0603 indicated?

**YES** -Substitute a known-good TCM (see <u>**HOW TO**</u> <u>**TROUBLESHOOT CIRCUIT AT THE TCM**</u>), then recheck. If the symptom/indication goes away with a known-good TCM, replace the original TCM.

**NO** -Intermittent failure, the system is OK at this time. Check for poor connections or loose terminals at TCM.

DTC P0705: Short in Transmission Range Switch Circuit (Multiple Shift-position Input)

2005-2006 Models

- NOTE: Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.
  - This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
- 1. Clear the DTC with the HDS.
- 2. Move the shift lever, through all positions. Stop for at least 1 second in each position.
- 3. Check that DTC P0705 recurs.

Is DTC P0705 indicated?

**YES** -Go to step 4.

**NO** -Intermittent failure, the system is OK at this time. Check for poor connections or loose terminals at the transmission range switch and TCM.

4. Test the transmission range switch (see <u>TRANSMISSION RANGE</u> <u>SWITCH TEST</u> ).

Is the switch OK?

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

**YES** -Go to step 5.

### **NO** -Replace the transmission range switch (see **TRANSMISSION RANGE SWITCH REPLACEMENT**), then go to step 14.

- 5. Turn the ignition switch ON (II).
- 6. Shift to all positions other than the R position.
- 7. Measure the voltage between TCM connector terminals A11 and A4.

### TCM CONNECTOR A (26P)



Wire side of female terminals

G03681837

### **Fig. 136: Measuring Voltage Between TCM Connector A (26P) Terminals** <u>A11 And A4</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there about 10 V?

YES -Go to step 8.

 ${\bf NO}$  -Check for short in the wire between TCM connector terminal A11 and the transmission range switch or A/T gear position indicator, and

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

check for an open in the wires between TCM connector terminals A4, and ground (G101). If the wires are OK, check for loose terminal fit in the TCM connectors. If necessary, substitute a known-good TCM (see <u>HOW</u> <u>TO TROUBLESHOOT CIRCUIT AT THE TCM</u>), then recheck. If the symptom/ indication goes away with a known-good TCM, replace the original TCM.

- 8. Shift to any position other than the P and N positions.
- 9. Measure the voltage between TCM connector terminals A10 and A4.





Wire side of female terminals

G03681838

#### **Fig. 137: Measuring Voltage Between TCM Connector A (26P) Terminals** <u>A10 And A4</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there about 5 V?

YES -Go to step 10.NO -Check for short in the wire between TCM connector terminal A10

and the A/T gear position indicator, and check for short in the P and N position wires between the gauge assembly and the transmission range switch. If the wires are OK, check for loose terminal fit in the TCM connectors. If necessary, substitute a known-good TCM (see <u>HOW TO</u> <u>TROUBLESHOOT CIRCUIT AT THE TCM</u>), then recheck. If the symptom/ indication goes away with a known-good TCM, replace the original TCM.

- 10. Shift to any position other than the D position.
- 11. Measure the voltage between TCM connector terminals A9 and A4.

## TCM CONNECTOR A (26P)



Wire side of female terminals

G03681839

### **Fig. 138: Measuring Voltage Between TCM Connector A (26P) Terminals** <u>A9 And A4</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there about 5 V?* 

YES -Go to step 12.

**NO** -Check for short in the wire between TCM connector terminal A9 and the transmission range switch. If the wire is OK, check for loose terminal fit in the TCM connectors. If necessary, substitute a known-good TCM (see **HOW TO TROUBLESHOOT CIRCUIT AT THE TCM**), then recheck. If the symptom/indication goes away with a known-good TCM, replace the original TCM.

- 12. Shift to any position other than the L position.
- 13. Measure the voltage between TCM connector terminals A7 and A4 or A17.

## TCM CONNECTOR A (26P)



Wire side of female terminals

G03681840

### Fig. 139: Measuring Voltage Between TCM Connector A (26P) Terminals A7 And A4 Or A17 Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there about 10 V?

**YES** -Check for loose terminal fit in the TCM connectors. If necessary,

substitute a known-good TCM and recheck.

**NO** -Check for short in the wire between TCM connector terminal A7 and the transmission range switch or A/T gear position indicator. If the wire is OK, check for loose terminal fit in the TCM connectors. If necessary, substitute a known-good TCM (see <u>HOW TO TROUBLESHOOT</u> <u>CIRCUIT AT THE TCM</u>), then recheck. If the symptom/ indication goes away with a known-good TCM, replace the original TCM.

- 14. Clear the DTC with the HDS.
- 15. Shift the shift lever out of the P position, then move to each position slowly.
- 16. Check that DTC P0705 recurs.

Is DTC P0705 indicated?

**YES** -Return to step 4 . and recheck. **NO** -Troubleshooting is complete.

DTC P0706: Open in Transmission Range Switch Circuit

2005-2006 Models

- NOTE:
- Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.
  - This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
- 1. Test the transmission range switch (see <u>TRANSMISSION RANGE</u> <u>SWITCH TEST</u> ).

Is the switch OK?

**YES** -Go to step 2.

**NO** -Replace the transmission range switch (see **TRANSMISSION RANGE SWITCH REPLACEMENT**), then go to step 13.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

- 2. Connect the transmission range switch connector.
- 3. Check for continuity between TCM connector terminal A4 and body ground, and between A17 and body ground.



Wire side of female terminals

G03681841

### Fig. 140: Checking Continuity Between TCM Connector Terminal A4, A17 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** -Go to step 4.

**NO** -Repair an open in the wires between TCM connector terminals A4, A17, and ground (G101), or repair poor ground (G101).

- 4. Turn the ignition switch ON (II).
- 5. Shift to the R position.

6. Measure the voltage between TCM connector terminals A11 and A4.

### TCM CONNECTOR A (26P)



Wire side of female terminals

G03681842

### **Fig. 141: Measuring Voltage Between TCM Connector A (26P) Terminals** <u>A11 And A4</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there voltage?

**YES** -Repair an open in the wire between TCM connector terminal A11 and the transmission range switch.

NO -Go to step 7.

- 7. Shift to the P or N position.
- 8. Measure the voltage between TCM connector terminals A10 and A4.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

### **TCM CONNECTOR A (26P)**



Wire side of female terminals

G03681843

#### Fig. 142: Measuring Voltage Between TCM Connector A (26P) Terminals A10 And A4 Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there voltage?

**YES** -Repair an open in the wire between TCM connector terminal A10 and the A/T gear position indicator.

**NO** -Go to step 9.

- 9. Shift to the D position.
- 10. Measure the voltage between TCM connector terminals A9 and A4.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

## TCM CONNECTOR A (26P)



### Wire side of female terminals

G03681844

### **Fig. 143: Measuring Voltage Between TCM Connector A (26P) Terminals** <u>A9 And A4</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there voltage?

**YES** -Repair an open in the wire between TCM connector terminal A9 and the transmission range switch.

**NO** -Go to step 11.

- 11. Shift to the L position.
- 12. Measure the voltage between TCM connector terminals A7 and A4.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

## TCM CONNECTOR A (26P)



### Wire side of female terminals

G03681845

#### **Fig. 144: Measuring Voltage Between TCM Connector A (26P) Terminals** <u>A7 And A4</u> **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there voltage?

**YES** -Repair an open in the wire between TCM connector terminal A7 and the transmission range switch.

**NO** -Check for loose terminal fit in the TCM connectors. If necessary, substitute a known-good TCM (see <u>HOW TO TROUBLESHOOT</u> <u>CIRCUIT AT THE TCM</u>), then recheck. If the symptom/ indication goes away with a known-good TCM, replace the original TCM.

- 13. Clear the DTC with the HDS.
- 14. Test-drive the vehicle in the D position until the vehicle speed reaches 31 mph (50 km/h), and stop the wheels.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

15. Check that DTC P0706 recurs.

Is DTC P0706 indicated?

**YES** -Return to step 1 . and recheck.

**NO** -Troubleshooting is complete.

DTC P0716: Range/Performance Problem in CVT Input Shaft (Drive Pulley) Speed Sensor Circuit

2005-2006 Models

- NOTE: Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.
  - This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
  - 1. Raise the front of the vehicle, make sure it is securely supported, and allow the front wheels to rotate freely.
  - 2. Start the engine, and shift into the D position. Push on the accelerator pedal until the engine speed is the same speed as indicated by the freeze data.
- 3. Monitor the ENGINE SPEED and DRIVE PULLEY with the HDS in the data list.

Do the ENGINE SPEED and DRIVE PULLEY signals fluctuate?

**YES** -Intermittent failure, the system is OK at this time. Check for poor connections or loose terminals at the CVT input shaft (drive pulley) speed sensor and TCM.

NO -Go to step 4.

- 4. Turn the ignition switch OFF.
- 5. Check for continuity between TCM connector terminals A4 and body ground, and between A17 and body ground.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



Wire side of female terminals

G03681846

### Fig. 145: Checking Continuity Between TCM Connector Terminals A4, A17 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

YES -Go to step 6.

**NO** -Repair an open in the wires between TCM connector terminals A4, A17, and ground (G101), or repair poor ground (G101).

- 6. Disconnect CVT input shaft (drive pulley) speed sensor connector.
- 7. Turn the ignition switch ON (II).
- 8. Check for voltage between CVT input shaft (drive pulley) speed sensor connector terminal No. 2 and body ground.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

## CVT INPUT SHAFT (DRIVE PULLEY) SPEED SENSOR CONNECTOR



## Wire side of female terminals

G03681847

**Fig. 146: Checking Voltage Between CVT Input Shaft (Drive Pulley) Speed Sensor Connector Terminal 2 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

*Is there about 5 V?* 

**YES** -Go to step 15. **NO** -Go to step 9.

- 9. Turn the ignition switch OFF.
- 10. Disconnect TCM connector B (22P).
- 11. Check for continuity between CVT input shaft (drive pulley) speed sensor connector terminal No. 2 and body ground.

## CVT INPUT SHAFT (DRIVE PULLEY) SPEED SENSOR CONNECTOR



# Wire side of female terminals

G03681848

Fig. 147: Checking Continuity Between CVT Input Shaft (Drive Pulley) Speed Sensor Connector Terminal 2 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.
2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

Is there continuity?

**YES** -Repair a short to ground in the wire between TCM connector terminal B10 and the CVT input shaft (drive pulley) speed sensor. **NO** -Go to step 12.

- 12. Connect TCM connector B (22P).
- 13. Turn the ignition switch ON (II).
- 14. Measure the voltage between TCM connector terminals B10and A4.

### **TCM CONNECTORS**



Wire side of female terminals

G03681849

### Fig. 148: Measuring Voltage Between TCM Connector Terminals B10 And A4 Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there about 5 V?

YES -Repair an open in the wire between TCM connector terminal B10

and the CVT input shaft (drive pulley) speed sensor.

**NO** -Check for loose or poor connections at TCM connector terminal B10. If the connection is OK, substitute a known-good TCM (see <u>HOW TO</u> <u>**TROUBLESHOOT CIRCUIT AT THE TCM**</u>), then recheck. If the symptom/indication goes away with a known-good TCM, replace the original TCM.

15. Measure the voltage between CVT input shaft (drive pulley) speed sensor connector terminal No. 1 and body ground.

# CVT INPUT SHAFT (DRIVE PULLEY) SPEED SENSOR CONNECTOR



# Wire side of female terminals

G03681850

### Fig. 149: Measuring Voltage Between CVT Input Shaft (Drive Pulley)

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

### **Speed Sensor Connector Terminal 1 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there about 5 V?

YES -Go to step 22.

NO -Go to step 16.

- 16. Turn the ignition switch OFF.
- 17. Disconnect TCM connector B (22P).
- 18. Check for continuity between CVT input shaft (drive pulley) speed sensor connector terminal No. 1 and body ground.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# CVT INPUT SHAFT (DRIVE PULLEY) SPEED SENSOR CONNECTOR



Wire side of female terminals

G03681851

### **Fig. 150: Checking Continuity Between CVT Input Shaft (Drive Pulley) Speed Sensor Connector Terminal 1 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there continuity?

**YES** -Repair a short to ground in the wire between TCM connector terminal B22 and the CVT input shaft (drive pulley) speed sensor. **NO** -Go to step 19.

19. Connect TCM connector B (22P).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

- 20. Turn the ignition switch ON (II).
- 21. Measure the voltage between TCM connector terminals B22 and A4.

### **TCM CONNECTORS**



Wire side of female terminals

G03681852

### **Fig. 151: Measuring Voltage Between TCM Connector Terminals B22** <u>And A4</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there about 5 V?* 

**YES** -Repair an open in the wire between TCM connector terminal B22 and the CVT input shaft (drive pulley) speed sensor.

**NO** -Check for loose or poor connections at TCM connector terminal B22. If the connection is OK, substitute a known-good TCM (see <u>HOW TO</u> <u>**TROUBLESHOOT CIRCUIT AT THE TCM**</u>), then recheck. If the symptom/indication goes away with a known-good TCM, replace the original TCM.

22. Measure the voltage between CVT input shaft (drive pulley) speed sensor connector terminals No. 1 and No. 3.

# CVT INPUT SHAFT (DRIVE PULLEY) SPEED SENSOR CONNECTOR



# Wire side of female terminals

G03681853

**Fig. 152:** Measuring Voltage Between CVT Input Shaft (Drive Pulley) Speed Sensor Connector Terminals 1 And 3 Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there about 5 V?

**YES** -Replace the CVT input shaft (drive pulley) speed sensor (see **SPEED SENSOR REPLACEMENT** ), then go to step 23.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

**NO** -Repair an open in the wire between TCM connector terminal B17 and the CVT input shaft (drive pulley) speed sensor.

- 23. Clear the DTC with the HDS.
- 24. Test-drive the vehicle for several minutes under the same conditions as those indicated by the freeze data.
- 25. Check that DTC P0716 recurs.

Is DTC P0716 indicated?

**YES** -Return to step 1 . and recheck. **NO** -Troubleshooting is complete.

DTC P0717: Problem in CVT Input Shaft (Drive Pulley) Speed Sensor Circuit (No Signal Input)

2005-2006 Models

- NOTE: Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.
  - This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
- 1. Start the engine, and press the brake pedal securely.
- 2. Shift to the D position, and let the engine idle.
- 3. Check the DRIVE PULLEY with the HDS in the data list.

Is the DRIVE PULLEY 128 RPM or less?

**YES** -Go to step 4.

**NO** -Intermittent failure, the system is OK at this time. Check for poor connections or loose terminals at the CVT input shaft (drive pulley) speed sensor and TCM.

4. Turn the ignition switch OFF.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

5. Check for continuity between TCM connector terminals A4 and body ground, and between A17 and body ground.



Wire side of female terminals

G03681854

### Fig. 153: Checking Continuity Between TCM Connector Terminals A4, A17 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

YES -Go to step 6.

**NO** -Repair an open in the wires between TCM connector terminals A4, A17, and ground (G101), or repair poor ground (G101).

- 6. Disconnect CVT input shaft (drive pulley) speed sensor connector.
- 7. Turn the ignition switch ON (II).
- 8. Measure the voltage between CVT input shaft (drive pulley) speed sensor

connector terminal No. 1 and body ground.

# CVT INPUT SHAFT (DRIVE PULLEY) SPEED SENSOR CONNECTOR



# Wire side of female terminals

G03681855

**Fig. 154:** Measuring Voltage Between CVT Input Shaft (Drive Pulley) Speed Sensor Connector Terminal 1 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there about 5 V?* 

YES -Go to step 9. NO -Go to step 19.

9. Turn the ignition switch OFF.

10. Check for continuity between CVT input shaft (drive pulley) speed sensor connector terminal No. 2 and body ground.

# CVT INPUT SHAFT (DRIVE PULLEY) SPEED SENSOR CONNECTOR



# Wire side of female terminals

G03681856

Fig. 155: Checking Continuity Between CVT Input Shaft (Drive Pulley) Speed Sensor Connector Terminal 2 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** -Repair a short to ground in the wire between TCM connector terminal B10andthe CVT input shaft (drive pulley) speed sensor. **NO** -Go to step 11.

11. Check for continuity between CVT input shaft (drive pulley) speed sensor connector terminal No. 3 and body ground.

# CVT INPUT SHAFT (DRIVE PULLEY) SPEED SENSOR CONNECTOR



# Wire side of female terminals

G03681857

Fig. 156: Checking Continuity Between CVT Input Shaft (Drive Pulley) Speed Sensor Connector Terminal 3 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

Is there continuity?

**YES** -Go to step 12.

**NO** -Repair loose terminal or open in the wire between TCM connector terminal B17 and the CVT input shaft (drive pulley) speed sensor.

- 12. Turn the ignition switch ON (II).
- 13. Measure the voltage between CVT input shaft (drive pulley) speed sensor connector terminals No. 2 and No. 3.

# CVT INPUT SHAFT (DRIVE PULLEY) SPEED SENSOR CONNECTOR



Wire side of female terminals

G03681858

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

### **Fig. 157: Measuring Voltage Between CVT Input Shaft (Drive Pulley) Speed Sensor Connector Terminals 2 And 3 Courtesy of AMERICAN HONDA MOTOR CO., INC.**

*Is there about 5 V?* 

**YES** -Go to step 14. **NO** -Go to step 25.

- 14. Connect CVT input shaft (drive pulley) speed sensor connector.
- 15. Measure the voltage between TCM connector terminals B10and B17.

# TCM CONNECTOR B (22P)



## Wire side of female terminals

G03681859

**Fig. 158: Measuring Voltage Between TCM Connector B (22P) Terminals B10 And B17** 

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

### Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there about 0 V or about 5 V?* 

YES -Go to step 16.

**NO** -Replace the CVT input shaft (drive pulley) speed sensor (see <u>SPEED</u> <u>SENSOR REPLACEMENT</u> ), then go to step 26 .

- 16. Raise the front of the vehicle, make sure it is securely supported, and allow the front wheels to rotate freely.
- 17. Start the engine, shift to the D position, and let the engine idle.
- 18. Measure the voltage between TCM connector terminals B10 and B17.

# TCM CONNECTOR B (22P)



Wire side of female terminals

G03681860

Fig. 159: Measuring Voltage Between TCM Connector B (22P) Terminals

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

### **B10 And B17** Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there 1.5-3.5 V?

**YES** -Check for loose or poor connections at TCM connector terminals B10and B17. If the connections are OK, substitute a known-good TCM (see **<u>HOW TO TROUBLESHOOT CIRCUIT AT THE TCM</u>**), then recheck. If the symptom/ indication goes away with a known-good TCM, replace the original TCM.

**NO** -Replace the CVT input shaft (drive pulley) speed sensor (see **SPEED SENSOR REPLACEMENT** ), then go to step 26 .

- 19. Turn the ignition switch OFF.
- 20. Disconnect TCM connector B (22P).
- 21. Check for continuity between CVT input shaft (drive pulley) speed sensor connector terminal No. 1 and body ground.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# CVT INPUT SHAFT (DRIVE PULLEY) SPEED SENSOR CONNECTOR



Wire side of female terminals

G03681861

### **Fig. 160: Checking Continuity Between CVT Input Shaft (Drive Pulley) Speed Sensor Connector Terminal 1 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there continuity?

**YES** -Repair a short to ground in the wire between TCM connector terminal B22 and the CVT input shaft (drive pulley) speed sensor. **NO** -Go to step 22.

22. Connect TCM connector B (22P).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

- 23. Turn the ignition switch ON (II).
- 24. Measure the voltage between TCM connector terminals B22 and A4.

### **TCM CONNECTORS**



Wire side of female terminals

G03681862

### **Fig. 161: Measuring Voltage Between TCM Connector Terminals B22** <u>And A4</u> **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

*Is there about 5 V?* 

**YES** -Repair an open in the wire between TCM connector terminal B22 and the CVT input shaft (drive pulley) speed sensor.

**NO** -Check for loose or poor connections at TCM connector terminal B22. If the connection is OK, substitute a known-good TCM (see <u>HOW TO</u> <u>**TROUBLESHOOT CIRCUIT AT THE TCM**</u>), then recheck. If the symptom/indication goes away with a known-good TCM, replace the original TCM.

25. Measure the voltage between TCM connector terminals B10 and B17.

# TCM CONNECTOR B (22P) NDR (RED/BLU)



Wire side of female terminals

G03681863

### **Fig. 162: Measuring Voltage Between TCM Connector B (22P) Terminals** <u>B10 And B17</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there about 5 V?* 

**YES** -Repair an open in the wire between TCM connector terminal B10 and the CVT input shaft (drive pulley) speed sensor.

**NO** -Check for loose or poor connections at TCM connector terminal B10. If the connection is OK, substitute a known-good TCM (see <u>HOW TO</u> <u>TROUBLESHOOT CIRCUIT AT THE TCM</u>), then recheck. If the

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

symptom/indication goes away with a known-good TCM, replace the original TCM.

- 26. Clear the DTC with the HDS.
- 27. Test-drive the vehicle for several minutes under the same conditions as those indicated by the freeze data.
- 28. Check that DTC P0717 recurs.

Is DTC P0717 indicated?

**YES** -Return to step 1 . and recheck. **NO** -Troubleshooting is complete.

DTC P0721: Range/Performance Problem in CVT Output Shaft (Driven Pulley) Speed Sensor Circuit

2005-2006 Models

- NOTE: Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.
  - This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
  - 1. Raise the front of the vehicle, make sure it is securely supported, and allow the front wheels to rotate freely.
  - 2. Start the engine, and shift into the D position. Push on the accelerator pedal until the rotational speed of the SECONDARY SHAFT SPEED is the same speed as indicated by the freeze data.
- 3. Monitor the SECONDARY SHAFT SPEED and DRIVEN PULLEY with the HDS in the data list.

Do the SECONDARY SHAFT SPEED and DRIVEN PULLEY signals fluctuate with the same speed?

YES -Intermittent failure, the system is OK at this time. Check for poor

connections or loose terminals at the CVT output shaft (driven pulley) speed sensor and TCM.

NO -Go to step 4.

- 4. Turn the ignition switch OFF.
- 5. Check for continuity between TCM connector terminals A4 and body ground, and between A17 and body ground.



Wire side of female terminals

G03681864

### **Fig. 163: Checking Continuity Between TCM Connector Terminals A4,** <u>A17 And Body Ground</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** -Go to step 6.

**NO** -Repair an open in the wires between TCM connector terminals A4, A17, and ground (G101), or repair poor ground (G101).

- 6. Disconnect CVT output shaft (driven pulley) speed sensor connector.
- 7. Turn the ignition switch ON (II).
- 8. Check for voltage between CVT output shaft (driven pulley) speed sensor connector terminal No. 2 and body ground.

# CVT OUTPUT SHAFT (DRIVEN PULLEY) SPEED SENSOR CONNECTOR



Wire side of female terminals

G03681865

**Fig. 164: Checking Voltage Between CVT Output Shaft (Driven Pulley) Speed Sensor Connector Terminal 2 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

*Is there about 5 V?* 

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

YES -Go to step 15.

**NO** -Go to step 9.

- 9. Turn the ignition switch OFF.
- 10. Disconnect TCM connector B (22P).
- 11. Check for continuity between CVT output shaft (driven pulley) speed sensor connector terminal No. 2 and body ground.

# CVT OUTPUT SHAFT (DRIVEN PULLEY) SPEED SENSOR CONNECTOR



# Wire side of female terminals

G03681866

**Fig. 165: Checking Continuity Between CVT Output Shaft (Driven Pulley) Speed Sensor Connector Terminal 2 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

Is there continuity?

**YES** -Repair a short to ground in the wire between TCM connector terminal B9 and the CVT output shaft (driven pulley) speed sensor. **NO** -Go to step 12.

- 12. Connect TCM connector B (22P).
- 13. Turn the ignition switch ON (II).
- 14. Measure the voltage between TCM connector terminals B9 and A4.

### **TCM CONNECTORS**



Wire side of female terminals

G03681867

### **Fig. 166: Measuring Voltage Between TCM Connector Terminals B9 And** <u>A4</u> **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

*Is there about 5 V?* 

**YES** -Repair an open in the wire between TCM connector terminal B9 and the CVT output shaft (driven pulley) speed sensor.

**NO** -Check for loose or poor connections at TCM connector terminal B9. If the connection is OK, substitute a known-good TCM (see <u>HOW TO</u> <u>**TROUBLESHOOT CIRCUIT AT THE TCM**</u>), then recheck. If the symptom/indication goes away with a known-good TCM, replace the original TCM.

15. Measure the voltage between CVT output shaft (driven pulley) speed sensor connector terminal No. 1 and body ground.

## CVT OUTPUT SHAFT (DRIVEN PULLEY) SPEED SENSOR CONNECTOR



Wire side of female terminals

G03681868

**Fig. 167: Measuring Voltage Between CVT Output Shaft (Driven Pulley) Speed Sensor Connector Terminal 1 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

*Is there about 5 V?* 

YES -Go to step 22.

**NO** -Go to step 16.

- 16. Turn the ignition switch OFF.
- 17. Disconnect TCM connector B (22P).
- 18. Check for continuity between CVT output shaft (driven pulley) speed sensor connector terminal No. 1 and body ground.

# CVT OUTPUT SHAFT (DRIVEN PULLEY) SPEED SENSOR CONNECTOR



# Wire side of female terminals

G03681869

**Fig. 168: Checking Continuity Between CVT Output Shaft (Driven Pulley) Speed Sensor Connector Terminal 1 And Body Ground** 

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

### **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there continuity?

**YES** -Repair a short to ground in the wire between TCM connector terminal B21 and the CVT output shaft (driven pulley) speed sensor. **NO** -Go to step 19.

- 19. Connect TCM connector B (22P).
- 20. Turn the ignition switch ON (II)
- 21. Measure the voltage between TCM connector terminals B21 and A4.

### **TCM CONNECTORS**



Wire side of female terminals

G03681870

**Fig. 169: Measuring Voltage Between TCM Connector Terminals B21** <u>And A4</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there about 5 V?* 

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

**YES** -Repair an open in the wire between TCM connector terminal B21 and the CVT output shaft (driven pulley) speed sensor.

**NO** -Check for loose or poor connections at TCM connector terminal B21. If the connection is OK, substitute a known-good TCM (see <u>HOW TO</u> <u>**TROUBLESHOOT CIRCUIT AT THE TCM**</u>), then recheck. If the symptom/indication goes away with a known-good TCM, replace the original TCM.

22. Measure the voltage between CVT output shaft (driven pulley) speed sensor connector terminals No. 1 and No. 3.

### CVT OUTPUT SHAFT (DRIVEN PULLEY) SPEED SENSOR CONNECTOR



Wire side of female terminals

G03681871

**Fig. 170: Measuring Voltage Between CVT Output Shaft (Driven Pulley) Speed Sensor Connector Terminals 1 And 3 Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

*Is there about 5 V?* 

**YES** -Replace the CVT output shaft (driven pulley) speed sensor (see **SPEED SENSOR REPLACEMENT** ), then go to step 23.

**NO** -Repair an open in the wire between TCM connector terminal B8 and the CVT output shaft (driven pulley) speed sensor.

- 23. Clear the DTC with the HDS.
- 24. Test-drive the vehicle for several minutes under the same conditions as those indicated by the freeze data.
- 25. Check that DTC P0721 recurs.

Is DTC P0721 indicated?

**YES** -Return to step 1 . and recheck.

**NO** -Troubleshooting is complete.

DTC P0722: Problem in CVT Output Shaft (Driven Pulley) Speed Sensor Circuit (No Signal Input)

2005-2006 Models

- NOTE: Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.
  - This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
  - 1. Start the engine, and press the brake pedal securely.
  - 2. Shift to the D position, and drive the vehicle at engine idle.
  - 3. Check the DRIVEN PULLEY with the HDS in the data list.

Is the DRIVEN PULLEY 0 RPM?

YES -Go to step 4.

NO -Intermittent failure, the system is OK at this time. Check for poor

connections or loose terminals at the CVT output shaft (driven pulley) speed sensor and TCM.

- 4. Turn the ignition switch OFF.
- 5. Check for continuity between TCM connector terminals A4 and body ground, and between A17 and body ground.



Wire side of female terminals

G03681872

### **Fig. 171: Checking Continuity Between TCM Connector A (26P) Terminals A4, A17 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there continuity?

**YES** -Go to step 6.

**NO** -Repair an open in the wires between TCM connector terminals A4, A17, and ground (G101), or repair poor ground (G101).

6. Disconnect CVT output shaft (driven pulley) speed sensor connector.

- 7. Turn the ignition switch ON (II).
- 8. Measure the voltage between CVT output shaft (driven pulley) speed sensor connector terminal No. 1 and body ground.

## CVT OUTPUT SHAFT (DRIVEN PULLEY) SPEED SENSOR CONNECTOR



Wire side of female terminals

G03681873

**Fig. 172:** Measuring Voltage Between CVT Output Shaft (Driven Pulley) Speed Sensor Connector Terminal 1 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there about 5 V?* 

**YES** -Go to step 9. **NO** -Go to step 19.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

- 9. Turn the ignition switch OFF.
- 10. Check for continuity between CVT output shaft (driven pulley) speed sensor connector terminal No. 2 and body ground.

# CVT OUTPUT SHAFT (DRIVEN PULLEY) SPEED SENSOR CONNECTOR



# Wire side of female terminals

G03681874

### **Fig. 173: Checking Continuity Between CVT Output Shaft (Driven Pulley) Speed Sensor Connector Terminal 2 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there continuity?

YES -Repair a short to ground in the wire between TCM connector

terminal B9 and the CVT output shaft (driven pulley) speed sensor.

**NO** -Go to step 11.

11. Check for continuity between CVT output shaft (driven pulley) speed sensor connector terminal No. 3 and body ground.

### CVT OUTPUT SHAFT (DRIVEN PULLEY) SPEED SENSOR CONNECTOR



Wire side of female terminals

G03681875

### Fig. 174: Checking Continuity Between CVT Output Shaft (Driven Pulley) Speed Sensor Connector Terminal 3 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

YES -Go to step 12.

NO -Repair loose terminal or open in the wire between TCM connector

terminal B8 and the CVT output shaft (driven pulley) speed sensor.

- 12. Turn the ignition switch ON (II).
- 13. Measure the voltage between CVT output shaft (driven pulley) speed sensor connector terminals No. 2 and No. 3.

### CVT OUTPUT SHAFT (DRIVEN PULLEY) SPEED SENSOR CONNECTOR



Wire side of female terminals

G03681876

**Fig. 175: Measuring Voltage Between CVT Output Shaft (Driven Pulley) Speed Sensor Connector Terminals 2 And 3 Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

*Is there about 5 V?* 

**YES** -Go to step 14. **NO** -Go to step 25.

- 14. Connect CVT output shaft (driven pulley) speed sensor connector.
- 15. Measure the voltage between TCM connector terminals B9and B8.

# TCM CONNECTOR B (22P)



Wire side of female terminals

G03681877

### **Fig. 176: Measuring Voltage Between TCM Connector B (22P) Terminals B9 And B8 Courtesy of AMERICAN HONDA MOTOR CO., INC.**

*Is there about OV or about 5 V?* 

YES -Go to step 16.NO -Replace the CVT output shaft (driven pulley) speed sensor (see <a href="mailto:SPEED SENSOR REPLACEMENT">SPEED SENSOR REPLACEMENT</a> ), then go to step 26 .

16. Raise the front of the vehicle, make sure it is securely supported, and allow the

front wheels to rotate freely.

- 17. Start the engine, shift to the D position, and drive the vehicle at engine idle.
- 18. Measure the voltage between TCM connector terminals B9 and B8.

# TCM CONNECTOR B (22P)



# Wire side of female terminals

G03681878

### **Fig. 177: Measuring Voltage Between TCM Connector B (22P) Terminals B9 And B8** Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there 1.5-3.5 V?* 

**YES** -Check for loose or poor connections at TCM connector terminals B9 and B8. If the connections are OK, substitute a known-good TCM (see **HOW TO TROUBLESHOOT CIRCUIT AT THE TCM**), then

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

recheck. If the symptom/indication goes away with a known-good TCM, replace the original TCM.

**NO** -Replace the CVT output shaft (driven pulley) speed sensor (see **SPEED SENSOR REPLACEMENT** ), then go to step 26.

- 19. Turn the ignition switch OFF.
- 20. Disconnect TCM connector B (22P).
- 21. Check for continuity between CVT output shaft (driven pulley) speed sensor connector terminal No. 1 and body ground.

# CVT OUTPUT SHAFT (DRIVEN PULLEY) SPEED SENSOR CONNECTOR



Wire side of female terminals

G03681879

**Fig. 178: Checking Continuity Between CVT Output Shaft (Driven Pulley) Speed Sensor Connector Terminal 1 And Body Ground**
2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

## **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there continuity?

**YES** -Repair a short to ground in the wire between TCM connector terminal B21 and the CVT output shaft (driven pulley) speed sensor. **NO** -Go to step 22.

- 22. Connect TCM connector B (22P).
- 23. Turn the ignition switch ON (II).
- 24. Measure the voltage between TCM connector terminals B21 and A4.

## **TCM CONNECTORS**



Wire side of female terminals

G03681880

**Fig. 179: Measuring Voltage Between TCM Connector Terminals B21** <u>And A4</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there about 5 V?* 

**YES** -Repair an open in the wire between TCM connector terminal B21 and the CVT output shaft (driven pulley) speed sensor.

**NO** -Check for loose or poor connections at TCM connector terminal B21. If the connection is OK, substitute a known-good TCM (see <u>HOW TO</u> <u>**TROUBLESHOOT CIRCUIT AT THE TCM**</u>), then recheck. If the symptom/indication goes away with a known-good TCM, replace the original TCM.

25. Measure the voltage between TCM connector terminals B9 and B8.

TCM CONNECTOR B (22P)



Wire side of female terminals

G03681881

**Fig. 180: Measuring Voltage Between TCM Connector B (22P) Terminals B9 And B8 Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

*Is there about 5 V?* 

**YES** -Repair an open in the wire between TCM connector terminal B9 and the CVT output shaft (driven pulley) speed sensor.

**NO** -Check for loose or poor connections at TCM connector terminal B9. If the connection is OK, substitute a known-good TCM (see <u>HOW TO</u> <u>**TROUBLESHOOT CIRCUIT AT THE TCM**</u>), then recheck. If the symptom/indication goes away with a known-good TCM, replace the original TCM.

- 26. Clear the DTC with the HDS.
- 27. Test-drive the vehicle for several minutes under the same conditions as those indicated by the freeze data.
- 28. Check that DTC P0722 recurs. Is DTC P0722 indicated?

YES -Return to step 1 . and recheck.

**NO** -Troubleshooting is complete.

DTC P0726: Range/Performance Problem in Engine RPM Signal Input Circuit

2005-2006 Models

- NOTE:
- Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.
  - This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
- 1. Raise the front of the vehicle, make sure it is securely supported, and allow the front wheels to rotate freely.
- 2. Start the engine, and shift into the D position. Push on the accelerator pedal until the rotational speed of the DRIVE PULLEY is the same speed as indicated by the freeze data.
- 3. Monitor the ENGINE SPEED and DRIVE PULLEY with the HDS in the data list.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

*Do the ENGINE SPEED and DRIVE PULLEY signals fluctuate with the same speed?* 

**YES** -Intermittent failure, the system is OK at this time. Check for poor connections or loose terminals at the gauge assembly and TCM.

NO -Go to step 4.

4. Check the tachometer in the gauge assembly operation.

Does the tachometer operate properly?

**YES** -Go to step 5.

**NO** -Replace the gauge assembly (see <u>GAUGE ASSEMBLY</u> <u>REPLACEMENT</u> ).

- 5. Turn the ignition switch OFF.
- 6. Disconnect TCM connector A (26P).
- 7. Disconnect ECM connector A (32P).
- 8. Check for continuity between TCM connector terminal A5 and ECM connector A19.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



Wire side of female terminals

G03681882

#### **Fig. 181: Checking Continuity Between TCM Connector Terminal A5** And ECM Connector A19 Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** -Check for loose or poor connections at TCM connector terminal A5 and ECM connector terminal A19. If the connections are OK, substitute a known-good TCM (see <u>HOW TO TROUBLESHOOT CIRCUIT AT</u> <u>THE TCM</u>), then recheck. If the symptom/indication goes away with a known-good TCM, replace the original TCM.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

**NO** -Repair an open in the wire between TCM connector terminal A5 and ECM connector terminal A19.

DTC P0727: Problem in Engine RPM Signal Input Circuit (No Signal Input)

2005-2006 Models

- NOTE:
- Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.
  - This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
- 1. Start the engine.
- 2. Check the ENGINE SPEED with the HDS in the data list.

Is the ENGINE SPEED 128 RPM or less?

YES -Go to step 3.

**NO** -Intermittent failure, the system is OK at this time. Check for poor connections or loose terminals at the gauge assembly and TCM.

3. Check the tachometer in the gauge assembly operation.

Does the tachometer operate properly?

YES -Go to step 4. NO -Replace the gauge assembly (see <u>GAUGE ASSEMBLY</u> <u>REPLACEMENT</u>).

- 4. Turn the ignition switch OFF.
- 5. Disconnect TCM connector A (26P).
- 6. Disconnect ECM connector A (32P).
- 7. Check for continuity between TCM connector terminal A5 and ECM connector A19.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



Wire side of female terminals

G03681883

## Fig. 182: Checking Continuity Between TCM Connector Terminal A5 And ECM Connector A19 Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** -Check for loose or poor connections at TCM connector terminal A5 and ECM connector terminal A19. If the connections are OK, substitute a known-good TCM (see <u>HOW TO TROUBLESHOOT CIRCUIT AT</u> <u>THE TCM</u>), then recheck. If the symptom/indication goes away with a known-good TCM, replace the original TCM.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

**NO** -Repair an open in the wire between TCM connector terminal A5 and ECM connector terminal A19.

DTC P0780: Problem in Shift Control System

2005-2006 Models

## NOTE: Record all freeze data and review General Troubleshooting Information (see <u>GENERAL TROUBLESHOOTING</u> <u>INFORMATION</u>) before you troubleshoot.

1. Check whether the HDS indicates another code.

Does the HDS indicate another code?

**YES** -Do the DTC Troubleshooting for the indicated code(s). Recheck for DTC P0780 after troubleshooting.

NO -Go to step 2.

2. Measure the stall speed RPM in the D position (see STALL SPEED TEST ).

Is the stall speed over 3,500 RPM?

**YES** -Replace the transmission.

**NO** -If the stall speed is below 2,000 RPM, replace the lower valve body assembly. If the stall speed is 2,000-3,500 RPM, go to step 3.

3. Drive the vehicle at 37 mph (60 km/h) constantly for several minutes, and check the engine speed with respect to vehicle speed (see **<u>ROAD TEST</u>**).

Is the engine speed within specification?

**YES** -Replace the lower valve body assembly.

**NO** -Replace the transmission.

DTC P0801: Problem in Inhibitor Solenoid Circuit

2005-2006 Models

## NOTE: • Record all freeze data and review General

Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.

- This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
- 1. Turn the ignition switch OFF.
- 2. Disconnect the solenoid harness connector (8P).
- Measure the resistance between solenoid harness connector (8P) terminals No.
  5 and body ground.

# **SOLENOID HARNESS CONNECTOR (8P)**



Terminal side of male terminals

G03681884

**Fig. 183: Measuring Resistance Between Solenoid Harness Connector (8P) Terminals 5 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

Is the resistance 11.7-21.0 ohm?

**YES** -Go to step 4.

**NO** -Remove the lower valve body (see **LOWER VALVE BODY** <u>ASSEMBLY REPLACEMENT</u>), and check for an open or a short in the solenoid harness. If the wire is OK, replace the inhibitor solenoid (see **INHIBITOR SOLENOID REPLACEMENT**).

- 4. Disconnect TCM connector B (22P).
- 5. Check for continuity between TCM connector terminal B1 and body ground.

# TCM CONNECTOR B (22P)

# INH SOL (GRN/BLK)



Wire side of female terminals

G03681885

### **Fig. 184: Checking Continuity Between TCM Connector B (22P) Terminal B1 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there continuity?

**YES** -Repair a short to ground in the wire between TCM connector terminal B1 and the solenoid harness connector (8P).

- **NO** -Go to step 6.
- 6. Connect the solenoid harness connector (8P).

7. Measure the resistance between TCM connector terminal B1 and body ground.

# TCM CONNECTOR B (22P)



Wire side of female terminals

G03681886

#### **Fig. 185: Measuring Resistance Between TCM Connector B (22P) Terminal B1 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there 11.7-21.0 ohm?

**YES** -Check for loose terminal fit in the TCM connectors. If necessary, substitute a known-good TCM (see <u>HOW TO TROUBLESHOOT</u> <u>CIRCUIT AT THE TCM</u>), then recheck. If the symptom/ indication goes away with a known-good TCM, replace the original TCM.

**NO** -Repair an open in the wire between TCM connector terminal B1 and the solenoid harness connector (8P).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

DTC P0811: Problem in Start Clutch Control System

2005-2006 Models

## NOTE: Record all freeze data and review General Troubleshooting Information (see <u>GENERAL TROUBLESHOOTING</u> <u>INFORMATION</u>) before you troubleshoot.

1. Check whether the HDS indicates another code.

Does the HDS indicate the another code?

**YES** -Do the DTC Troubleshooting for the indicated code(s). Recheck for DTC P0811 after troubleshooting.

NO -Go to step 2.

- 2. Warm up the engine to normal operating temperature (the radiator fan comes on), if necessary.
- 3. Turn the ignition switch OFF.
- 4. Disconnect solenoid harness connector (8P).
- 5. Start the engine, and shift to the D position.
- 6. Check whether the vehicle moves.

Does the vehicle move?

**YES** -Go to step 7.

**NO** -Replace the start clutch.

- 7. Turn the ignition switch OFF.
- 8. Connect solenoid harness connector (8P).
- 9. Start the engine, and shift to the D position.
- 10. Check whether the vehicle creeps and check the creeping speed on level ground.

Does the vehicle creep and is the creeping speed about 3 mph (5 km/h)?

**YES** -Go to step 11.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

**NO** -Replace the lower valve body assembly.

11. Measure the stall speed RPM in the D position.

Is the stall speed over 3,500 RPM?

**YES** -Replace the start clutch or transmission.

**NO** -The system is OK at this time. If necessary, substitute a known-good TCM (see <u>HOW TO TROUBLESHOOT CIRCUIT AT THE TCM</u>) and recheck.

DTC P0962: CVT Drive Pulley Pressure Control Valve Circuit Low Voltage

2005-2006 Models

- NOTE: Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.
  - This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
  - 1. Clear the DTC with the HDS.
- 2. Check that DTC P0962 recurs.

Is DTC P0962 indicated?

**YES** -Go to step 3.

**NO** -Intermittent failure, the system is OK at this time. Check for poor connections or loose terminals at the solenoid harness connector, TCM, and the CVT drive pulley pressure control valve.

- 3. Turn the ignition switch OFF.
- 4. Disconnect the solenoid harness connector (8P).
- Measure the resistance between solenoid harness connector (8P) terminals No. 3 and No. 7.

# **SOLENOID HARNESS CONNECTOR (8P)**

# (BLU/WHT)



# Terminal side of male terminals

G03681887

### **Fig. 186: Measuring Resistance Between Solenoid Harness Connector (8P)** <u>Terminals 3 And 7</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there 3.8-6.8 ohm?* 

YES -Go to step 6.

**NO** -Remove the lower valve body c, and check for an open or a short in the solenoid harness. If the wire is OK, replace the CVT drive pulley pressure control valve (see )<u>CVT START CLUTCH PRESSURE</u> <u>CONTROL VALVE REPLACEMENT</u>, then go to step 11.

- 6. Disconnect TCM connector A (26P).
- 7. Check for continuity between TCM connector terminal A3 and body ground, and between A16 and body ground.



G03681888

### Fig. 187: Checking Continuity Between TCM Connector Terminal A3, A16 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** -Repair a short to ground in the wire between TCM connector terminals A3 and the solenoid harness connector, or between A16 and the connector.

NO -Go to step 8.

- 8. Connect the solenoid harness connector (8P).
- 9. Measure the resistance between TCM connector terminals A3 and A16.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

## TCM CONNECTOR A (26P)

## DR LS- (GRN/YEL)



DR LS+ (BLU/WHT)

Wire side of female terminals

G03681889

## **Fig. 188: Measuring Resistance Between TCM Connector A (26P)** <u>Terminals A3 And A16</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there 3.8-6.8 ohm?* 

YES -Go to step 10.

**NO** -Repair an open in the wire between TCM connector terminal A3 and the solenoid harness connector, or between A16 and the connector.

10. Check for continuity between TCM connector terminals A4 and body ground, A13 and body ground, A17 and body ground, and between A26 and body ground.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



Wire side of female terminals

G03681890

#### **Fig. 189: Checking Continuity Between TCM Connector Terminals A4,** <u>A17, A13 And Body Ground</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there continuity?* 

**YES** -Substitute a known-good TCM (see <u>**HOW TO**</u> <u>**TROUBLESHOOT CIRCUIT AT THE TCM**</u>), then recheck. If the symptom/indication goes away with a known-good TCM, replace the original TCM.

**NO** -Repair an open in the wires between TCM connector terminals A4, A13, A17, A26, and ground (G101), or repair poor ground (G101).

- 11. Clear the DTC with the HDS.
- 12. Check that DTC P0962 recurs.

Is DTC P0962 indicated?

**YES** -Return to step 3 . and recheck.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

**NO** -Troubleshooting is complete.

DTC P0963: CVT Drive Pulley Pressure Control Valve Circuit High Voltage

2005-2006 Models

- NOTE:
- Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.
  - This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
- 1. Clear the DTC with the HDS.
- 2. Check that DTC P0963 recurs.

Is DTC P0963 indicated?

**YES** -Go to step 3.

**NO** -Intermittent failure, the system is OK at this time. Check for poor connections or loose terminals at the solenoid harness connector, TCM, and the CVT drive pulley pressure control valve.

- 3. Turn the ignition switch OFF.
- 4. Disconnect the solenoid harness connector (8P).
- Measure the resistance between solenoid harness connector (8P) terminals No. 3 and No. 7.

# **SOLENOID HARNESS CONNECTOR (8P)**

## (BLU/WHT)



# Terminal side of male terminals

G03681891

## **Fig. 190: Measuring Resistance Between Solenoid Harness Connector (8P)** <u>Terminals 3 And 7</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there 3.8-6.8 ohm?

**YES** -Go to step 6.

**NO** -Remove the lower valve body (see )**LOWER VALVE BODY** <u>ASSEMBLY REPLACEMENT</u>, and check for an open or a short in the solenoid harness. If the wire is OK, replace the CVT drive pulley pressure control valve (see <u>CVT DRIVE PULLEY PRESSURE CONTROL</u>

**VALVE REPLACEMENT** ), then go to step 11 .

- 6. Disconnect TCM connector A (26P).
- 7. Turn the ignition switch ON (II).
- 8. Check for the voltage between TCM connector terminals A3 and body ground, and between A16 and body ground.



### Fig. 191: Checking Voltage Between TCM Connector Terminals A3, A16 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there voltage?

**YES** -Repair a short to power in the wires between TCM connector terminals A3, A16, and the solenoid harness connector. **NO** -Go to step 9.

9. Check for continuity between TCM connector terminals A3 and body ground,

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

and between A16 and body ground.



G03681893

### **Fig. 192: Checking Continuity Between TCM Connector Terminals A3,** <u>A16 And Body Ground</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** -Repair a short to ground in the wire between TCM connector terminals A3 and the solenoid harness connector, or between A16 connector.

NO -Go to step 10.

10. Check for continuity between TCM connector terminals A4 and body ground, A3 and body ground, A17 and body ground, and between A26 and body ground.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



Wire side of female terminals

G03681894

### Fig. 193: Checking Continuity Between TCM Connector Terminals A4, A13, A17, A26 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there continuity?* 

**YES** -Substitute a known-good TCM (see <u>HOW TO</u> <u>**TROUBLESHOOT CIRCUIT AT THE TCM**</u>), then a know-good TCM, replace the original TCM

**NO** -Repair an open in the wires between TCM connector terminals A4, A13, A17, A26, and ground (G101), or repair poor ground (G101).

- 11. Clear the DTC with the HDS.
- 12. Check the DTC P0963 recurs.

Is DTC P0963 indicated?

**YES** -Return to step 3 . and recheck.

**NO** -Troubleshooting is complete.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

DTC P0966: CVT Driven Pulley Pressure Control Valve Circuit Low Voltage

2005-2006 Models

## NOTE:

- Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.
  - This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
- 1. Clear the DTC with the HDS.
- 2. Check that DTC P0966 recurs.

Is DTC P0966 indicated?

**YES** -Go to step 3.

**NO** -Intermittent failure, the system is OK at this time. Check for poor connections or loose terminals at the solenoid harness connector, TCM, and the CVT driven pulley pressure control valve.

- 3. Turn the ignition switch OFF.
- 4. Disconnect the solenoid harness connector (8P).
- 5. Measure the resistance between solenoid harness connector (8P) terminals No. 2 and No. 6.

# **SOLENOID HARNESS CONNECTOR (8P)**

# (GRN/WHT)



# Terminal side of male terminals

G03681895

**Fig. 194: Measuring Resistance Between Solenoid Harness Connector (8P) Terminals 2 And 6 Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

*Is there 3.8-6.8 ohm?* 

**YES** -Go to step 4.

**NO** -Remove the lower valve body (see )**LOWER VALVE BODY** <u>ASSEMBLY REPLACEMENT</u>, and check for an open or a short in the solenoid harness. If the wire is OK, replace the CVT driven pulley pressure control valve (see <u>CVT DRIVEN PULLEY PRESSURE</u>

## **<u>CONTROL VALVE REPLACEMENT</u>** ), then go to step 11.

- 6. Disconnect TCM connector A (26P).
- 7. Check for continuity between TCM connector terminal A2 and body ground, and between A15 and body ground.



### **Fig. 195: Checking Continuity Between TCM Connector A (26P) Terminal** <u>A2, A15 And Body Ground</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** -Repair a short to ground in the wire between TCM connector terminals A2 and the solenoid harness connector, or between A15 and the connector.

NO -Go to step 8.

8. Connect the solenoid harness connector (8P).

9. Measure the resistance between TCM connector terminals A2 and A15.

## TCM CONNECTOR A (26P)



DN LS+ (GRN/WHT)

Wire side of female terminals

G03681897

## **Fig. 196: Measuring Resistance Between TCM Connector A (26P)** <u>Terminals A2 And A15</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there 3.8-6.8 ohm?* 

YES -Go to step 10.

**NO** -Repair an open in the wire between TCM connector terminal A2 and the solenoid harness connector, or between A15 and the connector.

10. Check for continuity between TCM connector terminals A4 and body ground, A13 and body ground, A17 and body ground, and between A26 and body ground.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03681898

#### Fig. 197: Checking Continuity Between TCM Connector Terminals A4, A13, A17, A26 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there continuity?* 

**YES** -Substitute a known-good TCM (see <u>**HOW TO**</u> <u>**TROUBLESHOOT CIRCUIT AT THE TCM**</u>), then recheck. If the symptom/indication goes away with a known-good TCM, replace the original TCM.

**NO** -Repair an open in the wire between TCM connector terminals A4, A13, A17, A26, and ground (G101), or repair poor ground (G101).

- 11. Clear the DTC with the HDS.
- 12. Check that DTC P0966 recurs.

Is DTC P0966 indicated?

**YES** -Return to step 3 . and recheck.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

**NO** -Troubleshooting is complete.

DTC P0967: CVT Driven Pulley Pressure Control Valve Circuit High Voltage

2005-2006 Models

- NOTE:
- Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.
  - This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
- 1. Clear the DTC with the HDS.
- 2. Check that DTC P0967 recurs.

Is DTC P0967 indicated?

**YES** -Go to step 3.

**NO** -Intermittent failure, the system is OK at this time. Check for poor connections or loose terminals at the solenoid harness connector, TCM, and the CVT driven pulley pressure control valve.

- 3. Turn the ignition switch OFF.
- 4. Disconnect the solenoid harness connector (8P).
- Measure the resistance between solenoid harness connector (8P) terminals No. 2 and No. 6.

# **SOLENOID HARNESS CONNECTOR (8P)**

# (GRN/WHT)



# Terminal side of male terminals

G03681899

**Fig. 198: Measuring Resistance Between Solenoid Harness Connector (8P)** <u>Terminals 2 And 6</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there 3.8-6.8 ohm?

**YES** -Go to step 4.

**NO** -Remove the lower valve body (see )**LOWER VALVE BODY** <u>ASSEMBLY REPLACEMENT</u>, and check for an open or a short in the solenoid harness. If the wire is OK, replace the CVT driven pulley pressure control valve (see <u>CVT DRIVEN PULLEY PRESSURE</u>

## **<u>CONTROL VALVE REPLACEMENT</u>** ), then go to step 11.

- 6. Disconnect TCM connectors A (26P).
- 7. Turn the ignition switch ON (II).
- 8. Check for the voltage between TCM connector terminals A2 and body ground, and between A15 and body ground.



## Fig. 199: Checking Voltage Between TCM Connector Terminals A2, A15 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there voltage?

**YES** -Repair a short to power in the wires between TCM connector terminals A2, A15, and the solenoid harness connector. **NO** -Go to step 9.

9. Check for continuity between TCM connector terminals A2 and body ground,

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

and between A15 and body ground.



G03681901

#### Fig. 200: Checking Continuity Between TCM Connector A (26P) Terminals A2 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** -Repair a short to ground in the wire between TCM connector terminals A2 and the solenoid harness connector, or between A15 and the connector.

NO -Go to step 10.

10. Check for continuity between TCM connector terminals A4 and body ground, A13 and body ground, A17 and body ground, and between A26 and body ground.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



Wire side of female terminals

G03681902

#### Fig. 201: Checking Continuity Between TCM Connector Terminals A4, A17, A13, A26 And Body Ground **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

*Is there continuity?* 

**YES** -Substitute a known-good TCM (see **<u>HOW TO</u>** TROUBLESHOOT CIRCUIT AT THE TCM ), then recheck. If the symptom/indication goes away with a known-good TCM, replace the original TCM.

**NO** -Repair an open in the wires between TCM connector terminals A4, A13, A17, A26, and ground (G101), or repair poor ground (G101).

- 11. Clear the DTC with the HDS.
- 12. Check that DTC P0967 recurs.

Is DTC P0967 indicated?

**YES** -Return to step 3 . and recheck.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

**NO** -Troubleshooting is complete.

DTC P0970: CVT Start Clutch Pressure Control Valve Circuit Low Voltage

2005-2006 Models

- NOTE:
- Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.
  - This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
- 1. Clear the DTC with the HDS.
- 2. Check that DTC P0970 recurs.

Is DTC P0970 indicated?

**YES** -Go to step 6.

**NO** -Go to step 3.

- 3. Apply the parking brake, and block the front wheels securely.
- 4. Start the engine, fully press the brake pedal, and shift to the D position.
- 5. Check that DTC P0970 recurs.

Is DTC P0970 indicated?

YES -Go to step 6.

**NO** -Intermittent failure, the system is OK at this time. Check for poor connections or loose terminals at the solenoid harness connector, TCM, and the CVT start clutch pressure control valve.

- 6. Turn the ignition switch OFF.
- 7. Disconnect the solenoid harness connector (8P).
- 8. Measure the resistance between solenoid harness connector (8P) terminals No.4 and No.8.

# **SOLENOID HARNESS CONNECTOR (8P)**



# Terminal side of male terminals

G03681903

## **Fig. 202: Measuring Resistance Between Solenoid Harness Connector (8P)** <u>Terminals 4 And 8</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there 3.8-6.8 ohm?

**YES** -Go to step 9.

**NO** -Remove the lower valve body (see )**LOWER VALVE BODY** <u>ASSEMBLY REPLACEMENT</u>, and check for an open or a short in the solenoid harness. If the wire is OK, replace the CVT start clutch pressure control valve (see <u>CVT START CLUTCH PRESSURE CONTROL</u>

**VALVE REPLACEMENT** ), then go to step 14.

- 9. Disconnect TCM connector A (26P).
- 10. Check for continuity between TCM connector terminals A1 and body ground, and between A14 and body ground.



### Fig. 203: Checking Continuity Between TCM Connector Terminals A1, A14 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** -Repair a short to ground in the wire between TCM connector terminal A1 and the solenoid harness connector, or between A14 and the connector.

NO -Go to step 11.

11. Connect the solenoid harness connector (8P).
12. Measure the resistance between TCM connector terminals A1 and A14.

# TCM CONNECTOR A (26P)



Wire side of female terminals

G03681905

### **Fig. 204: Measuring Resistance Between TCM Connector A (26P)** <u>Terminals A1 And A14</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there 3.8-6.8 ohm?* 

**YES** -Go to step 13.

**NO** -Repair an open in the wire between TCM connector terminal A1 and the solenoid harness connector, or between A14 and the connector.

13. Check for continuity between TCM connector terminals A4 and body ground, A13 and body ground, A17 and body ground, and between A26 and body ground.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03681906

#### Fig. 205: Checking Continuity Between TCM Connector Terminals A4, A13, A17, A26 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there continuity?* 

**YES** -Substitute a known-good TCM (see <u>**HOW TO**</u> <u>**TROUBLESHOOT CIRCUIT AT THE TCM**</u>), then recheck. If the symptom/indication goes away with a known-good TCM, replace the original TCM.

**NO** -Repair an open in the wires between TCM connector terminals A4, A13, A17, A26, and ground (G101), or repair poor ground (G101).

- 14. Clear the DTC with the HDS.
- 15. Check that DTC P0970 recurs.

Is DTC P0970 indicated?

**YES** -Return to step 6 . and recheck.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

**NO** -Troubleshooting is complete.

DTC P0971: CVT Start Clutch Pressure Control Valve Circuit High Voltage

2005-2006 Models

- NOTE:
- Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.
  - This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
- 1. Clear the DTC with the HDS.
- 2. Check that DTC P0971 recurs.

Is DTC P0971 indicated?

**YES** -Go to step 6.

**NO** -Go to step 3.

- 3. Apply the parking brake, and block the front wheels securely.
- 4. Start the engine, fully press the brake pedal, and shift to the D position.
- 5. Check that DTC P0971 recurs.

Is DTC P0971 indicated?

YES -Go to step 6.

**NO** -Intermittent failure, the system is OK at this time. Check for poor connections or loose terminals at the solenoid harness connector, TCM, and the CVT start clutch pressure control valve.

- 6. Turn the ignition switch OFF.
- 7. Disconnect the solenoid harness connector (8P).
- 8. Measure the resistance between solenoid harness connector (8P) terminals No.4 and No.8.

# **SOLENOID HARNESS CONNECTOR (8P)**



# Terminal side of male terminals

G03681907

## **Fig. 206: Measuring Resistance Between Solenoid Harness Connector (8P)** <u>Terminals 4 And 8</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there 3.8-6.8 ohm?* 

**YES** -Go to step 9.

**NO** -Remove the lower valve body (see )**LOWER VALVE BODY** <u>ASSEMBLY REPLACEMENT</u>, and check for an open or a short in the solenoid harness. If the wire is OK, replace the CVT start clutch pressure control valve (see <u>CVT START CLUTCH PRESSURE CONTROL</u>

**VALVE REPLACEMENT** ), then go to step 14.

- 9. Disconnect TCM connectors A (26P).
- 10. Turn the ignition switch ON (II).
- 11. Check for the voltage between TCM connector terminals A1 and body ground, and between A14 and ground.



## Fig. 207: Checking Voltage Between TCM Connector A (26P) Terminals A1, A14 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there voltage?

**YES** -Repair a short to power in the wires between TCM connector terminals A1, A14, and the solenoid harness connector. **NO** -Go to step 12.

12. Check for continuity between TCM connector terminals A1 and body ground,

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

and between A14 and body ground.



G03681909

### **Fig. 208: Checking Continuity Between TCM Connector A (26P) Terminals A1, A14 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there continuity?

**YES** -Repair a short to ground in the wire between TCM connector terminal A1 and the solenoid harness connector, or between A14 and the connector.

NO -Go to step 13.

13. Check for continuity between TCM connector terminals A4 and body ground, A13 and body ground, A17 and body ground, and between A26 and body ground.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



Wire side of female terminals

G03681910

### Fig. 209: Checking Continuity Between TCM Connector A (26P) Terminals A4, A13, A17, A26 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** -Substitute a known-good TCM (see <u>**HOW TO**</u> <u>**TROUBLESHOOT CIRCUIT AT THE TCM**</u>), then recheck. If the symptom/indication goes away with a known-good TCM, replace the original TCM.

**NO** -Repair an open in the wires between TCM connector terminals A4, A13, A17, A26, and ground (G101), or repair poor ground (G101).

14. Carry out step 1 thru 4, and check that DTC P0971 recurs.

Is DTC P0971 indicated?

YES -Return to step 6 . and recheck.

**NO** -Troubleshooting is complete.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

DTC P1655: Problem in TCM-to-ECM Communication Lines

2005-2006 Models

- NOTE: Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.
  - This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
  - 1. Turn the ignition switch OFF.
  - 2. Disconnect TCM connector B (22P) and ECM connector C (31P).
- 3. Check for continuity between TCM connector terminal B7 and ECM connector terminal C15.

TCM CONNECTOR B (22P) ECM CONNECTOR C (31P)



Wire side of female terminals

G03681911

Fig. 210: Checking Continuity Between TCM Connector B (22P) Terminal

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

## **<u>B7 And ECM Connector C (31P) Terminal C15</u>** Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

YES -Go to step 4.

**NO** -Repair an open in the wire between TCM connector terminal B7 and ECM connector terminal C15.

4. Check for continuity between TCM connector terminal B7 and body ground, or between ECM connector terminal C15 and body ground.

## TCM CONNECTOR B (22P) ECM CONNECTOR C (31P)



Wire side of female terminals

G03681912

Fig. 211: Checking Continuity Between TCM Connector B (22P) Terminal B7 And Body Ground, Or Between ECM Connector C (31P) Terminal C15 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

**YES** -Repair a short to ground in the wire between TCM connector terminal B7, ECM connector terminal C15 terminal, and body ground. **NO** -Go to step 5.

- 5. Connect TCM connector B (22P).
- 6. Turn the ignition switch ON (II).
- 7. Measure the voltage between ECM connector terminal C15 and body ground.

# ECM CONNECTOR C (31P)



# Wire side of female terminals G03681913

## Fig. 212: Measuring Voltage Between ECM Connector C (31P) Terminal

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

## **<u>C15 And Body Ground</u>** Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there about 10 V?

YES -Go to step 8.

**NO** -Check for loose terminal fit in the TCM connectors. If necessary, substitute a known-good TCM (see <u>HOW TO TROUBLESHOOT</u> <u>CIRCUIT AT THE TCM</u>), then recheck. If the symptom/indication goes away with a known-good TCM, replace the original TCM.

- 8. Turn the ignition switch OFF.
- 9. Connect ECM connector C (31P).
- 10. Turn the ignition switch ON (II).
- 11. Measure the voltage between ECM connector terminal C15 and body ground.

# ECM CONNECTOR C (31P)



Wire side of female terminals

G03681914

**Fig. 213: Measuring Voltage Between ECM Connector C (31P) Terminal** <u>C15 And Body Ground</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there battery voltage?

YES -Go to step 12.NO -Replace the ECM.12. Turn the ignition switch OFF.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

- 13. Disconnect TCM connector B (22P) and ECM connector C (31P).
- 14. Check for continuity between TCM connector terminal B6 and ECM connector terminal C11.

# TCM CONNECTOR B (22P) ECM CONNECTOR C (31P)



Wire side of female terminals

G03681915

## **Fig. 214: Checking Continuity Between TCM Connector B (22P) Terminal B6 And ECM Connector C (31P) Terminal C11 Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there continuity?

YES -Go to step 15.

**NO** -Repair an open in the wire between TCM connector terminal B6 and ECM connector terminal C11.

15. Check for continuity between TCM connector terminal B6 and body ground, or between ECM connector terminal C11 and body ground.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# TCM CONNECTOR B (22P) ECM CONNECTOR C (31P)



Wire side of female terminals

G03681916

#### Fig. 215: Checking Continuity Between TCM Connector Terminal B6 And Body Ground Or Between ECM Connector Terminal C11 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** -Repair a short to ground in the wire between TCM connector terminal B6, ECM connector terminal C11, and ground.

NO -Go to step 16.

- 16. Connect ECM connector C (31P).
- 17. Turn the ignition switch ON (II).
- 18. Measure the voltage between TCM connector terminal B6 and body ground.

# TCM CONNECTOR B (22P)



Wire side of female terminals

G03681917

## **Fig. 216:** Measuring Voltage Between TCM Connector B (22P) Terminal B6 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there about 10 V?

**YES** -Go to step 19.

**NO** -Check for loose terminal fit in the ECM connectors. If necessary, substitute a known-good ECM (see <u>HOW TO SUBSTITUTE THE</u> <u>ECM</u>), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM.

- 19. Turn the ignition switch OFF.
- 20. Connect TCM connector B (22P).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

- 21. Turn the ignition switch ON (II).
- 22. Measure the voltage between TCM connector terminal B6 and body ground.

# TCM CONNECTOR B (22P)



Wire side of female terminals

G03681918

### **Fig. 217: Measuring Voltage Between TCM Connector B (22P) Terminal B6 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there battery voltage?

YES -Substitute a known-good TCM (see <u>HOW TO</u> <u>TROUBLESHOOT CIRCUIT AT THE TCM</u>) and recheck. If the check results are same, replace the ECM. NO -Replace the TCM.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

#### DTC P1782: TP Sensor Circuit Low Voltage

2005-2006 Models

- NOTE: Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.
  - This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
  - 1. Turn the ignition switch ON (II).
  - 2. Check the TP SENSOR in the DATA LIST with the HDS.

*Is there about 0.5 V when the throttle is fully closed and about 4.5 V when the throttle is fully opened?* 

**YES** -Check for poor connections or loose terminals at the TP sensor, the TCM, and the ECM, then recheck. If DTC P1782 is indicated, go to step 3.

**NO** -Do the DTC Troubleshooting for the TP sensor circuit low voltage (see **<u>DTC P0122: TP SENSOR CIRCUIT LOW VOLTAGE</u>**). Recheck for DTC P1782 after troubleshooting.

- 3. Turn the ignition switch OFF.
- 4. Disconnect the TP sensor 3P connector.
- 5. Disconnect TCM connector B (22P).
- 6. Connect TP sensor 3P connector terminal No. 2 to body ground with a jumper wire.

# **TP SENSOR 3P CONNECTOR**



# Wire side of female terminals

G03681919

**Fig. 218: Connecting TP Sensor 3P Connector Terminal 2 To Body Ground With Jumper Wire Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

7. Check for continuity between TCM connector terminal B4 and body ground.

# TCM CONNECTOR B (22P)



Wire side of female terminals

G03681920

#### **Fig. 219: Checking Continuity Between TCM Connector Terminal B4 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there continuity?

**YES** -Substitute a known-good TCM (see <u>**HOW TO**</u> <u>**TROUBLESHOOT CIRCUIT AT THE TCM**</u>), then recheck. If the symptom/indication goes away with a known-good TCM, replace the original TCM.

NO -Repair an open in the wire between TCM (B4), and the TP sensor.

DTC P1783: TP Sensor Circuit High Voltage

- NOTE: Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.
  - This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
  - 1. Turn the ignition switch ON (II).
- 2. Check the TP SENSOR in the DATA LIST with the HDS.

Is there about 0.5 V when the throttle is fully closed and about 4.5 V when the throttle is fully opened?

**YES** -Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the TP sensor, the TCM, and at the ECM.

NO -Go to step 3.

3. Check the DTCs with HDS.

Is DTC P0123 indicated?

**YES** -Do the DTC Troubleshooting for the TP sensor circuit high voltage (see **DTC P0123: TP SENSOR CIRCUIT HIGH VOLTAGE**). Recheck for DTC P1783 after troubleshooting.

**NO** -Substitute a known-good TCM (see <u>HOW TO TROUBLESHOOT</u> <u>CIRCUIT AT THE TCM</u>), then recheck. If the symptom/indication goes away with a known-good TCM, replace the original TCM.

DTC P1784: MAP Sensor Circuit Low Voltage

2005-2006 Models

NOTE: • Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you

troubleshoot.

- This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
- 1. Turn the ignition switch ON (II).
- 2. Check the MAP SENSOR in the DATA LIST with the HDS.

Is about 101 kPa (760 mmHg, 30 in.Hg), or 2.9 V indicated?

**YES** -Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the MAP sensor, the TCM, and at the ECM.

**NO** -Go to step 3.

3. Check the DTCs with HDS.

Is DTC P0107 indicated?

YES -Do the DTC Troubleshooting for the MAP sensor circuit low voltage (see <u>DTC P0107: MAP SENSOR CIRCUIT LOW</u>
<u>VOLTAGE</u>). Recheck for DTC P1784 after troubleshooting.
NO -Go to step 4.

- 4. Disconnect the TCM connector B (22P) and ECM connector C (31P).
- 5. Check for continuity between MAP sensor connector terminal No. 3 and body ground.

# **MAP SENSOR 3P CONNECTOR**



# Wire side of female terminals

G03681921

#### **Fig. 220: Checking Continuity Between MAP Sensor Connector Terminal** <u>3 And Body Ground</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** -Repair a short in the wire between the TCM (B2), and the MAP sensor.

**NO** -Substitute a known-good TCM (see **HOW TO TROUBLESHOOT** 

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

<u>**CIRCUIT AT THE TCM</u>**), then recheck. If the symptom/indication goes away with a known-good TCM, replace the original TCM.</u>

DTC P1785: MAP Sensor Circuit High Voltage

2005-2006 Models

- NOTE:
- Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.
  - This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
- 1. Turn the ignition switch ON (II).
- 2. Check the MAP SENSOR in the DATA LIST with the HDS.

Is about 101 kPa (760 mmHg, 30 in.Hg), or 2.9 V indicated?

**YES** -Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the MAP sensor, the TCM, and at the ECM.

**NO** -Go to step 3.

3. Check the DTCs with HDS.

Is DTC P0108 indicated?

YES -Do the DTC Troubleshooting for the MAP sensor circuit high voltage (see <u>DTC P0108: MAP SENSOR CIRCUIT HIGH</u> <u>VOLTAGE</u>). Recheck for DTC P1785 after troubleshooting.
NO -Go to step 4.

4. Connect MAP sensor 3P connector terminal NO. 3 to body ground with a jumper wire.

# **MAP SENSOR 3P CONNECTOR**



Wire side of female terminals

G03681922

### **Fig. 221: Connecting MAP Sensor 3P Connector Terminal 3 To Body** <u>Ground With Jumper Wire</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

5. Check for continuity between TCM connector terminal B2 and body ground.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# TCM CONNECTOR B (22P)



Wire side of female terminals

G03681923

#### Fig. 222: Checking Continuity Between TCM Connector B (22P) Terminal B2 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** -Substitute a Known-good TCM (see <u>**HOW TO</u></u> <u><b>TROUBLESHOOT CIRCUIT AT THE TCM**</u>), then recheck. If the symptom/indication goes away with a Known-good TCM, replace the original TCM.</u>

NO -Repair an open in the wire between TCM (B2), and the MAP sensor.

DTC P1792: Problem in Engine Coolant Temperature Sensor Circuit

- NOTE: Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.
  - This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
  - 1. Turn the ignition switch ON (II).
- 2. Check whether the HDS indicates code for the engine coolant temperature (ECT) sensor.

Does the scan tool or the HDS indicate code for ECT sensor?

**YES** -Do the DTC Troubleshooting for the ECT sensor circuit low voltage (see **DTC P0117: ECT SENSOR CIRCUIT LOW VOLTAGE**), and the ECT sensor circuit high voltage (see **DTC P0118: ECT SENSOR CIRCUIT HIGH VOLTAGE**). Recheck for DTC P1792 after troubleshooting.

**NO** -Turn the ignition switch OFF, then go to step 3.

- 3. Disconnect TCM connectors A (26P) and B (22P).
- 4. Turn the ignition switch ON (II).
- 5. Measure the voltage between TCM connector terminals B20 and A4.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# **TCM CONNECTORS**



## Wire side of female terminals

G03681924

#### **Fig. 223: Measuring Voltage Between TCM Connector Terminals B20** And A4 Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there about 5 V?* 

YES -Go to step 6.

**NO** -Repair an open or short in VREF wire between TCM connector terminals B20 and the ECM.

6. Measure the voltage between TCM connector terminals A19 and A4.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

## TCM CONNECTOR A (26P)



Wire side of female terminals

G03681925

#### **Fig. 224: Measuring Voltage Between TCM Connector A (26P) Terminals** <u>A19 And A4</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there 0.1-4.8 V?* 

**YES** -Check for loose terminal fit in the TCM connectors. If necessary, substitute a Known-good TCM (see <u>HOW TO TROUBLESHOOT</u> <u>CIRCUIT AT THE TCM</u>), then recheck. If the symptom/indication goes away with a Known-good TCM, replace the original TCM. NO -Repair an open or short in the wire between TCM connector terminal

A19 and the ECT sensor.

DTC P1799: Problem in Intake Air Temperature Sensor Circuit

2005-2006 Models

# NOTE: • Record all freeze data and review General

Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.

- This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
- 1. Turn the ignition switch ON (II).
- 2. Check whether the HDS indicates code for the intake air temperature (IAT) sensor.

Does the scan tool or the HDS Indicate code for IAT sensor?

**YES** -Do the DTC Troubleshooting for the IAT sensor circuit low voltage (see **DTC P0112: IAT SENSOR CIRCUIT LOW VOLTAGE**), and the IAT sensor circuit high voltage (see **DTC P0113: IAT SENSOR CIRCUIT HIGH VOLTAGE**). Recheck for DTC P1799 after troubleshooting.

**NO** -Turn the ignition switch OFF, then go to step 3.

- 3. Disconnect TCM connectors A (26P) and B (22P).
- 4. Turn the ignition switch ON (II).
- 5. Measure the voltage between TCM connector terminals B20 and A4.

# TCM CONNECTORS



## Wire side of female terminals

G03681926

### Fig. 225: Measuring Voltage Between TCM Connector Terminals B20 And A4 Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there about 5 V?* 

YES -Go to step 6.

**NO** -Repair an open or short in VREF wire between TCM connector terminals B20 and the ECM.

6. Measure the voltage between TCM connector terminals B19and A4.

# TCM CONNECTORS



Wire side of female terminals

G03681927

### Fig. 226: Measuring Voltage Between TCM Connector Terminals B19 And A4 Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there 0.1-4.8 V?* 

**YES** -Check for loose terminal fit in the TCM connectors. If necessary, substitute a Known-good TCM (see <u>HOW TO TROUBLESHOOT</u> <u>CIRCUIT AT THE TCM</u>), then recheck. If the symptom/indication goes away with a Known-good TCM, replace the original TCM. **NO** -Repair an open or short in the wire between TCM connector terminal B19and the IAT sensor.

DTC P1850: Problem in Creep Aid System Solenoid Valve A Circuit

2005-2006 Models

### NOTE:

- Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.
- This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
- 1. Turn the ignition switch OFF.
- 2. Disconnect TCM connectors A (26P) and B (22P).
- 3. Turn the ignition switch ON (II).
- 4. Measure the voltage between TCM connector terminals B11 and A4.

## **TCM CONNECTORS**



Wire side of female terminals

G03681928

**Fig. 227: Measuring Voltage Between TCM Connector Terminals B11** And A4 Courtesy of AMERICAN HONDA MOTOR CO., INC.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

Is there voltage?

**YES** -Repair a short to power in the wire between TCM connector terminal B11 and the creep aid system solenoid valve A. **NO** -Go to step 5.

- 5. Turn the ignition switch OFF.
- Disconnect the 4P connector from the creep aid system solenoid valves A and B.
- 7. Check for continuity between TCM connector terminals B11 and A4.

## **TCM CONNECTORS**



Wire side of female terminals

G03681929

#### Fig. 228: Checking Continuity Between TCM Connector Terminals B11 And A4 Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** -Repair a short to ground in the wire between TCM connector

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

terminal B11 and the creep aid system solenoid valve A.

**NO** -Go to step 8.

- 8. Connect the creep aid system solenoid valves A and B connector.
- 9. Measure the resistance between TCM connector terminals B11 and A4.

## TCM CONNECTORS



Wire side of female terminals

G03681930

### **Fig. 229:** Measuring Resistance Between TCM Connector Terminals B11 And A4 Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there 8-24 ohm?

**YES** -Check for loose terminal fit in the TCM connectors. If necessary, substitute a Known-good TCM (see <u>HOW TO TROUBLESHOOT</u> <u>CIRCUIT AT THE TCM</u>), then recheck. If the symptom/indication goes away with a Known-good TCM, replace the original TCM. **NO** -Check for an open in the wire between TCM connector terminal B11

and the creep aid system solenoid valve A. If the wire is OK, replace the creep aid system solenoid valves A and B.

DTC PI851: Problem in Creep Aid System Solenoid Valve B Circuit

2005-2006 Models

- NOTE:
- Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.
  - This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
- 1. Turn the ignition switch OFF.
- 2. Disconnect TCM connectors A (26P) and B (22P).
- 3. Turn the ignition switch ON (II).
- 4. Measure the voltage between TCM connector terminals B18 and A4.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

## **TCM CONNECTORS**



Wire side of female terminals

G03681931

## **Fig. 230:** Measuring Voltage Between TCM Connector Terminals B18 And A4 Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there voltage?

**YES** -Repair a short to power in the wire between TCM connector terminal B18 and the creep aid system solenoid valve B.

**NO** -Go to step 5.

- 5. Turn the ignition switch OFF.
- 6. Disconnect the 4P connector from the creep aid system solenoid valves A and B.
- 7. Check for continuity between TCM connector terminals B18 and A4.
2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# TCM CONNECTORS



## Wire side of female terminals

G03681932

### Fig. 231: Checking Continuity Between TCM Connector Terminals B18 And A4 Courtesy of AMERICAN HONDA MOTOR CO. INC.

Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** -Repair a short to ground in the wire between TCM connector terminal B18 and the creep aid system solenoid valve B. **NO** -Go to step 8.

- 8. Connect the creep aid system solenoid valves A and B connector.
- 9. Measure the resistance between TCM connector terminal b18 and A4

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# **TCM CONNECTORS**



Wire side of female terminals

G03681933

# Fig. 232: Measuring Resistance Between TCM Connector Terminal B18 And A4

**Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

Is there 8-24 ohm

**YES** -Check for loose terminal fit in the TCM connectors. If necessary, substitute a known-good TCM (see <u>HOW TO TROUBLESHOOT</u> <u>CIRCUIT AT THE TCM</u>), then recheck If the symptom/indication goes away with a known good TCM, replace the original TCM.

**NO** --Check for an open in the wire between TCM connector terminal B18 and the creep aid system solenoid valve B If the wire is OK, replace the creep aid system solenoid valves A and B.

DTC P2159: Range/Performance Problem in CVT Speed Sensor Circuit

- NOTE: Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.
  - This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
  - 1. Raise the front of the vehicle, make sure it is securely supported, and allow the front wheels to rotate freely.
  - 2. Start the engine, and shift into the D position. Push on the accelerator pedal until the rotational speed of the VEHICLE SPEED SENSOR is the same speed as indicated by the freeze data.
- 3. Monitor the SECONDARY SHAFT SPEED and VEHICLE SPEED SENSOR with the HDS in the data list.

Do the SECONDARY SHAFT SPEED and VEHICLE SPEED SENSOR signals fluctuate with the same speed?

**YES** -Intermittent failure, the system is OK at this time. Check for poor connections or loose terminals at the CVT speed sensor and TCM.

NO -Go to step 4.

- 4. Turn the ignition switch OFF.
- 5. Check for continuity between TCM connector terminals A4 and body ground, and between A17 and body ground.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



Wire side of female terminals

G03681934

## **Fig. 233: Checking Continuity Between TCM Connector Terminals A4,** <u>A17 And Body Ground</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** -Go to step 6.

**NO** -Repair an open in the wires between TCM connector terminals A4, A17, and ground (G 101), or repair poor ground (G101).

- 6. Disconnect CVT speed sensor connector.
- 7. Turn the ignition switch ON (II).
- 8. Check for voltage between CVT speed sensor connector terminal No. 2 and body ground.

# **CVT SPEED SENSOR CONNECTOR**



# Wire side of female terminals

G03681935

**Fig. 234: Checking Voltage Between CVT Speed Sensor Connector Terminal 2 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

*Is there about 5 V?* 

**YES** -Go to step 15. **NO** -Go to step 9.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

- 9. Turn the ignition switch OFF.
- 10. Disconnect TCM connector B (22P).
- 11. Check for continuity between CVT speed sensor connector terminal No. 2 and body ground.

# **CVT SPEED SENSOR CONNECTOR**



# Wire side of female terminals

G03681936

Fig. 235: Checking Continuity Between CVT Speed Sensor Connector Terminal 2 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

Is there continuity?

**YES** -Repair a short to ground in the wire between TCM connector terminal B15 and the CVT speed sensor.

NO -Go to step 12.

- 12. Connect TCM connector B (22P).
- 13. Turn the ignition switch ON (II).
- 14. Measure the voltage between TCM connector terminals B15 and A4.

# **TCM CONNECTORS**



Wire side of female terminals

G03681937

## Fig. 236: Measuring Voltage Between TCM Connector Terminals B15 And A4 Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there about 5 V?

**YES** -Repair an open in the wire between TCM connector terminal

B15and the CVT speed sensor.

**NO** -Check for loose or poor connections at TCM connector terminal B15. If the connection is OK, substitute a known-good TCM (see <u>HOW TO</u> <u>**TROUBLESHOOT CIRCUIT AT THE TCM**</u>), then recheck. If the symptom/indication goes away with a known-good TCM, replace the original TCM.

15. Measure the voltage between CVT speed sensor connector terminal No. 1 and body ground.

# **CVT SPEED SENSOR CONNECTOR**



# Wire side of female terminals

G03681938

**Fig. 237: Measuring Voltage Between CVT Speed Sensor Connector Terminal 1 And Body Ground** 

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there about 5 V?* 

YES -Go to step 22.

NO -Go to step 16.

- 16. Turn the ignition switch OFF.
- 17. Disconnect TCM connector B (22P).
- 18. Check for continuity between CVT speed sensor connector terminal No. 1 and body ground.

# **CVT SPEED SENSOR CONNECTOR**



Wire side of female terminals

G03681939

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

## Fig. 238: Checking Continuity Between CVT Speed Sensor Connector Terminal 1 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** -Repair a short to ground in the wire between TCM connector terminal B3 and the CVT speed sensor.

NO -Go to step 19.

- 19. Connect TCM connector B (22P).
- 20. Turn the ignition switch ON (II).
- 21. Measure the voltage between TCM connector terminals B3and A4.

# **TCM CONNECTORS**



Wire side of female terminals

G03681940

# **Fig. 239: Measuring Voltage Between TCM Connector Terminals B3 And** <u>A4</u> **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

*Is there about 5 V?* 

**YES** -Repair an open in the wire between TCM connector terminal B3 and the CVT speed sensor.

**NO** -Check for loose or poor connections at TCM connector terminal B3. If the connection is OK, substitute a known-good TCM (see <u>HOW TO</u> <u>**TROUBLESHOOT CIRCUIT AT THE TCM**</u>), then recheck. If the symptom/indication goes away with a known-good TCM, replace the original TCM.

22. Measure the voltage between CVT speed sensor connector terminals No. 1 and No. 3.

# **CVT SPEED SENSOR CONNECTOR**



Wire side of female terminals

G03681941

## **Fig. 240: Measuring Voltage Between CVT Speed Sensor Connector Terminals 1 And 3**

# Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there about 5 V?

**YES** -Replace the CVT speed sensor (see **<u>SPEED SENSOR</u> <u>REPLACEMENT</u>**), then go to step 23.

**NO** -Repair an open in the wire between TCM connector terminal B16 and the CVT speed sensor.

- 23. Clear the DTC with the HDS.
- 24. Test-drive the vehicle for several minutes under the same conditions as those indicated by the freeze data.
- 25. Check that DTC P2159 recurs.

Is DTC P2159 indicated?

YES -Return to step 4 . and recheck.

**NO** -Troubleshooting is complete.

DTC P2160: Problem in CVT Speed Sensor Circuit (No Signal Input)

2005-2006 Models

NOTE:

- Record all freeze data and review General Troubleshooting Information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>) before you troubleshoot.
  - This code is caused by an electrical circuit problem and cannot be caused by a mechanical problem in the transmission.
- 1. Raise the front of the vehicle, make sure it is securely supported, and allow the front wheels to rotate freely.
- 2. Start the engine, and drive the vehicle in the D position. Accelerate the vehicle slowly until the vehicle speed reaches 12 mph (20 km/h).
- 3. Check the SECONDARY SHAFT SPEED with the HDS in the data list.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

Is the SECONDARY SHAFT SPEED 2 km/h or less?

**YES** -Go to step 4.

**NO** -Intermittent failure, the system is OK at this time. Check for poor connections or loose terminals at the CVT speed sensor and TCM.

- 4. Turn the ignition switch OFF.
- 5. Check for continuity between TCM connector terminals A4 and body ground, and between A17 and body ground.



Wire side of female terminals

G03681942

## **Fig. 241: Checking Continuity Between TCM Connector Terminals A4,** <u>A17 And Body Ground</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** -Go to step 6.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

**NO** -Repair an open in the wires between TCM connector terminals A4, A17, and ground (G 101), or repair poor ground (G 101).

- 6. Disconnect CVT speed sensor connector.
- 7. Turn the ignition switch ON (II).
- 8. Check for voltage between CVT speed sensor connector terminal No. 2 and body ground.

# **CVT SPEED SENSOR CONNECTOR**



Wire side of female terminals G03681943

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

## **Fig. 242: Checking Voltage Between CVT Speed Sensor Connector Terminal 2 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

*Is there about 5 V?* 

**YES** -Go to step 15. **NO** -Go to step 9.

- 9. Turn the ignition switch OFF.
- 10. Disconnect TCM connector B (22P).
- 11. Check for continuity between CVT speed sensor connector terminal No. 2 and body ground.

# **CVT SPEED SENSOR CONNECTOR**



# Wire side of female terminals

G03681944

## **Fig. 243: Checking Continuity Between CVT Speed Sensor Connector Terminal 2 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there continuity?

**YES** -Repair a short to ground in the wire between TCM connector terminal B15 and the CVT speed sensor.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

**NO** -Go to step 12.

- 12. Connect TCM connector B (22P).
- 13. Turn the ignition switch ON (II).
- 14. Measure the voltage between TCM connector terminals B15 and A4.

# **TCM CONNECTORS**



Wire side of female terminals

G03681945

### Fig. 244: Measuring Voltage Between TCM Connector Terminals B15 And A4 Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there about 5 V?* 

**YES** -Repair an open in the wire between TCM connector terminal B15 and the CVT speed sensor.

**NO** -Check for loose or poor connections at TCM connector terminal B15. If the connection is OK, substitute a known-good TCM (see <u>HOW TO</u> <u>**TROUBLESHOOT CIRCUIT AT THE TCM**</u>), then recheck. If the

symptom/indication goes away with a known-good TCM, replace the original TCM.

15. Measure the voltage between CVT speed sensor connector terminal No. 1 and body ground.

# **CVT SPEED SENSOR CONNECTOR**



Wire side of female terminals

G03681946

**Fig. 245: Measuring Voltage Between CVT Speed Sensor Connector Terminal 1 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

*Is there about 5 V?* 

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

**YES** -Go to step 22 . **NO** -Go to step 16.

- 16. Turn the ignition switch OFF.
- 17. Disconnect TCM connector B (22P).
- 18. Check for continuity between CVT speed sensor connector terminal No. 1 and body ground.

# **CVT SPEED SENSOR CONNECTOR**



# Wire side of female terminals

G03681947

**Fig. 246: Checking Continuity Between CVT Speed Sensor Connector Terminal No. 1 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

Is there continuity?

**YES** -Repair a short to ground in the wire between TCM connector terminal B3 and the CVT speed sensor.

NO -Go to step 19.

- 19. Connect TCM connector B (22P).
- 20. Turn the ignition switch ON (II).
- 21. Measure the voltage between TCM connector terminals B3 and A4.

# **TCM CONNECTORS**



Wire side of female terminals

G03681948

### **Fig. 247: Measuring Voltage Between TCM Connector Terminals B3 And** <u>A4</u> **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there about 5 V?

**YES** -Repair an open in the wire between TCM connector terminal B3 and the CVT speed sensor.

**NO** -Check for loose or poor connections at TCM connector terminal B3. If the connection is OK, substitute a known-good TCM (see <u>HOW TO</u> <u>**TROUBLESHOOT CIRCUIT AT THE TCM**</u>), then recheck. If the symptom/indication goes away with a known-good TCM, replace the original TCM.

22. Measure the voltage between CVT speed sensor connector terminals No. 1 and No. 3.

# **CVT SPEED SENSOR CONNECTOR**



Wire side of female terminals

G03681949

**Fig. 248: Measuring Voltage Between CVT Speed Sensor Connector** <u>Terminals 1 And 3</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there about 5 V?* 

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

**YES** -Replace the CVT speed sensor (see **<u>SPEED SENSOR</u> <u>REPLACEMENT</u>**), then go to step 23.

**NO** -Repair an open in the wire between TCM connector terminal B16 and the CVT speed sensor.

- 23. Clear the DTC with the HDS.
- 24. Test-drive the vehicle for several minutes under the same conditions as those indicated by the freeze data.
- 25. Check that DTC P2160 recurs.

Is DTC P2160 indicated?

**YES** -Return to step 4 . and recheck. **NO** -Troubleshooting is complete.

### D INDICATOR CIRCUIT TROUBLESHOOTING

1. Turn the ignition switch ON (II), and watch the D indicator.

Does the D indicator come on and stay on?

YES -Go to step 2.

**NO** -If the light comes on for about 2 seconds and then goes off, it's OK. If it does not come on at all, go to step 12.

- 2. Make sure the Honda diagnostic system (HDS) is not connected to the DLC.
- 3. Turn the ignition switch OFF.
- 4. Disconnect TCM connector A (26P).
- 5. Turn the ignition switch ON (II).
- 6. Measure the voltage between TCM connector terminal A20 and body ground.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# TCM CONNECTOR A (26P)



Wire side of female terminals

G03681950

### **Fig. 249: Measuring Voltage Between TCM Connector A (26P) Terminal** <u>A20 And Body Ground</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there voltage?

**YES** -Repair a short to power in the wire between TCM connector terminal A20 and the gauge assembly.

NO -Go to step 7.

- 7. Turn the ignition switch OFF.
- 8. Reconnect TCM connector A (26P).
- 9. Turn the ignition switch ON (II).
- 10. Shift to any position other than the D position.

11. Measure the voltage between TCM connector terminal A9 and body ground.

# TCM CONNECTOR A (26P)



Wire side of female terminals

G03681951

### **Fig. 250: Measuring Voltage Between TCM Connector A (26P) Terminal** <u>A9 And Body Ground</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there voltage?

**YES** -Faulty TCM or the gauge assembly.

**NO** -Check for short to ground in the wire between TCM connector terminal A9 and the transmission range switch. If the wire is OK, check the transmission range switch.

12. Shift to the D position, and watch the D indicator.

Does the D indicator come on?

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

**YES** -Check for loose terminal fit in the TCM connectors, and recheck the D indicator several times. If the problem is intermittent, substitute a known-good TCM (see <u>HOW TO TROUBLESHOOT CIRCUIT AT</u> <u>THE TCM</u>), and recheck. If the light then works OK every time, replace the original TCM.

NO -Go to step 13.

- 13. Turn the ignition switch OFF.
- 14. Disconnect TCM connector A (26P).
- 15. Check for continuity between TCM connector terminal A4 and body ground, and between terminal A17 and body ground.



# **TCM CONNECTOR A (26P)**

G03681952

### Fig. 251: Checking Continuity Between TCM Connector Terminal A4, A17 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity between each terminal and ground?

**YES** -Go to step 16.

**NO** -Repair an open in the wire(s) between TCM connector terminal A4 or A17 and ground (G101), or repair poor ground (G101).

- 16. Turn the ignition switch ON (II).
- 17. Measure the voltage between TCM connector terminals A4 and A12, and between terminals A17 and A25.



Wire side of female terminals

G03681953

Fig. 252: Measuring Voltage Between TCM Connector Terminals A4 And A12 And Between Terminals A17 And A25 Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there battery voltage?

YES -Go to step 18.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

**NO** -Repair an open or short in the wire between TCM connector terminals A12 or A25 and the under-dash fuse/relay box.

- 18. Turn the ignition switch OFF.
- 19. Reconnect TCM connector A (26P).
- 20. Connect the multimeter between TCM connector terminals A20 and A4.

# TCM CONNECTOR A (26P)



Wire side of female terminals

G03681954

## **Fig. 253:** Connecting Multimeter Between TCM Connector A (26P) Terminals A20 And A4 Courtesy of AMERICAN HONDA MOTOR CO., INC.

21. Turn the ignition switch ON (II), and check for the voltage.

Is there voltage for at least 2 seconds?

**YES** -Check for an open in the wire between TCM connector terminal A20 and the gauge assembly. If the wire is OK, check for a faulty D indicator bulb or a faulty printed circuit board in the gauge assembly.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

**NO** -Go to step 22.

- 22. Turn the ignition switch OFF.
- 23. Disconnect TCM connector A (26P).
- 24. Check for continuity between TCM connector terminal A20 and gauge assembly connector terminal C10.

### TCM CONNECTOR A (26P) GAUGE ASSEMBLY CONNECTOR C (10P)



Wire side of female terminals

G03681955

# Fig. 254: Checking Continuity Between TCM Connector A (26P) Terminal A20 And Gauge Assembly Connector Terminal C10 Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** -Check for loose terminal fit in the TCM connectors. Check the transmission range switch. If necessary, substitute a known-good TCM (see **<u>HOW TO TROUBLESHOOT CIRCUIT AT THE TCM</u>**), and

recheck.

**NO** -Repair an open in the wire between TCM connector terminal A20 and gauge assembly.

### MODE SWITCH CIRCUIT TROUBLESHOOTING

SRS components are located in this area. Review the SRS component locations (see <u>COMPONENT LOCATION INDEX</u>), and the precautions and procedures (see <u>PRECAUTIONS AND PROCEDURES</u>) before performing repairs or service.

1. Test the mode switch (see **MODE SWITCH TEST** ).

Is the switch OK?

YES -Go to step 2.

**NO** -Replace the mode switch.

- 2. Connect the mode switch connector.
- 3. Remove the steering column covers, and disconnect cable reel 4P connector (see <u>CABLE REEL REPLACEMENT</u> ).
- 4. Check for continuity between cable reel 4P connector terminals No. 1 and No. 3 while pressing the S mode switch, and when the switch is released. Check for continuity between terminals No. 1 and No. 4 while pressing the D mode switch, and when the switch is released.

# **CABLE REEL 4P CONNECTOR**



# Terminal side of male terminals G03681956

### Fig. 255: Checking Continuity Between Cable Reel 4P Connector <u>Terminals 1 And 3</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there continuity while pressing each switch, and no continuity when each switch is released?* 

YES -Go to step 5.

**NO** -Repair an open or short in the wire between the cable reel 4P connector and the switch connector, or replace the mode switch.

- 5. Turn the ignition switch ON (II).
- 6. Measure the voltage between cable reel 4P connector terminal No. 3 and body ground, and between terminal No. 4 and body ground.

# **CABLE REEL 4P CONNECTOR**



Wire side of female terminals G03681957

# **Fig. 256: Measuring Voltage Between Cable Reel 4P Connector Terminal 3 And Body Ground, And Between Terminal 4 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there about 10 V between each terminal and body ground?

**YES** -Repair an open in the wire between cable reel 4P connector terminal No. 1 and ground, or repair poor ground (G402).

**NO** -Go to step 7.

7. Measure the voltage between TCM connector terminals A21 and A4 for S mode switch circuit. Measure the voltage between terminals A24 and A 4 for D mode switch circuit.



Wire side of female terminals

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

### **Fig. 257: Measuring Voltage Between TCM Connector Terminals A21** And A4 Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there about 10 V?

**YES** -Repair an open or short in the S mode switch wire between TCM connector terminal A21 and the cable reel 4P connector, and repair open or short in the D mode switch wire between terminal A24 and the cable reel 4P connector.

**NO** -Replace the TCM.

### S INDICATOR CIRCUIT TROUBLESHOOTING

- 1. Turn the ignition switch ON (II).
- 2. Shift to the D position.
- 3. Measure the voltage between TCM connector terminals A18 and A4 with S mode position selected by turning S mode switch on.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# TCM CONNECTOR A (26P)



Wire side of female terminals

G03681959

### **Fig. 258: Measuring Voltage Between TCM Connector Terminals A18 And A4 Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there about 10 V?

YES -Go to step 4.

NO -Go to step 5.

4. Measure the voltage between gauge assembly connector terminal B1 and body ground.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



Wire side of female terminals

G03681960

## **Fig. 259: Measuring Voltage Between Gauge Assembly Connector B (22P) Terminal B1 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there 10 V?

**YES** -Check for blown S indicator bulb. If the indicator bulb is OK, check for loose terminal fit in the TCM and gauge assembly connectors. If necessary, substitute a known-good TCM (see <u>HOW TO</u>

**TROUBLESHOOT CIRCUIT AT THE TCM**) or gauge assembly and recheck.

**NO** -Repair an open in the wire between TCM connector terminal A18 and the gauge assembly connector B(22P).

- 5. Turn the ignition switch OFF.
- 6. Disconnect TCM connector A (26P).
- 7. Disconnect gauge assembly connector B (22P).

8. Check for continuity between TCM connector terminal A18 and body ground.

# TCM CONNECTOR A (26P)



G03681961

# **Fig. 260:** Checking Continuity Between TCM Connector A (26P) Terminal A18 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** -Repair a short in the wire between TCM connector terminal A18 and the gauge assembly connector B (22P).

**NO** -Check for loose terminal fit in the TCM and gauge assembly connectors. If necessary, substitute a known-good TCM (see <u>HOW TO</u> <u>**TROUBLESHOOT CIRCUIT AT THE TCM**</u>) or gauge assembly and recheck.
2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

#### CREEP AID SYSTEM SOLENOID VALVE A AND B TROUBLESHOOTING

- 1. Turn the ignition switch OFF.
- 2. Raise the front and rear of the vehicle, and make sure it is securely supported.
- 3. Disconnect the creep aid system solenoid connector.
- 4. Check for creep aid system solenoid valve A operation by connecting the battery positive terminal to creep aid system solenoid connector terminal No. 2, and connecting the battery negative terminal to the connector terminal No. 4. Check for the solenoid valve B operation with connecting the battery positive terminal to the connector terminal No. 1, and connecting the connector terminal No. 3.

# CREEP AID SYSTEM SOLENOID VALVE A AND B CONNECTOR



## Terminal side of male terminals

G03681962

## **Fig. 261: Checking Operation Of Creep Aid System Solenoid Valve A** Courtesy of AMERICAN HONDA MOTOR CO., INC.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

Is a clicking sound heard when connecting battery terminals?

**YES** -Go to step 5.

NO -Replace the creep aid system solenoid valves A and B.

- 5. While connecting the battery positive terminal to the connector terminals No. 1 and No. 2, and connecting the battery negative terminal to the connector terminal No. 2 and No. 4, press the brake pedal.
- 6. Release the brake pedal, and check the application of the brake by rotating the wheel by hand. Repeat the same test for all wheels. All the wheels should stay locked for 1 second after the brake pedal released.

# CREEP AID SYSTEM SOLENOID VALVE A AND B CONNECTOR



Terminal side of male terminals

G03681963

## **Fig. 262: Checking Application Of Brake** Courtesy of AMERICAN HONDA MOTOR CO., INC.

Do the brakes operate properly?

**YES** -The brake system and the creep aid system operate properly. **NO** -The brakes on the right front wheel and the left rear wheel or on the left front wheel and right rear wheel drag, replace the creep aid system valve body. If the brake on the one of the wheels or all wheels drag, inspect the brake system.

#### ROAD TEST

## **Special Tools Required**

## Backprobe set 07SAZ-001000A (two required)

- 1. Warm up the engine to normal operating temperature (the radiator fan comes on).
- 2. Apply parking brake, and block rear wheels. Start the engine, then shift to the D position while pressing the brake pedal. Press the accelerator pedal, and release it suddenly. The engine should not stall.
- 3. Connect the Honda diagnostic system (HDS), and go to the PGM-FI Data List; then go to step 8 . If you don't have a HDS, go to step 4.
- 4. Remove the passenger's carpet, then remove the right kick panel.
- 5. Remove the mounting bolts securing the EPS control unit, but do not disconnect the EPS control unit connectors, then remove the TCM cover (A).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



6. Remove the TCM (B).

G03681964

#### **Fig. 263: Identifying Loosening Torque Of EPS Control Unit Mounting Bolts Courtesy of AMERICAN HONDA MOTOR CO., INC.**

- 6. Remove the TCM (B).
- 7. Connect a digital multimeter (A) and the special tools (B) to check voltage between TCM connector terminals B4and A4.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



**TCM CONNECTORS** 



Wire side of female terminals

G03681965

#### **Fig. 264: Checking Voltage Between TCM Connector Terminals B4 And** <u>A4</u> **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

# 8. Test-drive the vehicle on a flat road in the position shown. While driving, check that the engine speeds meet the approximate vehicle speeds shown in the

## **D** Position with **D** mode: Engine Speed RPM

table.

Throttle Opening	Vehicle Speed	Engine Speed (RPM)
Throttle position sensor voltage: 0.75	25 mph (40 km/h)	1,000-1,400
V	37 mph (60 km/h)	1,117-1,517
Throttle position sensor voltage: 2.0 V	25 mph (40 km/h)	2,150-2,750
	37 mph (60 km/h)	2,360-2,960
	62 mph (100 km/h)	2,650-3,250
Throttle position sensor voltage: 4.5 V	25 mph (40 km/h)	3,570-4,170
	37 mph (60 km/h)	4,170-4,770
	62 mph (100 km/h)	4,950-5,550

## **D POSITION WITH D MODE - ENGINE SPEED RPM**

## S Position with S mode: Engine Speed RPM

## S POSITION WITH S MODE - ENGINE SPEED RPM

Throttle Opening	Vehicle Speed	Engine Speed (RPM)
Throttle position sensor voltage: 0.75 V	25 mph (40 km/h)	1,700-2,300
	37 mph (60 km/h)	2,300-2,900
	62 mph (100 km/h)	3,400-4,000
	25 mph (40 km/h)	2,500-3,100

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

Throttle position sensor voltage: 2.0 V	37 mph (60 km/h)	2,800-3,400
	62 mph (100 km/h)	3,700-4,300
Throttle position sensor voltage: 4.5 V	25 mph (40 km/h)	4,475-5,075
	37 mph (60 km/h)	5,050-5,650
	62 mph (100 km/h)	5,200-5,800

## L Position: Engine Speed RPM

## L POSITION - ENGINE SPEED RPM

Throttle Opening	Vehicle Speed	Engine Speed (RPM)
Throttle position sensor voltage: 0.75 V	25 mph (40 km/h)	2,930-3,530
	37 mph (60 km/h)	3,620-4,220
	62 mph (100 km/h)	4,340-4,940
Throttle position sensor voltage: 2.0 V	25 mph (40 km/h)	3,460-4,060
	37 mph (60 km/h)	4,060-4,660
	62 mph (100 km/h)	4,692-5,292
Throttle position sensor voltage: 4.5 V	25 mph (40 km/h)	4,475-5,075
	37 mph (60 km/h)	5,050-5,650
	62 mph (100 km/h)	5,200-5,800

#### STALL SPEED TEST

- 1. Make sure the transmission fluid is filled to the proper level (see <u>CVT FLUID</u> <u>LEVEL CHECK</u>).
- 2. Apply the parking brake, and block the front wheels.
- 3. Connect a tachometer to the engine, and start the engine.
- 4. Make sure the A/C switch is OFF.
- 5. After the engine has warmed up to normal operating temperature (the radiator

fan comes on), shift to the D position.

- 6. Fully press the brake pedal and accelerator pedal for 6 to 8 seconds, and note the engine speed. Do not move the shift lever while raising the engine speed.
- 7. Allow 2 minutes for cooling, then repeat the test in the L and R positions.
  - NOTE: Do not test stall speed for more than 10 seconds at a time.
    - Stall speed tests should be used for diagnostic purposes only.
    - Stall speed tests should be the same in the D, L, and R positions.
    - Do not test stall speed with the A/T pressure gauges installed.

**Stall Speed RPM** 

Specification: 2,500 RPM

## Service Limit: 2,350-2,650 RPM

8. If the measurements are out of the service limit, problems and probable causes are listed in the table:

Problem	Probable cause
Stall speed RPM high in the D, L, and R positions	<ul> <li>ATF pump output low</li> <li>ATF pump defective</li> <li>Clogged ATF strainer</li> <li>Pressure high (PH) regulator valve stuck closed</li> <li>Slippage of forward clutch</li> <li>Start clutch defective</li> </ul>
Stall speed high in the R position	• Slippage of reverse brake

## DDADI EMG AND DDADADI E CALIGEG

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

	Start clutch defective
Stall speed low in the D, L, and R positions	<ul> <li>Engine output low</li> <li>Start clutch defective</li> </ul>
	• Pulley control valves A and B stuck

#### PRESSURE TEST

## **Special Tools Required**

- A/T high pressure gauge 07AAJ-PLYA100
- A/T pressure hose, 2,210 mm 07MAJ-PY4011A
- A/T pressure hose adapter 07MAJ-PY40120
- A/T oil pressure gauge set w/Panel 07406-0020400 or 07406-0020401
- A/T low pressure gauge 07406-0070300
- 1. Before testing, make sure the transmission fluid is filled to the proper level (see <u>CVT FLUID LEVEL CHECK</u>).
- 2. Lift the vehicle up on a hoist, or apply parking brake, block rear wheels, and raise the front of the vehicle. Make sure it is securely supported.
- 3. Allow the front wheels to rotate freely.
- 4. Remove the engine under cover on the transmission side.
- 5. Use the following special tools. Do not allow dust or other foreign particles to enter the ports while connecting the gauges.
  - NOTE: Drive pulley pressure and driven pulley pressure may be above 3.43 MPa (35.0 kgf/cm<sup>2</sup>, 498 psi) when there is a transmission problem that causes the TCM to go into fail-safe mode.
    - When troubleshooting you must use the A/T high pressure gauge (07AAJ-PLYA 100) when measuring drive pulley pressure and driven pulley

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

#### A/T OIL PRESSURE GAUGE SET W/PANEL 07406-0020400 or 07406-0020401



### A/T HIGH PRESSURE GAUGE 07AAJ-PLYA100



A/T LOW PRESSURE GAUGE 07406-0070300



A/T PRESSURE HOSE, 2,210 mm 07MAJ-PY4011A (4 Required)



A/T PRESSURE HOSE ADAPTER 07MAJ-PY40120 (4 Required)



G03681966

## **Fig. 265: Identifying Special Tools** Courtesy of AMERICAN HONDA MOTOR CO., INC.

6. Connect the gauge (07406-0020400 or 07406-0020401) to the reverse brake

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

#### pressure inspection port (A).



G03681967

## **Fig. 266: Identifying Reverse Brake Pressure Inspection Port** Courtesy of AMERICAN HONDA MOTOR CO., INC.

7. Connect the gauge (07406-0020400 or 07406-0020401) to the forward clutch pressure inspection port (B).

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03681968

## **Fig. 267: Identifying Forward Clutch Pressure Inspection Port Courtesy of AMERICAN HONDA MOTOR CO., INC.**

- 8. Connect the low pressure gauge (07406-0070300) to the lubrication pressure inspection port (C).
- 9. Connect the commercially available oil pressure gauges (specs described in step 6) to the drive pulley pressure inspection port (D) and the driven pulley pressure inspection port (E).
- 10. Warm up the engine (the radiator fan comes on), then turn off the engine, and connect the tachometer.
- 11. Start the engine, and run it at 1,500 RPM.
- 12. Shift to the D position, and measure the forward clutch pressure at the forward clutch pressure inspection port (B).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

## **Forward Clutch Pressure**

2001-2003 models

## Standard: 1.40-1.75 MPa

(14.3-17.8 kgf/cm<sup>2</sup>, 203-253 psi)

## 2004-2006 models

## Standard: 1.57-1.84 MPa

## (16.0-18.8 kgf/cm<sup>2</sup>, 228-267 psi)

13. Shift to the R position, and measure the reverse brake pressure at the reverse brake pressure inspection port (A).

## **Reverse Brake Pressure**

2001-2003 models

## Standard: 1.40-1.75 MPa

(14.3-17.8 kgf/cm<sup>2</sup>, 203-253 psi)

2004-2006 models

Standard: 1.57-1.84 MPa

## (16.0-18.8 kgf/cm<sup>2</sup>, 228-267 psi)

14. Shift to the N position, and measure the drive pulley pressure at the drive pulley pressure inspection port (D).

## **Drive Pulley Pressure**

Standard: 0.20-0.70 MPa

## (2.0-7.1 kgf/cm<sup>2</sup>, 29-101 psi)

15. Measure the driven pulley pressure at the driven pulley pressure inspection port (E).

## **Driven Pulley Pressure**

## Standard: 1.50-2.30 MPa

## (15.3-23.5 kgf/cm<sup>2</sup>, 218-334 psi)

16. Measure the lubrication pressure at the lubrication pressure inspection port (C) while holding engine speed at 3,000 RPM.

## **Lubrication Pressure**

## Standard: 0.20 MPa

## (2.0 kgf/cm<sup>2</sup>, 28 psi) or more

17. If the measurements are out of standard, problems and probable causes are listed in the table:

Problem	Probable causes
No or low forward clutch pressure	• Forward clutch defective
No or low reverse brake pressure	• Reverse brake defective
No or low drive pulley pressure	<ul> <li>ATF pump defective</li> <li>PH regulator valve defective</li> <li>Pulley control valve A defective</li> </ul>
	• Pulley control valve B defective
Drive nulley pressure too	<ul> <li>PH regulator valve defective</li> <li>Pulley control valve A defective</li> <li>Pulley control valve B defective</li> </ul>

## PROBLEM AND PROBABLE CAUSES

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

high	• CVT drive pulley pressure control valve defective
No or low driven pulley pressure	<ul> <li>ATF pump defective</li> <li>PH regulator valve defective</li> <li>Pulley control valve A defective</li> <li>Pulley control valve B defective</li> <li>CVT driven pulley pressure control valve defective</li> </ul>
Driven pulley pressure too high	• PH regulator valve defective
No or low lubrication pressure	<ul> <li>ATF pump defective</li> <li>Lubrication valve defective</li> </ul>

18. Install the sealing bolts with new sealing washers, and tighten the bolts to the specified torque.

Torque: 18 N.m (1.8 kgf.m, 13 lbf.ft)

## NOTE: Do not reuse old sealing washers.

19. Install the engine undercover.

#### SOLENOID VALVE TEST

1. Disconnect the solenoid harness connector (8P).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03681969

## **Fig. 268: Disconnecting Solenoid Harness Connector (8P) Courtesy of AMERICAN HONDA MOTOR CO., INC.**

2. Measure CVT drive pulley pressure control valve assembly resistance between solenoid harness connector terminals No. 3 and No. 7.

## Standard: 3.8-6.8 ohm

3. Measure CVT driven pulley pressure control valve assembly resistance between terminals No. 2 and No. 6.

## Standard: 3.8-6.8 ohm

4. Measure CVT start clutch pressure control valve assembly resistance between terminals No. 4 and No. 8.

## Standard: 3.8-6.8 ohm

5. Measure the inhibitor solenoid resistance between terminal No. 5 and body ground.

## Standard: 11.7-21.0

- 6. Replace the lower valve body assembly, if the measurement of any solenoid is out of standard.
- 7. If all of the resistances are within the standard, a clicking sound should be heard when connecting the battery terminals to the solenoid harness connector terminals.
  - CVT drive pulley pressure control valve assembly
  - No. 3 to battery positive terminal
  - No. 7 to battery negative terminal
  - CVT driven pulley pressure control valve assembly
  - No. 2 to battery positive terminal
  - No. 6 to battery negative terminal
  - CVT start clutch pressure control valve assembly

- No. 4 to battery positive terminal
- No. 8 to battery negative terminal
- Inhibitor solenoid
- No.5 to battery positive terminal and body ground to negative terminal
- 8. If no clicking sound is heard, remove the lower valve body assembly, and check the solenoid.

#### SPEED SENSOR REPLACEMENT

1. Disconnect the connectors from the CVT input shaft (drive pulley) speed sensor (A), the CVT output shaft (driven pulley) speed sensor (B), and the CVT speed sensor (C).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03681970

Fig. 269: Identifying Loosening Torque Of CVT Input Shaft (Drive Pulley) Speed Sensor, CVT Output Shaft (Driven Pulley) Speed Sensor, And CVT Speed Sensor Bolts And Torque Specifications

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

## Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 2. Remove the 6 mm bolts, then remove the speed sensors.
- 3. Replace the O-rings (D) with new ones before installing the speed sensors.
- 4. Install the CVT input shaft (drive pulley) speed sensor, CVT output shaft (driven pulley) speed sensor, and CVT speed sensor.
- 5. Check the speed sensor connectors for rust, dirt, or oil, then connect the connectors securely.

#### CREEP AID SYSTEM SOLENOID VALVE TEST

1. Disconnect the connector from the creep aid system solenoid valves A and B.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03681971

## **Fig. 270: Disconnecting Connector From Creep Aid System Solenoid** <u>Valves A And B</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

2. Measure the solenoid valve A resistance between the solenoid valve connector

terminals No. 2 and No. 4, and measure the solenoid valve B resistance between terminals No. 1 and No. 3.

## Standard: 8-24 ohm

- 3. If the resistance of either solenoid valve is out of the standard, replace the creep aid system solenoid valves A and B.
- 4. If the resistance is within the standard, connect the battery positive terminal to solenoid valve connector terminal No. 1, and connect the battery negative terminal to terminal No. 3. A clicking sound should be heard.

Connect the battery positive terminal to terminal No. 2, and connect the battery negative terminal to terminal No. 4. A clicking sound should be heard.

5. If no clicking sound is heard, replace creep aid system solenoid valves A and B.

#### START CLUTCH CALIBRATION PROCEDURES

When the following parts are replaced or removed, the TCM must memorize the feedback signal for the start clutch control.

- Battery
- Back-up fuse
- TCM
- Transmission assembly
- Lower valve body assembly
- Engine assembly replacement or overhaul
- Start clutch replacement.

There are two methods to calibrate the start clutch control using the Honda diagnostic system (HDS), or the SCS mode.

#### Calibration Procedure with the HDS

1. Connect the HDS to the DLC (A).

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03681972

#### **Fig. 271: Identifying Data Link Connector** Courtesy of AMERICAN HONDA MOTOR CO., INC.

2. Follow the tester's prompts in the Start Clutch Calibration Procedures (see the HDS Operator's manual).

Calibration Procedure with SCS mode

- 1. Apply parking brake, and block all four wheels securely.
- 2. Warm up the engine to normal operating temperature (the radiator fan comes on).
- 3. Make sure that the MIL does not come on and the D indicator does not blink.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

- 4. If the MIL comes on or the D indicator blinks, check the PGM-FI control system or the A/T control system.
- 5. Turn the ignition switch OFF.
- 6. Connect the HDS to the DLC, and follow the screen prompts to short-circuit the SCS signal terminal using the tester menu.
- 7. Press the brake pedal, and continue pressing the pedal until completion of the calibration.
- 8. Start the engine, and shift to the N position. Shift to the L position and return to the N position. Repeat this shifting three times within 20 seconds after the engine is started.
- 9. Check that the D indicator comes on for one minute with the shift lever in the N position, then goes off.
- 10. If the D indicator blinks, or the D indicator comes on, and stays on (it does not go off after one minute).

Turn the ignition switch OFF, restart the procedures with step 6.

- 11. Shift to the D position, and check that the D indicator light comes on for 2 minutes, then it goes off.
- 12. If the D indicator blinks, or the D indicator comes on, and stays on (it does not go off after 1 minute).

Turn the ignition switch OFF, restart the procedures with step 6.

- 13. Turn the ignition switch OFF to reach completion.
- 14. Test-drive the vehicle to verify that a problem does not occur on the start clutch control system.

#### MODE SWITCH TEST

1. Remove the screws securing the mode switch, then remove the switch.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03681973

## **Fig. 272: Identifying Mode Switch Connector Terminals Courtesy of AMERICAN HONDA MOTOR CO., INC.**

- 2. Disconnect the connector from the switch.
- 3. Check the S mode switch for continuity between connector terminals No. 2 and No. 3.

There should be continuity while pressing the S mode switch, and no continuity when the switch released.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

4. Check the D mode switch for continuity between connector terminals No. 1 and No. 3.

There should be continuity while pressing the D mode switch, and no continuity when the switch is released.

- 5. If either switch is faulty, replace it.
- 6. If the switch is OK, but switch failure occurred, check and repair the wire harness on the mode switch circuit.

#### MODE SWITCH REPLACEMENT

1. Remove the screws securing the mode switch, then remove the switch.

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03681974

## **Fig. 273: Removing Mode Switch** Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 2. Disconnect the connector from the switch.
- 3. Install the new mode switch.

#### CVT FLUID LEVEL CHECK

## **NOTE:** Keep all foreign particles out of the transmission.

- 1. Warm up the engine to normal operating temperature (the radiator fan comes on).
- 2. Park the vehicle on level ground, and turn the engine off.

# NOTE: Check the fluid level within 60-90 seconds after turning the engine off.

3. Remove the dipstick (yellow loop) (A) from the transmission, and wipe it with a clean cloth.

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03681975

## **Fig. 274: Identifying Dipstick** Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 4. Insert the dipstick back into the transmission.
- Remove the dipstick and check the fluid level in 60-90 seconds after the engines is turned off. It should be between the upper mark (A) and lower mark (B) on the Hot portion of the gauge (C). Do not check the fluid level when the engine is cold.

# NOTE: Some dipstick do not have HOT and COLD printed on them.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



**Fig. 275: Identifying Hot And Cold Mark On Dipstick** Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 6. If the level is below the lower mark, check for fluid leaks at the transmission, hose and line joints, and cooler lines.
- 7. if the level exceeds the upper mark (A), drain the fluid for proper level.
- 8. Pour the recommended fluid into the opening of the dipstick pipe (A) to bring it to the upper mark. Always use Honda Continuously Variable

Transmission Fluid (CVT Fluid). Using a non-Honda CVT Fluid can affect shift quality.

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03681977

## **Fig. 276: Identifying Opening Of Dipstick Pipe** Courtesy of AMERICAN HONDA MOTOR CO., INC.

9. Insert the dipstick back into the transmission.

#### **CVT FLUID REPLACEMENT**

## **NOTE:** Keep all foreign particles out of the transmission.

- 1. Bring the transmission up to normal operating temperature (the radiator fan comes on) by driving the vehicle.
- 2. Park the vehicle on level ground, and turn the engine off.
- 3. Remove the engine under cover on the transmission side.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

4. Remove the drain plug (A), and drain the continuously variable transmission fluid (CVTF).



G03681978

## **Fig. 277: Identifying Loosening Torque Of Drain Plug** Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 5. Reinstall the drain plug with a new sealing washer (B).
- 6. Remove the air cleaner housing.
- 7. Refill transmission with the recommended fluid into the filler hole (A) to the upper mark on the dipstick. Always use Honda Continuously Variable

Transmission Fluid (CVT Fluid). Using a non-Honda CVT Fluid can affect shift quality.

## **Continuously Variable Transmission Fluid**

- Capacity:
- 3.3 L (3.5 US qt) at change

## 5.5 L (5.8 US qt) at overhaul



G03681979

## **Fig. 278: Identifying Filler Hole And Torque Specifications Courtesy of AMERICAN HONDA MOTOR CO., INC.**

8. Check that the fluid level is between the upper mark (A) and lower mark (B)

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

on the COLD portion of the gauge.



G03681980

## **Fig. 279: Identifying Hot And Cold Mark On Dipstick** Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 9. Install the ATF filler bolt with a new sealing washer.
- 10. Insert the dipstick back into the transmission.
- 11. Warm up the engine to normal operating temperature (the radiator fan comes on).
- 12. Check that the fluid level is between the upper mark (C) and lower mark (A) on HOT level.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

13. Install the air cleaner housing, and install the engine cover.

#### LOWER VALVE BODY ASSEMBLY REPLACEMENT

- 1. Raise the front of the vehicle, and make sure it is securely supported.
- 2. Apply the parking brake, and block the rear wheels securely.
- 3. Remove the air cleaner housing.
- 4. Disconnect the solenoid harness connector (8P).
- 5. Remove the engine under cover on the transmission housing.
- 6. Remove the drain plug (A), and drain the continuously variable transmission fluid (CVT Fluid). Reinstall the drain plug with a new sealing washer (B).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03681981

#### **Fig. 280: Identifying Loosening Torque Of Drain Plug** Courtesy of AMERICAN HONDA MOTOR CO., INC.

7. Remove the ATF cooler inlet hose (A) from the ATF cooler inlet line (B). Turn the end of the ATF cooler inlet hose up to prevent CVT Fluid from flowing out, and plug the ATF cooler hose and line.
2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03681982

## **Fig. 281: Removing ATF Cooler Inlet Hose From ATF Cooler Inlet Line Courtesy of AMERICAN HONDA MOTOR CO., INC.**

8. Remove the bolt (A) securing the ATF cooler inlet line (B) on the transmission.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03681983

**Fig. 282: Identifying Loosening Torque Of Bolt Securing ATF Cooler Inlet Line On Transmission Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

- 9. Remove the ATF pan (C).
- 10. Remove the ATF strainer (D).
- 11. Remove the lower valve body assembly (E), and remove the bolt (F) securing the solenoid harness connector (G) with holding the lower valve body assembly, then remove the harness connector and valve body assembly.
- 12. Replace the lower valve body assembly, and install it in the reverse order of removal.
- 13. Check the solenoid harness connector for rust, dirt, or oil, then connect the connector securely.
- 14. Refill the transmission with CVT Fluid (see <u>CVT FLUID</u> <u>REPLACEMENT</u>).
- 15. Install the engine under cover and the air cleaner housing.
- 16. Do the start clutch calibration procedure (see **<u>START CLUTCH</u>** <u>**CALIBRATION PROCEDURES**</u>).

### CVT START CLUTCH PRESSURE CONTROL VALVE REPLACEMENT

### 2004-2006 Models

- 1. Remove the lower valve body (see **LOWER VALVE BODY ASSEMBLY <u>REPLACEMENT</u> ).**
- 2. Disconnect the CVT start clutch pressure control valve connector (A).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03681984

### Fig. 283: Disconnecting CVT Start Clutch Pressure Control Valve Connector And Torque Specifications Courtesy of AMERICAN HONDA MOTOR CO., INC.

3. Remove the CVT start clutch pressure control valve (B).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

- 4. Check that the filter (C) is in good condition, replace it if it is clogged or damaged.
- 5. Install the new CVT start clutch pressure control valve with the dowel pins (D) and separator plate (E) on the lower valve body (F).
- 6. Connect the CVT start clutch pressure control valve connector.
- 7. Install the lower valve body (see <u>LOWER VALVE BODY ASSEMBLY</u> <u>REPLACEMENT</u>).

### CVT DRIVE PULLEY PRESSURE CONTROL VALVE REPLACEMENT

#### 2004-2006 Models

- 1. Remove the lower valve body (see **LOWER VALVE BODY ASSEMBLY <u>REPLACEMENT</u> ).**
- 2. Remove the solenoid harness clamp (A).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



### **Fig. 284: Removing Solenoid Harness Clamp And Torque Specifications Courtesy of AMERICAN HONDA MOTOR CO., INC.**

3. Disconnect the CVT drive pulley pressure control valve connector (B).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

- 4. Remove the seven bolts, and remove the CVT drive pulley pressure control valve (C). The CVT start clutch pressure control valve (D) also be removed, it uses those four bolts.
- 5. Check that the filter (E) is in good condition, replace it if it is clogged or damaged.
- 6. Install the new CVT drive pulley pressure control valve with the dowel pins (F) and separator plate (G), and CVT start clutch pressure control valve with the dowel pins (H) and separator plate (I) on the lower valve body (J).
- 7. Connect the CVT drive pulley pressure control valve connector.
- 8. Install the solenoid harness clamp.
- 9. Install the lower valve body (see <u>LOWER VALVE BODY ASSEMBLY</u> <u>REPLACEMENT</u>).

### CVT DRIVEN PULLEY PRESSURE CONTROL VALVE REPLACEMENT

#### 2004-2006 Models

- 1. Remove the lower valve body (see **LOWER VALVE BODY ASSEMBLY <u>REPLACEMENT</u> ).**
- 2. Disconnect the CVT driven pulley pressure control valve connector (A) and the inhibitor solenoid connector (B).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03681986

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

## Fig. 285: Disconnecting CVT Driven Pulley Pressure Control Valve Connector And Inhibitor Solenoid Connector With Specified Torques Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 3. Remove the CVT driven pulley pressure control valve (C), and remove the inhibitor solenoid (D) from the CVT driven pulley pressure control valve.
- 4. Check that the filter (E) is in good condition, replace it if it is clogged or damaged.
- 5. Replace the O-rings (F) on the inhibitor solenoid, if necessary.
- 6. Install the inhibitor solenoid on the new CVT driven pulley pressure control valve.
- 7. Install the new CVT driven pulley pressure control valve with the dowel pins(G) and separator plate (H) on the lower valve body (I).
- 8. Connect the CVT driven pulley pressure control valve connector and the inhibitor solenoid connector.
- 9. Install the lower valve body (see <u>LOWER VALVE BODY ASSEMBLY</u> <u>REPLACEMENT</u>).

### INHIBITOR SOLENOID REPLACEMENT

2004-2006 Models

- 1. Remove the lower valve body (see **LOWER VALVE BODY ASSEMBLY <u>REPLACEMENT</u> ).**
- 2. Disconnect the inhibitor solenoid connector (A).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03681987

## **Fig. 286: Disconnecting Inhibitor Solenoid Connectors Courtesy of AMERICAN HONDA MOTOR CO., INC.**

- 3. Remove the inhibitor solenoid (B).
- 4. Install the new inhibitor solenoid on the CVT pulley pressure control valve.
- 5. Connect the inhibitor solenoid connector.
- 6. Install the lower valve body (see <u>LOWER VALVE BODY ASSEMBLY</u> <u>REPLACEMENT</u>).

TRANSMISSION REMOVAL

## **Special Tools Required**

Engine support hanger, A and Reds AAR-T-12566 These special tools are available through the Honda Tool and Equipment Program 1-888-424-6857

# NOTE:

- Use fender covers to avoid damaging painted surfaces.
  Special tool Reds engine support hanger AAR-T-12566 must be used with the side engine mount installed.
- 1. Before removing the transmission, read the Service Precautions for the IMA System (see <u>SERVICE PRECAUTIONS</u>).
- 2. Turn the battery module switch OFF, and measure the voltage at the junction board terminals (see <u>TURNING OFF POWER TO THE HIGH VOLTAGE</u> <u>CIRCUIT</u>).
- 3. Shift the shift lever into the N position.
- 4. Make sure you have the anti-theft code for the radio, then write down the audio presets.
- 5. Disconnect the battery negative terminal, then remove the positive terminal.
- 6. Remove the battery hold-down bracket, then remove the battery and battery tray.
- 7. Remove the engine cover, air cleaner housing, and resonator.
- 8. Remove the engine under cover and engine under cover bracket.
- 9. Remove the drain plug (A), and drain the continuously variable transmission fluid (CVTF). Reinstall the drain plug with a new sealing washer (B).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03681988

### **Fig. 287: Identifying Loosening Torque Of Drain Plug Courtesy of AMERICAN HONDA MOTOR CO., INC.**

10. Remove the starter cable, then remove the starter.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03681989

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

## **Fig. 288: Removing Starter** Courtesy of AMERICAN HONDA MOTOR CO., INC.

 Disconnect the CVT input shaft (drive pulley) speed sensor connector (A), solenoid harness connector (8P) (B), and remove the transmission ground cable (C).



G03681990

## **Fig. 289: Disconnecting CVT Input Shaft (Drive Pulley) Speed Sensor** <u>Connector, Solenoid Harness Connector (8P)</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

12. Loosen the locknut (A) on the shift cable (B).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03681991

## **Fig. 290: Loosening Locknut On Shift Cable** Courtesy of AMERICAN HONDA MOTOR CO., INC.

13. Remove the spring clip (C) and washers (D), and separate the shift cable from

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

the control lever (E) and the shift cable bracket (F). Do not bend the shift cable excessively.

- 14. Remove the shift cable bracket.
- 15. Remove the harness clamps (A) from the clamp brackets (B), and remove the transmission range switch connector (C) from the connector bracket, then disconnect it.



G03681992

### **Fig. 291: Disconnecting Transmission Range Switch Connector** Courtesy of AMERICAN HONDA MOTOR CO., INC.

Disconnect the vehicle speed sensor connector (D), CVT speed sensor connector (E), and CVT output shaft (driven pulley) speed sensor connector (F).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

17. Remove the front and upper transmission housing mounting bolts.



G03681993

Fig. 292: Removing Front And Upper Transmission Housing Mounting

## **Bolts Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Remove the spindle nut (A), and tap the driveshaft inward with a plastic hammer to allow the special tool on the lower arm ball joint (see <u>KNUCKLE/HUB/HUB BEARING UNIT REPLACEMENT</u>).



G03681994

## **Fig. 293: Removing Spindle Nut** Courtesy of AMERICAN HONDA MOTOR CO., INC.

19. Remove the cotter pins (B) and castle nuts (C), and separate the lower arms (D) from the knuckles (E) (see step 10 on **FRONT SUSPENSION** ).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

20. Remove the driveshafts from the differential (see step 10 on **DRIVELINE/AXLE** ).



G03681995

### **Fig. 294: Removing Driveshafts From Differential** Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 21. Remove the driveshafts. Coat all precision finished surfaces with clean engine oil, then tie the plastic bags over the driveshaft ends.
- 22. Remove the ATF cooler hoses (A) from the ATF cooler lines (B). Turn the ends of the ATF cooler hoses up to prevent CVTF from flowing out, then plug the ATF cooler hoses and lines. Check for any signs of leakage at the hose joints.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03681996

## **Fig. 295: Removing ATF Cooler Hoses From ATF Cooler Lines Courtesy of AMERICAN HONDA MOTOR CO., INC.**

23. Remove the rear mount/bracket.

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03681997

## **Fig. 296: Removing Rear Mount/Bracket** Courtesy of AMERICAN HONDA MOTOR CO., INC.

24. Remove the eight drive plate bolts at the opening of the starter while rotating the engine crankshaft pulley.



G03681998

## **Fig. 297: Removing Drive Plate Bolt** Courtesy of AMERICAN HONDA MOTOR CO., INC.

25. Lift and support the engine assembly with an engine hanger (P/N AAR-T-

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

1256). Raise the transmission just enough to take the weight off of the mounts.



G03681999

### **Fig. 298: Supporting Engine Assembly With Engine Hanger** Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 26. Place a jack under the transmission.
- 27. Remove the transmission ground cable from the transmission mount bracket, and remove the transmission mount bracket.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682000

### **Fig. 299: Removing Transmission Mount Bracket** Courtesy of AMERICAN HONDA MOTOR CO., INC.

28. Remove the heat shield (A) and exhaust manifold bracket (B), then remove the lower transmission housing mounting bolts.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682001

### **Fig. 300: Removing Heat Shield And Exhaust Manifold Bracket Courtesy of AMERICAN HONDA MOTOR CO., INC.**

- 29. Pull the transmission away from the engine until it clears the dowel pins, then lower it on the jack.
- 30. Remove the flywheel from the transmission.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682002

### **Fig. 301: Removing Flywheel From Transmission** Courtesy of AMERICAN HONDA MOTOR CO., INC.

31. Inspect the drive plate and replace it if it is damaged.

#### DRIVE PLATE REMOVAL AND INSTALLATION

- 1. Remove the transmission assembly (see **TRANSMISSION REMOVAL** ).
- 2. Remove the drive plate (A) and washer (B) from the engine crankshaft.

## 2001-2003 Models:



G03682003

**Fig. 302: Identifying Loosening Torque Of Drive Plate Bolts (2001-2003** <u>Models)</u> **Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

2004-2006 Models:

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682004

### Fig. 303: Identifying Loosening Torque Of Drive Plate Bolts (2004-2006 Models) Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 3. Install the drive plate, and install the washer in the direction shown on the engine crankshaft.
- 4. Tighten the six bolts in a crisscross pattern.
- 5. Install the transmission assembly (see **TRANSMISSION INSTALLATION** ).

#### TRANSMISSION INSTALLATION

### **Special Tools Required**

Engine support hanger, A and Reds AAR-T-12566 These special tools are available

through the Honda Tool and Equipment Program 1-888-424-6857

## **NOTE:** Use fender covers to avoid damaging painted surfaces.

- 1. Clean the ATF cooler (see <u>ATF COOLER CLEANING</u>).
- 2. Remove the used grease in the flywheel hub cap and flywheel splines.
- 3. Push out about 2 grams (0.07 oz.) of super high temp area grease (P/N 08798-9002) using a ruler. One gram equals 40 mm of ruler length.



G03682005

**Fig. 304: Identifying Dimension Of 2 Gram Grease** Courtesy of AMERICAN HONDA MOTOR CO., INC.

4. Fill the inside of the flywheel hub cap (A) with the measured grease. Do not use more than 2.5 gram (0.086 oz.) or you will damage the transmission.



## **Fig. 305: Identifying Flywheel Hub Cap** Courtesy of AMERICAN HONDA MOTOR CO., INC.

5. Install a new rubber sealing ring (A) on the input shaft (B), and install the 14 mm dowel pins (C) in the flywheel housing.



G03682007

## **Fig. 306: Installing Rubber Sealing Ring On Input Shaft** Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 6. Install the flywheel (D) on the input shaft.
- 7. Place the transmission on a jack, and raise it to the engine level.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

8. Install the lower transmission housing mounting bolts.



Fig. 307: Identifying Loosening Torque Of Lower Transmission Housing Mounting Bolts Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 9. Install the exhaust manifold bracket (A) and heat shield (B).
- 10. Install the transmission mount bracket (A). Tighten the bolt (B) loosely, and tighten the nuts (C) to the specified torque, then tighten the bolt to the specified torque.



G03682009

## Fig. 308: Identifying Tightening Torque Of Transmission Mount Bracket Bolts

## Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 11. Install the transmission ground cable (D) on the transmission mount bracket.
- 12. Install the front and upper transmission housing mounting bolts.



G03682010

### **Fig. 309: Identifying Tightening Torque Of Upper Transmission Housing Mounting Bolts**

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

### Courtesy of AMERICAN HONDA MOTOR CO., INC.

13. Install the rear mount/bracket.



Fig. 310: Identifying Tightening Torque Of Rear Mount/Bracket Bolts

## **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

- 14. Remove the engine hanger.
- 15. Attach the flywheel to the drive plate with eight bolts. Rotate the crankshaft pulley as necessary to tighten the bolts to 1/2 of the specified torque, then to the final torque, in a crisscross pattern. After installing the last bolt, check that the crankshaft rotate freely.



G03682012

**Fig. 311: Identifying Tightening Torque Of Drive Plate Bolt** Courtesy of AMERICAN HONDA MOTOR CO., INC.
2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

16. Connect the ATF cooler hoses (A) to the ATF cooler lines (B) (see step 1).



G03682013

# **Fig. 312: Connecting ATF Cooler Hoses To ATF Cooler Lines Courtesy of AMERICAN HONDA MOTOR CO., INC.**

17. Install new set rings (A) on the driveshafts (B).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682014

# **Fig. 313: Installing Set Rings On Driveshafts** Courtesy of AMERICAN HONDA MOTOR CO., INC.

- Install the right and left driveshaft (see <u>DRIVESHAFT INSTALLATION</u>). While installing the driveshafts in the differential, be sure not to allow dust or other foreign particles to enter the transmission.
  - NOTE: Clean the areas where the driveshafts contact the transmission (differential) with solvent or carburetor cleaner, and dry with compressed air.
    Turn the right and left steering knuckle fully outward, and slide the driveshafts into the differential until you feel its set ring engages the side gear.

19. Connect the ball joints (A) to the knuckles (B), and install the castle nuts (C)

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

and new cotter pins (D).



G03682015

# **Fig. 314: Identifying Tightening Torque Of Castle Nuts** Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 20. Install the spindle nuts (E) on the driveshaft (see **DRIVESHAFT INSTALLATION** ).
- 21. Install the engine under cover and its bracket.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682016

# **Fig. 315: Identifying Tightening Torque Of Engine Under Cover Bolts** Courtesy of AMERICAN HONDA MOTOR CO., INC.

22. Connect the CVT output shaft (driven pulley) speed sensor connector (A), CVT speed sensor connector (B), and vehicle speed sensor connector (C).

### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682017

# Fig. 316: Connecting CVT Output Shaft (Driven Pulley) Speed Sensor Connector, CVT Speed Sensor Connector, And Vehicle Speed Sensor Connector Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 23. Connect the transmission range switch connector (D), and install it on the connector bracket, then install the harness clamps (E) on the brackets (F).
- 24. Install the shift cable bracket (A).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682018

# **Fig. 317: Identifying Tightening Torque Of Shift Cable Bracket Bolts Courtesy of AMERICAN HONDA MOTOR CO., INC.**

- 25. Install the shift cable end (B) on the control lever (C). Install the shift cable on its bracket, and tighten the locknut (D). Do not bend the shift cable excessively.
- 26. Install the plastic washer (E), then the steel washer (F), and install the spring

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

clip (G) in the direction shown.

27. Connect the solenoid harness connector (8P) (A) and CVT input shaft (drive pulley) speed sensor connector (B).



G03682019

# Fig. 318: Identifying Tightening Torque Of Transmission Ground Cable Bolt Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 28. Install the transmission ground cable (C).
- 29. Install the starter and starter cable.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682020

# **Fig. 319: Identifying Tightening Torque Of Starter And Starter Cable Bolts Courtesy of AMERICAN HONDA MOTOR CO., INC.**

- 30. Refill transmission with the recommended fluid into the filler hole (see  $\underline{CVT}$ <u>FLUID REPLACEMENT</u>).
- 31. Install the battery tray and battery, then secure the battery with its hold-down bracket.
- 32. Install the resonator and air cleaner housing.
- 33. Clean the battery posts and cable terminals with sandpaper.
- 34. Connect the battery terminals in the direction shown.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



# G03682021

# **Fig. 320: Identifying Direction For Connecting Battery Terminals** Courtesy of AMERICAN HONDA MOTOR CO., INC.

35. Apply grease to the battery terminals.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

- 36. Remove the No. 15 (40 A) fuse from the under-hood fuse/relay box.
- 37. If the IMA battery level gauge (BAT) displays no segments, start the engine, and hold it between 3,500 RPM and 4,000 RPM without load (in the P or N position) until the BAT displays at least three segments.
- 38. Reinstall the No. 15 (40 A) fuse from the under-hood fuse/relay box.
- 39. Check the ignition timing (see **IGNITION TIMING INSPECTION**).
- 40. Apply parking brake, and start the engine.
- 41. Shift the transmission through all gears three times, and check the shift lever operation, A/T gear position indicator operation, and shift cable adjustment.
- 42. Check and adjust the front wheel alignment (see WHEEL ALIGNMENT).
- 43. Start the engine and let it reach normal operating temperature (the radiator fan comes on) with the transmission in the P or N position, then turn it off and check the CVTF level (see <u>CVT FLUID LEVEL CHECK</u>).
- 44. Install the engine cover.
- 45. Remove the No. 15 (40 A) fuse from the under-hood fuse/relay box.
- 46. If the IMA battery level gauge (BAT) displays no segments, start the engine, and hold it between 3,500 RPM and 4,000 RPM without load (in the P or N position) until the BAT displays at least three segments.
- 47. Reinstall the No. 15 (40 A) fuse to the under-hood fuse/relay box.
- 48. Do the start clutch calibration procedures (see <u>START CLUTCH</u> <u>CALIBRATION PROCEDURES</u>).
- 49. Do the ECM idle learn procedure (see ECM IDLE LEARN PROCEDURE ).
- 50. Perform a road test (see **<u>ROAD TEST</u>**).
- 51. Enter the radio anti-theft code, then enter the audio presets, and set the clock.

# ATF COOLER CLEANING

# **Special Tools Required**

- ATF Cooler Cleaner GHTTTCF6H
- Magnetic Non bypass Spin-on Filter GTHGNBP2 These special tools are available through the Honda Tool and Equipment Program 1-888-424-6857

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

Before installing an overhauled or remanufactured automatic transmission, you must thoroughly clean the ATF cooler to prevent system contamination. Failure to do so could cause a repeat automatic transmission failure.

The cleaning procedure involves heated CVTF delivered under high pressure (100 psi). Check the security of all hoses and connections. Always wear safety glasses or a face shield, along with gloves and protective clothing. If you get CVTF in your eyes or on your skin, rinse with water immediately.

# WARNING: Improper use of the ATF cooler cleaner can result in burns and other serious injuries. Always wear eye protection and protective clothing, and follow this procedure.

1. Check the fluid in the cooler cleaner tank. (The fluid level should be 4.5 inches from the top of the filler neck.) Adjust the level if needed; do not overfill. Use only Honda CVTF; do not use any additives.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



# **Fig. 321: Checking Fluid In Cooler Cleaner Tank** Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 2. Plug the cooler cleaner into a 110 V grounded electrical outlet.
  - NOTE: Make sure the outlet has no other appliances (light fixtures, drop lights, extension cords) plugged into it. Also, never plug the cooler cleaner into an extension cord or drop light; you could damage the unit.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



# **Fig. 322: Plugging Cooler Cleaner Into 110 V Grounded Electrical Outlet Courtesy of AMERICAN HONDA MOTOR CO., INC.**

3. Flip the HEAT toggle switch to ON; the green indicator above the toggle switch comes on. Wait 1 hour for the cooler cleaner to reach its operating temperature. (The cooler cleaner is ready to use when the temperature gauge reads 140 to 150°F.)

# **NOTE:** If the red indicator above the HEAT toggle switch

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# comes on, the fluid level in the tank is too low for the tank heater to work (see step 1 . of this procedure).

4. Select the appropriate pair of fittings, and attach them to the radiator, to the hoses, or to the banjo bolts for flow through the ATF cooler cleaner.



G03682024

# **Fig. 323:** Attaching Fittings To Radiator Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 5. Connect the red hose to the cooler outlet line (the line that normally goes to the external filter on the transmission).
- 6. Connect the blue hose to the cooler inlet line.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

- 7. Connect a shop air hose (regulated to 100 to 125 psi) to the air purge valve.
  - NOTE: The quick-connect fitting has a one-way check valve to keep CVTF from entering your shop's air system. Do not remove or replace the fitting. Attach the coupler provided with the cooler cleaner to your shop air line if your coupler is not compatible.
- 8. Flip the MOTOR toggle switch to ON; the green indicator above the toggle switch comes on. Let the pump run for 5 minutes. While the pump is running, open and close the air purge valve periodically to cause agitation and improve the cleaning process. Always open the valve slowly. At the end of the 5-minutes cleaning period, leave the air purge valve open.
  - NOTE: While the pump is running with the air purge valve open, it is normal to see vapor coming from the filler/breather tube vents.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682025

# **Fig. 324: Opening Air Purge Valve** Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 9. With the air purge valve open, flip the MOTOR toggle switch to OFF; the green indicator goes off. Leave the air purge valve open for at least 15 seconds to purge the lines and hoses of residual CVTF, then close the valve.
- 10. Disconnect the red and blue hoses from the ATF cooler. Now connect the red hose to the cooler inlet line.
- 11. Now connect the blue hose to the cooler outlet line.
- 12. Flip the MOTOR toggle switch to ON, and let the pump run for 5 minutes. While the pump is running, open and close the air purge valve periodically. Always open the valve slowly. At the end of the 5-minutes cleaning period, leave the air purge valve open.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# NOTE: While the pump is running with the air purge valve open, it is normal to see vapor coming from the filler/breather tube vents.

- 13. With the air purge valve open, flip the MOTOR toggle switch to OFF. Leave the air purge valve open for at least 15 seconds to purge the lines and hoses of residual CVTF, then close the valve.
- 14. Disconnect the red and blue hoses from the ATF cooler lines.
- 15. Connect the red and blue hoses to each other.
- 16. Disconnect the shop air from the air purge valve. Disconnect and stow the coupler if used.
- 17. Disconnect and stow the fittings from the ATF cooler inlet and outlet lines.
- 18. Unplug the cooler cleaner from the 110 V outlet.

### **Tool Maintenance**

Follow these instructions to keep the ATF cooler cleaner working properly:

- Replace the two magnetic non bypass spin-on filters once a year or when you notice a restriction in the CVTF flow.
- Check the level and condition of the fluid in the tank before each use.
- Replace the CVTF in the tank when it looks dark or dirty.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682026

# **Fig. 325: View Of ATF Cooler Cleaner** Courtesy of AMERICAN HONDA MOTOR CO., INC.

### ATF COOLER HOSE REPLACEMENT

1. Lubricate hose and line joints with CVTF, then install the ATF cooler hoses (A) to the ATF cooler lines (B).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682027

# **Fig. 326: Installing ATF Cooler Hoses To ATF Cooler Lines Courtesy of AMERICAN HONDA MOTOR CO., INC.**

2. Secure the ATF cooler hoses with the clips (C) in the position shown.

### SHIFT LEVER REMOVAL

- 1. Remove the front console (see **FRONT CONSOLE REMOVAL/INSTALLATION** ).
- 2. Shift the transmission into the R position.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

3. Remove the nut securing the shift cable end, then separate the cable end from the shift lever.



G03682028

**Fig. 327: Separating Cable From Shift Lever** Courtesy of AMERICAN HONDA MOTOR CO., INC.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

4. Rotate the socket holder (A) on the shift cable (B) a quarter turn; the projection (C) on the socket holder faces direction to remove. Then slide the holder to remove the shift cable from the shift cable bracket base (D). Do not remove the shift cable by twisting the shift cable guide (E).



G03682029

# **Fig. 328: Removing Shift Cable From Shift Cable Bracket Courtesy of AMERICAN HONDA MOTOR CO., INC.**

5. Disconnect the shift lock solenoid connector (A) and park pin switch/indicator lamp connector (B).

### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682030

# **Fig. 329: Removing Shift Lever Assembly** Courtesy of AMERICAN HONDA MOTOR CO., INC.

6. Remove the shift lever assembly.

### SHIFT LEVER INSTALLATION

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

1. Install the shift lever assembly.



G03682031

Fig. 330: Identifying Tightening Torque Of Shift Lever Assembly Bolts

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

- 2. Turn the ignition switch ON (II), and verify that the R position indicator comes on.
- 3. If necessary, push the shift cable (A) until it stops, then release it. Pull the shift cable back one step so that the shift position is in the R position. Do not push and pull the shift cable by holding the shift cable guide (B).



# **Fig. 331: Pushing And Pulling Shift Cable** Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 4. Turn the ignition switch OFF.
- 5. Insert a 6.0 mm (0.24 in.) pin (A) through the positioning hole (B) on the shift lever bracket base and into the positioning hole (C) on the shift lever. The shift lever is secured in the R position.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682033

# **Fig. 332: Inserting Pin Through Positioning Hole On Shift Lever Bracket Base And Into Positioning Hole Courtesy of AMERICAN HONDA MOTOR CO., INC.**

6. Align the socket holder (A) on the shift cable (B) with the slot in the bracket base (C), then slide the holder into the base. Install the shift cable end (D) over the mounting stud (E) by aligning its square hole (F) with the square fitting (G) at the bottom of the stud. Rotate the holder a quarter turn to secure the shift cable. Do not install the shift cable by twisting the shift cable guide (H).

### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



# **Fig. 333: Installing Shift Cable** Courtesy of AMERICAN HONDA MOTOR CO., INC.

7. Verify that the shift cable end (A) is properly installed on the mounting stud (B).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# **Properly Installed:**





# **Improperly Installed:**



Cable end rides on the bottom of the mounting stud.

G03682035

# **Fig. 334: Identifying Proper And Improper Installed Shift Cable Courtesy of AMERICAN HONDA MOTOR CO., INC.**

- 8. If improperly installed, remove the shift cable from the shift cable bracket base, and reinstall the shift cable. Do not install the shift cable end on the mounting stud while the shift cable is on the shift cable bracket base.
- 9. Install and tighten the nut.

### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682036

# **Fig. 335: Identifying Tightening Torque Of Shift Cable Nut Courtesy of AMERICAN HONDA MOTOR CO., INC.**

- 10. Remove the 6.0 mm (0.24 in.) pin that was installed to hold the shift lever.
- 11. Connect the shift lock solenoid connector and park pin switch/indicator lamp connector.
- 12. Move the shift lever to each position, and verify that the A/T gear position indicator follows the transmission range switch.
- 13. Push the shift lock release, and verify that the shift lever releases.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# 14. Reinstall the front console (see **FRONT CONSOLE <u>REMOVAL/INSTALLATION</u> ).**

### SHIFT LEVER DISASSEMBLY/REASSEMBLY



G03682037

# **Fig. 336: Exploded View Of Shift Lever And Torque Specifications Courtesy of AMERICAN HONDA MOTOR CO., INC.**

### SHIFT CABLE REPLACEMENT

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

- 1. Remove the front console (see **FRONT CONSOLE REMOVAL/INSTALLATION** ).
- 2. Shift the transmission into the R position.
- 3. Remove the nut securing the shift cable end, then separate the cable end from the shift lever.

### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682038

# **Fig. 337: Separating Cable End From Shift Lever** Courtesy of AMERICAN HONDA MOTOR CO., INC.

4. Rotate the socket holder (A) on the shift cable (B) a quarter turn; the projection (C) on the socket holder faces direction to remove. Then slide the holder to remove the shift cable from the shift cable bracket base (D).

### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682039

# **Fig. 338: Removing Shift Cable From Shift Cable Bracket Base Courtesy of AMERICAN HONDA MOTOR CO., INC.**

5. Remove the shift cable bracket (A) in the cabin, under the dash.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



6 x 1.0 mm 12 N·m (1.2 kgf·m, 8.7 lbf·ft)

G03682040

# **Fig. 339: Identifying Loosening Torque Of Shift Cable Bracket Bolt Courtesy of AMERICAN HONDA MOTOR CO., INC.**

- 6. Remove the air cleaner housing.
- 7. Loosen the locknut (A) on the shift cable (B).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682041

# Fig. 340: Separating Shift Cable From Control Lever And Shift Cable Bracket Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 8. Remove the spring clip (C) and washers (D), and separate the shift cable from the control lever (E) and the shift cable bracket (F).
- 9. Remove the grommet, and pull the shift cable out.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682042

# **Fig. 341: Removing Shift Cable** Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 10. Insert the new shift cable through the grommet hole, then install the grommet.
- 11. Verify that the transmission is in the R position on the control lever.
- 12. Install the shift cable end (A) on the control lever (B). Install the shift cable on its bracket (C), and tighten the locknut (D). Do not bend the shift cable

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

excessively.



G03682043

# **Fig. 342: Identifying Tightening Torque Of Lock Nut** Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 13. Install the plastic washer (E), then the steel washer (F), and install the spring clip (G) in the direction shown.
- 14. Turn the ignition switch ON (II), and verify that the R position indicator comes on.
- 15. If necessary, push the shift cable (A) until it stops, then release it. Pull the shift
2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

cable back one step so that the shift position is in the R position. Do not push and pull the shift cable by holding the shift cable guide (B).



# **Fig. 343: Pushing And Pulling Shift Cable** Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 16. Turn the ignition switch OFF.
- 17. Insert a 6.0 mm (0.24 in.) pin (A) through the positioning hole (B) on the shift lever bracket base and into the positioning hole (C) on the shift lever. The shift lever is secured in the R position.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682045

# **Fig. 344: Inserting Pin Through Positioning Hole On Shift Lever Bracket Base And Into Positioning Hole Courtesy of AMERICAN HONDA MOTOR CO., INC.**

18. Align the socket holder (A) on the shift cable (B) with the slot in the bracket base (C), then slide the holder into the base. Install the shift cable end (D) over the mounting stud (E) by aligning its square hole (F) with the square fitting (G) at the bottom of the stud. Rotate the holder a quarter turn to secure the shift

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

cable. Do not install the shift cable by twisting the shift cable guide (H).



G03682046

# **Fig. 345: Installing Shift Cable** Courtesy of AMERICAN HONDA MOTOR CO., INC.

19. Verify that the shift cable end (A) is properly installed on the mounting stud (B).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# **Properly Installed:**





**Improperly Installed:** 



Cable end rides on the bottom of the mounting stud.

G03682047

# **Fig. 346: Identifying Proper And Improperly Installed Shift Cable Courtesy of AMERICAN HONDA MOTOR CO., INC.**

- 20. If improperly installed, remove the shift cable from the shift cable bracket base, and reinstall the shift cable. Do not install the shift cable end on the mounting stud while the shift cable is on the shift cable bracket base.
- 21. Install and tighten the nut.

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682048

# **Fig. 347: Identifying Tightening Torque Of Shift Cable Nut** Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 22. Remove the 6.0 mm (0.24 in.) pin that was installed to hold the shift lever.
- 23. Move the shift lever to each position, and verify that the A/T gear position indicator follows the transmission range switch.
- 24. Allow the wheels to rotate freely.
- 25. Start the engine, and check the shift lever operation in all gears.
- 26. Reinstall the front console (see **FRONT CONSOLE <u>REMOVAL/INSTALLATION</u> ).**

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

#### SHIFT CABLE ADJUSTMENT

- 1. Remove the front console (see **FRONT CONSOLE <u>REMOVAL/INSTALLATION</u> ).**
- 2. Shift the transmission into the R position.
- 3. Remove the nut securing the shift cable end, then separate the cable end from the shift lever.

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682049

# **Fig. 348: Separating Cable End From Shift Lever** Courtesy of AMERICAN HONDA MOTOR CO., INC.

4. Rotate the socket holder (A) on the shift cable (B) a quarter turn; the projection (C) on the socket holder faces direction to remove. Then slide the holder to

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

remove the shift cable from the shift cable bracket base (D). Do not remove the shift cable by twisting the shift cable guide (E).



G03682050

# **Fig. 349: Removing Shift Cable** Courtesy of AMERICAN HONDA MOTOR CO., INC.

5. Push the shift cable (A) until it stops, then release it. Pull the shift cable back one step so that the shift position is in the R position. Do not push and pull the shift cable by holding the shift cable guide (B).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



# **Fig. 350: Pushing And Pulling Shift Cable** Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 6. Turn the ignition switch ON (II), and verify that the R position indicator light comes on.
- 7. Turn the ignition switch OFF.
- 8. Insert a 6.0 mm (0.24 in.) pin (A) through the positioning hole (B) on the shift lever bracket base and into the positioning hole (C) on the shift lever. The shift lever is secured in the R position.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682052

# **Fig. 351: Inserting Pin Through Positioning Hole On Shift Lever Bracket Base And Into Positioning Hole Courtesy of AMERICAN HONDA MOTOR CO., INC.**

9. Align the socket holder (A) on the shift cable (B) with the slot in the bracket base (C), then slide the holder into the base. Install the shift cable end (D) over the mounting stud (E) by aligning its square hole (F) with the square fitting (G) at the bottom of the stud. Rotate the holder a quarter turn to secure the shift cable. Do not install the shift cable by twisting the shift cable guide (H).

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682053

# **Fig. 352: Installing Shift Cable Courtesy of AMERICAN HONDA MOTOR CO., INC.**

10. Verify that the shift cable end (A) is properly installed on the mounting stud (B).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# **Properly Installed:**





**Improperly Installed:** 



Cable end rides on the bottom of the mounting stud.

G03682054

# **Fig. 353: Identifying Properly And Improperly Installed Shift Cable Courtesy of AMERICAN HONDA MOTOR CO., INC.**

- 11. If improperly installed, remove the shift cable from the shift cable bracket base, and reinstall the shift cable. Do not install the shift cable end on the mounting stud while the shift cable is on the shift cable bracket base.
- 12. Install and tighten the nut.

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682055

# **Fig. 354: Identifying Tightening Torque Of Shift Cable Nut** Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 13. Remove the 6.0 mm (0.24 in.) pin that was installed to hold the shift lever.
- 14. Move the shift lever to each position, and verify that the A/T gear position indicator follows the transmission range switch.
- 15. Allow the wheels to rotate freely.
- 16. Start the engine, and check the shift lever operation in all gears.
- 17. Reinstall the front console (see **FRONT CONSOLE <u>REMOVAL/INSTALLATION</u> ).**

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# A/T GEAR POSITION INDICATOR

## COMPONENT LOCATION INDEX



G03682056

# **Fig. 355:** A/T Gear Position Indicator Component Location Index Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

#### CIRCUIT DIAGRAM



G03682057

# **Fig. 356:** A/T Gear Position Indicator Circuit Diagram Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### **INDICATOR INPUT TEST**

1. If the D indicator or MIL has been reported on, check for a DTC, and repair the

system as indicated by the DTC.

- 2. If the D indicator does not come on, and the A/T gear position indicator light does not come on, remove the gauge assembly from the dashboard, then disconnect the gauge assembly connectors B (22P) and C (10P).
- 3. Inspect the connectors and connector terminals to be sure they are making good contact.
- 4. If the terminals are bent, loose, or corroded, repair them as necessary, and recheck the system.
- 5. Shift to the P position, and check for continuity between C1 terminal (BLU/BLK) and ground. There should be continuity in the P position and no continuity in any other shift lever position. If the test results are different, check for a faulty transmission range switch or an open in the wire.

# GAUGE ASSEMBLY CONNECTOR C (10P)



Wire side of female terminals

G03682058

**Fig. 357: Checking Continuity Between Gauge Assembly Connector C** (10P) Terminals And Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 6. Turn the ignition switch ON (II), and shift to the R position by pressing the brake pedal. Check for voltage between C2 terminal (WHT) and ground. There should be 0 V in the R position, and about 5 V in any other position. If the test results are different, check for a faulty transmission range switch or an open in the wire.
- 7. Shift to the N position, and check for continuity between C3 terminal (RED/BLK) and ground. There should be continuity in the N position and no continuity in any other position. If the test results are different, check for a faulty transmission range switch or an open in the wire.
- 8. Shift to the D position, and check for voltage between C10 terminal (GRN/BLK) and ground. There should be battery voltage in the D position, and 5 V in any other position. If the test results are different, check for faulty transmission range switch and TCM, or an open in the wire.
- 9. Shift to the L position, and check for voltage between C4 terminal (BLU) and ground. There should be 0 V in the L position, and about 5 V in any other position. If the test results are different, check for a faulty transmission range switch or an open in the wire.
- 10. Shift to the D position and check for voltage between B1 terminal (LT GRN) and ground. There should be 10 V while pressing the S mode switch and 0 V when the switch is released. If the test results are different, check for a faulty mode switch and TCM, or an open in the wire.



Wire side of female terminals

G03682059

# Fig. 358: Checking Continuity And Resistance Of Gauge Assembly Connector B (22P) Terminals And Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 11. Check for voltage between the B8 terminal (YEL) and ground. There should be battery voltage. If the test result is different, check for a blown No. 6 (7.5 A) fuse in the under-dash fuse/relay box or an open in the wire.
- 12. Check for continuity between the B16 terminal (BRN) and ground. There should be continuity under all conditions. If the test result is different, check for a poor ground (G401) or an open in the wire.
- 13. If the input test found nothing wrong, but the indicator is faulty, replace the printed circuit board.

## TRANSMISSION RANGE SWITCH TEST

- 1. Remove the air cleaner housing.
- 2. Remove the transmission range switch connector from the connector bracket, then disconnect it.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682060

**Fig. 359: Disconnecting Transmission Range Switch Connector Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

**Connector Terminal Specifications** 

CONNECTOR TERMINAL SPECIFICATIONS Terminal signal

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

1	GND
2	L
3	D
4	N
5	R
6	P

- 3. Check for continuity between terminals at the connector. There should be continuity between terminals listed for each switch position.
  - In the P position:

Between terminals No. 1 and No. 6

• In the R position:

Between terminals No. 1 and No. 5

• In the N position:

Between terminals No. 1 and No. 4

• In the D position:

Between terminals No. 1 and No. 3

• In the L position:

Between terminals No. 1 and No. 2

4. If there is no continuity between any terminals, adjust the transmission range switch. If the transmission range switch adjustment is OK, replace the transmission range switch.

## TRANSMISSION RANGE SWITCH REPLACEMENT

- 1. Remove the air cleaner housing.
- 2. Remove the transmission range switch connector from the connector bracket

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

(A), then disconnect it.



G03682061

# **Fig. 360: Identifying Loosening Torque Of Connector Bracket Bolts Courtesy of AMERICAN HONDA MOTOR CO., INC.**

- 3. Remove the transmission range switch (B).
- 4. Shift the transmission into the N position by turning the control lever (A). Do not squeeze the end (B) of the control shaft tips together when shifting. If the tips are squeezed together it will cause a faulty signal or position due to the play between the control shaft and the switch.



G03682062

# **Fig. 361: Turning Control Lever** Courtesy of AMERICAN HONDA MOTOR CO., INC.

5. Set the transmission range switch to the N position. The switch clicks in the N position.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682063

**Fig. 362: Identifying Transmission Range Switch N Position Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

- 6. Install the transmission range switch gently over the control shaft, then tighten the bolts. Do not move the switch when tightening the bolts.
- 7. Connect the connector securely, then install it on its bracket.
- 8. Turn the ignition switch ON (II). Move the shift lever through all positions, and check the transmission range switch synchronization with the A/T gear position indicator.



G03682064

# **Fig. 363: Identifying A/T Gear Position Indicator Courtesy of AMERICAN HONDA MOTOR CO., INC.**

- 9. Check that the engine can start in the P and N positions, and will not start in any other shift lever position.
- 10. Check that the back-up lights come on when the shift lever is in the R position.
- 11. Allow the wheels to rotate freely, then start the engine, and check the shift

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

lever operation.

# A/T INTERLOCK SYSTEM

### COMPONENT LOCATION INDEX



G03682065

# **Fig. 364:** A/T Interlock System Component Location Index Courtesy of AMERICAN HONDA MOTOR CO., INC.

**CIRCUIT DIAGRAM** 

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



# **Fig. 365: A/T Interlock System Circuit Diagram** Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### SHIFT LOCK SYSTEM CIRCUIT TROUBLESHOOTING

1. Press the brake pedal.

Are the brake lights ON?

YES -Go to step 2.NO -Repair faulty brake light circuit.

- 2. Turn the ignition switch ON (II), and shift to the P position.
- 3. Press the brake pedal, and release the accelerator.
- 4. Measure the voltage between ECM connector terminal A28 and body ground.

# ECM CONNECTOR A (32P)



# Wire side of female terminals G03682067

Fig. 366: Measuring Voltage Between ECM Connector A (32P) Terminal

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# **A28 And Body Ground** Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there battery voltage?

**YES** -Check for an open in the wire between ECM connector terminal A28 and the gauge assembly interlock control system circuit, and check for loose terminal fit in the gauge assembly connectors. If necessary, substitute a known-good gauge assembly and recheck.

NO -Go to step 5.

- 5. Turn the ignition switch OFF.
- 6. Disconnect TCM connectors A (26P) and B (22P).
- 7. Press the brake pedal, and measure the voltage between TCM connector terminals B12 and A4.

# **TCM CONNECTORS**



Wire side of female terminals

G03682068

# Fig. 367: Measuring Voltage Between TCM Connector Terminals B12

# **And A4 Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there battery voltage while pressing the brake pedal?

**YES** -Release the brake pedal, and go to step 8.

**NO** -Repair an open in the wire between TCM connector terminal B12 and the brake pedal position switch.

- 8. Reconnect TCM connectors A (26P) and B (22P).
- 9. Turn the ignition switch ON (II).
- 10. Measure the voltage between TCM connector terminals B4 and A4.

# **TCM CONNECTORS**



Wire side of female terminals

G03682069

**Fig. 368: Measuring Voltage Between TCM Connector Terminals B4 And** <u>A4</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there about 0.5 V?

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

**YES** -Go to step 15. **NO** -Go to step 11.

- 11. Turn the ignition switch OFF.
- 12. Disconnect the throttle position (TP) sensor connector.
- 13. Turn the ignition switch ON (II).
- 14. Measure the voltage between TP sensor connector terminals No. 1 and No. 3.

# **TP SENSOR CONNECTOR**



Wire side of female terminals

G03682070

**Fig. 369: Measuring Voltage Between TP Sensor Connector Terminals 1** <u>And 3</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

*Is there about 5 V?* 

**YES** -Check for an open or a short in the wire between TCM connector terminal B4 and the TP sensor. If the wire is OK, replace the TP sensor. **NO** -Go to step 15.

- 15. Turn the ignition switch OFF.
- 16. Disconnect ECM connector B (25P).
- 17. Check for continuity between TP sensor connector terminal No. 3 and body ground.

# **TP SENSOR CONNECTOR**



# Wire side of female terminals

G03682071

Fig. 370: Checking Continuity Between TP Sensor Connector Terminal 3 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

Is there continuity?

**YES** -Check for a short to ground in the wire between TP sensor connector terminal No. 3 and ground. If the wire is OK, replace the TP sensor.

NO -Go to step 18.

- 18. Remove the front console (see **FRONT CONSOLE REMOVAL/INSTALLATION** ).
- 19. Disconnect the shift lock solenoid connector.
- 20. Turn the ignition switch ON (II).
- 21. Press the brake pedal, and check the voltage between shift solenoid connector terminals.

# SHIFT LOCK SOLENOID CONNECTOR



# Wire side of female terminals

G03682072

# **Fig. 371: Checking Voltage Between Shift Solenoid Connector Terminals Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there battery voltage?

**YES** -Go to step 21.

**NO** -Check for an open or short in the wires between the shift lock solenoid connector and the gauge assembly. If wires are OK, check for a loose terminal fit in the gauge assembly connector. If necessary, substitute a known-good gauge assembly and recheck.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

- 22. Connect the battery positive terminal to shift lock solenoid connector terminal No. 1, and connect the battery negative terminal to connector terminal No. 2. Do not connect the battery positive terminal to connector terminal No. 2 or you will damage the diode inside the shift lock solenoid.
- 23. Check that the shift lock solenoid operates.

# SHIFT LOCK SOLENOID CONNECTOR



# Terminal side of male terminals G03682073

# **Fig. 372: Checking Shift Lock Solenoid Operation Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Does the shift lock solenoid operate properly?

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

**YES** -Check for loose gauge assembly connectors. If necessary, substitute a known-good gauge assembly and recheck. **NO** -Replace the shift lock solenoid.

### **KEY INTERLOCK SYSTEM CIRCUIT TROUBLESHOOTING**

- 1. Disconnect steering lock assembly 5P connector.
- 2. Turn the ignition switch to ACC (I) or ON (II).
- 3. Connect the battery positive terminal to steering lock assembly 5P connector terminal No. 4, and connect the battery negative terminal to connector terminal No. 5.
# STEERING LOCK ASSEMBLY 5P CONNECTOR



Wire side of female terminals

G03682074

# **Fig. 373: Connecting Battery Positive Terminal To Steering Lock** Assembly 5P Connector Terminal 4 And Battery Negative Terminal To <u>Terminal 5</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

4. Check the key interlock solenoid operation. A clicking sound should be heard when pushing the ignition key in, and you should not be able to turn it to OFF (0) position.

Does the key interlock solenoid operate properly?

**YES** -Go to step 5.

**NO** -Faulty key interlock solenoid/switch. Replace the ignition key cylinder/steering lock assembly.

5. Check for continuity between steering lock assembly 5P connector terminals No. 3 and No. 4.

# STEERING LOCK ASSEMBLY 5P CONNECTOR



# Wire side of female terminals

G03682075

**Fig. 374: Checking Continuity Between Steering Lock Assembly 5P Connector Terminals 3 And 4** 

# Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there continuity while pushing the key in, and no continuity when the key is released?* 

YES -Go to step 6.

**NO** -Replace the ignition key cylinder/steering lock assembly.

6. Measure the voltage between steering lock assembly 5P connector terminal No. 4 and body ground.

# STEERING LOCK ASSEMBLY 5P CONNECTOR



# Terminal side of male terminals G03682076

**Fig. 375: Measuring Voltage Between Steering Lock Assembly 5P** Connector Terminal 4 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there battery voltage?* 

YES -Go to step 7.

**NO** -Check for a blown No. 6 (10 A) fuse in the under-hood fuse/relay box. If the fuse is OK, repair open or short in the wire between steering lock assembly 5P connector terminal No. 4 and the under-hood fuse/relay box.

7. Measure the voltage between steering lock assembly 5P connector terminals No. 3 and No. 4. (shift lever must be in the P position)

# STEERING LOCK ASSEMBLY 5P CONNECTOR



# Terminal side of male terminals G03682077

Fig. 376: Measuring Voltage Between Steering Lock Assembly 5P

# **<u>Connector Terminals 3 And 4</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there battery voltage when the shift lever is in the P position, and 0 V when the shift lever is out of the P position?

YES -Go to step 8.

**NO** -Check for an open or a short in the wire between steering lock assembly connector terminal No. 3 and the gauge assembly. If the wire is OK, check loose terminal fit in the gauge assembly connectors. If necessary, substitute a known-good gauge assembly and recheck.

8. Shift the shift lever back to the P position, and measure the voltage between steering lock assembly connector terminals No. 4 and No. 5.

# STEERING LOCK ASSEMBLY 5P CONNECTOR



Terminal side of male terminals

G03682078

## Fig. 377: Measuring Voltage Between Steering Lock Assembly Connector <u>Terminals 4 And 5</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there battery voltage when the shift lever is in the P position, and 0 V when the shift lever is out of the P position?

**YES** -Check for loose terminal fit in the gauge assembly connectors, substitute a known-good gauge assembly and recheck. **NO** -Go to step 9.

9. Remove the front console (see **FRONT CONSOLE** 

# **<u>REMOVAL/INSTALLATION</u>** ).

- 10. Disconnect the park pin switch connector.
- 11. Check for continuity between park pin switch connector terminals No. 3 and No. 4 while you move the shift lever in and out of the P position.

# PARK PIN SWITCH CONNECTOR



# Terminal side of male terminals G03682079

Fig. 378: Checking Continuity Between Park Pin Switch Connector Terminals 3 And 4

# Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity with the shift lever in the P position, and no continuity with the shift lever is out of the P position?

**YES** -Repair an open or short in the wire between steering lock assembly connector terminal No. 5 and park pin switch connector, and repair open in the wire between the park pin switch connector and ground.

**NO** -Replace the park pin switch.

#### SHIFT LOCK SOLENOID TEST

- 1. Remove the front console (see **FRONT CONSOLE REMOVAL/INSTALLATION** ).
- 2. Disconnect the shift lock solenoid connector.

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



**Fig. 379: Disconnecting Shift Lock Solenoid Connector Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

- Connect the battery positive terminal to shift lock solenoid connector terminal No. 1, and connect the battery negative terminal to connector terminal No. 2. Do not connect the battery positive terminal to connector terminal No. 2 or you will damage the diode inside the shift lock solenoid.
- 4. Check that the shift lever can be moved from the P position. Release the battery terminals from the solenoid connector. Move the shift lever back to the P position, and check that it locks securely.
- 5. Check that the shift lock releases when the shift lock release is pushed, and check that it locks when the shift lock release is released.
- 6. If the shift lock solenoid does not work properly, replace it.

# SHIFT LOCK SOLENOID REPLACEMENT

- 1. Remove the front console (see **FRONT CONSOLE REMOVAL/INSTALLATION** ).
- 2. Disconnect the shift lock solenoid connector.
- 3. Pry the shift lock solenoid clamp (A) with a screwdriver, and remove it.

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682081

## **Fig. 380: Removing Shift Lock Solenoid** Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 4. Remove the shift lock solenoid.
- 5. Install the shift lock solenoid plunger (B) and plunger spring (C) in the new shift lock solenoid (D).
- 6. Install the shift lock solenoid by aligning the joint of the shift lock solenoid plunger with the tip of the shift lock stop (E).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

- 7. Secure the shift lock solenoid with the solenoid clamp.
- 8. Connect the shift lock solenoid connector.
- 9. Install the front console (see **FRONT CONSOLE <u>REMOVAL/INSTALLATION</u> ).**

## PARK PIN SWITCH TEST

- 1. Remove the front console (see **FRONT CONSOLE REMOVAL/INSTALLATION** ).
- 2. Disconnect the park pin switch connector.

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682082

# **Fig. 381: Disconnecting Park Pin Switch Connector** Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 3. Shift to the P position, then check for continuity between connector terminals No. 3 and No. 4. There should be continuity.
- 4. If there is no continuity between connector terminals No. 3 and No. 4, replace the parking pin switch.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

- 5. Shift out of the P position, and check for continuity between connector terminals No. 3 and No. 4. There should be no continuity.
- 6. If there is continuity between connector terminals No. 3 and No. 4, replace the park pin switch.

## PARK PIN SWITCH REPLACEMENT

- 1. Remove the front console (see **FRONT CONSOLE REMOVAL/INSTALLATION** ).
- 2. Remove the A/T gear position indicator panel light, and remove the bulb (A) from the socket (B).



G03682083

#### Fig. 382: Removing Park Pin Switch

# **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

- 3. Separate the A/T gear position indicator panel from the shift lever bracket base (C).
- 4. Disconnect the park pin switch connector (D), and remove it from the bracket base.
- 5. Remove the park pin switch clamp (E) and the park pin switch (F).
- 6. Install the new park pin switch in the shift lever bracket base, and install the park pin switch clamp to secure it.
- 7. Install the removed parts in the reverse order of removal.

# TRANSMISSION LOWER VALVE BODY

## ATF PAN, ATF STRAINER, AND LOWER VALVE BODY ASSEMBLY REMOVAL

1. Remove the bolt (A) securing the ATF cooler inlet line (B).

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682084

# **Fig. 383: Removing ATF Cooler Inlet Line** Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 2. Remove the ATF pan (C) (15 bolts).
- 3. Remove the ATF strainer (D).
- 4. Remove the lower valve body assembly (E) mounting bolts.
- 5. Remove the bolt (F) securing the solenoid harness connector (G) with holding the lower valve body assembly, and remove the connector and valve body assembly.
- 6. Clean the inlet opening (A) of the ATF strainer (B) thoroughly with compressed air, then check that it is in good condition, and that the inlet opening is not clogged.



# **Fig. 384: Identifying Inlet Opening And ATF Strainer** Courtesy of AMERICAN HONDA MOTOR CO., INC.

7. Test the ATF strainer by pouring clean CVT Fluid through the inlet opening.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

and replace it if it is clogged or damaged.

## CVT START CLUTCH PRESSURE CONTROL VALVE REMOVAL AND INSTALLATION

2004-2006 Models:

1. Disconnect the CVT start clutch pressure control valve connector (A).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682086

# **Fig. 385: Identifying Loosening Torque Of CVT Start Clutch Pressure** <u>Control Valve Bolts</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 2. Remove the CVT start clutch pressure control valve (B).
- 3. Check that the filter (C) is in good condition, replace it if it is clogged or damaged.
- 4. Install the CVT start clutch pressure control valve with the dowel pins (D) and separator plate (E) on the lower valve body (F).
- 5. Connect the CVT start clutch pressure control valve connector.

## CVT DRIVE PULLEY PRESSURE CONTROL VALVE REMOVAL AND INSTALLATION

#### 2004-2006 Models:

1. Remove the solenoid harness clamp (A).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# Fig. 386: Removing CVT Drive Pulley Pressure Control Valve And Torque Specifications Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 2. Disconnect the CVT drive pulley pressure control valve connector (B).
- 3. Remove the seven bolts, and remove the CVT drive pulley pressure control valve (C). The CVT start clutch pressure control valve (D) also be removed, it uses those four bolts.
- 4. Check that the filter (E) is in good condition, replace it if it is clogged or damaged.
- 5. Install the CVT drive pulley pressure control valve with the dowel pins (F) and separator plate (G), and CVT start clutch pressure control valve with the dowel pins (H) and separator plate (I) on the lower valve body (J).
- 6. Connect the CVT drive pulley pressure control valve connector.
- 7. Install the solenoid harness clamp.

## CVT DRIVEN PULLEY PRESSURE CONTROL VALVE REMOVAL AND INSTALLATION

#### 2004-2006 Models:

1. Disconnect the CVT driven pulley pressure control valve connector (A) and the inhibitor solenoid connector (B).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682088

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# Fig. 387: Disconnecting CVT Driven Pulley Pressure Control Valve Connector And Inhibitor Solenoid Connector With Specified Torques Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 2. Remove the CVT driven pulley pressure control valve (C), and remove the inhibitor solenoid (D) from the CVT driven pulley pressure control valve.
- 3. Check that the filter (E) is in good condition, replace it if it is clogged or damaged.
- 4. Replace the O-rings (F) on the inhibitor solenoid, if necessary.
- 5. Install the inhibitor solenoid on the new CVT driven pulley pressure control valve.
- 6. Install the CVT driven pulley pressure control valve with the dowel pins (G) and separator plate (H) on the lower valve body (I).
- 7. Connect the CVT driven pulley pressure control valve connector and the inhibitor solenoid connector.

## INHIBITOR SOLENOID REMOVAL AND INSTALLATION

#### 2004-2006 Models:

1. Disconnect the inhibitor solenoid connector (A).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682089

# **Fig. 388: Identifying Loosening Torque Of Inhibitor Solenoid Bolt Courtesy of AMERICAN HONDA MOTOR CO., INC.**

- 2. Remove the inhibitor solenoid (B).
- 3. Install the inhibitor solenoid on the CVT driven pulley pressure control valve.
- 4. Connect the inhibitor solenoid connector.

# TRANSMISSION HOUSING/FLYWHEEL HOUSING

FLYWHEEL HOUSING AND START CLUTCH REMOVAL

**Exploded View** 

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682090

# **Fig. 389: Exploded View Of Flywheel Housing And Start Clutch Courtesy of AMERICAN HONDA MOTOR CO., INC.**

# **Special Tools Required**

Start clutch remover 07TAE-P4VA120

# NOTE: Refer to the <u>EXPLODED VIEW</u> as needed during the following procedure.

- 1. Remove the flywheel housing (19 bolts).
- 2. Remove the differential assembly.
- 3. Remove the snap ring and thrust shim on the ATF pump drive sprocket, then remove the bolts securing the ATF pump drive sprocket.
- 4. Remove the ATF pump drive chain, then remove the ATF pump drive sprocket, sprocket hub, thrust washers and thrust needle bearing from the input shaft.
- 5. Remove the park pawl shaft, park pawl spring then and park pawl.
- 6. Remove the snap ring securing the start clutch, and remove the cotter retainer and the cotters.
- 7. Set the special tool on the start clutch (A), then attach the pawl (B) of the special tool to the park gear (C) securely. Do not place the pawl of the special tool on the start clutch guide. If the pawl contacts the start clutch guide, the clutch guide may be damaged. Do not allow dust or other foreign particles to enter into the driven pulley shaft.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



## Fig. 390: Setting Special Tool On Start Clutch And Attaching Pawl Of Special Tool To Park Gear Courtesy of AMERICAN HONDA MOTOR CO., INC.

8. Remove the start clutch (A) and the secondary drive gear assembly (B) with

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

the special tool.



**Fig. 391: Removing Start Clutch And Secondary Drive Gear Assembly Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

- 9. Remove the secondary gear shaft.
- 10. Remove the secondary drive gear from the start clutch.
- 11. Remove the sealing ring (A) from the secondary drive gear (B), and clean it; the ring will be reinstalled on the new secondary drive gear when assembling the transmission.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682093

**Fig. 392: Removing Sealing Ring From Secondary Drive Gear** Courtesy of AMERICAN HONDA MOTOR CO., INC.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

#### ATF PUMP REPLACEMENT

- 1. Remove the ATF pump drive sprocket mounting bolts, then remove the ATF pump drive chain.
- 2. Expand the snap ring under the ATF pump driven sprocket, and remove the ATF pump driven sprocket from the ATF pump.



G03682094

# **Fig. 393: Removing ATF Pump Driven Sprocket From ATF Pump** Courtesy of AMERICAN HONDA MOTOR CO., INC.

3. Remove the ATF pump from the transmission housing.



G03682095

# **Fig. 394: Identifying Loosening Torque Of ATF Pump Bolts Courtesy of AMERICAN HONDA MOTOR CO., INC.**

4. Install the 22 x 10 mm ATF pipe (A) and the 18 x 10 mm ATF pipe (B) in the

transmission housing, then install the new O-rings (C) over the ATF pipes.

- 5. Install the new ATF pump body (D) with the dowel pins (E). Do not pinch the O-rings.
- 6. Install the snap ring (F) in the snap ring groove.
- 7. Install the ATF pump driven sprocket.
- 8. Install the ATF pump drive chain and ATF pump drive sprocket.

## DRIVEN PULLEY SHAFT BEARING REMOVAL/INSTALLATION

# **Special Tools Required**

- Attachment, 72 x 75 mm 07746-0010600
- Driver 07749-0010000

# NOTE: Coat all parts with CVT Fluid before assembly.

1. To remove the driven pulley shaft bearing from the transmission housing, expand the snap ring with the snap ring pliers, then push the bearing out.

# NOTE: Do not remove the snap ring unless it is necessary to clean the groove in the housing.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682096

# **Fig. 395: Removing Driven Pulley Shaft Bearing Courtesy of AMERICAN HONDA MOTOR CO., INC.**

2. Install the bearing in the direction shown.
2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682097

# **Fig. 396: Identifying Direction For Installing Drive Pulley Shaft Bearing Courtesy of AMERICAN HONDA MOTOR CO., INC.**

- 3. Expand the snap ring with the snap ring pliers, and install the bearing part-way into the housing.
- 4. Release the pliers, then push the bearing down into the housing until the snap ring snaps in place around it.
- 5. After installing the bearing verify that the snap ring (A) is seated in the bearing and housing groove, and that the ring end gap (B) is 0-9 mm (0-0.35 in.).

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682098

Fig. 397: Identifying Ring End Gap

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# Courtesy of AMERICAN HONDA MOTOR CO., INC.

## FLYWHEEL HOUSING INPUT SHAFT OIL SEAL REPLACEMENT

# **Special Tools Required**

- Attachment, 32 x 35 mm 07746-0010100
- Driver 07749-0010000
- 1. Remove the input shaft oil seal (A) from the flywheel housing (B).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



# **Fig. 398: Removing Input Shaft Oil Seal From Flywheel Housing** Courtesy of AMERICAN HONDA MOTOR CO., INC.

2. Install the new oil seal in the flywheel housing with the special tools in the specification shown.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



# **Fig. 399: Installing Oil Seal In Flywheel Housing Courtesy of AMERICAN HONDA MOTOR CO., INC.**

SECONDARY GEAR SHAFT THRUST CLEARANCE INSPECTION

- NOTE: If the transmission housing or flywheel housing was replaced, secondary gear shaft thrust clearance must be inspected.
  - 1. Install the secondary gear shaft in the transmission housing.

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



**Sectional View** 



G03682101

# **Fig. 400: Installing Secondary Gear Shaft In Transmission Housing Courtesy of AMERICAN HONDA MOTOR CO., INC.**

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# **Sectional View**

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



# **Sectional View**



2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# **Fig. 401: Measuring Distance Between Transmission Housing Surface And Top Of Bearing Courtesy of AMERICAN HONDA MOTOR CO., INC.**

- 2. Measure the distance (A) between the transmission housing surface and the top of the bearing, then note the measurement (Measurement A).
- 3. Measure the distance (B) between the flywheel housing surface and bearing mounting surface in the housing, then note the measurement (Measurement B).

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682103

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# **Fig. 402: Measuring Distance Between Flywheel Housing Surface And Bearing Mounting Surface Courtesy of AMERICAN HONDA MOTOR CO., INC.**

**Sectional View** 

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682104

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# **Fig. 403: Sectional View Of Flywheel Housing Surface Courtesy of AMERICAN HONDA MOTOR CO., INC.**

4. Calculate the secondary gear shaft clearance by subtracting Measurement B from Measurement A.

Standard: 0.5-0.65 mm (0.02-0.03 in.)

# NOTE: The standard clearance includes the thickness of the flywheel housing gasket (0.5 mm, 0.02 in.)

5. If the clearance is out of standard, adjust it with the 25 x 35 mm thrust shim (see 25 X 35 MM THRUST SHIM SELECTION ).

# SECONDARY GEAR SHAFT BEARING REPLACEMENT

# **Special Tools Required**

- Driver, 40 mm I.D. 07746-0030100
- Attachment, 25 mm I.D. 07746-0030200
- 1. Remove the bearing (A) from the secondary gear shaft (B) with a universal two-jaw (or three-jaw) puller (C). Place a shaft protector (D) between the secondary gear shaft and a puller to prevent damaging the shaft.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



**Fig. 404: Removing Bearing From Secondary Gear Shaft Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

2. Install the new bearing (A) on the secondary gear shaft (B) of the transmission housing side with the special tools and a press.



**Sectional View** 



2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# **Fig. 405: Installing Bearing On Secondary Gear Shaft** Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 3. Select the 25 x 35 mm thrust shim (see 25 X 35 MM THRUST SHIM SELECTION ).
- 4. Install the selected thrust shim, then install the new bearing (A) on the secondary gear shaft (B) of the flywheel housing side using the special tools and a press.

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



**Sectional View** 



2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# **Fig. 406: Installing Thrust Shim** Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### 25 X 35 MM THRUST SHIM SELECTION

# NOTE: If the secondary gear shaft bearings or secondary gear shaft is replaced, select the 25 x 35 mm thrust shim to adjust the secondary gear shaft thrust clearance.

- 1. Remove the bearing on flywheel housing side of the secondary gear shaft (see <u>SECONDARY GEAR SHAFT BEARING REPLACEMENT</u>).
- 2. Install the secondary gear shaft in the transmission housing.
- Measure the distance (A) between the transmission housing surface and the 25 x 35 mm thrust shim mounting surface on the secondary gear shaft, then note the measurement (Measurement A).

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



## **Fig. 407: Measuring Distance Between Transmission Housing Surface And Thrust Shim Mounting Surface Courtesy of AMERICAN HONDA MOTOR CO., INC.**

4. Measure the distance (B) between the flywheel housing surface and bearing mounting surface in the housing, then note the measurement (Measurement B).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



**Fig. 408: Measuring Distance Between Flywheel Housing Surface And Bearing Mounting Surface** 

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

# **Sectional View**

5. Calculate the thickness of the 25 x 35 mm thrust shim using the formula:

# Formula:

25 x 35 mm Thrust Shim Thickness = Measurement B - Measurement A -Bearing thickness (17 mm) + Flywheel housing gasket thickness (0.5 mm) Standard: 0-0.15 mm (0-0.006 in.)

6. Select the  $25 \times 35$  mm thrust shim using the table.

# THRUST SHIM, 25 x 35 mm

111KUG1 0111V1, 25 X 55 WIWI 01 ECI		
No.	Part Number	Thickness
А	90551-P4V-000	2.8 mm (0.110 in.)
В	90552-P4V-000	2.9 mm (0.114 in.)
С	90553-P4V-000	3.0 mm (0.118 in.)
D	90554-P4V-000	3.1 mm (0.122 in.)
E	90555-P4V-000	3.2 mm (0.126 in.)
F	90556-P4V-000	3.3 mm (0.130 in.)
G	90557-P4V-000	3.4 mm in.)
Η	90558-P4V-000	3.5 mm (0.138 in.)
Ι	90559-P4V-000	3.6 mm (0.142 in.)
J	90560-P4V-000	3.7 mm (0.146 in.)
K	90561-P4V-000	3.8 mm (0.150 in.)

# **THRUST SHIM, 25 X 35 MM SPECIFICATIONS**

- 7. Remove the secondary gear shaft from the transmission housing.
- Install the selected 25 x 35 mm thrust shim in the secondary gear shaft, then install the bearing (see <u>SECONDARY GEAR SHAFT BEARING</u> <u>REPLACEMENT</u>).

#### **END COVER/INTERMEDIATE HOUSING**

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

#### FORWARD CLUTCH, REVERSE BRAKE, AND INTERMEDIATE HOUSING REMOVAL

**Exploded View** 



G03682110

**Fig. 409: Exploded View Of Forward Clutch, Reverse Brake, And** Intermediate Housing

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# Courtesy of AMERICAN HONDA MOTOR CO., INC.

# **Special Tools Required**

Reverse brake spring compressor 07TAE-P4V0110

# NOTE: Refer to the <u>EXPLODED VIEW</u> as needed during the following procedure.

- 1. Remove the end cover.
- 2. Remove the manual valve body lines.
- 3. Remove the planetary carrier/input shaft assembly, then remove the ring gear.
- 4. Remove the reverse brake snap ring, then remove the reverse brake end-plate, brake discs, brake plates, and disc spring.
- 5. Remove the snap ring securing the forward clutch end-plate, then remove the forward clutch end-plate, discs and plates.
- 6. Remove the snap ring securing the forward clutch to the drive pulley shaft, then remove the forward clutch.
- 7. Install the special tool to remove the snap ring securing the reverse brake return spring retainer.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# **Fig. 410: Removing Snap Ring** Courtesy of AMERICAN HONDA MOTOR CO., INC.

8. Compress the return spring with the special tool, then remove the snap ring. Be sure the special tool set over the reverse brake return springs.



G03682112

# **Fig. 411: Identifying Reverse Brake Return Spring** Courtesy of AMERICAN HONDA MOTOR CO., INC.

9. Remove the special tool, then remove the spring retainer/return spring assembly (A).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682113

# **Fig. 412: Removing Spring Retainer/Return Spring Assembly** Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 10. Apply air pressure to reverse brake pressure circuit hole (B) to remove the reverse brake piston (C).
- 11. Remove the snap ring retainer from the drive pulley shaft.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

- 12. Remove the CVT input shaft (drive pulley) speed sensor.
- 13. Remove the manual valve body and separator plate.
- 14. Remove the roller. Push the control shaft toward the outside of the transmission housing if the transmission range switch is removed.
- 15. Remove the intermediate housing, then remove the ATF feed pipes from the transmission housing.

#### MANUAL VALVE BODY DISASSEMBLY, INSPECTION, AND REASSEMBLY

1. Clean all parts thoroughly in solvent or carburetor cleaner, and dry with compressed air. Blow out all passages.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682114

# **Fig. 413: Inspecting Manual Valve Body** Courtesy of AMERICAN HONDA MOTOR CO., INC.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

- 2. Inspect the manual valve body for wear, scratches, and scoring.
- 3. If the manual valve body is worn or damaged, replace it.
- 4. Coat all parts with CVTF during reassembly.

#### CONTROL SHAFT REMOVAL/INSTALLATION

- 1. Remove the transmission range switch from the control shaft.
- 2. Remove the bolt (A) and lock washer (B).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# **Fig. 414: Identifying Loosening Torque Of Lock Washer Bolt Courtesy of AMERICAN HONDA MOTOR CO., INC.**

- 3. Remove the control lever (C) from the control shaft (D).
- 4. Remove the control shaft assembly from the transmission housing (E).
- 5. Inspect the oil seal (F), and replace it if it is worn or damaged.
- 6. Inspect the end of the control shaft tips together for squeeze. If the end of the control shaft is squeezed, worn or damaged, replace the control shaft assembly.
- 7. Install the control shaft assembly in the transmission housing.
- 8. Install the control lever to the control shaft.
- 9. Install and tighten the bolt with the new lock washer, then bend the lock tab of the lock washer.

# NOTE: Do not install the transmission range switch, install it after installing the end cover in the transmission assembly.

# PLANETARY CARRIER BEARING REPLACEMENT

# **Special Tools Required**

- Driver 07749-0010000
- Attachment, 32 x 35 mm 07746-0010100
- 1. Remove the snap ring securing the planetary carrier bearing.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682116

# **Fig. 415: Removing Planetary Carrier Bearing Snap Ring Courtesy of AMERICAN HONDA MOTOR CO., INC.**

2. Remove the planetary carrier bearing.

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682117

# **Fig. 416: Removing Planetary Carrier Bearing Courtesy of AMERICAN HONDA MOTOR CO., INC.**

3. Install the new bearing with the special tools.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682118

# **Fig. 417: Installing Bearing Courtesy of AMERICAN HONDA MOTOR CO., INC.**

4. Install the snap ring to secure the bearing on the planetary carrier.

# FORWARD CLUTCH

#### **CLUTCH DISASSEMBLY**

# **Special Tools Required**

- Clutch spring compressor bolt assembly 07GAE-PG40200 or 07GAE-PG4020A
- Clutch spring compressor attachment 07HAE-PL50101
- Clutch spring compressor attachment 07LAE-PX40100

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

1. Remove the snap ring (A), then remove the clutch end-plate, the clutch discs, and the plates with a screwdriver (B).



# G03682119

# **Fig. 418: Removing Snap Ring** Courtesy of AMERICAN HONDA MOTOR CO., INC.

2. 2001-2004 models: Remove the disc spring.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



Fig. 419: Removing Disc Spring (2001-2004 Models)
2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

## **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

3. 2005-2006 models: Remove the waved spring.



## G03682121

## **Fig. 420: Removing Waved Spring (2005-2006 Models)** Courtesy of AMERICAN HONDA MOTOR CO., INC.

4. Install the special tool on the clutch assembly.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682122

## **Fig. 421: Installing Special Tool On Clutch Assembly** Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 5. Be sure the special tool (A) is adjusted to have full contact with the spring retainer (B) on the clutch.
- 6. If either end of the special tool is set over an area of the spring retainer which is unsupported by the return spring, the retainer may be damaged.

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682123

## **Fig. 422: Identifying Contact Of Special Tool With Spring Retainer Courtesy of AMERICAN HONDA MOTOR CO., INC.**

7. Compress the spring until the snap ring can be removed.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



## **Fig. 423: Compressing Spring** Courtesy of AMERICAN HONDA MOTOR CO., INC.

8. Remove the snap ring (A). Then remove the special tools (B), spring retainer (C), and return spring.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



## **Fig. 424: Removing Snap Ring** Courtesy of AMERICAN HONDA MOTOR CO., INC.

9. Wrap a shop rag around the clutch drum (A), and apply air pressure to the fluid passage to remove the piston (B). Place a finger tip on the other end while applying air pressure.

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



## **Fig. 425: Removing Piston** Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### **CLUTCH INSPECTION**

1. Inspect the clutch piston and clutch piston check valve. If the clutch check valve is loose or damaged, replace the clutch piston.

## 2001-2004 Models:

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682127

## **Fig. 426: Inspecting Clutch (2001-2004 Models)** Courtesy of AMERICAN HONDA MOTOR CO., INC.

2005-2006 Models:

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682128

## **Fig. 427: Inspecting Clutch (2005-2006 Models)** Courtesy of AMERICAN HONDA MOTOR CO., INC.

2. Check the spring retainer for wear and damage.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

- 3. Inspect the clutch discs, clutch plates, and clutch end-plate for wear, damage, and discoloration.
  - If the clutch discs are worn or damaged, replace the disc and plates as a set.
  - If the clutch plates are worn, damaged, or discolored, replace the discs and plates as a set.
  - If the clutch end-plate is worn, damaged, or discolored, inspect the clutch end-plate-to-top-disc clearance, then replace the clutch end-plate.

## **CLUTCH REASSEMBLY**

# **Special Tools Required**

- Clutch spring compressor bolt assembly 07GAE-PG40200 or 07GAE-PG4020A
- Clutch spring compressor attachment 07HAE-PL50101
- Clutch spring compressor attachment 07LAE-PX40100
- 1. Soak the clutch discs thoroughly in CVTF for a minimum of 30 minutes.
- 2. Install new O-rings (A) on the piston (B).

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682129

## **Fig. 428: Installing O-Rings On Piston** Courtesy of AMERICAN HONDA MOTOR CO., INC.

3. Install the piston (A) in the clutch drum (B). Apply pressure and rotate to ensure proper seating. Lubricate the piston O-ring with CVTF before installing. Do not pinch the O-ring by installing the piston with too much force.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682130

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

## **Fig. 429: Installing Piston In Clutch Drum** Courtesy of AMERICAN HONDA MOTOR CO., INC.

4. Install the return spring (A) and spring retainer (B), and position the snap ring (C) on the retainer.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682131

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

## **Fig. 430: Installing Return Spring And Spring Retainer Courtesy of AMERICAN HONDA MOTOR CO., INC.**

5. Install the special tool.



G03682132

## **Fig. 431: Installing Special Tool** Courtesy of AMERICAN HONDA MOTOR CO., INC.

6. Be sure the special tool (A) is adjusted to have full contact with the spring retainer (B) on the clutches.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682133

## **Fig. 432: Identifying Contact Of Special Tool With Spring Retainer** Courtesy of AMERICAN HONDA MOTOR CO., INC.

7. If either end of the special tool is set over an area of the spring retainer which is unsupported by the return spring, the retainer may be damaged.

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682134

## **Fig. 433: Inspecting Damaged Retainer** Courtesy of AMERICAN HONDA MOTOR CO., INC.

8. Compress the return spring.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



## **Fig. 434: Compressing Return Spring** Courtesy of AMERICAN HONDA MOTOR CO., INC.

9. Install the snap ring (A).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682136

## **Fig. 435: Installing Snap Ring** Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 10. Remove the special tools.
- 11. 2001-2004 models: Install the disc spring in the direction shown.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682137

## **Fig. 436: Installing Disc Spring (2001-2004 Models)** Courtesy of AMERICAN HONDA MOTOR CO., INC.

12. 2005-2006 models: Install the waved spring.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682138

## **Fig. 437: Installing Waved Spring (2005-2006 Models)** Courtesy of AMERICAN HONDA MOTOR CO., INC.

13. Starting with a clutch plate, alternately install the clutch plates and discs. Install the clutch end-plate (A) with the flat side toward the disc (B).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682139

## **Fig. 438: Installing Clutch End-Plate** Courtesy of AMERICAN HONDA MOTOR CO., INC.

14. Install the snap ring (A) with a screwdriver (B).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682140

# **Fig. 439: Installing Snap Ring Courtesy of AMERICAN HONDA MOTOR CO., INC.**

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

15. Verify that the snap ring end gap (A) is 7.9 mm (0.311 in.) or move.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

## **Fig. 440: Identifying Snap Ring End Gap** Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 16. Check that the clutch piston engages by applying air pressure to the fluid passage, and also check that the piston releases when released air pressure.
- 17. Set a dial indicator (A) on the clutch end-plate (B).



## Fig. 441: Setting Dial Indicator On Clutch End-Plate

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

## Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 18. Zero the dial indicator with the clutch end-plate lifted up to the snap ring (C).
- 19. Release the clutch end-plate to lower the clutch end-plate, then put the special tool on the end-plate (A).



G03682143

# **Fig. 442: Setting Special Tool On End Plate Courtesy of AMERICAN HONDA MOTOR CO., INC.**

20. Press the special tool down with 39 N (4 kgf, 9 lbf) using a force gauge, and read the dial indicator (B). The dial indicator reads the clearance (C) between the clutch end-plate and top disc (D). Take measurements in at least three places, and use the average as the actual clearance.

# Clutch End-Plate-to-Top-Disc Clearance Service Limit: 0.6-0.8 mm (0.024-0.031 in.)

- 21. If the clearance is out of the service limit, select a new clutch end-plate from the following table, then recheck.
  - NOTE: If the thickest clutch end-plate is installed, but the clearance is still over the standard, replace the clutch discs and clutch plates.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682144

**Fig. 443: Identifying Thickness Of Forward Clutch End Plate And Torque Specifications Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

## FORWARD CLUTCH END-PLATE

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

## FORWARD CLUTCH END-PLATE THICKNESS

Mark	Part Number	Thickness
14	22574-P4V-003	3.4 mm (0.134 in.)
15	22561-P4V-003	3.5 mm (0.138 in.)
16	22562-P4V-003	3.6 mm (0.142 in.)
17	22563-P4V-003	3.7 mm (0.146 in.)
18	22564-P4V-003	3.8 mm (0.150 in.)
19	22565-P4V-003	3.9 mm (0.154 in.)
20	22566-P4V-003	4.0 mm (0.157 in.)
21	22567-P4V-003	4.1 mm (0.161 in.)
22	22568-P4V-003	4.2 mm (0.165 in.)
23	22569-P4V-003	4.3 mm (0.169 in.)
24	22570-P4V-003	4.4 mm (0.173 in.)
25	22571-P4V-003	4.5 mm (0.177 in.)
26	22572-P4V-003	4.6 mm (0.181 in.)
27	22573-P4V-003	4.7 mm (0.185 in.)

22. After replacing the clutch end-plate, make sure that the clearance is within tolerance.

## END COVER/INTERMEDIATE HOUSING

## INTERMEDIATE HOUSING, REVERSE BRAKE, AND FORWARD CLUTCH INSTALLATION

**Exploded View** 

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682145

## **Fig. 444: Exploded View Of Intermediate Housing, Reverse Brake, And Forward Clutch Courtesy of AMERICAN HONDA MOTOR CO., INC.**

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# **Special Tools Required**

Reverse brake spring compressor 07TAE-P4V0110

- 1. Install 8 x 50 mm ATF feed pipe in the transmission housing, and install the 10.9 x 39.6 mm ATF feed pipes with new O-rings in the transmission housing.
- 2. Install the two dowel pins and new transmission housing gasket on the transmission housing.
- 3. Push the control shaft toward the outside of the transmission housing, then install the intermediate housing.
- 4. Install the manual valve body separator plate and two dowel pins on the intermediate housing, and install the manual valve body (four bolts) with the detent spring (one bolt).
- 5. Put the control shaft back, then install the roller in the intermediate housing with aligning the groove on the control shaft.
- 6. Install the new O-rings (A) on the reverse brake piston (B), then install the piston in the intermediate housing (C).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

## **Fig. 445: Installing Reverse Brake Piston In Intermediate Housing Courtesy of AMERICAN HONDA MOTOR CO., INC.**

- 7. Install the spring retainer/return spring assembly (D); Install the return springs on the spring guide (E) on the reverse brake piston.
- 8. Install the special tool through the drive pulley shaft to compress the return spring. Be sure the special tool (spring compressor attachment) is set over the return springs, not over the reverse brake piston.

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682147

## **Fig. 446: Installing Special Tool** Courtesy of AMERICAN HONDA MOTOR CO., INC.

9. Compress the return springs, making sure that the special tool is set over the return springs and the spring retainer tabs do not ride on the reverse brake

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

piston.



G03682148

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

## **Fig. 447: Compressing Return Spring Courtesy of AMERICAN HONDA MOTOR CO., INC.**

- 10. Install the snap ring in the intermediate housing above the spring retainer.
- 11. Verify that the snap ring end gap (A) is 15 mm (0.59 in.) or more.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682149
2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

### **Fig. 448: Identifying Snap Ring End Gap** Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 12. Inspect the brake discs, brake plates, and brake end-plate for wear, damage, and discoloration.
  - If the discs or plates are worn or damaged, replace the disc and plates as a set.
  - If the end-plate is worn, damaged, or discolored, replace the end-plate.
- 13. Soak the reverse brake discs thoroughly in CVTF for a minimum of 30 minutes. Before installing the plates and discs, make sure the inside of the brake is free of dirt and other foreign matter.
- 14. Install the disc spring (A) in the direction shown.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682150

### **Fig. 449: Identifying Direction For Installing Disc Spring Courtesy of AMERICAN HONDA MOTOR CO., INC.**

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

- 15. Starting with the reverse brake plate (B), alternately install the plates and discs (C). Install the reverse brake end-plate (D).
- 16. Install the snap ring by installing its end gap in the direction (A) shown.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682151

**Fig. 450: Installing Snap Ring** Courtesy of AMERICAN HONDA MOTOR CO., INC.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

- 17. Verify that the inside diameter (B) of the snap ring is 143.5 mm (5.65 in.) and above.
- 18. Verify that the snap ring end gap (A) is 18 mm (0.71 in.) and above.



G03682152

**Fig. 451: Identifying Snap Ring End Gap** Courtesy of AMERICAN HONDA MOTOR CO., INC.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

19. Set a dial indicator (A) on the reverse brake end-plate (B).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682153

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

### Fig. 452: Setting Dial Indicator On Reverse Brake End-Plate And Torque Specifications Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 20. Zero the dial indicator with lifting the top disc (C) up to contact the reverse brake end-plate to the snap ring (D).
- 21. Release the end-plate to lower the end-plate, and place a steel plate across the width of the reverse brake end-plate.
- 22. Press the steel plate (A) down with 39 N (4 kgf, 9 lbf) using a force gauge, and read the dial indicator (B). the dial indicator reads the clearance (C) between the reverse brake end-plate (D) and top disc (E). Take measurements in at least three places, and use the average as the actual clearance.

### Standard: 0.55-0.70 mm (0.022-0.028 in.)

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682154

# **Fig. 453: Checking Clearance Between Reverse Brake End-Plate And Top Disc**

### **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

- 23. If the clearance is out of standard, select a new reverse brake end-plate from the following table, then recheck.
  - NOTE: If the thickest end-plate is installed, but the clearance is still over the service limit, replace the reverse brake discs and plates as a set.

### **REVERSE BRAKE END-PLATE**

#### No. Part Number Thickness 22551-P4V-003 3.6 mm (0.142 in.) 1 22551 -PWR-003 3.7 mm (0.146 in.) A 22552-P4V-003 3.8 mm (0.150 in.) 2 22552-PWR-003 3.9 mm (0.154 in.) В 22553-P4V-003 |4.0 mm (0.157 in.) 3 22553-PWR-003 4.1 mm (0.161 in.) 22554-P4V-003 4.2 mm (0.165 in.) 4 22554-PWR-003 4.3 mm (0.169 in.) D 5 22555-P4V-003 4.4 mm (0.173 in.) 22555-PWR-003 4.5 mm (0.177 in.) E 22556-P4V-003 4.6 mm (0.181 in.) 6 F 22556-PWR-003 4.7 mm (0.185 in.) 22557-P4V-003 4.8 mm (0.189 in.) 7 8 22558-P4V-003 5.0 mm (0.197 in.)

### **REVERSE BRAKE END-PLATE SPECIFICATIONS**

- 24. After replacing the reverse brake end-plate, make sure that the clearance is within tolerance.
- 25. Install the snap ring retainer (A) over the drive pulley shaft (B).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



**Fig. 454: Installing Snap Ring Retainer Over Drive Pulley Shaft** Courtesy of AMERICAN HONDA MOTOR CO., INC.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

- 26. Wrap the drive pulley shaft splines with tape to prevent O-ring damage. Install the new O-ring (C) in the drive pulley shaft O-ring grooves, then remove the tape.
- 27. Install the forward clutch (D) on the drive pulley shaft, then install the snap ring (E) to secure the forward clutch.
- 28. Verify that the snap ring outside diameter (A) is 41.4 mm (1.63 in.) or less.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682156

### **Fig. 455: Identifying Snap Ring Outer Diameter** Courtesy of AMERICAN HONDA MOTOR CO., INC.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

29. Install the ring gear (A) on the forward clutch (B).



G03682157

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

### Fig. 456: Installing Ring Gear On Forward Clutch And Torque Specifications Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 30. Install the planetary carrier/input shaft assembly (C) through the drive pulley shaft (D) with aligning the sun gear (E) to the clutch discs and aligning the planetary carrier to the reverse brake discs.
- 31. Install the manual valve body lines (A) with new 0-rings (B) on the manual valve body (C) and intermediate housing (D).
- 32. Install the ATF feed pipe (E) with new O-rings (F) on the manual valve body.
- 33. Install the two dowel pins (G) and the new end cover gasket (H) on the intermediate housing, and install the new O-rings (I) over the ATF feed pipes (J).
- 34. Install the end cover (K).
- 35. Install the CVT input shaft (drive pulley) speed sensor with a new O-ring.

## TRANSMISSION HOUSING/FLYWHEEL HOUSING

### START CLUTCH AND FLYWHEEL HOUSING INSTALLATION

## **Special Tools Required**

Start clutch installer 07TAE-P4VA130

1. Install the sealing ring (A) on the new secondary drive gear (B).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682158

### **Fig. 457: Intalling Sealing Ring On Secondary Drive Gear** Courtesy of AMERICAN HONDA MOTOR CO., INC.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

2. Install the park pawl (A), pawl spring (B), and pawl shaft (C) in the transmission housing, then move the control lever to any position other than the P position.



### **Fig. 458: Installing Park Pawl, Pawl Spring, And Pawl Shaft In Transmission Housing**

## Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 3. Install the secondary gear shaft (D) in the transmission housing.
- 4. Wrap the driven pulley shaft splines with tape to prevent O-rings damage, install the new O-rings (E) in the shaft O-ring grooves, and remove the tape.
- 5. Install the secondary drive gear assembly (F) in the new start clutch (G), then install them on the driven pulley shaft (H).
- 6. Pull the handle of the special tool up, then install the tip of it into the driven pulley shaft feed pipe hole, and set the special tool on the start clutch. Do not allow dirt or other foreign particles to enter into the transmission.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682160

### **Fig. 459: Pulling Special Tool Handle** Courtesy of AMERICAN HONDA MOTOR CO., INC.

7. Push the handle (A) of the special tool, then tighten the nut to seat the secondary drive gear assembly on the drive pulley shaft.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



### G03682161

### **Fig. 460: Seating Secondary Drive Gear Assembly On Drive Pulley Shaft Courtesy of AMERICAN HONDA MOTOR CO., INC.**

8. Pull the handle of the special tool up, and remove the special tool.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

9. Install the 25.5 mm cotters in the cotter groove on the driven pulley shaft, then measure the clearance between the cotters (A) and the start clutch guide (B) with a feeler gauge (C). Take measurements in at least three places, and use the average as the actual clearance.

Standard: 0-0.13 mm (0-0.005 in.)



### **Fig. 461: Measuring Thickness Of Cotter** Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 10. If the clearance is out of standard, remove the cotters, and measure their thickness.
- 11. Select and install the new 25.5 mm cotters as a set, then recheck.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

### COTTERS, 25.5 mm

### **COTTERS, 25.5 MM SPECIFICATIONS**

No.	Part Number	Thickness
A	90429-P4V-000	2.9 mm (0.114 in.)
В	90430-P4V-000	3.0 mm (0.118 in.)
С	90431-P4V-000	3.1 mm (0.122 in.)
D	90432-P4V-000	3.2 mm (0.126 in.)

- 12. After replacing the cotters, make sure that the clearance is within the tolerance.
- 13. Install the cotter retainer and snap ring.
- 14. Verify that the snap ring outside diameter (A) is 33.9 mm (1.33 in.) or less.



**Fig. 462: Identifying Snap Ring Outer Diameter** Courtesy of AMERICAN HONDA MOTOR CO., INC.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

15. Install the thrust washer (A), thrust needle bearing (B), thrust washer (C), ATF pump drive sprocket hub (D), 22 x 28 mm thrust shim (E), and snap ring (F) on the input shaft (G).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682164

### **Fig. 463: Installing Thrust Washer, Needle Bearing, Washer, ATF Pump Drive Sprocket Hub, Thrust Shim, And Snap Ring On Input Shaft Courtesy of AMERICAN HONDA MOTOR CO., INC.**

16. Verify that the snap ring outside diameter (A) is 26.3 mm (1.04 in.) or less.



**Fig. 464: Identifying Snap Ring Outside Diameter** Courtesy of AMERICAN HONDA MOTOR CO., INC.

17. Measure the clearance between the 22 x 28 mm thrust shim (A) and snap ring (B) with a feeler gauge (C). Take measurements in at least three places, and use the average as the actual clearance.

Standard: 0.37-0.65 mm (0.015-0.026 in.)



G03682166

### **Fig. 465: Measuring Thrust Shim Thickness** Courtesy of AMERICAN HONDA MOTOR CO., INC.

18. If the clearance is out of standard, remove the 22 x 28 mm thrust shim, and

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

measure its thickness.

19. Select and install a new 22 x 28 mm thrust shim, then recheck.

### THRUST SHIM, 22 x 28 mm

### **THRUST SHIM, 22 X 28 MM SPECIFICATIONS**

No.	Part Number	Thickness
С	90573-P4V-000	1.15 mm (0.045 in.)
D	90574-P4V-000	1.40 mm (0.055 in.)
E	90575-P4V-000	1.65 mm (0.065 in.)
F	90576-P4V-000	1.90 mm (0.075 in.)
G	90577-P4V-000	2.15 mm (0.085 in.)
Η	90578-P4V-000	2.40 mm (0.095 in.)

- 20. After replacing the 22 x 28 mm thrust shim, make sure the clearance is within the tolerance and the snap ring outside diameter is correct.
- 21. Install the ATF pump drive sprocket (A) on the sprocket hub (B), and put the ATF pump drive chain (C) on the ATF pump drive sprocket and ATF pump driven sprocket (D), then install and tighten the three bolts.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight





### **Fig. 466: Installing ATF Pump Drive Sprocket On Sprocket Hub And Torque Specifications**

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

22. Install the differential assembly (A).



G03682168

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

### **Fig. 467: Installing Differential Assembly And Torque Specifications Courtesy of AMERICAN HONDA MOTOR CO., INC.**

- 23. Install the ATF feed pipe (B) with a new O-ring (C) in the transmission housing (D).
- 24. Install the three dowel pins (E) and new flywheel housing gasket (F) on the transmission housing.
- 25. Install a new O-ring (G) over the ATF feed pipe.
- 26. Install the flywheel housing (H) and tighten the mounting bolts with the harness clamp bracket (I).

## TRANSMISSION LOWER VALVE BODY

### LOWER VALVE BODY ASSEMBLY, ATF STRAINER, AND ATF PAN INSTALLATION

1. Install the solenoid harness connector (A) with a new O-ring (B), and install the lower valve body assembly (C) with the ATF feed pipes (D).

#### 2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682169

### **Fig. 468: Installing Lower Valve Body Assembly, ATF Strainer, And ATF Pan With Specified Torques Courtesy of AMERICAN HONDA MOTOR CO., INC.**

- 2. Install the ATF strainer (E) with a new O-ring (F).
- 3. Install the ATF pan (G) with the two dowel pins (H) and a new ATF pan gasket (I).
- 4. Install the ATF cooler inlet line mounting bolt (J).

### TRANSMISSION RANGE SWITCH

#### TRANSMISSION RANGE SWITCH INSTALLATION

1. Set the transmission to the N position by turning the control lever (A). Do not squeeze the end of the control shaft tips together when setting. If the tips are squeeze together it will cause a faulty signal or position due to the play between the control shaft and the switch.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682170

**Fig. 469: Turning Control Lever** Courtesy of AMERICAN HONDA MOTOR CO., INC.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

2. Set the transmission range switch to the N position. The switch clicks in the N position.
2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682171

**Fig. 470: Identifying Transmission Range Switch N Position Courtesy of AMERICAN HONDA MOTOR CO., INC.**  2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

 Install the transmission range switch (A) gently on the selector control shaft (B), then tighten the bolts. Do not move the switch when tightening the bolts.



Fig. 471: Identifying Tightening Torque Of Transmission Range Switch

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

## **Bolts** Courtesy of AMERICAN HONDA MOTOR CO., INC.

### **CVT DIFFERENTIAL**

**COMPONENT LOCATION INDEX** 

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682173

## **Fig. 472: CVT Differential Component Location Index Courtesy of AMERICAN HONDA MOTOR CO., INC.**

**BACKLASH INSPECTION** 

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

1. Install the driveshafts on the differential, then place the axles on V-blocks.



G03682174

## **Fig. 473: Checking Pinion Gear Backlash** Courtesy of AMERICAN HONDA MOTOR CO., INC.

2. Check the backlash of the pinion gears (A) with a dial indicator (B).

### Standard: 0.05-0.15 mm (0.002-0.006 in.)

3. If the backlash is out of standard, replace the differential assembly.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

#### DIFFERENTIAL CARRIER/FINAL DRIVEN GEAR REPLACEMENT

1. Remove the final driven gear from the differential carrier. The final driven gear bolts have left-hand threads.



2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

## **Fig. 474: Identifying Loosening Torque Of Final Driven Gear Bolts** Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 2. Install the final driven gear with the chamfered side on the inner bore facing the differential carrier in the direction shown.
- 3. Tighten the eight bolts in the position shown in a crisscross pattern.

### CARRIER BEARING REPLACEMENT

## **Special Tools Required**

- Driver, 40 mm I.D. 07746-0030100
- Attachment 35 mm I.D. 07746-0030400
- 1. Remove the bearings (A) with a commercially available bearing puller (B) and shaft protector (C).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682176

### **Fig. 475: Removing Carrier Bearing** Courtesy of AMERICAN HONDA MOTOR CO., INC.

2. Install the bearings with the special tools and a press. Press the bearing on until

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

it bottoms.



G03682177

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

## **Fig. 476: Installing Carrier Bearing Courtesy of AMERICAN HONDA MOTOR CO., INC.**

#### OIL SEAL REPLACEMENT

### **Special Tools Required**

- Driver attachment, 58 mm 07JAD-PH80101
- Driver attachment, 64 x 72 mm 07JAD-PN00100 Driver 07749-0010000
- 1. Remove the oil seal from the transmission housing.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682178

### **Fig. 477: Removing Oil Seal From Transmission Housing Courtesy of AMERICAN HONDA MOTOR CO., INC.**

2. Remove the oil seal from the flywheel housing.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682179

### **Fig. 478: Removing Oil Seal From Flywheel Housing** Courtesy of AMERICAN HONDA MOTOR CO., INC.

3. Install the new oil seal in the transmission housing with the special tools.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682180

### **Fig. 479: Installing Oil Seal In Transmission Housing Courtesy of AMERICAN HONDA MOTOR CO., INC.**

4. Install the new oil seal in the flywheel housing with the special tools.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682181

## **Fig. 480: Installing Oil Seal In Flywheel Housing Courtesy of AMERICAN HONDA MOTOR CO., INC.**

#### CARRIER BEARING SIDE CLEARANCE INSPECTION

## **Special Tools Required**

- Driver, 40 mm I.D. 07746-0030100
- Attachment 35 mm I.D. 07746-0030400

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

1. Install the differential assembly in the transmission housing, then drive the differential to seat it in the housing.



G03682182

## **Fig. 481: Installing Differential Assembly In Transmission Housing Courtesy of AMERICAN HONDA MOTOR CO., INC.**

2. Install the three dowel pins (A) and the gasket (B) on the transmission housing

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

(C).

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

## **Fig. 482: Installing Dowel Pins And Gasket On Transmission Housing** <u>With Specified Torques</u> **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

- 3. Place the flywheel housing (D) on the transmission housing.
- 4. Install the housing bolts with the harness clamp bracket (E), and tighten the bolts in two or more steps in a crisscross pattern.
- 5. Install the set ring.

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight



G03682184

**Fig. 483: Installing Set Ring Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

6. Measure the clearance between the set ring and carrier bearing outer race with a feeler gauge.

### Standard: 0-0.15 mm (0-0.006 in.)



G03682185

### **Fig. 484: Measuring Clearance Between Set Ring And Carrier Bearing** <u>Outer Race</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 7. If the clearance is out of standard, remove the 66 mm set ring, and measure its thickness.
- 8. Select and install a new set ring, then recheck the clearance and make sure it is within the standard.

## SET RING, 66 mm

2000-06 TRANSMISSION Continuously Variable Transmission (CVT) - Insight

# **SET RING, 66 MM SPECIFICATIONS**

No.	Part Number	Thickness
1	90414-PN0-000	1.50 mm (0.059 in.)
2	90415-PN0-000	1.60 mm (0.063 in.)
3	90416-PN0-000	1.70 mm (0.067 in.)
4	90417-PN0-000	1.80 mm (0.071 in.)
5	90418-PN0-000	1.90 mm (0.075 in.)
6	90419-PN0-000	2.00 mm (0.079 in.)