2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

#### 2000-06 ENGINE PERFORMANCE

**PGM-FI System - Insight** 

## **COMPONENT LOCATION INDEX**



## **Fig. 1: Identifying PGM-FI Components Location (1 Of 2)** Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### 2000-06 ENGINE PERFORMANCE PGM-FI System - Insight





G03680705

## **Fig. 2: Identifying PGM-FI Components Location (2 Of 2)** Courtesy of AMERICAN HONDA MOTOR CO., INC.

## DTC TROUBLESHOOTING

## DTC INDEX

DTC	Description

DTC P0106	MAP Sensor Vacuum Connection Problem
DTC P0107	MAP Sensor Circuit Low Voltage
DTC P0108	MAP Sensor Circuit High Voltage
DTC P0111	IAT Sensor Circuit Range/ Performance Problem (2006
	model)
DTC P116	ECT Sensor Circuit Range/ Performance Problem (2006
	model)
<u>DTC P0112</u>	IAT Sensor Circuit Low Voltage
DTC P0113	IAT Sensor Circuit High Voltage
<b>DTC P0116</b>	ECT Sensor Circuit Range/ Performance Problem (2000-2005
	models)
DTC P0116	ECT Sensor Circuit Range/ Performance Problem (2006
	model)
DTC P0117	ECT Sensor Circuit Low Voltage
DTC P0118	ECT Sensor Circuit High Voltage
DTC P0122	TP Sensor Circuit Low Voltage
DTC P0123	TP Sensor Circuit High Voltage
DTC P0125	ECT Sensor Malfunction/Slow Response (2004-2005 models)
DTC P0125	ECT Sensor Malfunction/Slow Response (2006 model)
DTC P0128	Cooling System Malfunction
DTC P0133	A/F Sensor (Sensor 1) Circuit Slow Response (2004-2006
	models)
<u>DTC P1163</u>	A/F Sensor (Sensor 1)) Circuit Slow Response (2002-2003
	M/T models) (2001-2003 CVT models)
DTC P0134	A/F Sensor (Sensor 1) Signal Stuck Lean
<u>DTC P0135</u>	A/F Sensor (Sensor 1) Heater Circuit Malfunction (2002-2006
	M/T models) (CVT models)
DTC P0137	Secondary HO2S (Sensor 2) Circuit Low Voltage
DTC P0138	Secondary HO2S (Sensor 2) Circuit High Voltage (2000-2004
	models)
DTC P0138	Secondary HO2S (Sensor 2) Circuit High Voltage (2005-2006
	models)

DTC P0139	Secondary HO2S (Sensor 2) Slow Response
DTC P0141	Secondary HO2S (Sensor 2) Heater Circuit Malfunction
DTC P0143	Third H02S (Sensor 3) Circuit Low Voltage (2002-2006 M/T
	models)
<b>DTC P0144</b>	Third H02S (Sensor 3) Circuit High Voltage (2002-2006 M/T
	models)
<u>DTC P0145</u>	Third H02S (Sensor 3) Slow Response (2002-2006 M/T
	models)
<u>DTC P0147</u>	Third H02S (Sensor 3) Heater Circuit Malfunction (2002-
	2006 M/T models)
<u>DTC P0171</u>	Fuel System Too Lean
DTC P0172	Fuel System Too Rich
DTC P0300	Random Misfire and Any Combination of the Following
DTC P0301	No. 1 Cylinder Misfire Detected
DTC P0302	No. 2 Cylinder Misfire Detected
DTC P0303	No. 3 Cylinder Misfire Detected
<u>DTC P0301</u>	No. 1 Cylinder Misfire Detected
DTC P0302	No. 2 Cylinder Misfire Detected
DTC P0303	No. 3 Cylinder Misfire Detected
DTC P0325	Knock Sensor Circuit Malfunction
DTC P0335	CKP Sensor No Signal
DTC P0336	CKP Sensor Intermittent Interruption (2000-2003 models)
DTC P0339	CKP Sensor Intermittent Interruption (2004-2006 models)
DTC P0340	CMP Sensor A (TDC 1) No Signal (2004-2006 models)
<b>DTC P0344</b>	CMP Sensor A (TDC 1) Intermittent Interruption (2004-2006
	models)
DTC P0365	CMP Sensor B (TDC 2) No Signal (2004-2006 models)
DTC P0369	CMP Sensor B (TDC 2) Intermittent Interruption (2004-2006
	models)
<u>DTC P1361</u>	CMP Sensor A (TDC 1) Circuit Intermittent Interruption
	(2000-2003 models)
<u>DTC P1362</u>	CMP Sensor A (TDC 1) No Signal (2000-2003 models)

<u>DTC P1366</u>	CMP Sensor B (TDC 2) Circuit Intermittent Interruption
DTC <b>P1367</b>	CMP Sensor B (TDC 2) No Signal (2000-2003 models)
$\frac{DTCT1507}{DTC}$	VSS Circuit Malfunction
$\frac{DTCT0500}{DTC}$	ECM Power Source Circuit Uperported Voltage (2001, 2004
	models)
DTC P0563	ECM Power Source Circuit Unexpected Voltage (2005-2006
	models)
DTC P0607	ECM Internal Circuit Malfunction (2004-2006 models)
DTC P1607	ECM Internal Circuit Malfunction (2000-2003 models)
DTC P0630	VIN Not Programmed or Mismatch (2005-2006 models)
DTC P0685	ECM Power Control Circuit/Internal Circuit Malfunction
	(2006 model)
DTC P07xx	A/T Control System Malfunction
DTC P16xx	A/T Control System Malfunction
DTC P17xx	A/T Control System Malfunction
DTC P18xx	A/T Control System Malfunction
DTC P21xx	A/T Control System Malfunction
DTC P1106	BARO Sensor Range/Performance Problem (2000-2003
	models)
<b>DTC P2227</b>	BARO Sensor Range/Performance Problem (2004-2006
	models)
DTC P1107	BARO Sensor Circuit Low Voltage (2000-2003 models)
DTC P1108	BARO Sensor Circuit High Voltage (2000-2003 models)
DTC P2228	BARO Sensor Circuit Low Voltage (2004-2006 models)
DTC P2229	BARO Sensor Circuit High Voltage (2004-2006 models)
<u>DTC P1109</u>	BARO Sensor Circuit Out of Range High
DTC P1121	TP Sensor Signal Lower Than Expected
DTC P1122	TP Sensor Signal Higher Than Expected
<u>DTC P1128</u>	MAP Sensor Signal Lower Than Expected
<u>DTC P1129</u>	MAP Sensor Signal Higher Than Expected
DTC P1130	Secondary HO2S (Sensor 2) and Third HO2S (Sensor 3)

	Malfunction (2002-2006 M/T models)
DTC P1157	A/F Sensor (Sensor 1) AFS Circuit High Voltage (2002-2006
	M/T models) (CVT model)
DTC P1158	A/F Sensor (Sensor 1) AFS-Circuit Low Voltage (2002-2003
	M/T models) (2001-2003 CVT models)
DTC P2252	A/F Sensor (Sensor 1) AFS-Circuit Low Voltage (2004-2006
	models)
<u>DTC P1159</u>	A/F Sensor (Sensor 1) AFS+ Circuit Low Voltage (2002-2003
	M/T models) (2001-2003 CVT models)
DTC P2238	A/F Sensor (Sensor 1) AFS+ Circuit Low Voltage (2004-2006
	models)
DTC P1162	A/F Sensor (Sensor 1) Circuit Malfunction (2000-2001 M/T
	models)
<u>DTC P1163</u>	A/F Sensor (Sensor 1) Slow Response (2000-2001 M/T
	models)
<u>DTC P1164</u>	A/F Sensor (Sensor I) Range/Performance Problem (2000-
	$\frac{2003 \text{ M/1 models}}{2001-2003 \text{ CV1 models}}$
DTC P2A00	A/F Sensor (Sensor 1) Range/Performance Problem (2004-
DTC D11(5	2006 models)
DIC P1165	A/F sensor (Sensor 1) Circuit Range/Performance Problem
DTC D11((	(2000-2001 M/T models)
DIC P1100	A/F Sensor (Sensor 1) Heater Circuit Manunction (2000-2001 M/T models)
DTC P1167	A/E Sensor (Sensor 1) Heater System Malfunction (2000
	2002 M/T models)
DTC P1168	A/E Sensor (Sensor 1) LABEL Circuit Low Input (2000-2001
	M/T models)
DTC P1169	A/F Sensor (Sensor 1) LABEL Circuit High Input (2000-2001
	M/T models)
DTC P1172	A/F Sensor (Sensor 1) Circuit Out of Range High (2005-2006
	models)
DTC P1297	ELD Circuit Low Voltage
DTC P1298	ELD Circuit High Voltage

DTC P1522	Brake Booster Pressure Sensor Circuit Low Voltage
DTC P1523	Brake Booster Pressure Sensor Circuit High Voltage
DTC P1541	HTRS Passenger Compartment Heater Standby Signal Circuit
	Low Input;
DTC P1542	HTRS Passenger Compartment Heater Standby Signal Circuit
	High Input
DTC P15B2	Brake Fluid Pressure Sensor A Circuit Low Voltage (2005-
	2006 M/T models)
<u>DTC P15B3</u>	Brake Fluid Pressure Sensor A Range/Performance Problem
	(2005-2006 M/T models)
<u>DTC P15B4</u>	Brake Fluid Pressure Sensor B Circuit Low Voltage (2005-
	2006 M/T models)
<u>DTC P15B5</u>	Brake Fluid Pressure Sensor B Range Performance Problem
	(2005-2006 M/T models)
<u>DTC P15B6</u>	Brake Fluid Pressure Sensor A/B Circuit Malfunction (2005-
	2006 M/1 models)
DIC P1600	IMA System Malfunction
<u>DTC P1601</u>	IMA System Malfunction
<u>DTC P1640</u>	ACTTRQ Motor Torque Signal Circuit Low Input;
DTC P1641	ACTTRQ Motor Torque Signal Circuit High Input
<u>DTC P1642</u>	QBATT Battery Signal Circuit Low Input
<u>DTC P1643</u>	QBATT Battery Signal Circuit High Input
DTC P1644	MOTFSA Motor Control Module Signal Malfunction
<u>DTC P1645</u>	MOTFSB Motor Control Module Signal Malfunction
DTC P1646	MOTSTB Motor Control Module Signal Malfunction
DTC P1655	A/T Fl Signal A/B Circuit Malfunction (2001-2003 CVT
	models)
<u>DTC U0101</u>	A/T Fl Signal A/B Circuit Malfunction (2004-2006 CVT
	models)
<u>DTC P2270</u>	Secondary HO2S (Sensor 2) Circuit Signal Stuck Lean (2005-
	2006 models)
DTC P2271	Secondary HO2S (Sensor 2) Circuit Signal Stuck Rich (2005-
	2006 models)

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

## **DTC P2610** ECM Ignition Off Internal Timer Malfunction (2006 model)

## DTC P0106: MAP SENSOR VACUUM CONNECTION PROBLEM

## NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Reset the ECM with the HDS (see HDS CLEAR COMMAND).
- 2. Start the engine and keep the engine speed at 1,000 RPM for one minute with the transmission in Park or neutral position.
- 3. Check for Temporary DTCs or DTCs with the HDS.

## Is DTC P0106 indicated?

YES - Go to step 8.

NO - Go to step 4.

- 4. Turn the ignition switch OFF.
- 5. Turn the ignition switch ON (II).
- 6. Check the MAP SENSOR in the DATA LIST with the HDS.

## Does it indicate atmospheric pressure?

YES - Go to step 7.

**NO** - Replace the MAP sensor.

- 7. Start the engine. Hold the engine speed at 3,000 rpm without load (in Park or neutral) until the radiator fan comes on, then turn the ignition switch OFF.
- 8. Start the engine.
- 9. Check the MAP SENSOR in the DATA LIST with the HDS.

# Is about 40.0 kPa (12.0 in.Hg, 300 mmHg), or 1.23 V or less indicated within 1 second after starting the engine?

**YES** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the MAP sensor and the ECM.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

NO - Go to step 10.

10. Check for a vacuum leak between the MAP sensor and the throttle body.

## Is there a leak?

**YES** - Repair the vacuum leak.

NO - Go to step 11.

- 11. Turn the ignition switch OFF.
- 12. Turn the ignition switch ON (II).
- 13. Check the MAP SENSOR in the DATA LIST with the HDS.

## Does it indicate atmospheric pressure?

**YES** - Go to step 14.

**NO** - Replace the MAP sensor.

- 14. Start the engine. Hold the engine speed at 3,000 rpm without load (in Park or neutral) until the radiator fan comes on, then turn the ignition switch OFF.
- 15. Start the engine.
- 16. Check the MAP SENSOR in the DATA LIST with the HDS.

# Is about 40.0 kPa (12.0 in.Hg, 300 mmHg), or 1.23 V or less indicated within 1 second after starting the engine?

YES - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

**NO** - Replace the MAP sensor.

## DTC P0107: MAP SENSOR CIRCUIT LOW VOLTAGE

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Turn the ignition switch ON (II).
- 2. Check the MAP SENSOR in the DATA LIST with the HDS.

## Is about 101 kPa (30 in.Hg, 760 mmHg) or 2.9 V indicated?

**YES** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the MAP sensor and the ECM.

**NO** - Go to step 3.

- 3. Turn the ignition switch OFF.
- 4. Disconnect the MAP sensor 3P connector.
- 5. Turn the ignition switch ON (II).
- 6. Measure voltage between MAP sensor 3P connector terminals No. 1 and No. 2.

## **MAP SENSOR 3P CONNECTOR**



Wire side of female terminals

G03680706

**Fig. 3: Measuring Voltage Between Map Sensor 3P Connector Terminals No. 1 And 2 Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

## Is there about 5 V?

**YES** - Go to step 8.

**NO** - Go to step 7.

7. Measure voltage between ECM connector terminals C7 and C19.

## ECM CONNECTOR C (31P)



Wire side of female terminals

G03680707

**Fig. 4: Measuring Voltage Between ECM Connector Terminals C7 And** <u>C19</u> **Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

## Is there about 5 V?

**YES** - Repair open in the wire between the ECM (C19) and the MAP sensor.

**NO** - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u>

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

<u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u>), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u>).

8. Check the MAP SENSOR in the DATA LIST with the HDS.

## Is about 2 kPa (0.6 in.Hg, 15 mmHg), or 0.5 V or less indicated?

**YES** - Go to step 9.

**NO** - Replace the MAP sensor.

- 9. Turn the ignition switch OFF, and wait for 10 seconds.
- 10. Disconnect ECM connector C (31P).
- 11. Check for continuity between MAP sensor 3P connector terminal No. 3 and body ground.

# **MAP SENSOR 3P CONNECTOR**



## Wire side of female terminals

G03680708

**Fig. 5: Checking Continuity Between MAP Sensor 3P Connector Terminal No. 3 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

Is there continuity?

YES -

- Go to step 12 (CVT model).
- Repair short in the wire between the ECM (C17) and the MAP sensor (M/T model).

NO - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

- 12. Disconnect TCM connector B (22P).
- 13. Check for continuity between MAP sensor 3P connector terminal No. 3 and body ground.

# **MAP SENSOR 3P CONNECTOR**



## Wire side of female terminals

G03680709

**Fig. 6: Checking Continuity Between MAP Sensor 3P Connector Terminal** <u>No. 3 And Body Ground</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

**YES** - Repair short in the wire between the ECM (C17), the TCM (B2), and the MAP sensor.

**NO** - Substitute a known-good TCM, and recheck (see <u>HOW TO</u> <u>**TROUBLESHOOT CIRCUIT AT THE TCM**</u>). If the

symptom/indication goes away, replace the original TCM.

DTC P0108: MAP SENSOR CIRCUIT HIGH VOLTAGE

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Start the engine. Hold the engine speed at 3,000 rpm without load (in Park or neutral) until the radiator fan comes on, then let it idle.
- 2. Check the MAP SENSOR in the DATA LIST with the HDS.

## Is about 101 kPa (30 in.Hg, 760 mmHg), or 2.9 V or more indicated?

**YES** - Go to step 3.

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the MAP sensor and the ECM.

- 3. Turn the ignition switch OFF.
- 4. Disconnect the MAP sensor 3P connector.
- 5. Connect MAP sensor 3P connector terminals No. 2 and No. 3 with a jumper wire.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight





Wire side of female terminals

G03680710

## **Fig. 7: Connecting MAP Sensor 3P Connector Terminals No. 2 And 3** <u>With Jumper Wire</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 6. Turn the ignition switch ON (II).
- 7. Check the MAP SENSOR in the DATA LIST with the HDS.

Is about 101 kPa (30 in.Hg, 760 mmHg), or 2.9 V or more indicated?

**YES** - Go to step 8.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

**NO** - Replace the MAP sensor.

- 8. Remove the jumper wire.
- 9. Measure voltage between MAP sensor 3P connector terminals No. 1 and No. 2.

## **MAP SENSOR 3P CONNECTOR**



Wire side of female terminals G03680711

**Fig. 8: Measuring Voltage Between MAP Sensor 3P Connector Terminals** <u>No. 1 And 2</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

## Is there about 5 V?

YES - Go to step 10.

NO - Go to step 14.

- 10. Turn the ignition switch OFF.
- 11. Connect ECM connector terminals C7 and C17 with a jumper wire.

## ECM CONNECTOR C (31P)



Wire side of female terminals

G03680712

## Fig. 9: Connecting ECM Connector Terminals C7 And C17 With Jumper Wire Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 12. Turn the ignition switch ON (II).
- 13. Check the MAP SENSOR in the DATA LIST with the HDS.

## Is about 101 kPa (30 in.Hg, 760 mmHg), or 2.9 V or more indicated?

YES - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

**NO** - Repair open in the wire between the ECM (C17) and the MAP sensor.

- 14. Turn the ignition switch OFF, and wait for 10 seconds.
- 15. Disconnect ECM connector C (31P).
- 16. Connect MAP sensor 3P connector terminal No. 2 to body ground with a jumper wire.

# **MAP SENSOR 3P CONNECTOR**



## Wire side of female terminals

G03680713

**Fig. 10: Connecting MAP Sensor 3P Connector Terminal No. 2 To Body Ground With Jumper Wire Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

17. Check for continuity between ECM connector terminal C7 and body ground.

## ECM CONNECTOR C (31P)



Wire side of female terminals

G03680714

## **Fig. 11: Checking Continuity Between ECM Connector Terminal C7 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

## Is there continuity?

YES - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 MAT models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the

## original ECM (see <u>ECM REPLACEMENT</u>).

**NO** - Repair open in the wire between the ECM (C7) and the MAP sensor.

# DTC P0111: IAT SENSOR CIRCUIT RANGE/ PERFORMANCE PROBLEM (2006 MODEL); DTC P1116: ECT SENSOR CIRCUIT RANGE/ PERFORMANCE PROBLEM (2006 MODEL)

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

1. Check for poor connections or loose terminals at the ECT sensor and the IAT sensor.

## Are the connections and terminals OK?

YES - Go to step 2.

NO - Repair the connections or terminals, then go to step 25.

- 2. Start the engine, and let it idle for 10 minutes.
- 3. Check the ECT SENSOR in the DATA LIST with the HDS.

## Is about 129°F (54°C) or less, or 1.54 V or more indicated?

 $\mathbf{YES}$  - Replace the ECT sensor, then go to step 25 .

**NO** - Go to step 4.

- 4. Turn the ignition switch OFF.
- 5. Remove the IAT sensor.
- 6. Allow the IAT sensor to cool to  $77^{\circ}F(25^{\circ}C)$ .
- 7. Note the ambient temperature.
- 8. Connect the IAT sensor to the 2P connector. But do not install the sensor on the intake air duct.
- 9. Turn the ignition switch ON (II).
- 10. Note the value of the IAT SENSOR quickly in the DATA LIST with the HDS.
- 11. Compare the IAT SENSOR and the ambient temperature.

## **Does the IAT SENSOR differ 5.4°F (3°C) or more?**

#### 2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

**YES** - Replace the IAT sensor, then go to step 25. **NO** - Go to step 12.

- 12. Disconnect the IAT sensor from the 2P connector.
- 13. Using a heat gun, below hot air on the IAT sensor for a few seconds. Do not apply the heat longer than a few seconds or you will damage the sensor.
- 14. Connect the IAT sensor to the 2P connector. Do not install it on the intake air duct.
- 15. Check the IAT SENSOR in the DATA LIST with the HDS.

## Does the IAT SENSOR change 82°F (28°C) or more?

**YES** - Go to step 16.

NO - Replace the IAT sensor, then go to step 25.

- 16. Turn the ignition switch OFF.
- 17. Drain the coolant (see COOLANT REPLACEMENT).
- 18. Remove the ECT sensor.
- 19. Allow the ECT sensor to cool to  $77^{\circ}F(25^{\circ}C)$ .
- 20. Note the ambient temperature.
- 21. Connect the ECT sensor to the 2P connector. Do not install the sensor on the engine.
- 22. Turn the ignition switch ON (II).
- 23. Note the value of ECT SENSOR quickly in the DATA LIST with the HDS.
- 24. Compare the ECT SENSOR and the ambient temperature.

## **Does the ECT SENSOR differ 5.4°F (3°C) or more?**

**YES** - Replace the ECT sensor, then go to step 25.

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the ECT sensor and the ECM.

- 25. Turn the ignition switch ON (II).
- 26. Reset the ECM with the HDS.
- 27. Do the ECM idle learn procedure (see ECM IDLE LEARN PROCEDURE ).

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

28. Check for Temporary DTCs or DTCs with the HDS.

## Are any Temporary DTCs or DTCs indicated?

**YES** - If DTC P0111 and/or P1116 is indicated, check for poor connections or loose terminals at the ECT sensor, or the IAT sensor and the ECM, then go to step 1. If any other Temporary DTCs or DTCs are indicated, go to the indicated **DTC TROUBLESHOOTING** 

**NO** - Troubleshooting is complete.

## DTC P0112: IAT SENSOR CIRCUIT LOW VOLTAGE

## NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Turn the ignition switch ON (II).
- 2. Check the IAT SENSOR in the DATA LIST with the HDS.

## Is 302°F (150°C) or higher, or 0 V indicated?

**YES** - Go to step 3.

NO - Go to step 10.

- 3. Disconnect the IAT sensor 2P connector.
- 4. Check the IAT SENSOR in the DATA LIST with the HDS.

## Is 302°F (150°C) or higher, or 0 V indicated?

**YES** - Go to step 5.

**NO** - Replace the IAT sensor.

- 5. Turn the ignition switch OFF, and wait for 10 seconds.
- 6. Disconnect ECM connector C (31P).
- 7. Check for continuity between IAT sensor 2P connector terminal No. 2 and body ground.

# IAT SENSOR 2P CONNECTOR



## Wire side of female terminals

G03680715

**Fig. 12: Checking Continuity Between IAT Sensor Connector Terminal** <u>No. 2 And Body Ground</u> **Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

Is there continuity?

YES -

- Go to step 8 (CVT model).
- Repair short in the wire between the ECM (C25) and the IAT sensor (M/T model).

NO - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

- 8. Disconnect TCM connector B (22P).
- 9. Check for continuity between IAT sensor 2P connector terminal No. 2 and body ground.

# IAT SENSOR 2P CONNECTOR



## Wire side of female terminals

G03680716

**Fig. 13: Checking Continuity Between IAT Sensor 2P Connector Terminal** <u>No. 2 And Body Ground</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

**YES** - Repair short in the wire between the ECM (C25), the TCM (B19) and the IAT sensor.

**NO** - Substitute a known-good TCM, and recheck (see <u>HOW TO</u> <u>**TROUBLESHOOT CIRCUIT AT THE TCM**</u>). If the

symptom/indication goes away, replace the original TCM.

10. Check the temperature reading on the HDS.

# Is the correct ambient temperature indicated? If the engine is warm, the reading will be higher than ambient temperature.

**YES** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the IAT sensor and the ECM.

**NO** - Replace the IAT sensor.

## DTC P0113: IAT SENSOR CIRCUIT HIGH VOLTAGE

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Turn the ignition switch ON (II).
- 2. Check the IAT SENSOR in the DATA LIST with the HDS.

## Is $-4^{\circ}F$ (-20°C) or less, or 5 V indicated?

**YES** - Go to step 3.

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the IAT sensor and the ECM.

- 3. Turn the ignition switch OFF.
- 4. Disconnect the IAT sensor 2P connector.
- 5. Connect IAT sensor 2P connector terminals No. 1 and No. 2 with a jumper wire.

# IAT SENSOR 2P CONNECTOR



# JUMPER WIRE

# Wire side of female terminals

G03680717

## **Fig. 14: Connecting IAT Sensor 2P Connector Terminals No. 1 And 2** <u>With Jumper Wire</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 6. Turn the ignition switch ON (II).
- 7. Check the IAT SENSOR in the DATA LIST with the HDS.

#### 2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

## Is -4°F( -20°C) or less, or 5 V indicated?

YES - Go to step 8.

**NO** - Replace the IAT sensor.

- 8. Turn the ignition switch OFF.
- 9. Remove the jumper wire.
- 10. Turn the ignition switch ON (II).
- 11. Measure voltage between IAT sensor 2P connector terminal No. 2 and body ground.

# IAT SENSOR 2P CONNECTOR



## Wire side of female terminals

G03680718

**Fig. 15: Measuring Voltage Between IAT Sensor 2P Connector Terminal No. 2 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

Is there about 5 V?

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

**YES** - Go to step 12.

NO - Go to step 15.

- 12. Turn the ignition switch OFF.
- 13. Connect IAT sensor 2P connector terminal No. 1 to body ground with a jumper wire.

# IAT SENSOR 2P CONNECTOR



## Wire side of female terminals

G03680719

**Fig. 16: Connecting IAT Sensor 2P Connector Terminal No. 1 To Body** <u>Ground With Jumper Wire</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

14. Check for continuity between ECM connector terminal C18 and body ground.

## ECM CONNECTOR C (31P)



Wire side of female terminals

G03680720

## Fig. 17: Checking Continuity Between ECM Connector Terminal C18 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

## Is there continuity?

YES - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the
original ECM (see <u>ECM REPLACEMENT</u>).

**NO** - Repair open in the wire between the ECM (C18) and the IAT sensor.

15. Measure voltage between ECM connector terminal C25 and body ground.

#### 5 8 9 10 6 2 4 13 14 15 17|18 16 19 21 12 20 29 30 23 25 26 27 28 IAT (RED/YEL)

### ECM CONNECTOR C (31P)

Wire side of female terminals

G03680721

### **Fig. 18: Measuring Voltage Between ECM Connector Terminal C25 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

### Is there about 5 V?

**YES** - Repair open in the wire between the ECM (C25) and the IAT sensor.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

**NO** - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

DTC P0116: ECT SENSOR CIRCUIT RANGE/ PERFORMANCE PROBLEM (2000-2005 MODELS)

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Turn the ignition switch ON (II).
- 2. Check the ECT SENSOR in the DATA LIST with the HDS.

### Is about 176°F (80°C) or higher, or 0.86 V or less indicated?

**YES** - Go to step 3.

**NO** - Go to step 7.

- 3. Note the value of the ECT SENSOR in the DATA LIST with the HDS.
- 4. Turn the ignition switch OFF.
- 5. Cool the engine for 1 hour.
- 6. Check the ECT SENSOR in the DATA LIST with the HDS.

### Did the ECT change 3.6°F (2°C) or more?

**YES** - Intermittent failure, system is OK at this time. Check the thermostat and the cooling system.

**NO** - Replace the ECT sensor.

- 7. Note the value of the ECT SENSOR in the DATA LIST with the HDS.
- 8. Start the engine. Hold the engine speed at 3,000 rpm without load (in Park or neutral) until the radiator fan comes on, then let it idle.

9. Does the ECT SENSOR in the DATA LIST with the HDS.

### Does the ECT SENSOR change $3.6^{\circ}F(2^{\circ}C)$ or more?

**YES** - Intermittent failure, system is OK at this time. Check the thermostat and the cooling system.

**NO** - Replace the ECT sensor.

### DTC P0116: ECT SENSOR CIRCUIT RANGE/ PERFORMANCE PROBLEM (2006 MODEL)

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Turn the ignition switch ON (II).
- 2. Check the ECT SENSOR in the DATA LIST with the HDS.

### Is about $176^{\circ}F(80^{\circ}C)$ or higher, or 0.78 V or less indicated?

YES - Go to step 6.

**NO** - Go to step 3.

- 3. Note the value of the ECT SENSOR in the DATA LIST with the HDS.
- 4. Start the engine. Hold the engine speed at 3,000 rpm without load (in Park or neutral) until the radiator fan comes on, then let it idle.
- 5. Check the ECT SENSOR in the DATA LIST with the HDS.

### **Does the ECT SENSOR change 18°F (10°C) or higher?**

**YES** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the ECT sensor and the ECM.

**NO** - Go to step 11.

- 6. Note the value of the ECT SENSOR in the DATA LIST with the HDS.
- 7. Turn the ignition switch OFF.
- 8. Open the engine hood, and let the engine cool for 3 hours.
- 9. Turn the ignition switch ON (II).
- e x x

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

### 10. Check the ECT SENSOR in the DATA LIST with the HDS.

### Does the ECT SENSOR change 18°F (10°C) or more?

**YES** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the ECT sensor and the ECM.

**NO** - Go to step 11.

- 11. Turn the ignition switch OFF.
- 12. Replace the ECT sensor.
- 13. Turn the ignition switch ON (II).
- 14. Reset the ECM with the HDS.
- 15. Do the ECM idle learn procedure (see ECM IDLE LEARN PROCEDURE ).
- 16. Check for Temporary DTCs or DTCs with the HDS.

### Are any Temporary DTCs or DTCs Indicated?

**YES** - If DTC P0116 is indicated, check for poor connections or loose terminals at the ECT sensor and the ECM, then go to step 1. If any other Temporary DTCs or DTCs are indicated, go to the indicated  $\underline{DTC}$ **TROUBLESHOOTING**.

**NO** - Troubleshooting is complete.

### DTC P0117: ECT SENSOR CIRCUIT LOW VOLTAGE

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Turn the ignition switch ON (II).
- 2. Check the ECT SENSOR in the DATA LIST with the HDS.

### Is 302°F (150°C) or higher, or 0V indicated?

**YES** - Go to step 3.

NO - Intermittent failure, system is OK at this time. Check for poor

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

connections or loose terminals at the ECT sensor and the ECM.

- 3. Disconnect the ECT sensor 2P connector.
- 4. Check the ECT SENSOR in the DATA LIST with the HDS.

### Is 302°F (150°C) or higher, or 0 V indicated?

YES - Go to step 5.

**NO** - Replace the ECT sensor.

- 5. Turn the ignition switch OFF, and wait for 10 seconds.
- 6. Disconnect ECM connector C (31P).
- 7. Check for continuity between ECT sensor 2P connector terminal No. 1 and body ground.

## **ECT SENSOR 2P CONNECTOR**



## Wire side of female terminals

G03680722

**Fig. 19: Checking Continuity Between ECT Sensor 2P Connector Terminal No. 1 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

Is there continuity?

YES -

- Go to step 8 (CVT model).
- Repair short in the wire between the ECM (C26) and the ECT sensor (M/T model).

NO - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

- 8. Disconnect TCM connector A (26P).
- 9. Check for continuity between ECT sensor 2P connector terminal No. 1 and body ground.

## ECT SENSOR 2P CONNECTOR



## Wire side of female terminals

G03680723

**Fig. 20: Checking Continuity Between ECT Sensor 2P Connector Terminal No. 1 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

### Is there continuity?

YES - Repair short in the wire between the ECM (C26), the TCM (A19)

and the ECT sensor.

**NO** - Substitute a known-good TCM, and recheck (see <u>**HOW TO**</u> <u>**TROUBLESHOOT CIRCUIT AT THE TCM**</u>). If the symptom/indication goes away, replace the original TCM.

#### DTC P0118: ECT SENSOR CIRCUIT HIGH VOLTAGE

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Turn the ignition switch ON (II).
- 2. Check the ECT SENSOR in the DATA LIST with the HDS.

### Is $-4^{\circ}F$ (-20°C) or less, or 5 V indicated?

**YES** - Go to step 3.

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the ECT sensor and the ECM.

- 3. Turn the ignition switch OFF.
- 4. Disconnect the ECT sensor 2P connector.
- 5. Connect ECT sensor 2P connector terminals No. 1 and No. 2 with a jumper wire.

### ECT SENSOR 2P CONNECTOR



Wire side of female terminals G03680724

#### **Fig. 21: Connecting ECT Sensor 2P Connector Terminals No. 1 & 2 With Jumper Wire Courtesy of AMERICAN HONDA MOTOR CO., INC.**

- 6. Turn the ignition switch ON (II).
- 7. Check the ECT SENSOR in the DATA LIST with the HDS.

### Is $-4^{\circ}F$ (-20°C) or less, or 5 V indicated?

YES - Go to step 8.

**NO** - Replace the ECT sensor.

- 8. Turn the ignition switch OFF.
- 9. Remove the jumper wire.

- 10. Turn the ignition switch ON (II).
- 11. Measure voltage between ECT sensor 2P connector terminal No. 1 and body ground.

## ECT SENSOR 2P CONNECTOR



## Wire side of female terminals

G03680725

**Fig. 22: Measuring Voltage Between ECT Sensor 2P Connector Terminal No. 1 And Body Ground** 

### **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

### Is there about 5 V?

YES - Go to step 12.

NO - Go to step 14.

12. Connect ECT sensor 2P connector terminal No. 2 to body ground with a jumper wire.

## ECT SENSOR 2P CONNECTOR



### Wire side of female terminals G03680726

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

### **Fig. 23: Connecting ECT Sensor 2P Connector Terminal To Body Ground** <u>With Jumper Wire</u> **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

13. Check for continuity between ECM connector terminal C18 and body ground.

### ECM CONNECTOR C (31P)



Wire side of female terminals

G03680727

### **Fig. 24: Checking Continuity Between ECM Connector Terminal C18** <u>And Body Ground</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

### Is there continuity?

YES - Update the ECM if it does not have the latest software, or substitute

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2006 MAT models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

**NO** - Repair open in the wire between the ECM (C18) and the ECT sensor.

14. Measure voltage between ECM connector terminal C26 and body ground.



### ECM CONNECTOR C (31P)

Wire side of female terminals



### Fig. 25: Measuring Voltage Between ECM Connector Terminal C26 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

### Is there about 5 V?

**YES** - Repair open in the wire between the ECM (C26) and the ECT sensor.

NO - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

#### DTC P0122: TP SENSOR CIRCUIT LOW VOLTAGE

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Start the engine. Hold the engine speed at 3,000 rpm without load (in Park or neutral) until the radiator fan comes on, then turn the ignition switch OFF.
- 2. Turn the ignition switch ON (II).
- 3. Check the TP SENSOR in the DATA LIST with the HDS.

# Is there about 10% or 0.5 V when the throttle is fully closed and about 90% or 4.5 V when the throttle is fully opened?

**YES** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the TP sensor and the ECM.

**NO** - Go to step 4.

- 4. Turn the ignition switch OFF.
- 5. Disconnect the TP sensor 3P connector.

- 6. Turn the ignition switch ON (II).
- 7. Measure voltage between TP sensor 3P connector terminals No. 1 and No. 3.

### **TP SENSOR 3P CONNECTOR**



Wire side of female terminals

G03680729

**Fig. 26: Measuring Voltage Between TP Sensor 3P Connector Terminals** <u>No. 1 And 3</u> **Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

### Is there about 5 V?

YES - Go to step 8.
NO - Go to step 17.
8. Turn the ignition switch OFF.

9. At the sensor side, measure resistance between TP sensor 3P connector terminals No. 1 and No. 2 with the throttle fully closed.



### Terminal side of male terminals G03680730

**Fig. 27: Measuring Resistance Between TP Sensor 3P Connector Terminals No. 1 And 2** 

### Courtesy of AMERICAN HONDA MOTOR CO., INC.

### Is there about 0.5-0.9 k ohm?

**YES** - Go to step 10.

**NO** - Replace the throttle body (see **<u>THROTTLE BODY</u> <u>REMOVAL/INSTALLATION</u>**).

10. At the sensor side, measure resistance between TP sensor 3P connector terminals No. 2 and No. 3 with the throttle fully closed.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

### **TP SENSOR 3P CONNECTOR**



### Terminal side of male terminals

G03680731

**Fig. 28: Measuring Resistance Between TP Sensor 3P Connector Terminals No. 2 And 3 Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

Is there about 4.5 k ohm?

#### 2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

**YES** - Go to step 11.

### **NO** - Replace the throttle body (see **<u>THROTTLE BODY</u> <u>REMOVAL/INSTALLATION</u>**).

- 11. Disconnect ECM connector C (31P).
- 12. Check for continuity between TP sensor 3P connector terminal No. 2 and body ground.

# **TP SENSOR 3P CONNECTOR**



## Wire side of female terminals

G03680732

**Fig. 29: Checking Continuity Between TP Sensor 3P Connector Terminal No. 2 And Body Ground** 

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

### Courtesy of AMERICAN HONDA MOTOR CO., INC.

### Is there continuity?

YES -

- Go to step 13 (CVT model).
- Repair short in the wire between the ECM (C27) and the TP sensor (M/T model).

NO -Go to step 15.

- 13. Disconnect TCM connector B (22P).
- 14. Check for continuity between TP sensor 3P connector terminal No. 2 and body ground.

# **TP SENSOR 3P CONNECTOR**



## Wire side of female terminals

G03680733

**Fig. 30: Checking Continuity Between TP Sensor 3P Connector Terminal No. 2 And Body Ground** 

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

### **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

### Is there continuity?

**YES** - Repair short in the wire between the ECM (C27), the TCM (B4) and the TP sensor.

**NO** - Substitute a known-good TCM, and recheck (see <u>HOW TO</u> <u>**TROUBLESHOOT CIRCUIT AT THE TCM**</u>). If the

symptom/indication goes away, replace the original TCM.

15. Connect ECM connector terminal C27 to body ground with a jumper wire.



### ECM CONNECTOR C (31P)

Wire side of female terminals

### G03680734

Fig. 31: Connecting ECM Connector Terminal C27 To Body Ground With

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

### **Jumper Wire Courtesy of AMERICAN HONDA MOTOR CO., INC.**

16. Check for continuity between TP sensor 3P connector terminal No. 2 and body ground.

# **TP SENSOR 3P CONNECTOR**



# Wire side of female terminals

G03680735

**Fig. 32: Checking Continuity Between TP Sensor 3P Connector Terminal No. 2 And Body Ground** 

### Courtesy of AMERICAN HONDA MOTOR CO., INC.

### Is there continuity?

YES - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

**NO** - Repair open in the wire between the ECM (C27) and the TP sensor. 17. Measure voltage between ECM connector terminals C18 and C28.





Wire side of female terminals

### **Fig. 33: Measuring Voltage Between ECM Connector Terminals C18 And** <u>C28</u>

### Courtesy of AMERICAN HONDA MOTOR CO., INC.

### Is there about 5 V?

**YES** - Repair open in the wire between the ECM (C28) and the TP sensor. **NO** - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

DTC P0123: TP SENSOR CIRCUIT HIGH VOLTAGE

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Start the engine. Hold the engine speed at 3,000 rpm without load (in Park or neutral) until the radiator fan comes on, then turn the ignition switch OFF.
- 2. Turn the ignition switch ON (II).
- 3. Check the TP SENSOR in the DATA LIST with the HDS.

# Is there about 10% or 0.5 V when the throttle is fully closed and about 90% or 4.5 V when the throttle Is fully opened?

**YES** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the TP sensor and the ECM.

**NO** - Go to step 4.

- 4. Turn the ignition switch OFF.
- 5. Disconnect the TP sensor 3P connector.

- 6. Turn the ignition switch ON (II).
- 7. Measure voltage between TP sensor 3P connector terminals No. 1 and No. 3.

### **TP SENSOR 3P CONNECTOR**



Wire side of female terminals

G03680737

**Fig. 34: Measuring Voltage Between TP Sensor 3P Connector Terminals** <u>No. 1 And 3</u> **Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

Is there about 5 V?

YES - Replace the throttle body (see <u>THROTTLE BODY</u> <u>REMOVAL/INSTALLATION</u> ).

NO - Go to step 8.

8. Measure voltage between ECM connector terminals C18 and C28.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

### ECM CONNECTOR C (31P)



Wire side of female terminals

G03680738

#### Fig. 35: Measuring Voltage Between ECM Connector Terminals C18 And C28 Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Is there about 5 V?

YES - Repair open in the wire between the ECM (C18) and the TP sensor. NO - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the

### original ECM (see ECM REPLACEMENT).

#### DTC P0125: ECT SENSOR MALFUNCTION/SLOW RESPONSE (2004-2005 MODELS)

### NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Start the engine, and let it idle.
- 2. Check the ECT SENSOR in the DATA LIST with the HDS.

### Is about 86°F (30°C) or less, or 2.61 V or more Indicated?

**YES** - Go to step 3.

**NO** - Intermittent failure, system is OK at this time. Check the thermostat and the cooling system.

- 3. Let the engine idle 6 minutes.
- 4. Check the ECT SENSOR in the DATA LIST with the HDS.

### Is about 86°F (30°C) or less, or 2.61 V or more indicated?

**YES** - Replace the ECT sensor.

**NO** - Intermittent failure, system is OK at this time. Check the thermostat and the cooling system.

#### DTC P0125: ECT SENSOR MALFUNCTION/SLOW RESPONSE (2006 MODEL)

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Start the engine, and let it idle.
- 2. Check the ECT SENSOR in the DATA LIST with the HDS.

### Is about 86°F (30°C) or less, or 2.61 V or more indicated?

**YES** - Go to step 3.

#### 2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

**NO** - Intermittent failure, system is OK at this time. Check the thermostat and the cooling system.

- 3. Let the engine idle 6 minutes.
- 4. Check the ECT SENSOR in the DATA LIST with the HDS.

#### Is about 86°F (30°C) or less, or 2.61 V or more indicated?

**YES** - Go to step 5.

**NO** - Intermittent failure, system is OK at this time. Check the thermostat and the cooling system.

- 5. Turn the ignition switch OFF.
- 6. Replace the ECT sensor.
- 7. Turn the ignition switch ON (II).
- 8. Reset the ECM with the HDS.
- 9. Do the ECM idle learn procedure (see <u>ECM IDLE LEARN PROCEDURE</u>).
- 10. Allow the engine to cool to between  $23^{\circ}F(-5^{\circ}C)$  and  $77^{\circ}F(25^{\circ}C)$ .
- 11. Start the engine, and let it idle 20 minutes.
- 12. Check for Temporary DTCs or DTCs with the HDS.

### Are any Temporary DTCs or DTCs indicated?

**YES** - If DTC P0125 is indicated, check for poor connections or loose terminals at the ECT sensor and the ECM, then go to step 1 . If any other Temporary DTCs or DTCs are indicated, go to the indicated <u>DTC</u> **TROUBLESHOOTING** 

**NO** - Troubleshooting is complete.

#### DTC P0128: COOLING SYSTEM MALFUNCTION

NOTE: • If the DTCs listed below are stored at the same time as DTC P0128, troubleshoot those DTCs first, then recheck for P0128.

\*1: 2004 model

### \*2: 2004-2006 models

\*3: 2005-2006 models

P0106, P0107, P0108, P1128, P1129: MAP sensor

P1106, P1107, P1108 (P2227, P2228, P2229)<sup>\*2</sup> :

**Barometric pressure circuit** 

P1259 (P2646)<sup>\*1</sup> (P2646, P2647)<sup>\*3</sup> : VTEC system

P0401: EGR flow insufficient

P1491 (P0404)<sup>\*2</sup> : EGR valve lift insufficient

P1498 (P0406)<sup>\*2</sup> : EGR valve lift sensor high voltage

P0116, P0117, P0118 (P0125)<sup>\*2</sup> : Engine coolant temperature circuit

P0112, P0113: Intake air temperature sensor

P0500: Vehicle speed sensor

P0335, P0336 (P0339)<sup>\*2</sup> : Crankshaft position sensor

P0300: Random misfire

P0301, P0302, P0303: No. 1, No. 2, or No. 3 Cylinder misfire

P0505 (P0506, P0507)<sup>\*2</sup> : Idle control system malfunction

P1519  $(P0511)^{*2}$ : Idle air control valve

- DTC P0128 can set occasionally when the hood is opened while the engine is at normal operating temperature.
- Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL TROUBLESHOOTING INFORMATION</u>).
- 1. Check the engine coolant level.

### Is the engine coolant level low?

**YES** - Refill the engine coolant. If necessary, check the cooling system. **NO** - Go to step 2.

- 2. Turn the ignition switch ON (II).
- 3. Check the radiator fan.

### Does the radiator fan keep running?

**YES** - Refer to the radiator fan circuit diagram (see <u>**CIRCUIT**</u> <u>**DIAGRAM**</u>), and troubleshoot the radiator fan circuit; without A/C model (see <u>**RADIATOR FAN CIRCUIT TROUBLESHOOTING**</u>), with A/C model (see <u>**WITH A/C**</u>) and the radiator fan switch (see <u>**RADIATOR FAN SWITCH TEST**</u>).

Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

NO - Replace the thermostat (see THERMOSTAT REPLACEMENT).

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

DTC P0133: A/F SENSOR (SENSOR 1) CIRCUIT SLOW RESPONSE (2004-2006 MODELS); DTC P1163: A/F SENSOR (SENSOR 1)) CIRCUIT SLOW RESPONSE (2002-2003 M/T MODELS) (2001-2003 CVT MODELS)

### NOTE:

- Information marked with an asterisk (\*) applies to 2004-2006 models.
  - Information marked with double asterisk (\*\*) applies to 2002-2003 M/T models and 2001-2003 CVT models.
  - If DTC P1162 is stored at the same time as DTC P1163, troubleshoot DTC P1162 first, then recheck for DTC P1163 (2002-2003 M/T and 2001-2003 CVT models).
  - Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL TROUBLESHOOTING INFORMATION</u>).
- 1. Reset the ECM with the HDS (see ECM RESET).
- 2. Start the engine. Hold the engine speed at 3,000 rpm without load (in Park or neutral) until the radiator fan comes on.
- 3. Test-drive under these conditions:
  - 55 mph (89 km/n) steady speed
  - CVT in D position (M/T in 5th gear)
  - Until readiness code or DTC P0133\* (P1163)\*\* comes on
- 4. Check for a Temporary DTCs or DTCs with the HDS.

### Is DTC P0133\* (P1163)\*\* indicated?

**YES** - Replace the A/F sensor (Sensor 1) (see <u>A/F SENSOR</u> <u>REPLACEMENT</u> ).

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the A/F sensor (Sensor 1) and the ECM.

DTC P0134: A/F SENSOR (SENSOR 1) SIGNAL STUCK LEAN

NOTE: • If the vehicle was out of fuel and the engine stalled before this DTC was stored, refuel and clear the DTC.

# • Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL TROUBLESHOOTING INFORMATION</u>).

1. Check the installation of the A/F sensor (Sensor 1).

### Is it loose?

**YES** - Reinstall the A/F sensor (Sensor 1) (see <u>A/F SENSOR</u> <u>REPLACEMENT</u>.

**NO** - Go to step 2.

- 2. Reset the ECM with the HDS (see **ECM RESET** ).
- 3. Start the engine. Hold the engine speed at 3,000 rpm without load (in Park or neutral) until the radiator fan comes on, then let it idle for 2 minute.
- 4. Check for Temporary DTCs or DTCs with the HDS.

### Is DTC P0134 indicated?

**YES** - Replace the A/F sensor (Sensor 1) (see <u>A/F SENSOR</u> <u>REPLACEMENT</u>.

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the A/F sensor (Sensor 1) and the ECM.

DTC P0135: A/F SENSOR (SENSOR 1) HEATER CIRCUIT MALFUNCTION (2002-2006 M/T MODELS) (CVT MODELS)

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Reset the ECM with the HDS (see **ECM RESET** ).
- 2. Start the engine.
- 3. Check for Temporary DTCs or DTCs with the HDS.

### Is DTC P0135 indicated?
**YES** - Go to step 4.

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at C102 (located under the right side of the dash), the A/F sensor relay, the A/F sensor (Sensor 1), and the ECM.

- 4. Check these fuses:
  - No. 16 (30 A) fuse in the under-hood fuse/relay box.
  - No. 14 (30 A) fuse in the under-dash fuse/relay box.
  - No. 4 (7.5 A) in the under-dash fuse/relay box.

## Are any of the fuses blown?

**YES** - Repair short in the wire between the A/F sensor relay and the fuses. **NO** - Go to step 5.

5. Measure voltage between ECM connector terminals D5 and B20, 30 seconds after the ignition switch is turned ON (II).

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

## **ECM CONNECTORS**



Wire side of female terminals

G03680739

#### Fig. 36: Measuring Voltage Between ECM Connector Terminals D5 And B20 Counters of A MERICAN HONDA MOTOR CO. INC.

**Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

### Is there battery voltage?

YES - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

**NO** - Go to step 6.

6. Measure voltage between ECM connector terminals D11 and B20.

## **ECM CONNECTORS**



Wire side of female terminals

G03680740

#### Fig. 37: Measuring Voltage Between ECM Connector Terminals D11 And B20 Courtesy of AMERICAN HONDA MOTOR CO., INC.

## Is there battery voltage?

**YES** - Go to step 7. **NO** - Go to step 11.

- 7. Turn the ignition switch OFF, and wait for 10 seconds.
- 8. Disconnect ECM connector A (32P).

- 9. Turn the ignition switch ON (II).
- 10. Connect ECM connector terminal A11 to body ground with a jumper wire, then measure voltage between ECM connector terminals D5 and B20.



### **ECM CONNECTORS**

Wire side of female terminals

G03680741

### **Fig. 38: Connecting ECM Connector Terminal A11 To Body Ground With** <u>Jumper Wire</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

### Is there battery voltage?

YES - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

**NO** - Repair open or short in the wire between the A/F sensor (Sensor 1) and the ECM (D5).

- 11. Turn the ignition switch OFF, and wait for 10 seconds.
- 12. Disconnect ECM connector D (16P) and the A/F sensor (Sensor 1) 4P connector.
- 13. Check for continuity between A/F sensor (Sensor 1) 4P connector terminal No. 4 and body ground.

# A/F SENSOR (SENSOR 1) 4P CONNECTOR



Terminal side of male terminals

G03680742

#### Fig. 39: Checking Continuity Between A/F Sensor 4P Connector Terminal No. 4 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

### Is there continuity?

**YES** - Repair short in the wire between the A/F sensor relay, the A/F sensor (Sensor 1) and the ECM (D11).

**NO** - Go to step 14.

- 14. Turn the ignition switch ON (II).
- 15. Measure voltage between ECM connector terminals A11 and B20.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

## **ECM CONNECTORS**



Wire side of female terminals

G03680743

**Fig. 40: Measuring Voltage Between ECM Connector Terminals A11 And B20 Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

### Is there battery voltage?

**YES** - Repair open in the wire between the ECM (D11) and the A/F sensor (Sensor 1).

NO - Go to step 16.

16. Check for continuity in the wires between the A/F sensor relay and the fuses.

#### Is there continuity?

**YES** - The wires are OK. Replace the A/F sensor relay.

**NO** - Repair open in the wire between the A/F sensor relay and the fuses.

#### DTC P0137: SECONDARY HO2S (SENSOR 2) CIRCUIT LOW VOLTAGE

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Reset the ECM with the HDS (see <u>ECM RESET</u>).
- 2. Start the engine. Hold the engine speed at 3,000 rpm without load (in Park or neutral) until the radiator fan comes on.
- 3. Check the HO2S S2 at 3,000 rpm in the DATA LIST with the HDS.

#### Does the voltage stay at 0.3 V or less?

YES - Go to step 4.

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the secondary HO2S (Sensor 2) and the ECM.

- 4. Turn the ignition switch OFF.
- 5. Disconnect the secondary HO2S (Sensor 2) 4P connector.
- 6. Start the engine.
- 7. Check the HO2S S2 in the DATA LIST with the HDS.

### Does the voltage stay at 0.3 V or less?

YES - Go to step 9.

**NO** - Replace the secondary HO2S (Sensor 2) (see <u>SECONDARY HO2S</u> <u>REPLACEMENT</u>, and the third HO2S (Sensor 3)\* (see <u>THIRD HO2S</u> <u>REPLACEMENT</u>).

\*: 2002-2006 M/T models

8. Turn the ignition switch OFF, and wait for 10 seconds.

- 9. Disconnect ECM connector C (31P).
- 10. Check for continuity between secondary HO2S (Sensor 2) 4P connector terminal No. 2 and body ground.

# SECONDARY HO2S (SENSOR 2) 4P CONNECTOR



# Terminal side of male terminals G03680744

Fig. 41: Checking Continuity Between Secondary HO2S (Sensor 2) 4P Connector Terminal No. 2 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

## Is there continuity?

**YES** - Repair short in the wire between the ECM (C31) and the secondary HO2S (Sensor 2).

NO - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS) HOW TO TROUBLESHOOT CIRCUITS AT THE</u> <u>ECM</u>), 2002-2006 M/T models and CVT model (see <u>ECM UPDATING</u> <u>AND SUBSTITUTION FOR TESTING-2002-2006 M/T MODELS</u> <u>AND CVT MODEL</u>), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM</u> <u>REPLACEMENT</u>).

DTC P0138: SECONDARY HO2S (SENSOR 2) CIRCUIT HIGH VOLTAGE (2000-2004 MODELS)

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Reset the ECM with the HDS (see HDS CLEAR COMMAND).
- 2. Start the engine. Hold the engine speed at 3,000 rpm without load (in Park or neutral) until the radiator fan comes on.
- 3. Check the HO2S S2 in the DATA LIST with the HDS.

#### Does the voltage stay at 1.0 V or more?

YES - Go to step 4.

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the secondary HO2S (Sensor 2) and the ECM.

- 4. Turn the ignition switch OFF.
- 5. Disconnect the secondary HO2S (Sensor 2) 4P connector.
- 6. Connect secondary HO2S (Sensor 2) 4P connector terminals No. 1 and No. 2 with a jumper wire.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

# SECONDARY HO2S (SENSOR 2) 4P CONNECTOR



# Terminal side of male terminals G03680745

#### Fig. 42: Connecting Secondary HO2S Connector Terminals No. 1 And 2 With Jumper Wire Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 7. Turn the ignition switch ON (II).
- 8. Check the HO2S S2 in the DATA LIST with the HDS.

#### Is there 1.0 V or more?

**YES** - Go to step 9.

**NO** - Replace the secondary HO2S (Sensor 2) (see <u>SECONDARY HO2S</u> <u>REPLACEMENT</u>, and the third HO2S (Sensor 3)\* (see <u>THIRD HO2S</u> <u>REPLACEMENT</u>).

\*: 2002-2004 M/T models

- 9. Turn the ignition switch OFF.
- 10. Connect ECM connector terminals C31 and C18 with a jumper wire.



## ECM CONNECTOR C (31P)

Wire side of female terminals

G03680746

#### Fig. 43: Connecting ECM Connector Terminals C31 And C18 With Jumper Wire Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 11. Turn the ignition switch ON (II).
- 12. Check the HO2S S2 in the DATA LIST with the HDS.

### Is there 1.0 V or more?

YES - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2004 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

NO - Go to step 13.

- 13. Remove the jumper wire.
- 14. Connect secondary HO2S (Sensor 2) 4P connector terminal No. 2 to body ground with a jumper wire.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

## SECONDARY HO2S (SENSOR 2) 4P CONNECTOR



Terminal side of male terminals G03680747

**Fig. 44: Connecting Secondary HO2S Connector Terminal No. 2 To Body** <u>Ground With Jumper Wire</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

15. Check for continuity between ECM connector terminal C31 and body ground.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

## ECM CONNECTOR C (31P)



Wire side of female terminals

G03680748

### **Fig. 45: Checking Continuity Between ECM Connector Terminal C31** <u>And Body Ground</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

### Is there continuity?

YES - Go to step 16.

**NO** - Repair open in the wire between the ECM (C31) and the secondary HO2S (Sensor 2).

- 16. Turn the ignition switch OFF.
- 17. Disconnect the jumper wire.
- 18. Disconnect ECM connector C (31P).
- 19. Connect secondary HO2S (Sensor 2) 4P connector terminal No. 1 to body ground with a jumper wire.

## SECONDARY HO2S (SENSOR 2) 4P CONNECTOR



## Terminal side of male terminals

G03680749

#### **Fig. 46: Connecting Secondary HO2S Connector Terminal No. 1 To Body** <u>Ground With Jumper Wire</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

20. Check for continuity between ECM connector terminal C18 and body ground.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight



Wire side of female terminals

G03680750

#### Fig. 47: Checking Continuity Between ECM Connector Terminal C18 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

YES - Substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW</u> <u>TO SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-</u> <u>2001 M/T MODELS</u>) ), 2002-2004 M/T models and CVT model (see <u>ECM UPDATING AND SUBSTITUTION FOR TESTING-2002-2006</u> <u>M/T MODELS AND CVT MODEL</u> ), and recheck. If the symptom/indication goes away, replace the original ECM (see <u>ECM</u> <u>REPLACEMENT</u> ).

NO - Repair open in the wire between the ECM (C18) and the secondary

HO2S (Sensor 2).

DTC P0138: SECONDARY HO2S (SENSOR 2) CIRCUIT HIGH VOLTAGE (2005-2006 MODELS)

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Reset the ECM with the HDS (see ECM RESET).
- 2. Start the engine. Hold the engine speed at 3,000 rpm without load (in Park or neutral) until the radiator fan comes on.
- 3. Check the HO2S S2 at 3,000 rpm in the DATA LIST with the HDS.

## Does the voltage stay at 4.0 V or more?

**YES** - Go to step 4.

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the secondary HO2S (Sensor 2) and the ECM.

- 4. Turn the ignition switch OFF.
- 5. Disconnect the secondary HO2S (Sensor 2) 4P connector.
- 6. Connect secondary HO2S (Sensor 2) 4P connector terminals No. 1 and No. 2 with a jumper wire.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight



Terminal side of male terminals

G03680751

#### Fig. 48: Connecting Secondary HO2S Connector No. 1 And 2 Terminals With Jumper Wire Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 7. Turn the ignition switch ON (II).
- 8. Check the HO2S S2 in the DATA LIST with the HDS.

#### Is there 4.0 V or more?

YES - Go to step 9.

NO - Replace the secondary HO2S (Sensor 2) (see <u>SECONDARY HO2S</u> <u>REPLACEMENT</u>.

- 9. Turn the ignition switch OFF.
- 10. Disconnect the jumper wire.
- 11. Connect ECM connector terminals C31 and C18 with a jumper wire.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

# ECM CONNECTOR C (31P)



Wire side of female terminals

G03680752

#### **Fig. 49: Connecting ECM Connector Terminals C31 And C18 With** <u>Jumper Wire</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 12. Turn the ignition switch ON (II).
- 13. Check the HO2S S2 in the DATA LIST with the HDS.

#### Is there 4.0 V or more?

YES - Substitute a known-good ECM (see <u>ECM UPDATING AND</u> <u>SUBSTITUTION FOR TESTING-2002-2006 M/T MODELS AND</u> <u>CVT MODEL</u>), and recheck. If the symptom/indication goes away, replace the original ECM (see <u>ECM REPLACEMENT</u>).

NO - Go to step 14.

- 14. Turn the ignition switch OFF.
- 15. Disconnect the jumper wire.

16. Connect secondary HO2S (Sensor 2) 4P connector terminal No. 2 to body ground with a jumper wire.

## SECONDARY HO2S (SENSOR 2) 4P CONNECTOR



Terminal side of male terminals

G03680753

#### Fig. 50: Connecting Secondary HO2S Connector Terminal No. 2 To Body Ground With Jumper Wire Courtesy of AMERICAN HONDA MOTOR CO., INC.

17. Check the HO2S S2 in the DATA LIST with the HDS.

## Is there 4.0 V or more?

**YES** - Repair open in the wire between the ECM (C31) and the secondary HO2S (Sensor 2).

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

NO - Go to step 18.

- 18. Turn the ignition switch OFF.
- 19. Disconnect the jumper wire.
- 20. Disconnect ECM connector C (31P), and wait for 10 seconds.
- 21. Connect secondary HO2S (Sensor 2) 4P connector terminal No. 1 to body ground with a jumper wire.





Terminal side of male terminals

G03680754

Fig. 51: Connecting Secondary HO2S Connector Terminal No. 1 To Body Ground With Jumper Wire Courtesy of AMERICAN HONDA MOTOR CO., INC.

22. Check for continuity between ECM connector terminal C18 and body ground.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight



Wire side of female terminals

G03680755

**Fig. 52: Checking For Continuity Between ECM Connector Terminal C18** <u>And Body Ground</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

YES - Substitute a known-good ECM (see <u>ECM UPDATING AND</u> <u>SUBSTITUTION FOR TESTING-2002-2006 M/T MODELS AND</u> <u>CVT MODEL</u>), and recheck. If the symptom/indication goes away, replace the original ECM (see <u>ECM REPLACEMENT</u>).

**NO** - Repair open in the wire between the ECM (C18) and the secondary HO2S (Sensor 2).

#### DTC P0139: SECONDARY HO2S (SENSOR 2) SLOW RESPONSE

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Reset the ECM with the HDS (see <u>ECM RESET</u>).
- 2. Start the engine. Hold the engine speed at 3,000 rpm without load (in Park or neutral) until the radiator fan comes on.
- 3. Check the HO2S S2 at 3,000 rpm in the DATA LIST with the HDS.

## Does the voltage stay within 0.3- 0.6 V for 2 minutes?

**YES** - Replace the secondary HO2S (Sensor 2) (see <u>SECONDARY</u> <u>HO2S REPLACEMENT</u>, and the third HO2S (Sensor 3)\* (see <u>THIRD</u> <u>HO2S REPLACEMENT</u>).

\*: 2002-2006 M/T models

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the secondary HO2S (Sensor 2) and the ECM.

DTC P0141: SECONDARY HO2S (SENSOR 2) HEATER CIRCUIT MALFUNCTION

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Reset the ECM with the HDS (see ECM RESET).
- 2. Start the engine.
- 3. Check for Temporary DTCs or DTCs with the HDS.

## Is DTC P0141 indicated?

**YES** - Go to step 4.

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the secondary HO2S (Sensor 2) and the

ECM.

4. Check the No. 4 (7.5 A) fuse in the under-dash fuse/ relay box.

## Is the fuse OK?

YES - Go to step 11.

**NO** - Replace the fuse and retest.

- 5. Turn the ignition switch OFF.
- 6. Disconnect the secondary HO2S (Sensor 2) 4P connector.
- 7. At the secondary HO2S (Sensor 2) side, measure resistance between secondary HO2S (Sensor 2) 4P connector terminals No. 3 and No. 4.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

# SECONDARY HO2S (SENSOR 2) 4P CONNECTOR



# Wire side of female terminals

G03680756

**Fig. 53: Measuring Resistance Between Secondary HO2S (Sensor 2) 4P** <u>Connector Terminals No. 3 And 4</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Is there about 10-40 ohm ?

YES - Go to step 8.

#### 2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

**NO** - Replace the secondary HO2S (Sensor 2) (see <u>SECONDARY HO2S</u> <u>REPLACEMENT</u>, and the third HO2S (Sensor 3)\* (see <u>THIRD HO2S</u> <u>REPLACEMENT</u>).

\*: 2002-2006 M/T models

 At the secondary HO2S (Sensor 2) side, check for continuity between body ground and secondary HO2S (Sensor 2) 4P connector terminals No. 3 and No. 4 individually.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

# SECONDARY HO2S (SENSOR 2) 4P CONNECTOR



# Wire side of female terminals

G03680757

**Fig. 54:** Checking Continuity Between Body Ground And Secondary HO2S (Sensor 2) 4P Connector Terminals No. 3 And 4 Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Is there continuity?

YES - Replace the secondary HO2S (Sensor 2) (see SECONDARY

#### 2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

#### <u>HO2S REPLACEMENT</u>, and the third HO2S (Sensor 3)\* (see <u>THIRD</u> <u>HO2S REPLACEMENT</u>).

\*: 2002-2006 M/T models

**NO** - Go to step 9.

- 9. Turn the ignition switch ON (II).
- 10. Measure voltage between secondary HO2S (Sensor 2) 4P connector terminals No. 3 and No. 4.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

# SECONDARY HO2S (SENSOR 2) 4P CONNECTOR



Terminal side of male terminals

G03680758

Fig. 55: Measuring Voltage Between Secondary HO2S (Sensor 2) 4P Connector Terminals No. 3 And 4 Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there battery voltage?

YES - Go to step 11.
NO - Go to step 14 .
11. Turn the ignition switch OFF, and wait for 10 seconds.

- 12. Disconnect ECM connector C (31P).
- 13. Check for continuity between ECM connector terminal C12 and body ground.

# ECM CONNECTOR C (31P)



Wire side of female terminals

G03680759

#### Fig. 56: Checking Continuity Between ECM Connector Terminal C12 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

## Is there continuity?

**YES** - Repair short in the wire between the ECM (C12) and the secondary HO2S (Sensor 2).

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

NO - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

14. Measure voltage between secondary HO2S (Sensor 2) 4P connector terminal No. 4 and body ground.

# SECONDARY HO2S (SENSOR 2) 4P CONNECTOR



# Terminal side of male terminals G03680760

**Fig. 57: Measuring Voltage Between Secondary HO2S (Sensor 2) 4P Connector Terminal No. 4 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

Is there battery voltage?

**YES** - Go to step 15.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

NO - Repair open in the wire between the secondary HO2S (Sensor 2) and the No. 4 (7.5 A) fuse.

- 15. Turn the ignition switch OFF, and wait for 10 seconds.
- 16. Reconnect the secondary HO2S (Sensor 2) 4P connector.
- 17. Disconnect ECM connector C (31P).
- 18. Turn the ignition switch ON (II).
- 19. Measure voltage between ECM connector terminals B2 and C12.



# **ECM CONNECTORS**

Wire side of female terminals

G03680761

#### Fig. 58: Measuring Voltage Between ECM Connector Terminals B2 And

## **<u>C12</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.**

#### Is there 0.1 V or less?

**YES** - Repair open in the wire between the ECM (C12) and the secondary HO2S (Sensor 2).

NO - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

DTC P0143: THIRD HO2S (SENSOR 3) CIRCUIT LOW VOLTAGE (2002-2006 M/T MODELS)

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Reset the ECM with the HDS (see **HDS CLEAR COMMAND**).
- 2. Start the engine. Hold the engine speed at 3,000 rpm without load (in neutral) until the radiator fan comes on.
- 3. Test-drive under these conditions:
  - 55-65 mph (89-105 km/h) steady speed
  - Transmission in 4th or 5th gear
  - Until the readiness code or Temporary DTC P0143 and/or P0143 is set
- 4. Check for a Temporary DTCs or DTCs with the HDS.

## Is Temporary DTC P0143 and/or P0143 indicated?

**YES** - Go to step 6. **NO** - Go to step 5.

#### 2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

5. Check the HO2S S3 at 3,000 rpm in the DATA LIST with the HDS.

#### Does the voltage stay at 0.3 V or less?

**YES** - Go to step 6.

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the third HO2S (Sensor 3) and the ECM.

- 6. Turn the ignition switch OFF.
- 7. Disconnect the third HO2S (Sensor 3) 4P connector.
- 8. Start the engine.
- 9. Check the HO2S S3 in the DATA LIST with the HDS.

#### Does the voltage stay at 0.3 V or less?

**YES** - Go to step 10.

**NO** - Replace the secondary HO2S (Sensor 2) (see <u>SECONDARY HO2S</u> <u>REPLACEMENT</u>, and the third HO2S (Sensor 3) (see <u>THIRD HO2S</u> <u>REPLACEMENT</u>).

- 10. Turn the ignition switch OFF.
- 11. Disconnect ECM connector C (31P).
- 12. Check for continuity between third HO2S (Sensor 3) 4P connector terminal No. 2 and body ground.
2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

## THIRD HO2S (SENSOR 3) 4P CONNECTOR



## Terminal side of male terminals G03680762

Fig. 59: Checking Continuity Between Third HO2S (Sensor 3) 4P Connector Terminal No. 2 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Is there continuity?

**YES** - Repair short in the wire between the ECM (C16) and the third HO2S (Sensor 3).

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

**NO** - Update the ECM if it does not have the latest software, or substitute a known-good ECM (see <u>ECM UPDATING AND SUBSTITUTION</u> <u>FOR TESTING-2002-2006 M/T MODELS AND CVT MODEL</u>), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u>).

DTC P0144: THIRD HO2S (SENSOR 3) CIRCUIT HIGH VOLTAGE (2002-2006 M/T MODELS)

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Reset the ECM with the HDS (see <u>ECM RESET</u>).
- 2. Start the engine. Hold the engine speed at 3,000 rpm without load (in neutral) until the radiator fan comes on.
- 3. Test-drive under these conditions:
  - 55-65 mph (89 105 km/h) steady speed
  - Transmission in 4th or 5th gear
  - Until the readiness code or Temporary DTC P0144 and/or P0144 is set
- 4. Check for Temporary DTCs or DTCs with the HDS.

#### Is Temporary DTC P0144 and/or P0144 indicated?

YES - Go to step 6.

**NO** - Go to step 5.

5. Check the HO2S S3 at 3,000 rpm in the DATA LIST with the HDS.

#### Does the voltage stay at 1.0 V or more?

**YES** - Go to step 6.

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the third HO2S (Sensor 3) and the ECM.

- 6. Turn the ignition switch OFF.
- 7. Disconnect the third HO2S (Sensor 3) 4P connector.

8. Connect third HO2S (Sensor 3) 4P connector terminals No. 1 and No. 2 with a jumper wire.

#### THIRD HO2S (SENSOR 3) 4P CONNECTOR



Terminal side of male terminals

G03680763

#### Fig. 60: Connecting Third HO2S (Sensor 3) 4P Connector Terminals No. 1 And 2 With Jumper Wire Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 9. Turn the ignition switch ON (II).
- 10. Check the HO2S S3 in the DATA LIST with the HDS.

#### Is there 1.0 V or more?

**YES** - Go to step 11.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

**NO** - Replace the secondary HO2S (Sensor 2) (see <u>SECONDARY HO2S</u> <u>REPLACEMENT</u>, and the third HO2S (Sensor 3) (see <u>THIRD HO2S</u> <u>REPLACEMENT</u>).

- 11. Turn the ignition switch OFF.
- 12. Connect ECM connector terminals C16 and C18 with a jumper wire.

### ECM CONNECTOR C (31P)



Wire side of female terminals

G03680764

#### Fig. 61: Connecting ECM Connector Terminals C16 And C18 With Jumper Wire Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 13. Turn the ignition switch ON (II).
- 14. Check the HO2S S3 in the DATA LIST with the HDS.

#### Is there 1.0 V or more?

**YES** - Update the ECM if it does not have the latest software, or substitute a known-good ECM (see <u>ECM UPDATING AND SUBSTITUTION</u> <u>FOR TESTING-2002-2006 M/T MODELS AND CVT MODEL</u>), then recheck. If the symptom/ indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u>).

NO - Go to step 15.

- 15. Remove the jumper wire.
- 16. Connect third HO2S (Sensor 3) 4P connector terminal No. 2 to body ground with a jumper wire.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

#### THIRD HO2S (SENSOR 3) 4P CONNECTOR



Terminal side of male terminals

G03680765

**Fig. 62:** Connecting Third HO2S (Sensor 3) 4P Connector Terminal No. 2 <u>To Body Ground With Jumper Wire</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

17. Check for continuity between ECM connector terminal C16 and body ground.

## ECM CONNECTOR C (31P)



Wire side of female terminals

G03680766

#### Fig. 63: Checking Continuity Between ECM Connector Terminal C16 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Is there continuity?

**YES** - Repair open in the wire between the ECM (C18) and the third HO2S (Sensor 3).

**NO** - Repair open in the wire between the ECM (C16) and the third HO2S (Sensor 3).

#### DTC P0145: THIRD HO2S (SENSOR 3) SLOW RESPONSE (2002-2006 M/T MODELS)

#### NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Reset the ECM with the HDS (see <u>ECM RESET</u>).
- 2. Start the engine. Hold the engine speed at 3,000 rpm without load (in neutral) until the radiator fan comes on.
- 3. Test-drive under these conditions:
  - 55-65 mph (89-105 km/h) steady speed
  - Transmission in 4th or 5th gear
  - Until the readiness code or Temporary DTC P0145 and/or P0145 is set
- 4. Check for a Temporary DTCs or DTCs with the HDS.

#### Is Temporary DTC P0145 and/or P0145 indicated?

**YES** - Replace the secondary HO2S (Sensor 2) (see <u>SECONDARY</u> <u>HO2S REPLACEMENT</u>, and the third HO2S (Sensor 3) (see <u>THIRD</u> <u>HO2S REPLACEMENT</u>).

NO - Go to step 5.

5. Check the HO2S S3 at 3,000 rpm in the DATA LIST with the HDS.

#### Does the voltage stay within 0.3-0.6 V for 2 minutes?

**YES** - Replace the secondary HO2S (Sensor 2) (see <u>SECONDARY</u> <u>HO2S REPLACEMENT</u>, and the third HO2S (Sensor 3) (see <u>THIRD</u> <u>HO2S REPLACEMENT</u>).

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the third HO2S (Sensor 3) and the ECM.

DTC P0147: THIRD HO2S (SENSOR 3) HEATER CIRCUIT MALFUNCTION (2002-2006 M/T MODELS)

NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Reset the ECM with the HDS (see **ECM RESET** ).
- 2. Start the engine.
- 3. Check for Temporary DTCs or DTCs with the HDS.

#### Is DTC P0147 indicated?

**YES** - Go to step 4.

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the third HO2S (Sensor 3) and the ECM.

4. Check the No. 4 (7.5 A) fuse in the under-dash fuse/ relay box.

#### Is the fuse OK?

YES - Go to step 5.

**NO** - Replace the fuse and retest.

- 5. Turn the ignition switch OFF.
- 6. Disconnect the third HO2S (Sensor 3) 4P connector.
- 7. At the third HO2S (Sensor 3) side, measure resistance between third HO2S (Sensor 3) 4P connector terminals No. 3 and No. 4.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

## THIRD HO2S (SENSOR 3) 4P CONNECTOR



## Wire side of female terminals

G03680767

**Fig. 64: Measuring Resistance Between Third HO2S (Sensor 3) 4P** <u>Connector Terminals No. 3 And 4</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there about 10-40 ohm?

**YES** - Go to step 8.

**NO** - Replace the secondary HO2S (Sensor 2) (see <u>SECONDARY HO2S</u> <u>REPLACEMENT</u>, and the third HO2S (Sensor 3) (see <u>THIRD HO2S</u> <u>REPLACEMENT</u>).

8. At the third HO2S (Sensor 3) side, check for continuity between body ground and third HO2S (Sensor 3) 4P connector terminals No. 3 and No. 4 individually.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

## THIRD HO2S (SENSOR 3) 4P CONNECTOR



## Wire side of female terminals

G03680768

**Fig. 65: Checking Continuity Between Body Ground And Third HO2S** (Sensor 3) 4P Connector Terminals No. 3 And 4 Courtesy of AMERICAN HONDA MOTOR CO., INC.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

#### Is there continuity?

**YES** - Replace the secondary HO2S (Sensor 2) (see <u>SECONDARY</u> <u>HO2S REPLACEMENT</u>, and the third HO2S (Sensor 3) (see <u>THIRD</u> <u>HO2S REPLACEMENT</u>).

**NO** - Go to step 9.

- 9. Turn the ignition switch ON (II).
- 10. Measure voltage between third HO2S (Sensor 3) 4P connector terminals No. 3 and No. 4.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

## THIRD HO2S (SENSOR 3) 4P CONNECTOR



## Terminal side of male terminals G03680769

**Fig. 66: Measuring Voltage Between Third HO2S (Sensor 3) 4P Connector Terminals No. 3 And 4 Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

Is there battery voltage?

YES - Go to step 11.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

**NO** - Go to step 15.

- 11. Turn the ignition switch OFF, and wait for 10 seconds.
- 12. Disconnect ECM connector C (31P).
- 13. Check for continuity between ECM connector terminal C1 and body ground.

#### ECM CONNECTOR C (31P)



Wire side of female terminals

G03680770

#### **Fig. 67: Checking Continuity Between ECM Connector Terminal C1 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

#### Is there continuity?

**YES** - Repair short in the wire between the ECM (C1) and the third HO2S (Sensor 3).

**NO** - Update the ECM if it does not have the latest software, or substitute

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

#### a known-good ECM (see <u>ECM UPDATING AND SUBSTITUTION</u> <u>FOR TESTING-2002-2006 M/T MODELS AND CVT MODEL</u>), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u>).

14. Measure voltage between third HO2S (Sensor 3) 4P connector terminal No. 4 and body ground.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

## THIRD HO2S (SENSOR 3) 4P CONNECTOR



## Terminal side of male terminals G03680771

**Fig. 68: Measuring Voltage Between Third HO2S (Sensor 3) 4P Connector Terminal No. 4 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

Is there battery voltage?

**YES** - Go to step 15.

**NO** - Repair open in the wire between the third HO2S (Sensor 3) and the No. 4 (7.5 A) fuse.

- 15. Turn the ignition switch OFF, and wait for 10 seconds.
- 16. Reconnect the third HO2S (Sensor 3) 4P connector.
- 17. Disconnect ECM connector C (31P).
- 18. Turn the ignition switch ON (II).
- 19. Measure voltage between ECM connector terminals B2 and C1.



### ECM CONNECTORS

Wire side of female terminals

G03680772

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

#### **Fig. 69: Measuring Voltage Between ECM Connector Terminals B2 And** <u>C1</u>

#### Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Is there 0.1 V or less?

**YES** - Repair open in the wire between the ECM (C1) and the third HO2S (Sensor 3).

**NO** - Update the ECM if it does not have the latest software, or substitute a known-good ECM (see <u>ECM UPDATING AND SUBSTITUTION</u> <u>FOR TESTING-2002-2006 M/T MODELS AND CVT MODEL</u>), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u>).

#### DTC P0171: FUEL SYSTEM TOO LEAN; DTC P0172: FUEL SYSTEM TOO RICH

#### **Special Tools Required**

Vacuum pump/gauge, 0-30 in.Hg, Snap-on YA4000A or equivalent, commercially available

NOTE:
If some of the DTCs listed below are stored at the same time as DTC P0171 and/or P0172, troubleshoot those DTCs first, then recheck for P0171 and/or P0172.
P0106, P0107, P0108, P1128, P1129: MAP sensor
P1162, P1163, P1164, P1165: A/F sensor (Sensor 1)<sup>\*1</sup>
P1166, P1167, P1168, P1169: A/F sensor (Sensor 1) heater<sup>\*1</sup>
P1149, P1157, P1158, P1159, P1162, P1163, P1164: A/F sensor (Sensor 1)<sup>\*2</sup>

P0134, P1166, P1167: A/F sensor (Sensor 1) heater<sup>2</sup>

P0133, P1157, P2238, P2252, P2A00: A/F sensor (Sensor 1)<sup>\*3</sup>

P0134, P0135: A/F sensor (Sensor 1) heater<sup>\*3</sup>

P0137, P0138: Secondary HO2S (Sensor 2)

P0141: Secondary HO2S (Sensor 2) heater

P1259 (P2646)<sup>\*4</sup> (P2646, P2647)<sup>\*5</sup> : VTEC system

- \*1: 2000-2001 M/T models
- \*2: 2002-2003 models
- \*3: 2004-2006 models
- \*4: 2004 model
- \*5: 2005-2006 models
- Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL TROUBLESHOOTING INFORMATION</u>).
- 1. Check the fuel pressure.
  - 2000-2003 M/T models (see **2000-2003 M/T MODELS** )
  - 2001-2003 CVT models (see **<u>2001-2003 CVT MODELS</u>**)
  - 2004-2005 M/T models (see 2001-2003 CVT MODELS )
  - 2004-2005 CVT models (see **2004-2005 CVT MODELS** )
  - 2006 model (see **<u>2006 MODEL</u>**)

#### Is fuel pressure OK?

**YES** - Go to step 2.

- **NO** Check these items:
  - If the pressure is too high, check the fuel pressure regulator and the fuel return line.
  - If the pressure is too low, check the fuel level, the fuel pump, the fuel feed line, the fuel filter, and the fuel pressure regulator.
- 2. Start the engine. Hold the engine speed at 3,000 rpm without load (in Park or neutral) until the radiator fan comes on.
- 3. Check the A/F sensor (Sensor 1) output with the HDS.

#### Does it stay at less than 0.3 V or more than 1.0 V?

**YES** - Replace the A/F sensor (Sensor 1) (see <u>A/F SENSOR</u> <u>REPLACEMENT</u>.

NO - Go to step 4.

- 4. Turn the ignition switch OFF.
- 5. Disconnect the vacuum hose from the EVAP canister purge valve (A), and connect a vacuum pump/gauge, 0-30 in.Hg, to the hose.

#### 2000-06 ENGINE PERFORMANCE PGM-FI System - Insight



G03680773

Fig. 70: Disconnecting Vacuum Hose From EVAP Canister Purge Valve (2000-2005 Models) Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### 2000-06 ENGINE PERFORMANCE PGM-FI System - Insight



G03680774

#### Fig. 71: Disconnecting Vacuum Hose From EVAP Canister Purge Valve (2006 Model)

**Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

#### Does it hold vacuum?

**YES** - Check the valve clearances and adjust if necessary. If the valve clearances are OK, replace the fuel injectors.

**NO** - Replace the EVAP canister purge valve.

DTC P0300: RANDOM MISFIRE AND ANY COMBINATION OF THE FOLLOWING; DTC P0301: NO. 1 CYLINDER MISFIRE DETECTED; DTC P0302: NO. 2 CYLINDER MISFIRE DETECTED; DTC P0303: NO. 3 CYLINDER MISFIRE DETECTED

NOTE: • If the misfiring is frequent enough to trigger detection of increased emissions during two consecutive driving

cycles, the MIL will come on, and DTC P0300 (and some combination of P0301 through P0303) will be stored.

- If the misfiring is frequent enough to damage the catalyst, the MIL will blink whenever the misfiring occurs, and DTC P0300 (and some combination of P0301 through P0303) will be stored. When the misfiring stops, the MIL will remain on.
- Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL TROUBLESHOOTING INFORMATION</u>).
- 1. Troubleshoot the following DTCs first, if any of them were stored along with the random misfire DTC(s):

P0106, P0107, P0108, P1128, P1129: Manifold absolute pressure (MAP) sensor

P1162-P1169: Air fuel ratio (A/F) sensor  $(Sensor 1)^{*1}$ 

P1157, P1158, P1159, P1162-P1167: Air fuel ratio (A/F) sensor (Sensor 1)<sup>\*2</sup>

P0133, P1157, P2238, P2252, P2A00: A/F sensor (Sensor 1)<sup>\*3</sup>

P0171,P0172: Fuel system

P0335, P0336 (P0335, P0339)<sup>\*3</sup> : Crankshaft position (CKP) sensor

P0401, P1491, P1498 (P0401, P0404, P0406)<sup>\*3</sup> : Exhaust gas recirculation (EGR) system

P0505 (P0506, P0507) $^{*4}$ : Idle control system

P1259 (P2646)<sup>\*4</sup> (P2646, P2647)<sup>\*5</sup> : VTEC system

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

P1361, P1362, P1366, P1367 (P0340, P0344, P0365, P0369)<sup>\*3</sup> : Camshaft position A/B (CMP A/B) sensor

(Top Dead Center 1/2 (TDC 1/2) Sensor)

P1519  $(P0511)^{*3}$ : Idle air control (IAC) valve

- \*1: 2000-2001 M/T models
- \*2: 2002-2003 models
- \*3: 2004-2006 models
- \*4: 2004 model
- \*5: 2005-2006 models
- 2. Test-drive the vehicle to verify the symptom.
- 3. Find the symptom in the chart below, and do the related procedures to find the cause.

Symptom	<b>Procedure</b> (s)	Also check for:
	Check fuel pressure.	
	• 2000-2003 M/T models (see <b>2000-</b>	
	2003 M/T	
Random misfire only at	MODELS )	T .
low RPM and under	• 2001-2003 CVT	• Low compression.
load	models (see <u>2001-</u>	• Low quality fuel.
	<b>2003 CVT</b>	
	<u>MODELS</u> )	
	• 2004-2005 M/T	
	models (see <b><u>2004-</u></b>	
	2005 M/T	

#### **CYLINDER MISFIRE CHART**

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

Random misfire only during acceleration	MODELS )         • 2004-2005 CVT models (see 2004-2005 CVT MODELS )         • 2005 CVT MODELS )         • 2006 model (see 2006 MODEL )         Check fuel pressure.         • 2000-2003 M/T models (see 2000-2003 M/T MODELS )         • 2001-2003 CVT models (see 2001-2003 CVT MODELS )         • 2004-2005 M/T models (see 2001-2003 CVT MODELS )         • 2004-2005 M/T models (see 2004-2005 M/T MODELS )         • 2004-2005 M/T models (see 2004-2005 CVT MODELS )         • 2004-2005 CVT models (see 2004-2005 CVT MODELS )         • 2006 model (see 2004-2005 CVT MODELS )         • 2006 model (see 2004-2005 CVT models (see 2004-2005 CVT MODELS )         • 2000-2003 M/T MODELS )         • 2006 model (see 2004-2005 CVT models )	Malfunction in the VTEC system (see <u>VTEC</u> ROCKER ARM TEST ).
	<u>MODELS</u> ) • 2001-2003 CVT	

2006 Honda Insight			
2000-	06 ENGINE PERFORMANCE PGM-FI	System - Insight	
Random misfire at high RPM, under load, or under random conditions	models (see <u>2001-</u> <u>2003 CVT</u> <u>MODELS</u> ) • 2004-2005 M/T models (see <u>2004-</u> <u>2005 M/T</u> <u>MODELS</u> ) • 2004-2005 CVT models (see <u>2004-</u> <u>2005 CVT</u> <u>MODELS</u> ) • 2006 model (see <u>2006 MODEL</u> )	Correct valve clearances (see <u>VALVE</u> <u>CLEARANCE</u> <u>ADJUSTMENT</u> ).	

DTC P0301: NO. 1 CYLINDER MISFIRE DETECTED; DTC P0302: NO. 2 CYLINDER MISFIRE DETECTED; DTC P0303: NO. 3 CYLINDER MISFIRE DETECTED

#### NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. After checking and recording the freeze data, reset the ECM (see <u>ECM</u> <u>RESET</u>). If there is no freeze data of the misfire, just clear the DTC.
- 2. Start the engine, and listen for a clicking sound at the injector at the problem cylinder.

#### Does it click?

YES - Go to step 3.

**NO** - Go to step 30.

- 3. Turn the ignition switch OFF, and reset the ECM.
- 4. Exchange the ignition coil from the problem cylinder with one from another cylinder.
- 5. Test-drive the vehicle several times in the range of the freeze data or under various conditions if there was no freeze data.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

6. Check for Temporary DTCs or DTCs with the HDS.

#### Is DTC P0301, P0302 or P0303 indicated?

**YES** - Go to step 7.

**NO** - Intermittent misfire due to poor contact at the ignition coil connector (no misfire at this time).

7. Determine which cylinder(s) had the misfire.

## Does the misfire occur in the cylinder where the ignition coil was exchanged?

**YES** - Replace the faulty ignition coil.

NO - Go to step 8.

- 8. Turn the ignition switch OFF, and reset the ECM with the HDS.
- 9. Exchange the spark plug from the problem cylinder with one from another cylinder.
- 10. Test-drive the vehicle several times in the range of the freeze data or under various conditions if there was no freeze data.
- 11. Check for Temporary DTCs or DTCs with the HDS.

#### Is DTC P0301, P0302 or P0303 indicated?

YES - Go to step 12.

**NO** - Intermittent misfire due to spark plug fouling, etc. (no misfire at this time).

12. Determine which cylinder(s) had the misfire.

## Does the misfire occur in the cylinder where the spark plug was exchanged?

**YES** - Replace the faulty spark plug.

**NO** - Go to step 13.

13. Turn the ignition switch OFF, and reset the ECM with the HDS.

#### 2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

- 14. Exchange the injector from the problem cylinder with one from another cylinder.
- 15. Let the engine idle 2 minutes.
- 16. Test-drive the vehicle several minutes in the range of the freeze data or under various conditions if there was no freeze data.
- 17. Check for Temporary DTCs or DTCs with the HDS.

#### Is DTC P0301, P0302 or P0303 indicated?

**YES** - Go to step 18.

**NO** - Intermittent misfire due to bad contact at the injector connector (no misfire at this time).

18. Determine which cylinder(s) had the misfire.

#### Does the misfire occur in the cylinder where the injector was exchanged?

**YES** - Replace the faulty injector (see **INJECTOR REPLACEMENT** ). **NO** - Go to step 19.

- 19. Turn the ignition switch OFF.
- 20. Disconnect the ignition coil 3P connector from the problem cylinder.
- 21. Turn the ignition switch ON (II).
- 22. Measure voltage between ignition coil 3P connector terminal No. 3 and body ground.

## **IGNITION COIL 3P CONNECTOR**



## Wire side of female terminals

G03680775

**Fig. 72: Measuring Voltage Between Ignition Coil 3P Connector Terminal** <u>No. 3 And Body Ground</u> **Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

#### Is there battery voltage?

**YES** - Go to step 23.

**NO** - Repair open or short in the wire between the No. 7 (15 A) fuse and the ignition coil.

- 23. Turn the ignition switch OFF.
- 24. Check for continuity between ignition coil 3P connector terminal No. 2 and body ground.

## **IGNITION COIL 3P CONNECTOR**



## Wire side of female terminals

G03680776

**Fig. 73: Checking Continuity Between Ignition Coil 3P Connector Terminal No. 2 And Body Ground** 

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

#### **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

#### Is there continuity?

YES - Go to step 25.

**NO** - Repair open in the wire between the ignition coil and G101.

- 25. Disconnect ECM connector C (31P).
- 26. Check for continuity between body ground and the appropriate ECM connector terminal (see **BODY GROUND AND ECM CONNECTOR TERMINAL** ).



ECM CONNECTOR C (31P)

Wire side of female terminals

G03680777

**Fig. 74: Checking Continuity Between Body Ground And Appropriate ECM Connector Terminal Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

#### **BODY GROUND AND ECM CONNECTOR TERMINAL**

PROBLEM	ECM	

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

CYLINDER	DTC	TERMINAL	WIRE COLOR
No. 1	P0301	C4	WHT
No. 2	P0302	C13	WHT/GRN
No. 3	P0303	C14	WHT/BLK

#### Is there continuity?

**YES** - Repair short in the wire between the ECM and the ignition coil. **NO** - Go to step 27.

 27. Connect appropriate ignition coil 3P connector terminal No. 1 to body ground with a jumper wire (see <u>IGNITION COIL 3P CONNECTOR TO BODY</u> <u>GROUND</u>).

## **IGNITION COIL 3P CONNECTOR**



## Wire side of female terminals G03680778

Fig. 75: Connecting Appropriate Ignition Coil 3P Connector Terminal No. <u>1 To Body Ground With Jumper Wire</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### **IGNITION COIL 3P CONNECTOR TO BODY GROUND**

PROBLEM CYLINDER	DTC	WIRE COLOR

2006 Honda	Insight
------------	---------

No. 1	P0301	WHT
No. 2	P0302	WHT/GRN
No. 3	P0303	WHT/BLK

28. Check for continuity between body ground and the appropriate ECM connector terminal (see BODY GROUND AND ECM CONNECTOR).



Wire side of female terminals

G03680779

Fig. 76: Checking Continuity Between Body Ground And Appropriate **ECM Connector Terminal Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

BODY GROUND AND ECHI CONNECTOR TERMINAL				
PROBLEM		ECM		
CYLINDER	DTC	TERMINAL	WIRE COLOR	
No. 1	P0301	C4	WHT	
No. 2	P0302	C13	WHT/GRN	

#### **DDT7**

2006 Honda Insight 2000-06 ENGINE PERFORMANCE PGM-FI System - Insight				

#### Is there continuity?

YES - Go to step 29.

**NO** - Repair open in the wire between the ECM and the ignition coil.

29. Check the engine compression.

#### Is the engine compression OK?

YES - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

**NO** - Repair the engine.

- 30. Turn the ignition switch OFF, and wait for 10 seconds.
- 31. Disconnect ECM connector B (25P).
- 32. Turn the ignition switch ON (II).
- 33. Measure voltage between body ground and the appropriate ECM connector terminal (see **BODY GROUND AND ECM CONNECTOR TERMINAL** ).
### ECM CONNECTOR B (25P)



Wire side of female terminals

G03680780

### Fig. 77: Measuring Voltage Between Body Ground And Appropriate ECM **Connector Terminal Courtesy of AMERICAN HONDA MOTOR CO., INC.**

BODY GROUND AND ECM CONNECTOR TERMINAL			
PROBLEM CYLINDER	DTC	ECM TERMINAL	WIRE COLOR
No. 1	P0301	B11	BRN
No. 2	P0302	B3	RED
No. 3	P0303	B4	BLU

### Is there battery voltage?

**YES** - Go to step 34. NO - Go to step 43.

34. Turn the ignition switch OFF.

- 35. Disconnect the injector 2P connector from the problem cylinder.
- 36. At the injector side, measure resistance between injector 2P connector terminals No. 1 and No. 2.

# **INJECTOR 2P CONNECTOR**



# Terminal side of male terminals G03680781

### **Fig. 78: Measuring Resistance Between Injector 2P Connector Terminals** <u>No. 1 And 2</u>

#### 2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

### Courtesy of AMERICAN HONDA MOTOR CO., INC.

### Is there 10 - 130hm?

**YES** - Go to step 37.

**NO** - Replace the injector (see **INJECTOR REPLACEMENT** ).

- 37. Exchange the injector from the problem cylinder with one from another cylinder.
- 38. Reset the ECM with the HDS (see ECM RESET).
- 39. Let the engine idle 2 minutes.
- 40. Test-drive the vehicle several minutes in the range of the freeze data or under various conditions if there was no freeze data.
- 41. Check for Temporary DTCs or DTCs with the HDS.

### Is DTC P0301, P0302 or P0303 indicated?

YES - Go to step 42.

**NO** - Intermittent misfire due to injector malfunction, etc.

42. Determine which cylinder(s) had the misfire.

### Does the misfire occur in the cylinder where the injector was exchanged?

**YES** - Replace the faulty injector.

NO - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

- 43. Turn the ignition switch OFF.
- 44. Disconnect the injector 2P connector from the problem cylinder.
- 45. Turn the ignition switch ON (II).

46. Measure voltage between injector 2P connector terminal No. 2 and body ground.

# **INJECTOR 2P CONNECTOR**



# Wire side of female terminals

G03680782

**Fig. 79: Measuring Voltage Between Injector 2P Connector Terminal No.** <u>2 And Body Ground</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

### Is there battery voltage?

**YES** - Go to step 47.

**NO** - Repair open in the wire between the injector and the PGM-FI main relay.

- 47. Turn the ignition switch OFF.
- 48. Check for continuity between body ground and the appropriate ECM connector terminal (see **BODY GROUND AND ECM CONNECTOR TERMINAL**).



ECM CONNECTOR B (25P)

Wire side of female terminals

G03680783

**Fig. 80: Checking Continuity Between Body Ground And Appropriate** <u>ECM Connector Terminal</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

### **BODY GROUND AND ECM CONNECTOR TERMINAL**

PROBLEM CYLINDER	DTC	ECM TERMINAL	WIRE COLOR
No. 1	P0301	B11	BRN

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

No. 2	P0302	B3	RED
No. 3	P0303	B4	BLU

### Is there continuity?

YES - Repair short in the wire between the ECM and the injector.

**NO** - Go to step 49.

49. Connect appropriate injector 2P connector terminal No. 1 to body ground with a jumper wire (see **INJECTOR 2P CONNECTOR TERMINAL TO BODY** <u>**GROUND**</u>).

# **INJECTOR 2P CONNECTOR**



# Wire side of female terminals

G03680784

**Fig. 81: Connecting Appropriate Injector 2P Connector Terminal To Body Ground With Jumper Wire Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

INJECTOR 2P CONNECTOR TERMINAL TO BODY GROUND			
PROBLEM CYLINDER	DTC	WIRE COLOR	
No.1	P0301	BRN	
No. 2	P0302	RED	
No. 3	P0303	BLU	

50. Check for continuity between body ground and the appropriate ECM connector terminal (see **BODY GROUND AND ECM CONNECTOR TERMINAL**).

### **ECM CONNECTOR B (25P)**



Wire side of female terminals

G03680785

**Fig. 82: Checking Continuity Between Body Ground And Appropriate ECM Connector Terminal Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

### **BODY GROUND AND ECM CONNECTOR TERMINAL**

PROBLEM CYLINDER	DTC	ECM TERMINAL	WIRE COLOR

No.1	P0301	B11	BRN
No. 2	P0302	B3	RED
No. 3	P0303	B4	BLU

### Is there continuity?

YES - Replace the injector, then recheck.

NO - Repair open in the wire between the ECM and the injector.

### DTC P0325: KNOCK SENSOR CIRCUIT MALFUNCTION

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Reset the ECM with the HDS (see ECM RESET).
- 2. Start the engine. Hold the engine speed at 3,000 rpm without load (in Park or neutral) until the radiator fan comes on, then let it idle.
- 3. Hold the engine speed at 3,000-4,000 rpm for 10 seconds.
- 4. Check for Temporary DTCs or DTCs with the HDS.

### Is DTC P0325 indicated?

YES - Go to step 5.

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the knock sensor and the ECM.

- 5. Turn the ignition switch OFF, and wait for 10 seconds.
- 6. Disconnect the knock sensor 1P connector.
- 7. Disconnect ECM connector C (31P), then check for continuity between ECM connector terminal C22 and body ground.

## ECM CONNECTOR C (31P)



### Wire side of female terminals

G03680786

### Fig. 83: Checking Continuity Between ECM Connector Terminal C22 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

### Is there continuity?

**YES** - Repair short in the wire between the ECM (C22) and the knock sensor.

**NO** - Go to step 8.

8. Connect the knock sensor 1P connector terminal to body ground with a jumper wire.

## **KNOCK SENSOR 1P CONNECTOR**



Wire side of female terminals

G03680787

**Fig. 84: Connecting Knock Sensor 1P Connector Terminal To Body** <u>Ground With Jumper Wire</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

9. Check for continuity between ECM connector terminal C22 and body ground.

## ECM CONNECTOR C (31P)



Wire side of female terminals

G03680788

### Fig. 85: Checking Continuity Between ECM Connector Terminal C22 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

### Is there continuity?

**YES** - Go to step 10.

**NO** - Repair open in the wire between the ECM (C22) and the knock sensor.

- 10. Substitute a known-good knock sensor.
- 11. Check for Temporary DTCs or DTCs with the HDS.

### Is DTC P0325 indicated?

YES - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

**NO** - Replace the original knock sensor (see <u>KNOCK SENSOR</u> <u>REPLACEMENT</u> ).

DTC P0335: CKP SENSOR NO SIGNAL; DTC P0336: CKP SENSOR INTERMITTENT INTERRUPTION (2000-2003 MODELS); DTC P0339: CKP SENSOR INTERMITTENT INTERRUPTION (2004-2006 MODELS)

### NOTE:

- Information marked with an asterisk (\*) applies to 2000-2003 models.
  - Information marked with double asterisk (\*\*) applies to 2004-2006 models.
  - Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL TROUBLESHOOTING INFORMATION</u>).
- 1. Reset the ECM with the HDS (see **ECM RESET** ).
- 2. Start the engine.
- 3. Check for Temporary DTCs or DTCs with the HDS.

### Is DTC P0335, P0336\*, and/or (P0339)\*\* Indicated?

**YES** - Go to step 4.

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the CKP sensor and the ECM.

4. Turn the ignition switch OFF.

5. Disconnect the CKP sensor 2P connector, and at the sensor side, measure resistance between CKP sensor 2P connector terminals No. 1 and No. 2.

# **CKP SENSOR 2P CONNECTOR**



# Terminal side of male terminals G03680789

**Fig. 86: Measuring Resistance Between CKP Sensor 2P Connector Terminals No. 1 And 2 Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

### Is there 1,850-2,450 ohm?

YES - Go to step 6.

NO - Replace the CKP sensor (see  $\underline{CKP SENSOR REPLACEMENT}$ ).

6. At the sensor side, check for continuity between CKP sensor 2P connector terminal No. 1 and body ground and terminal No. 2 and body ground individually.

# **CKP SENSOR 2P CONNECTOR**



## Terminal side of male terminals G03680790

**Fig. 87: Checking Continuity Between CKP Sensor 2P Connector Terminal No. 1 & Body Ground And No. 2 & Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

### Is there continuity?

**YES** - Replace the CKP sensor (see CKP SENSOR REPLACEMENT).

#### 2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

**NO** - Go to step 7.

- 7. Reconnect the CKP sensor 2P connector.
- 8. Disconnect ECM connector C (31P), and measure resistance between ECM connector terminals C8 and C9.

### ECM CONNECTOR C (31P)



Wire side of female terminals

G03680791

### **Fig. 88: Measuring Resistance Between ECM Connector Terminals C8** <u>And C9</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

### Is there 1,850-2,450 ohm?

**YES** - Go to step 9.

**NO** - Repair open in the wire between the ECM (C8, C9) and the CKP sensor.

9. Check for continuity between ECM connector terminal C8 and body ground.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

### ECM CONNECTOR C (31P)



Wire side of female terminals

G03680792

### **Fig. 89: Checking Continuity Between ECM Connector Terminal C8 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

### Is there continuity?

**YES** - Repair short in the wire between ECM terminal C8 and the CKP sensor.

NO - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the

### original ECM (see ECM REPLACEMENT).

DTC P0340: CMP SENSOR A (TDC 1) NO SIGNAL (2004-2006 MODELS); DTC P0344: CMP SENSOR A (TDC 1) INTERMITTENT INTERRUPTION (2004-2006 MODELS); DTC P0365: CMP SENSOR B (TDC 2) NO SIGNAL (2004-2006 MODELS); DTC P0369: CMP SENSOR B (TDC 2) INTERMITTENT INTERRUPTION (2004-2006 MODELS); DTC P1361: CMP SENSOR A (TDC 1) CIRCUIT INTERMITTENT INTERRUPTION (2000-2003 MODELS); DTC P1362: CMP SENSOR A (TDC 1) NO SIGNAL (2000-2003 MODELS); DTC P1366: CMP SENSOR B (TDC 2) CIRCUIT INTERMITTENT INTERRUPTION (2000-2003 MODELS); DTC P1367: CMP SENSOR B (TDC 2) NO SIGNAL (2000-2003 MODELS)

### NOTE:

- Information marked with an asterisk (\*) applies to 2004-2006 models.
  - Information marked with double asterisk (\*\*) applies to 2000-2003 models.
  - Information marked with an asterisk (<sup>\*1</sup>) applies to DTC P0365\*, P0369\*, (P1366) \*\*, or (P1367) \*\*
  - Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL TROUBLESHOOTING INFORMATION</u>).
- 1. Reset the ECM with the HDS (see ECM RESET).
- 2. Start the engine.
- 3. Check for Temporary DTCs or DTCs with the HDS.

# Is DTC P0340\*, P0344\*, P0365\*, P0369\*, (P1361) \*\*, (P1362) \*\*, (P1366) \*\*, and/or (P1367) \*\* indicated?

**YES** - Go to step 4.

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at CMP (TDC 1) sensor A, CMP (TDC 2) sensor  $B^{*1}$  and the ECM.

- 4. Turn the ignition switch OFF.
- 5. Disconnect CMP (TDC 1) sensor A and CMP (TDC 2) sensor B<sup>\*1</sup> 2P connectors.

6. At the sensor side, measure resistance between CMP (TDC) sensor 2P connector terminals No. 1 and No. 2.

### CMP (TDC 1) SENSOR A 2P CONNECTOR CMP (TDC 2) SENSOR B 2P CONNECTOR\*<sup>1</sup>



Terminal side of male terminals

G03680793

**Fig. 90: Measuring Resistance Between CMP (TDC) Sensor 2P Connector** <u>Terminals No. 1 And 2</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there 1,850-2,450 ohm at 68°F (20°C)?

**YES** - Go to step 7.

**NO** - Replace CMP (TDC 1) sensor A and/or CMP (TDC 2) sensor B <sup>\*1</sup> (see <u>CMP SENSOR A/B (TDC SENSOR 1/2) REPLACEMENT</u>).

7. At the sensor side, check for continuity to body ground on each terminal individually.

### CMP (TDC 1) SENSOR A 2P CONNECTOR CMP (TDC 2) SENSOR B 2P CONNECTOR\*1



Terminal side of male terminals

G03680794

**Fig. 91: Checking Continuity To Body Ground On Each Terminal** Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** - Replace CMP (TDC 1) sensor A and/or CMP (TDC 2) sensor B\*1 (see <u>CMP SENSOR A/B (TDC SENSOR 1/2) REPLACEMENT</u>). NO - Go to step 8.

8. Reconnect CMP (TDC 1) sensor A and CMP (TDC 2) sensor  $B^{*1}$  2P

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

connectors.

- 9. Disconnect ECM connector C (31P).
- 10. Measure resistance between ECM connector terminals C20 and C21 (C29 and C30)  $^{*1}$ .



Wire side of female terminals

G03680795

# Fig. 92: Measuring Resistance Between ECM Connector Terminals C20And C21 (C29 And C30)\*1Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there 1,850-2,450 ohm?

YES -Go to step 11.NO -Repair open or short in the faulty sensor wire(s).

 Check for continuity between body ground and ECM connector terminal C20 (C29)\* individually.



Wire side of female terminals

G03680796

### Fig. 93: Checking Continuity Between Body Ground And ECM Connector <u>Terminal C20 (C29)\*</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** - Repair short to body ground in the faulty sensor wire(s). **NO** - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u>

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

<u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u>), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u>).

### DTC P0500: VSS CIRCUIT MALFUNCTION

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Test-drive the vehicle.
- 2. Check the VSS with the HDS.

### Is the correct speed indicated?

**YES** - Intermittent failure, system is OK at this time. Check for poor connections or loose wires at the VSS and the ECM.

NO - Go to step 3.

- 3. Turn the ignition switch OFF.
- 4. Block the rear wheels, and set the parking brake.
- 5. Raise the front of the vehicle, and make sure it is securely supported.
- 6. Turn the ignition switch ON (II).
- 7. Block the right front wheel, and slowly rotate the left front wheel.
- 8. Measure voltage between ECM connector terminals C5 and B20.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

### **ECM CONNECTORS**



Wire side of female terminals

G03680797

### **Fig. 94: Measuring Voltage Between ECM Connector Terminals C5 And B20 Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Does the voltage change between 0 V and 5 V?

YES - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u>

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

**MODELS AND CVT MODEL** ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see **ECM REPLACEMENT** ).

**NO** - Go to step 9.

- 9. Turn the ignition switch OFF, and wait for 10 seconds.
- 10. Disconnect ECM connector C (31P).
- 11. Turn the ignition switch ON (II).
- 12. Block the right front wheel, and slowly rotate the left front wheel.
- 13. Measure voltage between ECM connector terminals C5 and B20.



### ECM CONNECTORS

Wire side of female terminals

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

### **Fig. 95: Measuring Voltage Between ECM Connector Terminals C5 And B20**

### Courtesy of AMERICAN HONDA MOTOR CO., INC.

### Does the voltage change between 0 V and 5 V?

YES - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

**NO** - Check these items:

- A short or an open in the wire between the ECM (C5), the TCM (CVT model) and the VSS.
- If the wire is OK, test the VSS (see <u>GAUGE ASSEMBLY</u> <u>REPLACEMENT</u> ).
- Substitute a known-good TCM and recheck (see <u>HOW TO</u> <u>TROUBLESHOOT CIRCUIT AT THE TCM</u>). If the symptom/indication goes away, replace the original TCM (CVT model).

DTC P0560: ECM POWER SOURCE CIRCUIT UNEXPECTED VOLTAGE (2001-2004 MODELS)

- NOTE:
- If the No. 18 (7.5 A) fuse in the under-dash fuse/relay box is removed and the engine is started, the MIL will come on, and the ECM will store DTC P0560.
  - Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL TROUBLESHOOTING INFORMATION</u>).
- 1. Reset the ECM with the HDS (see ECM RESET).
- 2. Start the engine.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

3. Check for Temporary DTCs or DTCs with the HDS.

### Is DTC P0560 indicated?

**YES** - Go to step 4.

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the No. 18 (7.5 A) fuse in the under-dash fuse/relay box and the ECM.

- 4. Turn the ignition switch OFF.
- 5. Inspect the No. 18 (7.5 A) fuse in the under-dash fuse/relay box.

### Is the fuse OK?

YES - Go to step 6.

**NO** - Check for these problems:

- A short in the wire between the ECM (B21) and the No. 18 (7.5 A) fuse in the under-dash passenger's fuse/relay box.
- A short in the wire in the back up circuit (see <u>FUSE TO</u> <u>COMPONENTS INDEX</u> ).
- A blown No. 18 (7.5 A) fuse in the under-dash passenger's fuse/relay box.
- 6. Measure voltage between ECM connector terminal B21 and body ground.

# ECM CONNECTOR B (25P)



Wire side of female terminals

G03680799

### **Fig. 96: Measuring Voltage Between ECM Connector Terminal B21 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

Is there battery voltage?

YES - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2004 M/T models and CVT model (see <u>ECM</u>

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T MODELS AND CVT MODEL ), then recheck. If the

symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u>).

**NO** - Repair open in the wire between the ECM (B21) and the No. 18 (7.5 A) fuse in the under-dash passenger's fuse/relay box.

DTC P0563: ECM POWER SOURCE CIRCUIT UNEXPECTED VOLTAGE (2005-2006 MODELS)

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Reset the ECM with the HDS (see ECM RESET).
- 2. Turn the ignition switch OFF.
- 3. Wait 5 seconds.
- 4. Turn the ignition switch ON (II).
- 5. Check for Temporary DTCs or DTCs with the HDS.

### Is DTC P0563 indicated?

**YES** - Go to step 6.

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the No. 7 (15 A) fuse in the under-hood fuse/relay box and the ECM.

- 6. Turn the ignition switch OFF, and wait for 10 seconds.
- 7. Disconnect ECM connector A (32P).
- 8. Measure voltage between ECM connector terminal A8 and body ground.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

### ECM CONNECTOR A (32P)



Wire side of female terminals

G03680800

### Fig. 97: Measuring Voltage Between ECM Connector Terminal A8 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there battery voltage?

**YES** - Go to step 12.

**NO** - Go to step 9.

- 9. Remove the glove box (see <u>GLOVE BOX REMOVAL/INSTALLATION</u>).
- 10. Remove PGM-FI main relay 1 (IGP).
- 11. Check for continuity between ECM connector terminal A8 and body ground.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

### ECM CONNECTOR A (32P)



Wire side of female terminals

G03680801

### **Fig. 98: Checking Continuity Between ECM Connector Terminal A8 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

### Is there continuity?

**YES** - Repair short in the wire between the ECM (A8) and PGM-FI main relay 1 (IGP).

**NO** - Replace PGM-FI main relay 1 (IGP).

- 12. Reconnect ECM connector A (32P).
- 13. Measure voltage between ECM connector terminal A8 and body ground.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

### ECM CONNECTOR A (32P)



Wire side of female terminals

G03680802

### Fig. 99: Measuring Voltage Between ECM Connector Terminal A8 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

### Is there battery voltage?

**YES** - Go to step 14.

**NO** - Update the ECM if it does not have the latest software, or substitute a known-good ECM (see <u>ECM UPDATING AND SUBSTITUTION</u> <u>FOR TESTING-2002-2006 M/T MODELS AND CVT MODEL</u>), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u>).

- 14. Disconnect ECM connector B (25P).
- 15. Measure voltage between body ground and ECM connector terminals B1 and B9 individually.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

### ECM CONNECTOR B (25P)



### Wire side of female terminals

G03680803

### **Fig. 100: Measuring Voltage Between Body Ground And ECM Connector** <u>Terminals B1 And B9</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

### Is there battery voltage?

**YES** - Go to step 16.

**NO** - Update the ECM if it does not have the latest software, or substitute a known-good ECM (see <u>ECM UPDATING AND SUBSTITUTION</u> <u>FOR TESTING-2002-2006 M/T MODELS AND CVT MODEL</u>), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u>).

- 16. Remove PGM-FI main relay 1 (IGP).
- 17. Measure voltage between body ground and ECM connector terminals B1 and B9 individually.



### ECM CONNECTOR B (25P)

Wire side of female terminals

G03680804

### **Fig. 101: Measuring Voltage Between Body Ground And ECM Connector** <u>Terminals B1 And B9</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

### Is there battery voltage?

**YES** - Repair short to power in the wire between the ECM (B1, B9) and PGM-FI main relay 1 (IGP).

NO - Replace PGM-FI main relay 1 (IGP).

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

DTC P0607: ECM INTERNAL CIRCUIT MALFUNCTION (2004-2006 MODELS); DTC P1607: ECM INTERNAL CIRCUIT MALFUNCTION (2000-2003 MODELS)

### NOTE:

- Information marked with an asterisk (\*) applies to 2004-2006 models.
  - Information marked with double asterisk (\*\*) applies to 2000-2003 models.
  - Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL TROUBLESHOOTING INFORMATION</u>).
- 1. Reset the ECM with the HDS (see **ECM RESET** ).
- 2. Turn the ignition switch ON (II).
- 3. Wait 30 seconds.
- 4. Check for Temporary DTCs or DTCs with the HDS.

### Is DTC P0607\* (P1607) \*\* indicated?

YES - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

- **NO** Go to step 5.
- 5. Turn the ignition switch OFF.
- 6. Turn the ignition switch ON (II).
- 7. Wait 10 seconds.
- 8. Check for Temporary DTCs or DTCs with the HDS.

### Is DTC P0607\* (P1607) \*\* indicated?

**YES** - Update the ECM if it does not have the latest software, or substitute
2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u> ). NO - Intermittent failure, system is OK at this time.

DTC P0630: VIN NOT PROGRAMMED OR MISMATCH (2005-2006 MODELS)

- This DTC is stored only when the ECM does not have the VIN information of the vehicle. Use the HDS to input the missing VIN information.
  - Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL TROUBLESHOOTING INFORMATION</u>).
  - 1. Turn the ignition switch ON (II).
  - 2. Check the VIN with the HDS.

Does the HDS show the vehicle's VIN?

YES - Go to step 5.

NO - Go to step 3.

3. Input the VIN into the ECM with the HDS.

## Does the screen show COMPLETE?

YES - Go to step 5.

**NO** - Go to step 4.

4. Check for DTCs with the HDS.

# Is DTC P0603 indicated?

YES - Go to the DTC P0603 troubleshooting.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

**NO** - Update the ECM if it does not have the latest software, or substitute a known-good ECM (see <u>ECM UPDATING AND SUBSTITUTION</u> <u>FOR TESTING-2002-2006 M/T MODELS AND CVT MODEL</u>), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u>).

- 5. Clear the DTC with the HDS.
- 6. Turn the ignition switch OFF.
- 7. Turn the ignition switch ON (II), and wait 5 seconds.
- 8. Check for Temporary DTCs or DTCs with the HDS.

# Are any Temporary DTCs or DTCs indicated?

**YES** - If DTC P0630 is indicated, update the ECM if it does not have the latest software, or substitute a known-good ECM (see <u>ECM UPDATING</u> <u>AND SUBSTITUTION FOR TESTING-2002-2006 M/T MODELS</u> <u>AND CVT MODEL</u>), then recheck. If any other Temporary DTCs or DTCs are indicated, go to the indicated <u>DTC TROUBLESHOOTING</u>. **NO** - Intermittent failure, system is OK at this time.

DTC P0685: ECM POWER CONTROL CIRCUIT/INTERNAL CIRCUIT MALFUNCTION (2006 MODEL)

- NOTE:
  - If the problem doesn't return after you clear the DTC, or if this DTC is stored intermittently, check for loose terminals at the IGP line connections before you replacing the ECM.
    - Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL TROUBLESHOOTING INFORMATION</u>).
  - 1. Turn the ignition switch ON (II).
  - 2. Clear the DTC with the HDS.
  - 3. Start the engine, and let it idle for 30 seconds.
  - 4. Turn the ignition switch OFF.

- 5. Start the engine, and let it idle for 30 seconds.
- 6. Turn the ignition switch OFF.
- 7. Turn the ignition switch ON (II).
- 8. Check for Temporary DTCs or DTCs with the HDS.

# Is DTC P0685 indicated?

**YES** - Update the ECM if it does not have the latest software, or substitute a known-good ECM (see <u>ECM UPDATING AND SUBSTITUTION</u> <u>FOR TESTING-2002-2006 M/T MODELS AND CVT MODEL</u>), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u>).

NO - Intermittent failure, system is OK at this time.

DTC P07XX: A/T CONTROL SYSTEM MALFUNCTION; DTC P16XX: A/T CONTROL SYSTEM MALFUNCTION; DTC P17XX: A/T CONTROL SYSTEM MALFUNCTION; DTC P18XX: A/T CONTROL SYSTEM MALFUNCTION; DTC P21XX: A/T CONTROL SYSTEM MALFUNCTION;

- NOTE:
- This DTC is stored when there is a problem in the A/T control system. Check for A/T DTCs with the HDS, and go to the indicated <u>DTC TROUBLESHOOTING</u>.
  - Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL TROUBLESHOOTING INFORMATION</u>).

DTC P1106: BARO SENSOR RANGE/PERFORMANCE PROBLEM (2000-2003 MODELS); DTC P2227: BARO SENSOR RANGE/PERFORMANCE PROBLEM (2004-2006 MODELS)

- NOTE:
- Information marked with an asterisk (\*) applies to 2000-2003 models.
  - Information marked with double asterisk (\*\*) applies to 2004-2006 models.
  - Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL TROUBLESHOOTING INFORMATION</u>).

- 1. Reset the ECM with the HDS (see ECM RESET).
- 2. Start the engine. Hold the engine speed at 3,000 rpm without load (in Park or neutral) until the radiator fan comes on, then let it idle.
- 3. Test-drive with the CVT in D position (M/T in 4th gear).
- 4. Accelerate for 5 seconds using wide open throttle.
- 5. Check for a Temporary DTCs or DTCs with the HDS.

# Is DTC P1106\* (P2227)\*\* indicated?

YES - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

**NO** - Intermittent failure, system is OK at this time.

DTC P1107: BARO SENSOR CIRCUIT LOW VOLTAGE (2000-2003 MODELS); DTC P1108: BARO SENSOR CIRCUIT HIGH VOLTAGE (2000-2003 MODELS); DTC P2228: BARO SENSOR CIRCUIT LOW VOLTAGE (2004-2006 MODELS); DTC P2229: BARO SENSOR CIRCUIT HIGH VOLTAGE (2004-2006 MODELS)

# NOTE:

- Information marked with an asterisk (\*) applies to 2000-2003 models.
  - Information marked with double asterisk (\*\*) applies to 2004-2006 models.
  - Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL TROUBLESHOOTING INFORMATION</u>).
- 1. Reset the ECM with the HDS (see **HDS CLEAR COMMAND**).
- 2. Turn the ignition switch ON (II).
- 3. Check for Temporary DTCs or DTCs with the HDS.

## Is DTC P1107\* (P2228) \*\* or P1108\* (P2229) \*\* indicated?

YES - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

**NO** - Intermittent failure, system is OK at this time.

#### DTC P1109: BARO SENSOR CIRCUIT OUT OF RANGE HIGH

(2005-2006 models)

- NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).
  - 1. Reset the ECM with the HDS.
- 2. Start the engine.
- 3. Check for Temporary DTCs or DTCs with the HDS.

# Is DTC P1109 indicated?

**YES** - Update the ECM if it does not have the latest software, or substitute a known-good ECM (see <u>ECM UPDATING AND SUBSTITUTION</u> <u>FOR TESTING-2002-2006 M/T MODELS AND CVT MODEL</u>), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u>).

NO - Intermittent failure, system is OK at this time.

#### DTC P1121:TP SENSOR SIGNAL LOWER THAN EXPECTED

NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u>

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

# **TROUBLESHOOTING INFORMATION ).**

- 1. Turn the ignition switch ON (II).
- 2. Check the TP SENSOR in the DATA LIST with the HDS.

## Is 12.1% or higher indicated when the throttle is fully opened?

YES - Intermittent failure, system is OK at this time. NO - Replace the throttle body (see <u>THROTTLE BODY</u> <u>REMOVAL/INSTALLATION</u>).

#### DTC P1122: TP SENSOR SIGNAL HIGHER THAN EXPECTED

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Turn the ignition switch ON (II).
- 2. Check the TP SENSOR in the DATA LIST with the HDS.

### Is 18.9% or less indicated when the throttle is fully closed?

**YES** - Intermittent failure, system is OK at this time. **NO** - Replace the throttle body (see <u>**THROTTLE BODY**</u> <u>**REMOVAL/INSTALLATION**</u>).

DTC P1128: MAP SENSOR SIGNAL LOWER THAN EXPECTED

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Turn the ignition switch ON (II).
- 2. Check the MAP SENSOR in the DATA LIST with the HDS.

# Is 64.4 kPa (19.0 in.Hg, 483 mmHg) or more indicated?

**YES** - Intermittent failure, system is OK at this time.

**NO** - Replace the MAP sensor.

#### DTC P1129: MAP SENSOR SIGNAL HIGHER THAN EXPECTED

## NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Start the engine. Hold the engine speed at 3,000 rpm without load (in Park or neutral) until the radiator fan comes on, then let it idle.
- 2. Check the MAP SENSOR in the DATA LIST with the HDS.

# Is 47.2 kPa (13.9 in.Hg, 354 mmHg) or less indicated?

YES - Intermittent failure, system is OK at this time.

**NO** - Replace the MAP sensor.

DTC P1130: SECONDARY HO2S (SENSOR 2) AND THIRD HO2S (SENSOR 3) MALFUNCTION (2002-2006 M/T MODELS)

• This DTC is only stored when one or a combination of the DTCs listed are stored. Troubleshoot these DTCs, and this DTC will go away.

P0137, P0138, P0139: Secondary HO2S (Sensor 2)

P0137, P0138, P0139: Secondary HO2S (Sensor 2)

P0143, P0144, P0145: Third HO2S (Sensor 3)

P0147: Third HO2S (Sensor 3) heater

• Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL TROUBLESHOOTING INFORMATION</u>).

#### 2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

#### (CVT MODEL)

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Reset the ECM with the HDS (see ECM RESET).
- 2. Start the engine.
- 3. Check for Temporary DTCs or DTCs with the HDS.

# Is DTC P1157 indicated?

**YES** - Go to step 4.

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the A/F sensor (Sensor 1) and the ECM.

- 4. Turn the ignition switch OFF, and wait for 10 seconds.
- 5. Disconnect the A/F sensor (Sensor 1) 4P connector and ECM connector D (16P).
- 6. Connect A/F sensor (Sensor 1) 4P connector terminals No. 1 and No. 2 with a jumper wire.

# A/F SENSOR (SENSOR 1) 4P CONNECTOR



Terminal side of male terminals

G03680805

Fig. 102: Connecting A/F Sensor (Sensor 1) 4P Connector Terminals With Jumper Wire Courtesy of AMERICAN HONDA MOTOR CO., INC.

7. Check for continuity between ECM connector terminals D4 and D10.

# ECM CONNECTOR D (16P)



# Wire side of female terminals G03680806

Fig. 103: Checking For Continuity Between ECM Connector Terminals D4 And D10 Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Is there continuity?

YES - Go to step 10.

NO - Go to step 8.

8. Connect A/F sensor (Sensor 1) 4P connector terminal No. 2 to body ground with a jumper wire.

# A/F SENSOR (SENSOR 1) 4P CONNECTOR



Terminal side of male terminals

G03680807

**Fig. 104: Connecting A/F Sensor (Sensor 1) 4P Connector Terminal To Body Ground With Jumper Wire Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

9. Check for continuity between ECM connector terminal D4 and body ground.

# ECM CONNECTOR D (16P)



# Wire side of female terminals G03680808

**Fig. 105: Checking Continuity Between ECM Connector Terminal D4** And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Is there continuity?

**YES** - Repair open in the wire between the A/F sensor (Sensor 1) and the ECM (D10).

**NO** - Repair open in the wire between the A/F sensor (Sensor 1) and the ECM (D4).

- 10. Substitute a known-good A/F sensor (Sensor 1) (see <u>A/F SENSOR</u> <u>REPLACEMENT</u>).
- 11. Check for Temporary DTCs or DTCs with the HDS.

# Is DTC P1157 indicated?

**YES** - Update the ECM if it does not have the latest software, or substitute a known-good ECM (see <u>ECM UPDATING AND SUBSTITUTION</u> <u>FOR TESTING-2002-2006 M/T MODELS AND CVT MODEL</u>), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u>).

**NO** - Replace the A/F sensor (Sensor 1) (see <u>A/F SENSOR</u> <u>**REPLACEMENT**</u>.

DTC P1158: A/F SENSOR (SENSOR 1) AFS-CIRCUIT LOW VOLTAGE (2002-2003 M/T MODELS) (2001-2003 CVT MODELS); DTC P2252: A/F SENSOR (SENSOR 1) AFS-CIRCUIT LOW VOLTAGE (2004-2006 MODELS)

- NOTE: Information marked with an asterisk (\*) applies to 2001-2003 CVT models and 2002-2003 M/T models.
  - Information marked with a double asterisk (\*\*) applies to 2004-2006 models.
  - Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL TROUBLESHOOTING INFORMATION</u>).
- 1. Reset the ECM with the HDS (see ECM RESET).
- 2. Start the engine, and wait at least 2 minutes.
- 3. Check for Temporary DTCs or DTCs with the HDS.

# Is DTC P1158\* (P2252)\*\* indicated?

**YES** - Go to step 4.

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the A/F sensor (Sensor 1) and the ECM.

- 4. Turn the ignition switch OFF, and wait for 10 seconds.
- Disconnect the A/F sensor (Sensor 1) 4P connector, and ECM connector D (16P).
- Check for continuity between A/F sensor (Sensor 1) 4P connector terminal No. 1 and body ground.

# A/F SENSOR (SENSOR 1) 4P CONNECTOR



Terminal side of male terminals

G03680809

Fig. 106: Checking Continuity Between A/F Sensor (Sensor 1) 4P Connector Terminal And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

## Is there continuity?

**YES** - Repair short in the wire between the A/F sensor (Sensor 1) and the ECM (D10).

**NO** - Go to step 7.

- 7. Substitute a known-good A/F sensor (Sensor 1) (see <u>A/F SENSOR</u> <u>REPLACEMENT</u>.
- 8. Check for Temporary DTCs or DTCs with the HDS.

# Is DTC P1158\* (P2252)\*\* indicated?

**YES** - Update the ECM if it does not have the latest software, or substitute a known-good ECM (see <u>ECM UPDATING AND SUBSTITUTION</u> <u>FOR TESTING-2002-2006 M/T MODELS AND CVT MODEL</u>), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u>).

**NO** - Replace the original A/F sensor (Sensor 1) (see <u>A/F SENSOR</u> <u>**REPLACEMENT**</u>.

DTC P1159: A/F SENSOR (SENSOR 1) AFS+ CIRCUIT LOW VOLTAGE (2002-2003 M/T MODELS) (2001-2003 CVT MODELS); DTC P2238: A/F SENSOR (SENSOR 1) AFS+ CIRCUIT LOW VOLTAGE (2004-2006 MODELS)

- NOTE:
- Information marked with an asterisk (\*) applies to 2001-2003 CVT models and 2002-2003 M/T models.
  - Information marked with double asterisk (\*\*) applies to 2004-2006 models.
  - Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL TROUBLESHOOTING INFORMATION</u>).
- 1. Reset the ECM with the HDS (see **ECM RESET** ).
- 2. Start the engine, and wait at least 2 minutes.
- 3. Check for Temporary DTCs or DTCs with the HDS.

Is DTC P1159\* (P2238)\*\* indicated?

**YES** - Go to step 4.

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the A/F sensor (Sensor 1) and the ECM.

- 4. Turn the ignition switch OFF, and wait for 10 seconds.
- Disconnect the A/F sensor (Sensor 1) 4P connector and ECM connector D (16P).
- 6. Check for continuity between A/F sensor (Sensor 1) 4P connector terminal No. 2 and body ground.

# A/F SENSOR (SENSOR 1) 4P CONNECTOR



# Terminal side of male terminals

G03680810

**Fig. 107: Checking Continuity Between A/F Sensor (Sensor 1) 4P Connector Terminal No. 2 And Body Ground** 

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

## Courtesy of AMERICAN HONDA MOTOR CO., INC.

## Is there continuity?

**YES** - Repair short in the wire between the A/F sensor (Sensor 1) and the ECM (D4).

**NO** - Go to step 7.

- 7. Substitute a known-good A/F sensor (Sensor 1) (see <u>A/F SENSOR</u> <u>REPLACEMENT</u>.
- 8. Check for Temporary DTCs or DTCs with the HDS.

## Is DTC P1159\* (P2238)\*\* indicated?

**YES** - Update the ECM if it does not have the latest software, or substitute a known-good ECM (see <u>ECM UPDATING AND SUBSTITUTION</u> <u>FOR TESTING-2002-2006 M/T MODELS AND CVT MODEL</u>), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u>).

**NO** - Replace the A/F sensor (Sensor 1) (see <u>A/F SENSOR</u> <u>**REPLACEMENT**</u>.

DTC P1162: A/F SENSOR (SENSOR 1) CIRCUIT MALFUNCTION (2000-2001 M/T MODELS)

- NOTE: If DTC P1162 is stored at the same time as DTC P1167, troubleshoot DTC P1162 first, then recheck for DTC P1167.
  - Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL TROUBLESHOOTING INFORMATION</u>).
  - 1. Reset the ECM with the HDS (see **ECM RESET** ).
- 2. Start the engine, and wait at least 2 minutes.
- 3. Check for Temporary DTCs or DTCs with the HDS.

## Is DTC P1162 indicated?

#### 2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

**YES** - Go to step 4.

NO - Go to step 17.

- 4. Turn the ignition switch OFF.
- 5. Turn the ignition switch ON (II).
- 6. Measure voltage between ECM connector terminals D10 and C18.

# **ECM CONNECTORS**



Wire side of female terminals

G03680811

**Fig. 108: Measuring Voltage Between ECM Connector Terminals D10** <u>And C18</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there more than 0.5 V?

**YES** - Go to step 7.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

NO - Go to step 23.

7. Measure voltage between ECM connector terminals D11 and C18.



Wire side of female terminals

G03680812

## **Fig. 109: Measuring Voltage Between ECM Connector Terminals D11** <u>And C18</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

## Is there more than 0.5 V?

YES - Go to step 8.NO - Go to step 28 .

8. Measure voltage between ECM connector terminals D11 and C18.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

# **ECM CONNECTORS**



Wire side of female terminals

G03680813

### **Fig. 110: Measuring Voltage Between ECM Connector Terminals D11** <u>And C18</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

### Is there more than 5.0 V?

**YES** - Go to step 9. **NO** - Go to step 33.

- 9. Start the engine. Hold the engine speed at 3,000 rpm without load (in Park or neutral) until the radiator fan comes on, then let it idle.
- 10. Measure voltage between ECM connector terminals D10 and C18.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

# **ECM CONNECTORS**



Wire side of female terminals

G03680814

### **Fig. 111: Measuring Voltage Between ECM Connector Terminals D10** <u>And C18</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Is there more than 2.6-2.8 V?

**YES** - Go to step 11. **NO** - Go to step 37.

11. Measure voltage between ECM connector terminals D4 and C18.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

# **ECM CONNECTORS**



Wire side of female terminals

G03680815

#### **Fig. 112: Measuring Voltage Between ECM Connector Terminals D4 And** <u>C18</u> **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

### Is there more than 0.4 V?

YES - Substitute a known-good ECM (see <u>HOW TO SUBSTITUTE</u> <u>THE ECM FOR TESTING PURPOSES (2000-2001 M/T</u> <u>MODELS)</u>), and recheck. If the symptom/indication goes away, replace the original ECM (see <u>ECM REPLACEMENT</u>). NO - Go to step 12.

12. Turn the ignition switch OFF.

13. Disconnect ECM connector D (16P).

14. Check for continuity between ECM connector terminal D4 and body ground.

# ECM CONNECTOR D (16P)



# Wire side of female terminals

G03680816

Fig. 113: Checking Continuity Between ECM Connector Terminal D4 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### 2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

## Is there continuity?

**YES** - Go to step 15.

**NO** - Go to step 38.

- 15. Disconnect the A/F sensor (Sensor 1) 8P connector.
- 16. Check for continuity between ECM connector terminal D4 and body ground.

# ECM CONNECTOR D (16P)



# Wire side of female terminals

G03680817

**Fig. 114: Checking Continuity Between ECM Connector Terminal D4** <u>And Body Ground</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** - Repair short in the wire between the ECM (D4) and the A/F sensor (Sensor 1).

**NO** - Replace the A/F sensor (Sensor 1) (see <u>A/F SENSOR</u> <u>**REPLACEMENT**</u>.

17. Test-drive for several miles with the transmission in 3rd gear. Hold the engine speed at 1,500 rpm.

# Is DTC P1162 indicated?

**YES** - Go to step 18.

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the A/F sensor (Sensor 1) and the ECM.

- 18. Turn the ignition switch OFF.
- 19. Disconnect ECM connector D (16P).
- 20. Disconnect the A/F sensor (Sensor 1) 8P connector.
- 21. Connect ECM connector terminal D4 to body ground with a jumper wire.

# ECM CONNECTOR D (16P)



# Wire side of female terminals G03680818

## **Fig. 115: Connecting ECM Connector Terminal D4 To Body Ground With Jumper Wire Courtesy of AMERICAN HONDA MOTOR CO., INC.**

22. Check for continuity between A/F sensor (Sensor 1) 8P connector terminal No. 7 and body ground.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

# A/F SENSOR (SENSOR 1) 8P CONNECTOR



# Wire side of female terminals

G03680819

Fig. 116: Checking Continuity Between A/F Sensor (Sensor 1) 8P Connector Terminal No. 7 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** - Check for a poor connection at the A/F sensor (Sensor 1) connector and at the ECM. If the connections are OK, replace the A/F sensor (Sensor 1).

**NO** - Repair open in the wire between the ECM (D4) and the A/F sensor (Sensor 1).

- 23. Turn the ignition switch OFF.
- 24. Disconnect ECM connector D (16P).
- 25. Check for continuity between ECM connector terminal D10 and body ground.

# ECM CONNECTOR D (16P)



# Wire side of female terminals G03680820

**Fig. 117: Checking Continuity Between ECM Connector Terminal D10** And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Is there continuity?

YES - Go to step 26.

**NO** - Repair open in the wire between the ECM (D4) and the A/F sensor (Sensor 1).

- 26. Disconnect the A/F sensor (Sensor 1) 8P connector.
- 27. Check for continuity between ECM connector terminal D10 and body ground.

# ECM CONNECTOR D (16P)



# Wire side of female terminals G03680821

Fig. 118: Checking For Continuity Between ECM Connector Terminal

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

## **D10 And Body Ground** Courtesy of AMERICAN HONDA MOTOR CO., INC.

## Is there continuity?

**YES** - Repair short in the wire between the ECM (D4) and the A/F sensor (Sensor 1).

**NO** - Replace the A/F sensor (Sensor 1) (see <u>A/F SENSOR</u> <u>**REPLACEMENT**</u>.

- 28. Turn the ignition switch OFF.
- 29. Disconnect ECM connector D (16P).
- 30. Check for continuity between ECM connector terminal D11 and body ground.

# ECM CONNECTOR D (16P)



# Wire side of female terminals

G03680822

**Fig. 119: Checking Continuity Between ECM Connector Terminal D11** And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** - Go to step 31.

NO - Substitute a known-good ECM (see <u>HOW TO SUBSTITUTE</u> <u>THE ECM FOR TESTING PURPOSES (2000-2001 M/T</u> <u>MODELS</u>) ), and recheck. If the symptom/indication goes away, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

- 31. Disconnect the A/F sensor (Sensor 1) 8P connector.
- 32. Check for continuity between ECM connector terminal D11 and body ground.

# ECM CONNECTOR D (16P)



# Wire side of female terminals

G03680823

Fig. 120: Checking Continuity Between ECM Connector Terminal D11 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** - Repair short in the wire between the ECM (D11) and the A/F sensor (Sensor 1).

**NO** - Replace the A/F sensor (Sensor 1) (see <u>A/F SENSOR</u> <u>**REPLACEMENT**</u>.

- 33. Turn the ignition switch OFF.
- 34. Disconnect the A/F sensor (Sensor 1) 8P connector.
- 35. Turn the ignition switch ON (II).
- 36. Measure voltage between ECM connector terminals D11 and C18.



**ECM CONNECTORS** 

Wire side of female terminals

G03680824

# **Fig. 121: Measuring Voltage Between ECM Connector Terminals D11** <u>And C18</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.
2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

#### Is there more than 5.0 V?

**YES** - Replace the A/F sensor (Sensor 1) (see <u>A/F SENSOR</u> <u>REPLACEMENT</u>.

NO - Substitute a known-good ECM (see <u>HOW TO SUBSTITUTE</u> <u>THE ECM FOR TESTING PURPOSES (2000-2001 M/T</u> <u>MODELS</u>) ), and recheck. If the symptom/indication goes away, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

37. Measure voltage between ECM connector terminals D11 and C18.



Wire side of female terminals

G03680825

**Fig. 122: Measuring Voltage Between ECM Connector Terminals D11** <u>And C18</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

### **ECM CONNECTORS**

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

#### Is there less than 2.8 V?

**YES** - Replace the A/F sensor (Sensor 1) (see <u>A/F SENSOR</u> <u>REPLACEMENT</u>.

NO - Substitute a known-good ECM (see <u>HOW TO SUBSTITUTE</u> <u>THE ECM FOR TESTING PURPOSES (2000-2001 M/T</u> <u>MODELS</u>) ), and recheck. If the symptom/indication goes away, replace the original ECM (see <u>ECM REPLACEMENT</u>).

- 38. Disconnect the A/F sensor (Sensor 1) 8P connector.
- 39. Connect ECM connector terminal D4 to body ground with a jumper wire.

# ECM CONNECTOR D (16P)



## Wire side of female terminals

G03680826

#### **Fig. 123: Connecting ECM Connector Terminal D4 To Body Ground With Jumper Wire Courtesy of AMERICAN HONDA MOTOR CO., INC.**

40. Check for continuity between A/F sensor (Sensor 1) 8P connector terminal No.7 and body ground.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

# A/F SENSOR (SENSOR 1) 8P CONNECTOR



# Wire side of female terminals

G03680827

**Fig. 124:** Checking Continuity Between A/F Sensor (Sensor 1) 8P Connector Terminal No. 7 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

YES - Substitute a known-good ECM (see <u>HOW TO SUBSTITUTE</u> <u>THE ECM FOR TESTING PURPOSES (2000-2001 M/T</u>

 $\underline{\text{MODELS}}$  ), and recheck. If the symptom/indication goes away, replace the original ECM (see  $\underline{\text{ECM REPLACEMENT}}$  ).

**NO** - Repair open in the wire between the ECM (D4) and the A/F sensor (Sensor 1).

DTC P1163: A/F SENSOR (SENSOR 1) SLOW RESPONSE (2000-2001 M/T MODELS)

- NOTE: If DTC P1162, P1168, and/or P1169 are stored at the same time as DTC P1163, troubleshoot those DTCs first, then recheck for DTC P1163.
  - Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL TROUBLESHOOTING INFORMATION</u>).
  - 1. Reset the ECM with the HDS (see <u>ECM RESET</u>).
  - 2. Start the engine. Hold the engine speed at 3,000 rpm without load (in Park or neutral) until the radiator fan comes on.
- 3. Test-drive at 40-55 mph (64-88 km/h) for about 2 minutes. Try to keep the engine speed between 1,500 to 2,500 rpm. Then decelerate for at least 3 seconds with the throttle completely closed.
- 4. Check for Temporary DTCs or DTCs with the HDS.

### Is DTC P1163 indicated?

**YES** - Replace the A/F sensor (Sensor 1) (see <u>A/F SENSOR</u> <u>REPLACEMENT</u>.

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the A/F sensor and the ECM.

DTC P1164: A/F SENSOR (SENSOR 1) RANGE/PERFORMANCE PROBLEM (2000-2003 M/T MODELS) (2001-2003 CVT MODELS); DTC P2A00: A/F SENSOR (SENSOR 1) RANGE/PERFORMANCE PROBLEM (2004-2006 MODELS)

### NOTE: • Information marked with an asterisk (\*) applies to 2000-

2003 M/T models and 2001-2003 CVT models.

- Information marked with a double asterisk (\*\*) applies to 2004-2006 models.
- Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL TROUBLESHOOTING INFORMATION</u>).
- 1. Reset the ECM with the HDS (see ECM RESET).
- 2. Start the engine. Hold the engine speed at 3,000 rpm without load (in Park or neutral) until the radiator fan comes on.
- 3. Test-drive in D position (M/T in 5th gear). Starting at 1,600 rpm, accelerate using wide open throttle for at least 5 seconds. Then decelerate for at least 5 seconds with the throttle completely closed until the readiness code or DTC P2A00 (P1164)\* comes on.
- 4. Check for a Temporary DTCs or DTCs with the HDS.

## Is DTC P1164\* (P2A00)\*\* indicated?

**YES** - Replace the A/F sensor (Sensor 1) (see <u>A/F SENSOR</u> <u>REPLACEMENT</u>.

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at C102 (located under the right side of the dash), the A/F sensor relay, the A/F sensor (Sensor 1) and the ECM.

DTC P1165: A/F SENSOR (SENSOR 1) CIRCUIT RANGE/PERFORMANCE PROBLEM (2000-2001 M/T MODELS)

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Reset the ECM with the HDS (see <u>ECM RESET</u>).
- 2. Start the engine. Hold the engine speed at 3,000 rpm without load (in neutral) until the radiator fan comes on, then let it idle.
- 3. Test-drive in 4th gear. Starting at 1,600 rpm, accelerate for at least 5 seconds.

Then decelerate for at least 5 seconds with the throttle completely closed.

4. Check the Temporary DTCs or DTCs with the HDS.

### Is DTC P1165 indicated?

**YES** - Replace the A/F sensor (Sensor 1) (see <u>A/F SENSOR</u> <u>REPLACEMENT</u>.

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the A/F sensor (Sensor 1) and the ECM.

DTC P1166:A/F SENSOR (SENSOR 1) HEATER CIRCUIT MALFUNCTION (2000-2001 M/T MODELS)

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Reset the ECM with the HDS (see **ECM RESET** ).
- 2. Start the engine.
- 3. Check for Temporary DTCs or DTCs with the HDS.

## Is DTC P1166 indicated?

YES - Go to step 4.

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the A/F sensor (Sensor 1) and the ECM.

- 4. Turn the ignition switch OFF.
- 5. Disconnect the A/F sensor (Sensor 1) 8P connector.
- 6. At the sensor side, measure resistance between A/F sensor (Sensor 1) 8P connector terminals No. 1 and No. 2.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

# A/F SENSOR (SENSOR 1) 8P CONNECTOR



# Terminal side of male terminals G03680828

Fig. 125: Measuring Resistance Between A/F Sensor (Sensor 1) 8P Connector Terminals No. 1 And 2 Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there 2-13ohm?

YES - Go to step 7.

**NO** - Replace the A/F sensor (Sensor 1) (see <u>A/F SENSOR</u> <u>**REPLACEMENT**</u>.

7. At the sensor side, check for continuity between each terminal at the A/F sensor (Sensor 1) 8P connector and body ground.



Terminal side of male terminals G03680829

Fig. 126: Checking Continuity Between Terminal At A/F Sensor (Sensor 1) <u>8P Connector And Body Ground</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

### Is there continuity?

**YES** - Replace the A/F sensor (Sensor 1) (see <u>A/F SENSOR</u> <u>REPLACEMENT</u>.

**NO** - Go to step 8.

8. At the sensor side, check for continuity between A/F sensor (Sensor 1) 8P connector terminals No. 1, No. 3, No. 4, No. 6, No. 7, and No. 8 individually.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

# A/F SENSOR (SENSOR 1) 8P CONNECTOR



# Terminal side of male terminals G03680830

Fig. 127: Checking For Continuity Between A/F Sensor (Sensor 1) 8P Connector Terminals Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### 2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

### Is there continuity?

**YES** - Replace the A/F sensor (Sensor 1) (see <u>A/F SENSOR</u> <u>REPLACEMENT</u>.

**NO** - Go to step 9.

- 9. Start the engine, and let it idle.
- 10. Measure voltage between A/F sensor (Sensor 1) 8P connector terminal No. 1 and body ground.

# A/F SENSOR (SENSOR 1) 8P CONNECTOR



# Wire side of female terminals

G03680831

**Fig. 128: Measuring Voltage Between A/F Sensor (Sensor 1) 8P Connector Terminal No. 1 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

Is there more than 5.0 V?

YES - Go to step 16.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

**NO** - Go to step 11.

- 11. Turn the ignition switch OFF.
- 12. Disconnect ECM connector D (16P).
- 13. Check for continuity between ECM connector terminal D5 and body ground.

# ECM CONNECTOR D (16P)



# Wire side of female terminals G03680832

**Fig. 129: Checking Continuity Between ECM Connector Terminal D5 And Body Ground** 

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

#### **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

#### Is there continuity?

**YES** - Repair short in the wire between the ECM (D5) and the A/F sensor (Sensor 1).

NO - Go to step 14.

14. Connect ECM connector terminal D5 to body ground with a jumper wire.

# ECM CONNECTOR D (16P)



Wire side of female terminals G03680833

#### **Fig. 130: Connecting ECM Connector Terminal D5 To Body Ground With** Jumper Wire

### Courtesy of AMERICAN HONDA MOTOR CO., INC.

15. Check for continuity between A/F sensor (Sensor 1) 8P connector terminal No. 1 and body ground.

# A/F SENSOR (SENSOR 1) 8P CONNECTOR



# Wire side of female terminals G03680834

Fig. 131: Checking Continuity Between A/F Sensor (Sensor 1) 8P Connector Terminal No. 1 And Body Ground

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

#### **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

#### Is there continuity?

YES - Substitute a known-good ECM (see <u>HOW TO SUBSTITUTE</u> <u>THE ECM FOR TESTING PURPOSES (2000-2001 M/T</u>

 $\underline{\text{MODELS}}$  ), and recheck. If the symptom/indication goes away, replace the original ECM (see  $\underline{\text{ECM REPLACEMENT}}$  ).

**NO** - Repair open in the wire between the ECM (D5) and the A/F sensor (Sensor 1).

16. Measure voltage between A/F sensor (Sensor 1) 8P connector terminals No. 1 and No. 2.

# A/F SENSOR (SENSOR 1) 8P CONNECTOR



Wire side of female terminals

G03680835

**Fig. 132:** Measuring Voltage Between A/F Sensor (Sensor 1) 8P Connector <u>Terminals No. 1 And 2</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

*Is there more than 5.0 V?* 

YES -Substitute a known-good ECM (see <u>HOW TO SUBSTITUTE</u> THE ECM FOR TESTING PURPOSES (2000-2001 M/T

 $\underline{\text{MODELS}}$  ), and recheck. If the symptom/indication goes away, replace the original ECM (see  $\underline{\text{ECM REPLACEMENT}}$  ).

**NO** - Repair open in the wire between the A/F sensor (Sensor 1) and G101.

DTC P1167: A/F SENSOR (SENSOR 1) HEATER SYSTEM MALFUNCTION (2000-2002 M/T MODELS)

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Reset the ECM with the HDS (see ECM RESET).
- 2. Start the engine. Hold the engine speed at 3,000 rpm without load (in Park or neutral) until the radiator fan comes on.
- 3. Check for Temporary DTCs or DTCs with the HDS.

## Is DTC P1167 indicated?

**YES** - Go to step 4.

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the A/F sensor (Sensor 1) and the ECM.

- 4. Turn the ignition switch OFF.
- 5. Disconnect the A/F sensor (Sensor 1) 8P connector.
- 6. Turn the ignition switch ON (II).
- 7. Measure voltage between A/F sensor (Sensor 1) 8P connector terminal No. 6 and body ground.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

# A/F SENSOR (SENSOR 1) 8P CONNECTOR



# Wire side of female terminals

G03680836

Fig. 133: Measuring Voltage Between A/F Sensor (Sensor 1) 8P Connector <u>Terminal No. 6 And Body Ground</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there more than 5.0 V?

**YES** - Replace the A/F sensor (Sensor 1) (see <u>A/F SENSOR</u> <u>REPLACEMENT</u>.

NO - Go to step 8.

8. Measure voltage between ECM connector terminal D11 and body ground.

# ECM CONNECTOR D (16P)



# Wire side of female terminals G03680837

#### **Fig. 134: Measuring Voltage Between ECM Connector Terminal D11 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

#### Is there more than 5.0 V?

**YES** - Repair open in the wire between the ECM (D11) and the A/F sensor (Sensor 1).

NO - Substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW</u> <u>TO SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-</u> <u>2001 M/T MODELS</u>) ), 2002 M/T model (see <u>ECM UPDATING AND</u> <u>SUBSTITUTION FOR TESTING-2002-2006 M/T MODELS AND</u> <u>CVT MODEL</u> ), and recheck. If the symptom/indication goes away, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

DTC P1168: A/F SENSOR (SENSOR 1) LABEL CIRCUIT LOW INPUT (2000-2001 M/T MODELS)

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Reset the ECM with the HDS (see ECM RESET).
- 2. Start the engine, and let it idle.
- 3. Wait at least 2 minutes.
- 4. Check for Temporary DTCs or DTCs with the HDS.

### Is DTC P1168 indicated?

YES - Go to step 5.

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the A/F sensor (Sensor 1) and the ECM.

- 5. Turn the ignition switch OFF.
- 6. Disconnect ECM connector D (16P).
- 7. Check for continuity between ECM connector terminal D12 and body ground.

# ECM CONNECTOR D (16P)



Wire side of female terminals

G03680838

Fig. 135: Checking Continuity Between ECM Connector Terminal D12 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** - Go to step 8.

NO - Substitute a known-good ECM (see <u>HOW TO SUBSTITUTE</u> <u>THE ECM FOR TESTING PURPOSES (2000-2001 M/T</u>

<u>MODELS</u>) ), and recheck. If the symptom/indication goes away, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

- 8. Disconnect the A/F sensor (Sensor 1) 8P connector.
- 9. Check for continuity between ECM connector terminal D12 and body ground.

# ECM CONNECTOR D (16P)



# Wire side of female terminals

G03680839

Fig. 136: Checking Continuity Between ECM Connector Terminal D12 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

#### Is there continuity?

**YES** - Repair short in the wire between the ECM (D12) and the A/F sensor (Sensor 1).

**NO** - Replace the A/F sensor (Sensor 1) (see <u>A/F SENSOR</u> <u>**REPLACEMENT**</u>.

DTC P1169: A/F SENSOR (SENSOR 1) LABEL CIRCUIT HIGH INPUT (2000-2001 M/T MODELS)

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Reset the ECM with the HDS (see ECM RESET).
- 2. Start the engine, and let it idle.
- 3. Wait at least 2 minutes.
- 4. Check for Temporary DTCs or DTCs with the HDS.

### Is DTC P1169 indicated?

**YES** - Go to step 5.

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the A/F sensor (Sensor 1) and the ECM.

- 5. Turn the ignition switch OFF.
- 6. Disconnect the A/F sensor (Sensor 1) 8P connector.
- 7. Turn the ignition switch ON (II).
- 8. Measure voltage between A/F sensor (Sensor 1) 8P connector terminal No. 4 and body ground.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

# A/F SENSOR (SENSOR 1) 8P CONNECTOR



## Wire side of female terminals G03680840

Fig. 137: Measuring Voltage Between A/F Sensor (Sensor 1) 8P Connector Terminal No. 4 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there about 5 V?

**YES** - Go to step 9.

**NO** - Repair open in the wire between the ECM (D12) and the A/F sensor (Sensor 1).

- 9. Turn the ignition switch OFF.
- 10. Disconnect ECM connector C (31P).
- 11. Connect ECM connector terminal C18 to body ground with a jumper wire.





Wire side of female terminals

G03680841

**Fig. 138: Connecting ECM Connector Terminal C18 To Body Ground** <u>With Jumper Wire</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Check for continuity between A/F sensor (Sensor 1) 8P connector terminal No.
3 and body ground.

# A/F SENSOR (SENSOR 1) 8P CONNECTOR



## Wire side of female terminals G03680842

Fig. 139: Checking Continuity Between A/F Sensor (Sensor 1) 8P Connector Terminal No. 3 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** - Replace the A/F sensor (Sensor 1) (see <u>A/F SENSOR</u> <u>REPLACEMENT</u>.

**NO** - Repair open in the wire between the ECM (C18) and the A/F sensor (Sensor 1).

DTC P1172: A/F SENSOR (SENSOR 1) CIRCUIT OUT OF RANGE HIGH (2005-2006 MODELS)

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Turn the ignition switch ON (II).
- 2. Reset the ECM with the HDS (see <u>ECM RESET</u>).
- 3. Start the engine. Hold the engine speed at 3,000 rpm without load (in Park or neutral) until the radiator fan comes on, then let it idle.
- 4. Check for Temporary DTCs or DTCs with the HDS.

## Is DTC P1172 indicated?

**YES** - Replace the A/F sensor (Sensor 1) (see <u>A/F SENSOR</u> <u>REPLACEMENT</u>.

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the A/F sensor (Sensor 1) and the ECM.

#### DTC P1297: ELD CIRCUIT LOW VOLTAGE

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Reset the ECM with the HDS (see **ECM RESET** ).
- 2. Start the engine.
- 3. Turn on the headlights.
- 4. Check for Temporary DTCs or DTCs with the HDS.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

### Is DTC P1297 indicated?

**YES** - Go to step 5.

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the ELD and the ECM.

- 5. Turn the ignition switch and headlights OFF.
- 6. Disconnect the ELD 3P connector.
- 7. Turn the ignition switch ON (II).
- 8. Measure voltage between ELD 3P connector terminal No. 3 and body ground.

# **ELD 3P CONNECTOR**



Wire side of female terminals G03680843

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

#### **Fig. 140: Measuring Voltage Between ELD 3P Connector Terminal No. 3 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

#### Is there about 5 V?

**YES** - Replace the under-hood fuse/relay box.

NO - Go to step 9.

- 9. Turn the ignition switch OFF, and wait for 10 seconds.
- 10. Disconnect ECM connector A (32P).
- 11. Check for continuity between ECM connector terminal A30 and body ground.



#### **ECM CONNECTOR A (32P)**

Wire side of female terminals

G03680844

Fig. 141: Checking Continuity Between ECM Connector Terminal A30 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Is there continuity?

YES - Repair short in the wire between the ECM (A30) and the ELD. NO - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

DTC P1298: ELD CIRCUIT HIGH VOLTAGE

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Reset the ECM with the HDS (see ECM RESET).
- 2. Start the engine.
- 3. Turn on the headlights.
- 4. Check for Temporary DTCs or DTCs with the HDS.

## Is DTC P1298 indicated?

**YES** - Go to step 5.

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the ELD and the ECM.

- 5. Turn the ignition switch and headlights OFF.
- 6. Disconnect the ELD 3P connector.
- 7. Turn the ignition switch ON (II).
- 8. Measure voltage between ELD 3P connector terminal No. 1 and body ground.

# **ELD 3P CONNECTOR**



Wire side of female terminals

G03680845

#### **Fig. 142: Measuring Voltage Between ELD 3P Connector Terminal No. 1** And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

### Is there battery voltage?

**YES** - Go to step 9.

**NO** - Repair open in the wire between the No. 4 (7.5 A) fuse and the ELD. 9. Turn the ignition switch OFF.

10. Connect ELD 3P connector terminal No. 3 to body ground with a jumper wire.

# **ELD 3P CONNECTOR**



Wire side of female terminals

G03680846

### **Fig. 143: Connecting ELD 3P Connector Terminal No. 3 To Body Ground** <u>With Jumper Wire</u> **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

- 11. Disconnect ECM connector A (32P).
- 12. Check for continuity between ECM connector terminal A30 and body ground.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

## ECM CONNECTOR A (32P)



Wire side of female terminals

G03680847

#### Fig. 144: Checking Continuity Between ECM Connector Terminal A30 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Is there continuity?

YES - Go to step 13.

**NO** - Repair open in the wire between the ECM (A30) and the ELD.

13. Check for continuity between ELD 3P connector terminal No. 2 and body ground.

# **ELD 3P CONNECTOR**



# Wire side of female terminals

G03680848

**Fig. 145: Checking Continuity Between ELD 3P Connector Terminal No.** <u>2 And Body Ground</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?
**YES** - Go to step 14.

**NO** - Repair open in the wire between ELD connector terminal No. 2 and G301.

- 14. Reconnect the ELD 3P connector.
- 15. Start the engine, and let it idle.
- 16. While measuring voltage between ECM connector terminals A30 and B20, turn the headlights on (low).



Wire side of female terminals

G03680849

Fig. 146: Measuring Voltage Between ECM Connector Terminals A30 And B20 Courtesy of AMERICAN HONDA MOTOR CO., INC.

## Does the voltage drop?

YES - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

**NO** - Replace the under-hood fuse/relay box.

#### DTC P1522: BRAKE BOOSTER PRESSURE SENSOR CIRCUIT LOW VOLTAGE

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Reset the ECM with the HDS (see ECM RESET).
- 2. Start the engine, and let it idle.
- 3. Check for Temporary DTCs or DTCs with the HDS.

## Is DTC P1522 indicated?

**YES** - Go to step 4.

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the brake booster pressure sensor and the ECM.

- 4. Turn the ignition switch OFF.
- 5. Disconnect the brake booster pressure sensor 3P connector.
- 6. Turn the ignition switch ON (II).
- 7. Measure voltage between brake booster pressure sensor 3P connector terminals No. 1 and No. 2.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

## BRAKE BOOSTER PRESSURE SENSOR 3P CONNECTOR



Wire side of female terminals

G03680850

**Fig. 147: Measuring Voltage Between Brake Booster Pressure Sensor 3P** <u>Connector Terminals No. 1 And 2</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there about 5 V?

**YES** - Go to step 9. **NO** - Go to step 8.

8. Measure voltage between ECM connector terminals C18 and C28.

## ECM CONNECTOR C (31P)



Wire side of female terminals

G03680851

#### **Fig. 148: Measuring Voltage Between ECM Connector Terminals C18** <u>And C28</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Is there about 5 V?

**YES** - Repair open in the wire between the ECM (C28) and the brake booster pressure sensor.

NO - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> M/T MODELS) ), 2002-2006 M/T models and CVT model (see ECM

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

<u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u>), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u>).

- 9. Turn the ignition switch OFF.
- 10. Wait for 1 minute. If the radiator fan is running, wait for 1 minute after the radiator fan stops.
- 11. Disconnect ECM connector A (32P).
- 12. Check for continuity between brake booster pressure sensor 3P connector terminal No. 3 and body ground.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

# BRAKE BOOSTER PRESSURE SENSOR 3P CONNECTOR



# Wire side of female terminals

G03680852

**Fig. 149: Checking Continuity Between Brake Booster Pressure Sensor 3P** <u>Connector Terminal No. 3 And Body Ground</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

## Is there continuity?

**YES** - Repair short in the wire between the ECM (A10) and the brake booster pressure sensor.

**NO** - Go to step 13.

- 13. Substitute a known-good brake booster pressure sensor, then recheck.
- 14. Check for Temporary DTCs or DTCs with the HDS.

## Is DTC P1522 indicated?

YES - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

**NO** - Check the brake vacuum line. If the line is OK, replace the original brake booster pressure sensor.

#### DTC P1523: BRAKE BOOSTER PRESSURE SENSOR CIRCUIT HIGH VOLTAGE

- NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).
  - 1. Reset the ECM with the HDS (see ECM RESET).
  - 2. Start the engine, and let it idle.
  - 3. Check for Temporary DTCs or DTCs with the HDS.

## Is DTC P1523 indicated?

**YES** - Go to step 4.

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the brake booster pressure sensor and the

#### 2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

ECM.

- 4. Turn the ignition switch OFF.
- 5. Disconnect the brake booster pressure sensor 3P connector.
- 6. Turn the ignition switch ON (II).
- 7. Measure voltage between brake booster pressure sensor 3P connector terminal No. 3 and body ground.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

# BRAKE BOOSTER PRESSURE SENSOR 3P CONNECTOR



# Wire side of female terminals

G03680853

**Fig. 150:** Measuring Voltage Between Brake Booster Pressure Sensor 3P <u>Connector Terminal No. 3 And Body Ground</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there about 5 V?

**YES** - Go to step 8.

**NO** - Go to step 9.

8. Measure voltage between brake booster pressure sensor 3P connector terminals No. 1 and No. 2.



Wire side of female terminals

G03680854

**Fig. 151: Measuring Voltage Between Brake Booster Pressure Sensor 3P Connector Terminals No. 1 And 2** 

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

#### Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Is there about 5 V?

YES - Go to step 14.

**NO** - Repair open in the wire between the ECM (C18) and the brake booster pressure sensor.

- 9. Turn the ignition switch OFF.
- 10. Wait for 1 minute. If the radiator fan is running, wait for 1 minute after the radiator fan stops.
- 11. Disconnect ECM connector A (32P).
- 12. Connect brake booster pressure sensor 3P connector terminal No. 3 to body ground with a jumper wire.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

# BRAKE BOOSTER PRESSURE SENSOR 3P CONNECTOR



# Wire side of female terminals

G03680855

**Fig. 152: Connecting Brake Booster Pressure Sensor 3P Connector Terminal No. 3 To Body Ground With Jumper Wire Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

13. Check for continuity between ECM connector terminal A10 and body ground.



Wire side of female terminals

G03680856

### **Fig. 153: Checking For Continuity Between ECM Connector Terminal** <u>A10 And Body Ground</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

## Is there continuity?

YES - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

**NO** - Repair open in the wire between the ECM (A10) and the brake booster pressure sensor.

- 14. Substitute a known-good brake booster pressure sensor, then recheck.
- 15. Check for Temporary DTCs or DTCs with the HDS.

## Is DTC P1523 indicated?

**YES** - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

**NO** - Check the brake vacuum line. If the line is OK, replace the original brake booster pressure sensor.

DTC P1541: HTRS PASSENGER COMPARTMENT HEATER STANDBY SIGNAL CIRCUIT LOW INPUT; DTC P1542: HTRS PASSENGER COMPARTMENT HEATER STANDBY SIGNAL CIRCUIT HIGH INPUT

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Reset the ECM with the HDS (see <u>ECM RESET</u>).
- 2. Turn the ignition switch ON (II).
- 3. Check for Temporary DTCs or DTCs with the HDS.

## Is DTC P1541 or P1542 indicated?

**YES** - Go to step 4.

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the heater control panel and the ECM.

- 4. Turn the ignition switch OFF.
- 5. Disconnect the heater control panel 22P connector.
- 6. Turn the ignition switch ON (II).

7. Measure voltage between ECM connector terminal A23 and body ground.

## ECM CONNECTOR A (32P)



Wire side of female terminals

G03680857

#### **Fig. 154: Measuring Voltage Between ECM Connector Terminal A23 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

## Is there about 5 V?

**YES** - Go to step 11. **NO** - Go to step 8.

- 8. Turn the ignition switch OFF, and wait for 10 seconds.
- 9. Disconnect ECM connector A (32P).
- 10. Check for continuity between ECM connector terminal A23 and body ground.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

## ECM CONNECTOR A (32P)



Wire side of female terminals

G03680858

#### **Fig. 155: Checking Continuity Between ECM Connector Terminal A23 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

#### Is there continuity?

**YES** - Repair short in the wire between the ECM (A23) and the heater control panel.

NO - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see ECM REPLACEMENT ).

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

- 11. Turn the ignition switch OFF, and wait for 10 seconds.
- 12. Disconnect ECM connector A (32P).
- 13. Check for continuity between ECM connector terminal A23 and heater control panel 22P connector terminal No. 8.



#### ECM CONNECTOR A (32P)

Wire side of female terminals

G03680859

Fig. 156: Checking Continuity Between ECM Connector Terminal A23 And Heater Control Panel 22P Connector Terminal No. 8 Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Is there continuity?

**YES** - Replace the heater control panel.

**NO** - Repair open in the wire between the ECM (A23) and the heater control panel.

DTC P15B2: BRAKE FLUID PRESSURE SENSOR A CIRCUIT LOW VOLTAGE (2005-2006 M/T

#### 2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

MODELS);

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Turn the ignition switch ON (II).
- 2. Check BRAKE FLUID PRESSURE SENSOR A with the HDS.

### Is there 0.08 V or less?

**YES** - Go to step 3.

**NO** - The system is OK at this time. Check for poor connections or loose terminals at brake fluid pressure sensor A and the ECM.

- 3. Turn the ignition switch OFF.
- 4. Disconnect the brake fluid pressure sensor A 3P connector.
- 5. Turn the ignition switch ON (II).
- 6. Measure voltage between brake fluid pressure sensor A 3P connector terminals No. 1 and No. 2.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

## BRAKE FLUID PRESSURE SENSOR A 3P CONNECTOR



Wire side of female terminals

G03680860

**Fig. 157: Measuring Voltage Between Brake Fluid Pressure Sensor 3P** <u>Connector Terminals No. And 2</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there about 5.0 V?

YES - Go to step 11 .
NO - Go to step 7.
7. Turn the ignition switch OFF, and wait for 10 seconds.

- 8. Disconnect ECM connector C (31P).
- 9. Connect ECM connector terminal C28 to body ground with a jumper wire.

# ECM CONNECTOR C (31P)



Wire side of female terminals

G03680861

### Fig. 158: Connecting ECM Connector Terminal C28 To Body Ground With Jumper Wire Courtesy of AMERICAN HONDA MOTOR CO., INC.

10. Check for continuity between brake fluid pressure sensor A 3P connector terminal No. 2 and body ground.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

## BRAKE FLUID PRESSURE SENSOR A 3P CONNECTOR



Wire side of female terminals

G03680862

**Fig. 159: Checking Continuity Between Brake Fluid Pressure Sensor 3P** <u>Connector Terminal No. 2 And Body Ground</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** - Update the ECM if it does not have the latest software, or substitute a known-good ECM (see <u>ECM UPDATING AND SUBSTITUTION</u> <u>FOR TESTING-2002-2006 M/T MODELS AND CVT MODEL</u>), then recheck. If the symptom/ indication goes away with a known-good ECM,

replace the original ECM (see ECM REPLACEMENT).

**NO** - Repair open in the wire between the ECM (C28) and brake fluid pressure sensor A.

- 11. Turn the ignition switch OFF, and wait for 10 seconds.
- 12. Disconnect ECM connector A (32P).
- 13. Check for continuity between brake fluid pressure sensor A 3P connector terminal No. 3 and body ground.

# BRAKE FLUID PRESSURE SENSOR A 3P CONNECTOR



## Wire side of female terminals G03680863

Fig. 160: Checking Continuity Between Brake Fluid Pressure Sensor 3P

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

## **Connector Terminal No. 3 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

## Is there continuity?

**YES** - Repair short to ground between the ECM (A5) and brake fluid pressure sensor A.

NO - Go to step 14.

14. Connect ECM connector terminal A5 to body ground with a jumper wire.



## ECM CONNECTOR A (32P)

Wire side of female terminals

G03680864

#### **Fig. 161: Connecting ECM Connector Terminal A5 To Body Ground With** <u>Jumper Wire</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

15. Check for continuity between brake fluid pressure sensor A 3P connector terminal No. 3 and body ground.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

## BRAKE FLUID PRESSURE SENSOR A 3P CONNECTOR



## Wire side of female terminals

G03680865

Fig. 162: Checking Continuity Between Brake Fluid Pressure Sensor 3P Connector Terminal No. 3 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

## Is there continuity?

**YES** - Go to step 16.

**NO** - Repair open in the wire between the ECM (A5) and brake fluid pressure sensor A.

- 16. Connect ECM connector A (32P).
- 17. Connect brake fluid pressure sensor A 3P connector terminals No. 2 and No. 3 with a jumper wire.

## BRAKE FLUID PRESSURE SENSOR A 3P CONNECTOR



## Wire side of female terminals

G03680866

## **Fig. 163: Connecting Brake Fluid Pressure Sensor 3P Connector Terminals No. 2 And 3 With Jumper Wire Courtesy of AMERICAN HONDA MOTOR CO., INC.**

- 18. Turn the ignition switch ON (II).
- 19. Check BRAKE FLUID PRESSURE SENSOR A with the HDS.

#### Is there 0.08 V or less?

**YES** - Update the ECM if it does not have the latest software, or substitute a known-good ECM (see <u>ECM UPDATING AND SUBSTITUTION</u> <u>FOR TESTING-2002-2006 M/T MODELS AND CVT MODEL</u>), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u>).

**NO** - Replace brake fluid pressure sensor A (see **<u>BRAKE FLUID</u> <u>PRESSURE SENSOR REPLACEMENT</u>**).

DTC P15B3: BRAKE FLUID PRESSURE SENSOR A RANGE/PERFORMANCE PROBLEM (2005-2006 M/T MODELS)

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Turn the ignition switch ON (II).
- 2. Check BRAKE FLUID PRESSURE SENSOR A with the HDS without pressing the brake pedal.

## Is there 2.45 MPa or more?

**YES** - Go to step 3.

**NO** - The system is OK at this time. Check for poor connections or loose terminals at brake fluid pressure sensor A and the ECM.

- 3. Turn the ignition switch OFF.
- 4. Disconnect the brake fluid pressure sensor A 3P connector.
- 5. Turn the ignition switch ON (II).
- 6. Measure voltage between brake fluid pressure sensor A 3P connector terminals No. 1 and No. 2.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

## BRAKE FLUID PRESSURE SENSOR A 3P CONNECTOR



Wire side of female terminals

G03680867

**Fig. 164: Measuring Voltage Between Brake Fluid Pressure Sensor 3P** <u>Connector Terminals No. 1 And 2</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there about 5.0 V?

YES - Replace brake fluid pressure sensor A (see <u>BRAKE FLUID</u> <u>PRESSURE SENSOR REPLACEMENT</u>).

**NO** - Go to step 7.

- 7. Turn the ignition switch OFF, and wait for 10 seconds.
- 8. Disconnect ECM connector C (31P).
- 9. Connect ECM connector terminal C18 to body ground with a jumper wire.

## ECM CONNECTOR C (31P)



Wire side of female terminals

G03680868

### **Fig. 165: Connecting ECM Connector Terminal C18 To Body Ground** <u>With Jumper Wire</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

10. Check for continuity between brake fluid pressure sensor A 3P connector terminal No. 1 and body ground.

## BRAKE FLUID PRESSURE SENSOR A 3P CONNECTOR



Wire side of female terminals

G03680869

Fig. 166: Checking Continuity Between Brake Fluid Pressure Sensor 3P Connector Terminal No. 1 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

## Is there continuity?

**YES** - Update the ECM if it does not have the latest software, or substitute a known-good ECM (see <u>ECM UPDATING AND SUBSTITUTION</u> <u>FOR TESTING-2002-2006 M/T MODELS AND CVT MODEL</u>), then recheck. If the symptom/indication goes away with a known-good ECM,

replace the original ECM (see <u>ECM REPLACEMENT</u>).

**NO** - Repair open in the wire between brake fluid pressure sensor A and the ECM (C18).

DTC P15B4: BRAKE FLUID PRESSURE SENSOR B CIRCUIT LOW VOLTAGE (2005-2006 M/T MODELS)

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Turn the ignition switch ON (II).
- 2. Check BRAKE FLUID PRESSURE SENSOR B with the HDS.

## Is there 0.08 V or less?

**YES** - Go to step 3.

**NO** - The system is OK at this time. Check for poor connections or loose terminals at brake fluid pressure sensor B and the ECM.

- 3. Turn the ignition switch OFF.
- 4. Disconnect the brake fluid pressure sensor B 3P connector.
- 5. Turn the ignition switch ON (II).
- 6. Measure voltage between brake fluid pressure sensor B 3P connector terminals No. 1 and No. 2.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

## BRAKE FLUID PRESSURE SENSOR B 3P CONNECTOR



## Wire side of female terminals G03680870

**Fig. 167: Measuring Voltage Between Brake Fluid Pressure Sensor** <u>Connector Terminals No. 1 And 2</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Is there about 5.0 V?

YES - Go to step 11 .
NO - Go to step 7.
7. Turn the ignition switch OFF, and wait for 10 seconds.

- 8. Disconnect ECM connector C (31P).
- 9. Connect ECM connector terminal C23 to body ground with a jumper wire.

## ECM CONNECTOR C (31P)



Wire side of female terminals

G03680871

#### **Fig. 168: Connecting ECM Connector Terminal C23 To Body Ground** <u>With Jumper Wire</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

10. Check for continuity between brake fluid pressure sensor B 3P connector terminal No. 2 and body ground.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

## BRAKE FLUID PRESSURE SENSOR B 3P CONNECTOR



## Wire side of female terminals

G03680872

**Fig. 169: Checking Continuity Between Brake Fluid Pressure Sensor** <u>Connector Terminal No. 2 And Body Ground</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

## Is there continuity?

**YES** - Update the ECM if it does not have the latest software, or substitute a known-good ECM (see <u>ECM UPDATING AND SUBSTITUTION</u> <u>FOR TESTING-2002-2006 M/T MODELS AND CVT MODEL</u>), then recheck. If the symptom/indication goes away with a known-good ECM,

replace the original ECM (see ECM REPLACEMENT).

**NO** - Repair open in the wire between the ECM (C23) and brake fluid pressure sensor B.

- 11. Turn the ignition switch OFF, and wait for 10 seconds.
- 12. Disconnect ECM connector A (32P).
- 13. Check for continuity between brake fluid pressure sensor B 3P connector terminal No. 3 and body ground.

# BRAKE FLUID PRESSURE SENSOR B 3P CONNECTOR



## Wire side of female terminals G03680873

#### Fig. 170: Checking Continuity Between Brake Fluid Pressure Sensor

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

## **Connector Terminal No. 3 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

## Is there continuity?

**YES** - Repair short to ground between the ECM (A14) and brake fluid pressure sensor B.

NO - Go to step 14.

14. Connect ECM connector terminals A22 to body ground with a jumper wire.



## ECM CONNECTOR A (32P)

Wire side of female terminals

G03680874

#### **Fig. 171: Connecting ECM Connector Terminals A22 To Body Ground** <u>With Jumper Wire</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

15. Check for continuity between brake fluid pressure sensor B 3P connector terminal No. 3 and body ground.

## BRAKE FLUID PRESSURE SENSOR B 3P CONNECTOR



# Wire side of female terminals

G03680875

Fig. 172: Checking Continuity Between Brake Fluid Pressure Sensor Connector Terminal No. 3 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

## Is there continuity?

**YES** - Go to step 16.

**NO** - Repair open in the wire between the ECM (A22) and brake fluid pressure sensor B.
- 16. Connect ECM connector A (32P).
- 17. Connect brake fluid pressure sensor B 3P connector terminals No. 2 and No. 3 with a jumper wire.

### BRAKE FLUID PRESSURE SENSOR B 3P CONNECTOR



### Wire side of female terminals

G03680876

#### **Fig. 173: Connecting Brake Fluid Pressure Sensor Connector Terminals** <u>No. 2 And 3 With Jumper Wire</u> **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

- 18. Turn the ignition switch ON (II).
- 19. Check BRAKE FLUID PRESSURE SENSOR B with the HDS.

#### Is there 0.08 V or less?

**YES** - Update the ECM if it does not have the latest software, or substitute a known-good ECM (see <u>ECM UPDATING AND SUBSTITUTION</u> <u>FOR TESTING-2002-2006 M/T MODELS AND CVT MODEL</u>), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u>).

**NO** - Replace brake fluid pressure sensor B (see **BRAKE FLUID PRESSURE SENSOR REPLACEMENT** ).

DTC P15B5: BRAKE FLUID PRESSURE SENSOR B RANGE PERFORMANCE PROBLEM (2005-2006 M/T MODELS)

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Turn the ignition switch ON (II).
- 2. Check BRAKE FLUID PRESSURE SENSOR B with the HDS without pressing the brake pedal.

#### Is there 2.45 MPa or more?

**YES** - Go to step 3.

**NO** - The system is OK at this time. Check for poor connections or loose terminals at brake fluid pressure sensor B and the ECM.

- 3. Turn the ignition switch OFF.
- 4. Disconnect the brake fluid pressure sensor B 3P connector.
- 5. Turn the ignition switch ON (II).
- 6. Measure voltage between brake fluid pressure sensor B 3P connector terminals No. 1 and No. 2.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

### BRAKE FLUID PRESSURE SENSOR B 3P CONNECTOR



Wire side of female terminals

G03680877

**Fig. 174: Measuring Voltage Between Brake Fluid Pressure Sensor** <u>Connector Terminals No. 1 And 2</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there about 5.0 V?

YES - Replace brake fluid pressure sensor B (see <u>BRAKE FLUID</u> PRESSURE SENSOR REPLACEMENT ).

**NO** - Go to step 7.

- 7. Turn the ignition switch OFF, and wait for 10 seconds.
- 8. Disconnect ECM connector C (31P).
- 9. Connect ECM connector terminal C2 to body ground with a jumper wire.

### ECM CONNECTOR C (31P)



Wire side of female terminals

G03680878

#### **Fig. 175: Connecting ECM Connector Terminal C2 To Body Ground With** <u>Jumper Wire</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

10. Check for continuity between brake fluid pressure sensor B 3P connector terminal No. 1 and body ground.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

### BRAKE FLUID PRESSURE SENSOR B 3P CONNECTOR



## Wire side of female terminals

G03680879

Fig. 176: Checking Continuity Between Brake Fluid Pressure Sensor Connector Terminal No. 1 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Is there continuity?

**YES** - Update the ECM if it does not have the latest software, or substitute a known-good ECM (see <u>ECM UPDATING AND SUBSTITUTION</u> <u>FOR TESTING-2002-2006 M/T MODELS AND CVT MODEL</u>), then recheck. If the symptom/indication goes away with a known-good ECM,

replace the original ECM (see <u>ECM REPLACEMENT</u>).

**NO** - Repair open in the wire between brake fluid pressure sensor B and the ECM (C2).

DTC P15B6: BRAKE FLUID PRESSURE SENSOR A/B CIRCUIT MALFUNCTION (2005-2006 M/T MODELS)

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Turn the ignition switch ON (II).
- 2. Check BRAKE FLUID PRESSURE SENSOR B with the HDS without pressing the brake pedal.

#### Is there between 0.26 V and 0.74 V?

**YES** - Go to step 11.

NO - Go to step 3.

- 3. Turn the ignition switch OFF.
- 4. Change connectors between brake fluid pressure sensor A and B.
- 5. Turn the ignition switch ON (II).
- 6. Check BRAKE FLUID PRESSURE SENSOR B with the HDS without pressing the brake pedal.

#### Is there between 0.26 V and 0.74 V?

**YES** - Go to step 7.

**NO** - Replace brake fluid pressure sensor A (see **<u>BRAKE FLUID</u> <u>PRESSURE SENSOR REPLACEMENT</u>**).

- 7. Turn the ignition switch OFF, and wait for 10 seconds.
- 8. Disconnect ECM connector C (31P).
- 9. Connect ECM connector terminal C18 to body ground with a jumper wire.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

## ECM CONNECTOR C (31P)



Wire side of female terminals

G03680880

#### Fig. 177: Connecting ECM Connector Terminal C18 To Body Ground With Jumper Wire Courtesy of AMERICAN HONDA MOTOR CO., INC.

10. Check for continuity between brake fluid pressure sensor A 3P connector terminal No. 1 and body ground.

## BRAKE FLUID PRESSURE SENSOR A 3P CONNECTOR



## Wire side of female terminals

G03680881

Fig. 178: Checking Continuity Between Brake Fluid Pressure Sensor Connector Terminal No. 1 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Is there continuity?

**YES** - Update the ECM if it does not have the latest software, or substitute a known-good ECM (see <u>ECM UPDATING AND SUBSTITUTION</u> <u>FOR TESTING-2002-2006 M/T MODELS AND CVT MODEL</u>), then recheck. If the symptom/indication goes away with a known-good ECM,

replace the original ECM (see ECM REPLACEMENT).

 ${\bf NO}$  - Repair open in the wire between brake fluid pressure sensor A and the ECM (C18).

11. Check BRAKE FLUID PRESSURE SENSOR B with the HDS without pressing the brake pedal.

#### Is there between 0.26 V and 0.74 V?

**YES** - Go to step 12.

**NO** - Go to step 17.

- 12. Clear the DTC with the HDS.
- 13. Start the engine.
- 14. Test-drive the vehicle twice at 3 mph (5 km/h) or more with the throttle position at 9 degrees, or more.
- 15. Stop the vehicle, press the brake pedal, and hold it 10 seconds.
- 16. Check for Temporary DTCs or DTCs with the HDS.

#### Is DTC P15B6 indicated?

**YES** - Replace brake fluid pressure sensor A and B (see **<u>BRAKE FLUID</u> <u>PRESSURE SENSOR REPLACEMENT</u>**).

**NO** - The system is OK at this time. If any other Temporary DTCs or DTCs are indicated, go to the indicated **DTC TROUBLESHOOTING** 

- 17. Turn the ignition switch OFF.
- 18. Change connectors between brake fluid pressure sensor A and B.
- 19. Turn the ignition switch ON (II).
- 20. Check the PBRKS1 with the HDS without pressing the brake pedal.

#### Is there between 0.26 V and 0.74 V?

**YES** - Go to step 21.

NO -Replace brake fluid pressure sensor B (see .

21. Turn the ignition switch OFF, and wait for 10 seconds.

- 22. Disconnect ECM connector C (31P).
- 23. Connect ECM connector terminal C2 to body ground with a jumper wire.

### ECM CONNECTOR C (31P)



Wire side of female terminals

G03680882

#### Fig. 179: Connecting ECM Connector Terminal C2 To Body Ground With Jumper Wire Courtesy of AMERICAN HONDA MOTOR CO., INC.

24. Check for continuity between brake fluid pressure sensor B 3P connector terminal No. 1 and body ground.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

## BRAKE FLUID PRESSURE SENSOR B 3P CONNECTOR



## Wire side of female terminals

G03680883

Fig. 180: Checking Continuity Between Brake Fluid Pressure Sensor B 3P Connector Terminal No. 1 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Is there continuity?

**YES** - Update the ECM if it does not have the latest software, or substitute a known-good ECM (see <u>ECM UPDATING AND SUBSTITUTION</u> <u>FOR TESTING-2002-2006 M/T MODELS AND CVT MODEL</u>), then recheck. If the symptom/indication goes away with a known-good ECM,

replace the original ECM (see <u>ECM REPLACEMENT</u>).

**NO** - Repair open in the wire between brake fluid pressure sensor B and the ECM (C2).

DTC P1600: IMA SYSTEM MALFUNCTION; DTC P1601: IMA SYSTEM MALFUNCTION

- NOTE:
  This DTC is stored when there is a problem in the IMA system. Check for IMA DTCs with the HDS and go to the indicated <u>DTC TROUBLESHOOTING</u>
  - Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL TROUBLESHOOTING INFORMATION</u>).

DTC P1640: ACTTRQ MOTOR TORQUE SIGNAL CIRCUIT LOW INPUT; DTC P1641: ACTTRQ MOTOR TORQUE SIGNAL CIRCUIT HIGH INPUT

- NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information {see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u> ).
  - 1. Reset the ECM with the HDS (see **ECM RESET** ).
- 2. Turn the ignition switch ON (II).
- 3. Check for Temporary DTCs or DTCs with the HDS.

#### Is DTCP1640 or P1641 indicated?

**YES** - Go to step 4.

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the motor control module and the ECM.

- 4. Turn the ignition switch OFF.
- 5. Remove the IPU cover (see <u>POWER CONTROL UNIT (PCU)</u> <u>REMOVAL/INSTALLATION</u>), and disconnect motor control module connector C (31P).
- 6. Turn the ignition switch ON (II).
- 7. Measure voltage between ECM connector terminal D14 and body ground.

## ECM CONNECTOR D (16P)



## Wire side of female terminals

G03680884

**Fig. 181: Measuring Voltage Between ECM Connector Terminal D14 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

Is there about 5 V?

#### 2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

YES - Go to step 11.

**NO** - Go to step 8.

- 8. Turn the ignition switch OFF, and wait for 10 seconds.
- 9. Disconnect ECM connector D (16P).
- 10. Check for continuity between ECM connector terminal D14 and body ground.

## ECM CONNECTOR D (16P)



## Wire side of female terminals

G03680885

Fig. 182: Checking Continuity Between ECM Connector Terminal D14 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Is there continuity?

**YES** - Repair short in the wire between the ECM (D14) and the motor control module.

NO - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

- 11. Turn the ignition switch OFF, and wait for 10 seconds.
- 12. Disconnect ECM connector D (16P).
- 13. Check for continuity between ECM connector terminal D14 and motor control module connector terminal C5.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

## ECM CONNECTOR D (16P)



**Fig. 183: Checking Continuity Between ECM Connector Terminal D14** And Motor Control Module Connector Terminal C5 Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Is there continuity?

**YES** - Replace the battery module.

**NO** - Repair open in the wire between the ECM (D14) and the motor

control module.

DTC P1642: QBATT BATTERY SIGNAL CIRCUIT LOW INPUT; DTC P1643: QBATT BATTERY SIGNAL CIRCUIT HIGH INPUT

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Reset the ECM with the HDS (see ECM RESET).
- 2. Turn the ignition switch ON (II).
- 3. Check for Temporary DTCs or DTCs with the HDS.

#### Is DTC P1642 or P1643 indicated?

YES - Go to step 4.

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the motor control module and the ECM.

- 4. Turn the ignition switch OFF.
- Remove the IPU cover (see <u>POWER CONTROL UNIT (PCU)</u> <u>REMOVAL/INSTALLATION</u>), and disconnect motor control module connector C (31P).
- 6. Turn the ignition switch ON (II).
- 7. Measure voltage between ECM connector terminal D13 and body ground.

## ECM CONNECTOR D (16P)



## Wire side of female terminals

G03680887

**Fig. 184: Measuring Voltage Between ECM Connector Terminal D13 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

Is there about 5 V?

#### 2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

YES - Go to step 11.

NO - Go to step 8.

- 8. Turn the ignition switch OFF, and wait for 10 seconds.
- 9. Disconnect ECM connector D (16P).
- 10. Check for continuity between ECM connector terminal D13 and body ground.

## ECM CONNECTOR D (16P)



## Wire side of female terminals

G03680888

**Fig. 185: Checking Continuity Between ECM Connector Terminal D13 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

#### Is there continuity?

**YES** - Repair short in the wire between the ECM (D13) and the motor control module.

NO - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

- 11. Turn the ignition switch OFF, and wait for 10 seconds.
- 12. Disconnect ECM connector D (16P).
- 13. Check for continuity between ECM connector terminal D13 and motor control module connector terminal C16.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

## ECM CONNECTOR D (16P)



Fig. 186: Checking Continuity Between ECM Connector Terminal D13 And Motor Control Module Connector Terminal C16 Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Is there continuity?

**YES** - Replace the battery module.

NO - Repair open in the wire between the ECM (D13) and the motor

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

control module.

#### DTC P1644: MOTFSA MOTOR CONTROL MODULE SIGNAL MALFUNCTION; DTC P1645: MOTFSB MOTOR CONTROL MODULE SIGNAL MALFUNCTION; DTC P1646: MOTSTB MOTOR CONTROL MODULE SIGNAL MALFUNCTION

- NOTE:
- Information marked with an asterisk (<sup>\*1</sup>) applies to DTC P1645; information marked with (<sup>\*2</sup>) applies to DTC P1646.
- Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL TROUBLESHOOTING INFORMATION</u>).
- 1. Reset the ECM with the HDS (see ECM RESET).
- 2. Turn the ignition switch ON (II).
- 3. Check for Temporary DTCs or DTCs with the HDS.

#### Is DTC P1644, P1645, or P1646 indicated?

**YES** - Go to step 4.

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the motor control module and the ECM.

- 4. Turn the ignition switch OFF.
- Remove the IPU cover (see <u>POWER CONTROL UNIT (PCU)</u> <u>REMOVAL/INSTALLATION</u>), and disconnect motor control module connector A (32P).
- 6. Turn the ignition switch ON (II).
- 7. Measure voltage between ECM connector terminal D2, (D1)<sup>\*1</sup>, (D3)<sup>\*2</sup> and body ground.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

## ECM CONNECTOR D (16P)



Wire side of female terminals

G03680890

Fig. 187: Measuring Voltage Between ECM Connector Terminal D2, (D1) \*1, (D3)\*2 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Is there about 5 V?

YES - Go to step 11 . NO - Go to step 8.

8. Turn the ignition switch OFF, and wait for 10 seconds.

- 9. Disconnect ECM connector D (16P).
- 10. Check for continuity between ECM connector terminals D2, (D1)<sup>\*1</sup>, (D3)<sup>\*2</sup> and body ground.

ECM CONNECTOR D (16P)



Wire side of female terminals

G03680891

Fig. 188: Checking Continuity Between ECM Connector Terminals D2,  $(D1)^{\frac{*1}{1}}, (D3)^{\frac{*2}{2}}$  And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** - Repair short in the wire between the ECM (D2, (D1)  $^{*1}$ , (D3)  $^{*2}$ ) and the motor control module.

NO -Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

- 11. Turn the ignition switch OFF, and wait for 10 seconds.
- 12. Disconnect ECM connector D (16P).
- 13. Check for continuity between ECM connector terminal D2, (D1)  $^{*1}$ , (D3)  $^{*2}$  and motor control module connector terminal A16 (A15)  $^{*1}$  (A4)  $^{*2}$ .

#### 2000-06 ENGINE PERFORMANCE PGM-FI System - Insight



G03680892

Fig. 189: Checking Continuity Between ECM Connector Terminals D2, (D1) <sup>\*1</sup>/<sub>1</sub>, (D3) <sup>\*2</sup>/<sub>4</sub> And Motor Control Module Connector Terminals A16 (A15) <sup>\*1</sup>/<sub>4</sub> (A4) <sup>\*2</sup>/<sub>4</sub> Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Is there continuity?

**YES** - Replace the battery module.

**NO** - Repair open in the wire between ECM connector terminal D2 (D1)  $^{*1}$  (D3)  $^{*2}$  and the motor control module.

DTC P1655: A/T FL SIGNAL A/B CIRCUIT MALFUNCTION (2001-2003 CVT MODELS); DTC U0101: A/T FL SIGNAL A/B CIRCUIT MALFUNCTION (2004-2006 CVT MODELS)

#### NOTE: • Information marked with an asterisk (\*) applies to 2001-

2003 CVT models.

- Information marked with double asterisk (\*\*) applies to 2004-2006 CVT models.
- Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL TROUBLESHOOTING INFORMATION</u>).
- 1. Reset the ECM with the HDS (see ECM RESET).
- 2. Drive the vehicle several minutes until so the transmission upshifts and downshifts several times.
- 3. Check for Temporary DTCs or DTCs with the HDS.

#### Is DTC P1655\* (U0101)\*\* indicated?

**YES** - Go to step 4.

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the TCM and the ECM.

- 4. Turn the ignition switch OFF, and wait for 10 seconds.
- 5. Disconnect ECM connector C (31P).
- 6. Disconnect TCM connector B (22P).
- 7. Check for continuity between body ground and ECM connector terminals C15 and C11.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

## ECM CONNECTOR C (31P)



Wire side of female terminals

G03680893

#### **Fig. 190: Checking Continuity Between Body Ground And ECM** <u>Connector Terminals C15 And C11</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Is there continuity?

**YES** - Repair short in the wire between the ECM (C15, C11) and the TCM (B6, B7).

NO - Go to step 8.

8. Check for continuity between ECM connector terminal C15 and TCM connector terminal B7, and between ECM connector terminal C11 and TCM connector terminal B6.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight



TCM CONNECTOR B (22P)

Wire side of female terminals

G03680894

**Fig. 191: Checking Continuity Between ECM Connector Terminal C15 & TCM Connector Terminal B7 And Between ECM Connector Terminal C11 & TCM Connector Terminal B6 Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

Is there continuity?

**YES** - Check the these items:

Update the ECM if it does not have the latest software, or substitute a known-good ECM (see <u>ECM UPDATING AND SUBSTITUTION</u> <u>FOR TESTING-2002-2006 M/T MODELS AND CVT MODEL</u>), then recheck. If the symptom/indication goes away with a known-

good ECM, replace the original ECM (see <u>ECM</u> <u>**REPLACEMENT**</u>).

• Substitute a known-good TCM (see <u>HOW TO TROUBLESHOOT</u> <u>CIRCUIT AT THE TCM</u>), and recheck. If the symptom/indication goes away, replace the original TCM.

**NO** - Repair open in the wire between the ECM (C15, C11) and the TCM (B6, B7).

DTC P2270: SECONDARY HO2S (SENSOR 2) CIRCUIT SIGNAL STUCK LEAN (2005-2006 MODELS); DTC P2271: SECONDARY HO2S (SENSOR 2) CIRCUIT SIGNAL STUCK RICH (2005-2006 MODELS)

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Turn the ignition switch ON (II).
- 2. Reset the ECM with the HDS (see <u>ECM RESET</u>).
- 3. Start the engine. Hold the engine speed at 3,000 rpm without load (in Park or neutral) until the radiator fan comes on, then let it idle.
- 4. Test-drive under these conditions:
  - Engine coolant temperature above 176°F (80°C)
  - Vehicle speed between 35 mph (56 km/h) or more
  - Drive 1 minute or more
- 5. Check for Temporary DTCs or DTCs with the HDS.

#### Is DTC P2270 or P2271 indicated?

## **YES** - Replace the secondary HO2S (Sensor 2) (see <u>SECONDARY</u> <u>HO2S REPLACEMENT</u> ).

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the secondary HO2S (Sensor 2) and the ECM.

#### DTC P2610: ECM IGNITION OFF INTERNAL TIMER MALFUNCTION (2006 MODEL)

# NOTE: Before you troubleshoot, record all freeze data and review the general troubleshooting information (see <u>GENERAL</u> <u>TROUBLESHOOTING INFORMATION</u>).

- 1. Turn the ignition switch ON (II).
- 2. Clear the DTC with the HDS (see **DTC CLEAR**).
- 3. Check for Temporary DTCs or DTCs with the HDS.

#### Is P2610 indicated?

**YES** - Update the ECM if it does not have the latest software, or substitute a known-good ECM (see <u>ECM UPDATING AND SUBSTITUTION</u> <u>FOR TESTING-2002-2006 M/T MODELS AND CVT MODEL</u>), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u>).

**NO** - Intermittent failure, system is OK at this time. Check for poor connections or loose terminals at the ECM.

#### MIL CIRCUIT TROUBLESHOOTING

#### 2000-2004 MODELS

- 1. Connect the HDS (see <u>HOW TO USE THE HDS (HONDA DIAGNOSTIC</u> <u>SYSTEM)</u>).
- 2. Turn the ignition switch ON (II), and check the HDS.

#### **Does the HDS communicate with the ECM?**

**YES** - Go to step 3.

**NO** - Go to "DLC Circuit Troubleshooting" (see <u>DLC CIRCUIT</u> <u>TROUBLESHOOTING</u>).

3. Check for Temporary DTCs or DTCs with the HDS.

#### Are any Temporary DTCs or DTCs indicated?

YES - Go to the indicated DTC TROUBLESHOOTING

**NO** - Go to step 4.

- 4. Turn the ignition switch OFF.
- 5. Turn the ignition switch ON (II), and watch the malfunction indicator lamp (MIL).

## Does the MIL come on and stay on for more than 20 seconds after turning the ignition switch ON (II)?

**YES** - If the MIL always comes on and stays on, Go to step 61. But if the MIL sometimes works normally, first check for these problems:

- An intermittent short in the wire between the ECM (B17) and the data link connector (DLC).
- An intermittent short in the wire between the ECM (A18) and the gauge assembly.
- The readiness codes are not set (see <u>HOW TO SET READINESS</u> <u>CODES</u>). (This is indicated if the MIL blinks five times after you turn the ignition switch ON (II) and wait about 20 seconds.)

**NO** -If the MIL is always off, Go to step 6. But if the MIL sometimes works normally, first check for these problems.

- A loose No. 6 (7.5 A) fuse in the under-dash fuse/relay box.
- A loose No. 1 (50 A) fuse in the under-hood fuse/relay box.
- A loose No. 7 (15 A) fuse in the under-hood fuse/relay box.
- A loose No. 2 (15 A) fuse in the under-dash fuse/relay box.
- A poor connection at ECM terminal A18.
- An intermittent open in the GRN/ORN wire between the ECM (A18) and the gauge assembly.
- An intermittent short in the wire between the ECM (C19) and the manifold absolute pressure (MAP) sensor.
- An intermittent short in the wire between the ECM (C28) and the throttle position (TP) sensor, the brake booster pressure sensor, the fuel tank pressure (FTP) sensor, or the exhaust gas recirculation (EGR) valve position sensor.
- An intermittent short in the wire between the ECM (B6) and the

#### 2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

#### TCM.

- 6. Turn the ignition switch OFF.
- 7. Turn the ignition switch ON (II).

#### Is the low oil pressure indicator on?

YES - Go to step 10.

NO - Go to step 8.

8. Inspect the No. 6 (7.5 A) fuse in the under-dash fuse/relay box.

#### Is the fuse OK?

**YES** - Go to step 9.

**NO** - Repair short in the wire between the No. 6 (7.5 A) fuse and the gauge assembly. Also replace the No. 6 (7.5 A) fuse.

9. Inspect the No. 1 (50 A) fuse in the under-hood fuse/relay box.

#### Is the fuse OK?

**YES** - Repair open in the wire between the No. 1 (50 A) fuse and the gauge assembly. If the wires are OK, test the ignition switch (see **IGNITION KEY SWITCH TEST**).

NO - Repair short in the wire between the No. 1 (50 A) fuse and the under-dash fuse/relay box. Also replace the No. 1 (50 A) fuse.

10. Try to start the engine.

#### Does the engine start?

**YES** - Go to step 11.

NO - Go to step 14.

- 11. Turn the ignition switch OFF.
- 12. Connect ECM connector terminal A18 to body ground with a jumper wire.

## ECM CONNECTOR A (32P)



Wire side of female terminals

G03680895

#### **Fig. 192: Connecting ECM Connector Terminal A18 To Body Ground** <u>With Jumper Wire</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

13. Turn the ignition switch ON (II).

#### Is the MIL on?

**YES** - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u>
2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

<u>M/T MODELS</u>) ), 2002-2004 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u>), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see ECM REPLACEMENT).

**NO** - Check for an open in the wire between the ECM (A18) and the gauge assembly. Also check for a blown MIL bulb. If the wires and the bulb are OK, replace the gauge assembly.

- 14. Turn the ignition switch OFF.
- 15. Inspect the No. 7 (15 A) fuse in the under-hood fuse/relay box.

### Is the fuse OK?

YES - Go to step 22.

NO - Go to step 16.

- 16. Remove the blown No. 7 (15 A) fuse in the under-dash fuse/relay box.
- 17. Remove the PGM-FI main relay (IGP).
- 18. Check for continuity between body ground and PGM-FI main relay (IGP) 4P connector terminal No. 2.

# PGM-FI MAIN RELAY (IGP) 4P CONNECTOR



# Wire side of female terminals

G03680896

Fig. 193: Checking Continuity Between Body Ground And PGM-FI Main Relay (IGP) 4P Connector Terminal No. 2 Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

**YES** - Repair short in the wire between the No. 7 (15 A) fuse and the PGM-FI main relay (IGP). Also replace the No. 7 (15 A) fuse. **NO** - Go to step 19.

- 19. Disconnect each of the components or connectors below, one at a time, and check for continuity between PGM-FI main relay (IGP) 4P connector terminal No. 1 and body ground.
  - PGM-FI main relay (FUEL PUMP)
  - ECM connector B (25P)
  - Each injector 2P connector
  - Idle air control (IAC) valve 3P connector

# PGM-FI MAIN RELAY (IGP) 4P CONNECTOR



# Wire side of female terminals

G03680897

Fig. 194: Checking Continuity Between PGM-FI Main Relay (IGP) 4P Connector Terminal No. 1 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** - Go to step 20.

**NO** - Replace the component that made continuity to body ground go away when disconnected. If the item is the ECM, update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO SUBSTITUTE THE ECM FOR</u> <u>TESTING PURPOSES (2000-2001 M/T MODELS)</u>), 2002-2004 M/T models and CVT model (see <u>ECM UPDATING AND SUBSTITUTION</u> <u>FOR TESTING-2002-2006 M/T MODELS AND CVT MODEL</u>), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u>).

Also replace the No. 7 (15 A) fuse.

20. Disconnect the connectors from these components:

- PGM-FI main relay (FUEL PUMP)
- ECM connector B (25P)
- Injectors
- Idle air control (IAC) valve
- 21. Check for continuity between PGM-FI main relay (IGP) 4P connector terminal No. 2 and body ground.

# PGM-FI MAIN RELAY (IGP) 4P CONNECTOR



# Wire side of female terminals

G03680898

**Fig. 195: Checking Continuity Between PGM-FI Main Relay Connector Terminal No. 2 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

Is there continuity?

**YES** - Repair short in the wire between the PGM-FI main relay (IGP) and each item. Also replace the No. 7 (15 A) fuse.

**NO** - Replace the PGM-FI main relay (IGP). Also replace the No. 7 (15 A) fuse.

22. Inspect the No. 2 (15 A) fuse in the under-dash fuse/relay box.

### Is the fuse OK?

YES - Go to step 29.

**NO** - Go to step 23.

- 23. Remove the blown No. 2 (15 A) fuse in the under-dash fuse/relay box.
- 24. Remove the PGM-FI main relay (FUEL PUMP).
- 25. Remove the fuel tank (see **<u>FUEL TANK REPLACEMENT</u>**).
- 26. Check for continuity between fuel pump 5P connector terminal No. 5 and body ground.

# **FUEL PUMP 5P CONNECTOR**



# Wire side of female terminals

G03680899

### **Fig. 196: Checking Continuity Between Fuel Pump Connector Terminal** <u>No. 5 And Body Ground</u> **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

### Is there continuity?

**YES** - Repair short in the wire between the fuel pump and the PGM-FI main relay (FUEL PUMP). Also replace the No. 2 (15 A) fuse.

NO - Go to step 27.

- 27. Reinstall the PGM-FI main relay (FUEL PUMP).
- 28. Check for continuity between fuel pump 5P connector terminal No. 5 and body ground.

# **FUEL PUMP 5P CONNECTOR**



# Wire side of female terminals

G03680900

Fig. 197: Checking Continuity Between Fuel Pump 5P Connector Terminal No. 5 And Body Ground

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

### **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

### Is there continuity?

**YES** - Replace the PGM-FI main relay (FUEL PUMP). Also replace the No. 2 (15 A) fuse.

**NO** - Check the fuel pump, and replace it if necessary. Also replace the No. 2 (15 A) fuse.

29. Check for continuity between body ground and PGM-FI main relay diode 2P connector terminal No. 2.



### **PGM-FI MAIN RELAY DIODE 2P CONNECTOR**

### **Fig. 198: Checking Continuity Between Body Ground And PGM-FI Main Relay Diode 2P Connector Terminal No. 2**

### Courtesy of AMERICAN HONDA MOTOR CO., INC.

### Is there continuity?

YES - Go to step 30.

NO - Repair open in the wire between the PGM-FI main relay and G101.

30. Measure voltage between body ground and ECM connector terminals B1 and B9 individually.



G03680902

**Fig. 199: Measuring Voltage Between Body Ground And ECM Connector** <u>Terminals B1 And B9</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

### Is there battery voltage?

YES - Go to step 37.

#### 2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

NO - Go to step 31.

- 31. Turn the ignition switch OFF.
- 32. Remove the PGM-FI main relay (IGP).
- 33. Turn the ignition switch ON (II).
- 34. Measure voltage between PGM-FI main relay (IGP) 4P connector terminal No. 2 and body ground.

# PGM-FI MAIN RELAY (IGP) 4P CONNECTOR



# Wire side of female terminals

G03680903

Fig. 200: Measuring Voltage Between PGM-FI Main Relay (IGP) 4P Connector Terminal No. 2 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there battery voltage?

**YES** - Go to step 35.

**NO** - Repair open in the wire between the No. 7 (15 A) fuse and the PGM-FI main relay (IGP).

- 35. Turn the ignition switch OFF.
- 36. Check for continuity between PGM-FI main relay (IGP) 4P connector terminal No. 1 and ECM connector terminals B1 and B9 individually.



### Fig. 201: Checking Continuity Between PGM-FI Main Relay (IGP) 4P Connector Terminal No. 1 And ECM Connector Terminals B1 And B9 Courtesy of AMERICAN HONDA MOTOR CO., INC.

### Is there continuity?

**YES** - Replace the PGM-FI main relay (IGP).

NO - Repair open in the wire between the PGM-FI main relay (IGP) and

the ECM (B1, B9).

37. Measure voltage between body ground and ECM connector terminals B2, B10, B20, and B22 individually.

#### PG1 (BLK) 3 2 4 5 6 1 9 15 10 11 12 14 16 17 22 21 231 24 20 PG2 LG1 LG2 (BRN/ (BRN/BLK) (BLK) BLK)

## ECM CONNECTOR B (25P)

Wire side of female terminals

G03680905

**Fig. 202: Measuring Voltage Between Body Ground And ECM Connector** <u>Terminals</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there more than 1.0 V?

**YES** - Repair open in the wire(s) that had more than 1.0 V between G101 and the ECM (B2, B10, B20, B22).

NO - Go to step 38.

38. Measure voltage between body ground and ECM connector terminal C19.



### ECM CONNECTOR C (31P)

Wire side of female terminals

G03680906

**Fig. 203: Measuring Voltage Between Body Ground And ECM Connector** <u>Terminal C19</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there about 5 V?

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

**YES** - Go to step 46.

**NO** - Go to step 39.

- 39. Turn the ignition switch OFF.
- 40. Disconnect the manifold absolute pressure (MAP) sensor 3P connector.

ECM CONNECTOR C (31P)

- 41. Turn the ignition switch ON (II).
- 42. Measure voltage between body ground and ECM connector terminal C19.



Wire side of female terminals

G03680907

**Fig. 204: Measuring Voltage Between Body Ground And ECM Connector** <u>Terminal C19</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

### Is there about 5 V?

**YES** - Replace the MAP sensor.

**NO** - Go to step 43.

- 43. Turn the ignition switch OFF.
- 44. Disconnect ECM connector C (31P).
- 45. Check for continuity between ECM connector terminal C19 and body ground.



Wire side of female terminals

G03680908

Fig. 205: Checking Continuity Between ECM Connector Terminal C19 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

# ECM CONNECTOR C (31P)

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

### Is there continuity?

**YES** - Repair short in the wire between the ECM (C19) and the MAP sensor.

NO - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2004 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

46. Measure voltage between body ground and ECM connector terminal C28.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

# ECM CONNECTOR C (31P)



Wire side of female terminals

G03680909

#### **Fig. 206: Measuring Voltage Between Body Ground And ECM Connector** <u>Terminal C28</u> **Courtesy of AMERICAN HONDA MOTOR CO., INC.**

### Is there about 5 V?

YES -

- CVT model: Go to step 53.
- M/T model: Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW</u> <u>TO SUBSTITUTE THE ECM FOR TESTING PURPOSES</u> (2000-2001 M/T MODELS) ), 2002-2004 M/T models and CVT

model (see <u>ECM UPDATING AND SUBSTITUTION FOR</u> <u>TESTING-2002-2006 M/T MODELS AND CVT MODEL</u>), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u>).

NO - Go to step 47.

- 47. Turn the ignition switch OFF.
- 48. Disconnect the 3P connector from each of these sensors, one at a time, and measure voltage between body ground and ECM connector terminal C28 with the ignition switch ON (II).
  - Exhaust gas recirculation (EGR) valve position sensor
  - Brake booster pressure sensor
  - Fuel tank pressure (FTP) sensor
  - Throttle position (TP) sensor

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

# ECM CONNECTOR C (31P)



Wire side of female terminals

G03680910

### **Fig. 207: Measuring Voltage Between Body Ground And ECM Connector Terminal C28 With Ignition Switch ON (II) Courtesy of AMERICAN HONDA MOTOR CO., INC.**

### Is there about 5 V?

YES - Replace the sensor that restored about 5 V when disconnected.

**NO** - Go to step 49.

- 49. Turn the ignition switch OFF.
- 50. Disconnect the connectors from these sensors:
  - Exhaust gas recirculation (EGR) valve position sensor
  - Brake booster pressure sensor

- Fuel tank pressure (FTP) sensor
- Throttle position (TP) sensor
- 51. Disconnect ECM connector C (31P).
- 52. Check for continuity between ECM connector terminal C28 and body ground.

## ECM CONNECTOR C (31P)



Wire side of female terminals

G03680911

Fig. 208: Checking Continuity Between ECM Connector Terminal C28 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** - Repair short in the wire between the ECM (C28) and the EGR

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

valve position sensor, the brake booster pressure sensor, the FTP sensor, or the TP sensor.

NO - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2004 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

53. Measure voltage between body ground and ECM connector terminal B6.



### ECM CONNECTOR B (25P)

Wire side of female terminals

G03680912

**Fig. 209: Measuring Voltage Between Body Ground And ECM Connector Terminal B6 Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

### Is there about 5 V?

YES - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2004 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

NO - Go to step 54.

- 54. Turn the ignition switch OFF.
- 55. Disconnect TCM connector B (22P).
- 56. Turn the ignition switch ON (II).
- 57. Measure voltage between body ground and ECM connector terminal B6.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

### ECM CONNECTOR B (25P)



Wire side of female terminals

G03680913

### **Fig. 210: Measuring Voltage Between Body Ground And ECM Connector Terminal B6 Courtesy of AMERICAN HONDA MOTOR CO., INC.**

### Is there about 5 V?

**YES** - Substitute a known-good TCM, and recheck (see <u>HOW TO</u> <u>**TROUBLESHOOT CIRCUIT AT THE TCM**</u>). If the symptom/indication goes away, replace the original TCM. **NO** - Go to step 58.

- 58. Turn the ignition switch OFF.
- 59. Disconnect ECM connector B (25P).
- 60. Check for continuity between ECM connector terminal B6 and body ground.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

### ECM CONNECTOR B (25P)



Wire side of female terminals

G03680914

### **Fig. 211: Checking Continuity Between ECM Connector Terminal B6 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

### Is there continuity?

**YES** - Repair short in the wire between the ECM (B6) and the TCM (B20).

NO - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2004 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the

original ECM (see <u>ECM REPLACEMENT</u>).

61. Measure voltage between ECM connector terminal B17 and body ground.

# ECM CONNECTOR B (25P)



# Wire side of female terminals G03680915

**Fig. 212: Measuring Voltage Between ECM Connector Terminal B17 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

Is there about 5 V (or battery voltage)?

YES - Go to step 65.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

**NO** - Go to step 62.

- 62. Turn the ignition switch OFF.
- 63. Disconnect ECM connector B (25P).
- 64. Check for continuity between ECM connector terminal B17 and body ground.

# ECM CONNECTOR B (25P)



# Wire side of female terminals G03680916

Fig. 213: Checking Continuity Between ECM Connector Terminal B17 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

### Is there continuity?

YES - Repair short in the wire between the DLC and the ECM (B17). NO - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2004 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

- 65. Turn the ignition switch OFF.
- 66. Disconnect ECM connector B (25P).
- 67. Turn the ignition switch ON (II).

### Is the MIL on?

**YES** - Repair short in the wire between the gauge assembly and the ECM (B17). If the wires are OK, replace the gauge assembly.

NO - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2004 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

#### 2005-2006 MODELS

- 1. Connect the HDS (see <u>HOW TO USE THE HDS (HONDA DIAGNOSTIC</u> <u>SYSTEM)</u>).
- 2. Turn the ignition switch ON (II), and check the HDS.

### Does the HDS communicate with the ECM?

**YES** - Go to step 3.

**NO** - Go to "DLC Circuit Troubleshooting" (see <u>DLC CIRCUIT</u> <u>TROUBLESHOOTING</u>).

3. Check for Temporary DTCs or DTCs with the HDS.

### Are any Temporary DTCs or DTCs indicated?

**YES** - Go to the indicated **<u>DTC TROUBLESHOOTING</u> NO** - Go to step 4.

- 4. Turn the ignition switch OFF.
- 5. Turn the ignition switch ON (II) and watch the malfunction indicator lamp (MIL).

# Does the MIL come on and stay on for more than 20 seconds after turning the ignition switch ON (II)?

**YES** - If the MIL always comes on and stays on, go to step 81 . But if the MIL sometimes works normally, first check for these problems:

- An intermittent short in the wire between the ECM (B17) and the data link connector (DLC).
- An intermittent short in the wire between the ECM (A18) and the gauge assembly.
- The readiness codes are not set (see <u>HOW TO SET READINESS</u> <u>CODES</u>). (This is indicated if the MIL blinks five times after you turn the ignition switch ON (II) and wait about 20 seconds.)

**NO** - If the MIL is always off, go to step 6. But if the MIL sometimes works normally, first check for these problems:

- A loose No. 6 (7.5 A) fuse in the under-dash fuse/relay box.
- A loose No. 1 (50 A) fuse in the under-hood fuse/relay box.
- A loose No. 7 (15 A) fuse in the under-hood fuse/relay box.
- A loose No. 2 (15 A) fuse in the under-dash fuse/relay box.
- A poor connection at ECM terminal A18.
- An intermittent open in the GRN/ORN wire between the ECM (A18)

and the gauge assembly.

- An intermittent short in the wire between the ECM (C19) and the manifold absolute pressure (MAP) sensor.
- An intermittent short in the wire between the ECM (C28) and the throttle position (TP) sensor, the brake booster pressure sensor, the fuel tank pressure (FTP) sensor, the exhaust gas recirculation (EGR) valve position sensor, or brake fluid pressure sensor A (M/T model).
- An intermittent short in the wire between the ECM (C23) and brake fluid pressure sensor B (M/T model).
- An intermittent short in the wire between the ECM (B6) and the TCM (CVT model).
- 6. Turn the ignition switch OFF.
- 7. Turn the ignition switch ON (II).

### Is the low oil pressure indicator on?

**YES** - Go to step 10.

NO - Go to step 8.

8. Inspect the No. 6 (7.5 A) fuse in the under-dash fuse/relay box.

### Is the fuse OK?

YES - Go to step 9.

**NO** - Repair short in the wire between the No. 6 (7.5 A) fuse and the gauge assembly. Also replace the No. 6(7.5A) fuse.

9. Inspect the No. 1 (50 A) fuse in the under-hood fuse/relay box.

### Is the fuse OK?

**YES** - Repair open in the wire between the No. 1 (50 A) fuse and the gauge assembly. If the wires are OK, test the ignition switch (see <u>TEST</u>). **NO** - Repair short in the wire between the No. 1 (50 A) fuse and the under-dash fuse/relay box. Also replace the No. 1 (50 A) fuse.

10. Try to start the engine.

#### 2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

### **Does the engine start?**

**YES** - Go to step 11.

**NO** - Go to step 14.

- 11. Turn the ignition switch OFF.
- 12. Connect ECM connector terminal A18 to body ground with a jumper wire.

### ECM CONNECTOR A (32P)



Wire side of female terminals

G03680917

### **Fig. 214: Connecting ECM Connector Terminal A18 To Body Ground** <u>With Jumper Wire</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

13. Turn the ignition switch ON (II).

### Is the MIL on?

**YES** - Update the ECM if it does not have the latest software, or substitute a known-good ECM (see <u>ECM UPDATING AND SUBSTITUTION</u>

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

### FOR TESTING-2002-2006 M/T MODELS AND CVT MODEL ), then

recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u>).

**NO** - Check for an open in the wire between the ECM (A18) and the gauge assembly. Also check for a blown MIL bulb. If the wires and the bulb are OK, replace the gauge assembly.

- 14. Turn the ignition switch OFF.
- 15. Inspect the No. 7 (15 A) fuse in the under-hood fuse/relay box.

### Is the fuse OK?

YES - Go to step 22.

**NO** - Go to step 16.

- 16. Remove the blown No. 7 (15 A) fuse in the under-hood fuse/relay box.
- 17. Remove the PGM-FI main relay (IGP).
- 18. Check for continuity between body ground and PGM-FI main relay (IGP) 4P connector terminals No. 2 and No. 4 individually.

# PGM-FI MAIN RELAY (IGP) 4P CONNECTOR



# Wire side of female terminals G03680918

Fig. 215: Checking Continuity Between Body Ground And PGM-FI Main Relay (IGP) 4P Connector Terminals No. 2 And 4 Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Is there continuity?

**YES** - Repair short in the wire between the No. 7 (15 A) fuse and the

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

PGM-FI main relay (IGP). Also replace the No. 7 (15 A) fuse.

**NO** - Go to step 19.

- 19. Disconnect the connectors from these components:
  - PGM-FI main relay (FUEL PUMP)
  - ECM connector B (25P)
  - Injectors
  - Idle air control (IAC) valve
- 20. Check for continuity between PGM-FI main relay (IGP) 4P connector terminal No. 1 and body ground.
2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

# PGM-FI MAIN RELAY (IGP) 4P CONNECTOR



# Wire side of female terminals

G03680919

**Fig. 216:** Checking Continuity Between PGM-FI Main Relay (IGP) 4P Connector Terminal No. 1 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

#### Is there continuity?

**YES** - Repair short in YEL/BLK wire between the PGM-FI main relay (IGP) and each item. Also replace the No. 7 (15 A) fuse.

**NO** - Go to step 21.

- 21. Reconnect each of the components of the connectors below, one at a time, and check for continuity between PGM-FI main relay (IGP) 4P connector terminal No. 1 and body ground.
  - PGM-FI main relay (FUEL PUMP)
  - ECM connector B (25P)
  - Each injector 2P connector
  - Idle air control (IAC) valve 3P connector

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

# PGM-FI MAIN RELAY (IGP) 4P CONNECTOR



# Wire side of female terminals

G03680920

Fig. 217: Checking Continuity Between PGM-FI Main Relay (IGP) 4P Connector Terminal No. 1 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Is there continuity?

**YES** - Replace the component that made continuity to body ground go away when disconnected. If the item is the ECM, update the ECM if it does not have the latest software, or substitute a known-good ECM (see <u>ECM UPDATING AND SUBSTITUTION FOR TESTING-2002-2006</u> <u>M/T MODELS AND CVT MODEL</u>), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u>). Also replace the No. 7 (15 A) fuse.

**NO** - Replace the PGM-FI main relay (IGP). Also replace the No. 7 (15 A) fuse.

22. Inspect the No. 2 (15 A) fuse in the under-dash fuse/ relay box.

#### Is the fuse OK?

YES - Go to step 32.

**NO** - Go to step 23.

- 23. Remove the blown No. 2 (15 A) fuse from the under-dash fuse/relay box.
- 24. Remove ECM connector A (32P).
- 25. Check for continuity between ECM connector terminal A26 and body ground.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

### ECM CONNECTOR A (32P)



Wire side of female terminals

G03680921

#### **Fig. 218: Checking Continuity Between ECM Connector Terminal A26 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

#### Is there continuity?

YES - Go to step 26.

NO - Replace the No. 2 (15 A) fuse, and update the ECM if it does not have the latest software, or substitute a known-good ECM (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u>), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u>).

- 26. Remove the PGM-FI main relay (FUEL PUMP).
- 27. Check for continuity between ECM connector terminal A26 and body ground.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

### ECM CONNECTOR A (32P)



Wire side of female terminals

G03680922

#### **Fig. 219: Checking Continuity Between ECM Connector Terminal A26** And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Is there continuity?

**YES** - Repair short in the wire between the No. 2 (15 A) fuse and the ECM (A26), or the No. 2 (15 A) fuse and the PGM-FI main relay (FUEL PUMP). Also replace the No. 2 (15 A) fuse.

NO - Go to step 28.

- 28. Remove the fuel tank; 2005 model (see <u>2000-2005 MODELS</u>), 2006 model (see <u>2006 MODEL</u>).
- 29. Check for continuity between fuel pump 5P connector terminal No. 5 and body ground.

# **FUEL PUMP 5P CONNECTOR**



# Wire side of female terminals

G03680923

**Fig. 220: Checking Continuity Between Fuel Pump 5P Connector Terminal No. 5 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

#### Is there continuity?

**YES** - Repair short in the wire between the fuel pump and the PGM-FI main relay (FUEL PUMP). Also replace the No. 2 (15 A) fuse.

NO - Go to step 30.

- 30. Reinstall the PGM-FI main relay (FUEL PUMP).
- 31. Check for continuity between fuel pump 5P connector terminal No. 5 and body ground.

# **FUEL PUMP 5P CONNECTOR**



# Wire side of female terminals

G03680924

Fig. 221: Checking Continuity Between Fuel Pump 5P Connector Terminal No. 5 And Body Ground

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

#### Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Is there continuity?

**YES** - Replace the PGM-FI main relay (FUEL PUMP). Also replace the No. 2 (15 A) fuse.

**NO** - Check the fuel pump, and replace it if necessary. Also replace the No. 2 (15 A) fuse.

- 32. Turn the ignition switch ON (II).
- 33. Measure voltage between ECM connector terminal A26 and body ground.



#### ECM CONNECTOR A (32P)

Wire side of female terminals

G03680925

**Fig. 222: Measuring Voltage Between ECM Connector Terminal A26 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

Is there battery voltage?

**YES** - Go to step 34.

**NO** - Repair open in the wire between the No. 2 (15 A) fuse and the ECM (A26).

- 34. Turn the ignition switch OFF.
- 35. Measure voltage between ECM connector terminal A8 and body ground.

#### ECM CONNECTOR A (32P)



Wire side of female terminals

G03680926

#### Fig. 223: Measuring Voltage Between ECM Connector Terminal A8 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

### Is there battery voltage?

**YES** - Go to step 41.

NO - Go to step 36.

- 36. Remove the PGM-FI main relay (IGP).
- 37. Measure voltage between PGM-FI main relay (IGP) 4P connector terminal No. 4 and body ground.

# PGM-FI MAIN RELAY (IGP) 4P CONNECTOR



# Wire side of female terminals

G03680927

Fig. 224: Measuring Voltage Between PGM-FI Main Relay Connector Terminal No. 4 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there battery voltage?

**YES** - Go to step 38.

**NO** - Repair open in the wire between the No. 7 (15 A) fuse and the PGM-FI main relay (IGP).

- 38. Disconnect ECM connector A (32P).
- 39. Connect ECM connector A8 to body ground with a jumper wire.

#### ECM CONNECTOR A (32P)



Wire side of female terminals

G03680928

#### Fig. 225: Connecting ECM Connector A8 To Body Ground With Jumper Wire Courtesy of AMERICAN HONDA MOTOR CO., INC.

40. Check for continuity between body ground and PGM-FI main relay (IGP) 4P connector terminal No. 3.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

# PGM-FI MAIN RELAY (IGP) 4P CONNECTOR



# Wire side of female terminals

G03680929

Fig. 226: Checking Continuity Between Body Ground And PGM-FI Main Relay (IGP) 4P Connector Terminal No. 3 Courtesy of AMERICAN HONDA MOTOR CO., INC.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

#### Is there continuity?

**YES** - Replace the PGM-FI main relay (IGP).

**NO** - Repair open in the wire between the PGM-FI main relay (IGP) and the ECM (A8).

- 41. Turn the ignition switch ON (II).
- 42. Measure voltage between body ground and ECM connector terminals B1 and B9 individually.



### ECM CONNECTOR B (25P)

Wire side of female terminals

G03680930

**Fig. 227: Measuring Voltage Between Body Ground And ECM Connector Terminals B1 And B9 Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

Is there battery voltage?

#### 2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

**YES** - Go to step 49.

**NO** - Go to step 43.

- 43. Turn the ignition switch OFF.
- 44. Remove the PGM-FI main relay (IGP).
- 45. Turn the ignition switch ON (II).
- 46. Measure voltage between PGM-FI main relay (IGP) 4P connector terminal No. 2 and body ground.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

# PGM-FI MAIN RELAY (IGP) 4P CONNECTOR



# Wire side of female terminals

G03680931

**Fig. 228: Measuring Voltage Between PGM-FI Main Relay (IGP) 4P** <u>Connector Terminal No. 2 And Body Ground</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there battery voltage?

**YES** - Go to step 47.

**NO** - Repair open in the wire between the No. 7 (15 A) fuse and the PGM-FI main relay (IGP).

- 47. Turn the ignition switch OFF.
- 48. Check for continuity between PGM-FI main relay (IGP) 4P connector terminal No. 1 and ECM connector terminals B1 and B9 individually.



#### Fig. 229: Checking Continuity Between PGM-FI Main Relay (IGP) 4P Connector Terminal No. 1 And ECM Connector Terminals B1 And B9 Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Is there continuity?

**YES** - Replace the PGM-FI main relay (IGP).

**NO** - Repair open in the wire between the PGM-FI main relay (IGP) and the ECM (B1, B9).

49. Measure voltage between body ground and ECM connector terminals B2, B10,

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

B20, and B22 individually.

# ECM CONNECTOR B (25P)



Wire side of female terminals

G03680933

#### **Fig. 230:** Measuring Voltage Between Body Ground And ECM Connector <u>Terminals</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Is there more than 1.0 V?

**YES** - Repair open in the wire(s) that had more than 1.0 V between G101 and the ECM (B2, B10, B20, B22).

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

NO - Go to step 50.

50. Measure voltage between body ground and ECM connector terminal C19.

## ECM CONNECTOR C (31P)



Wire side of female terminals

G03680934

**Fig. 231: Measuring Voltage Between Body Ground And ECM Connector** <u>Terminal C19</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there about 5 V?

**YES** - Go to step 58 . **NO** - Go to step 51.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

- 51. Turn the ignition switch OFF.
- 52. Disconnect the manifold absolute pressure (MAP) sensor 3P connector.
- 53. Turn the ignition switch ON (II).
- 54. Measure voltage between body ground and ECM connector terminal C19.

### ECM CONNECTOR C (31P)



Wire side of female terminals

G03680935

**Fig. 232: Measuring Voltage Between Body Ground And ECM Connector** <u>Terminal C19</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there about 5 V?

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

**YES** - Replace the MAP sensor.

**NO** - Go to step 55.

- 55. Turn the ignition switch OFF, and wait for 10 seconds.
- 56. Disconnect ECM connector C (31P).
- 57. Check for continuity between ECM connector terminal C19 and body ground.

### ECM CONNECTOR C (31P)



Wire side of female terminals

G03680936

Fig. 233: Checking Continuity Between ECM Connector Terminal C19 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** - Repair short in the wire between the ECM (C19) and the MAP sensor.

**NO** - Update the ECM if it does not have the latest software, or substitute a known-good ECM (see <u>ECM UPDATING AND SUBSTITUTION</u> <u>FOR TESTING-2002-2006 M/T MODELS AND CVT MODEL</u>), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u>).

58. Measure voltage between body ground and ECM connector terminal C28.

### ECM CONNECTOR C (31P)



### Wire side of female terminals

G03680937

#### **Fig. 234: Measuring Voltage Between Body Ground And ECM Connector Terminal C28**

#### Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Is there about 5 V?

YES -

- M/T model: Go to step 65 .
- CVT model: Go to step 73 .
- NO Go to step 59.
- 59. Turn the ignition switch OFF.
- 60. Disconnect the 3P connector from each of these sensors, one at a time, and measure voltage between body ground and ECM connector terminal C28 with the ignition switch ON (II).
  - Exhaust gas recirculation (EGR) valve position sensor
  - Brake booster pressure sensor
  - Fuel tank pressure (FTP) sensor
  - Throttle position (TP) sensor
  - Brake fluid pressure sensor A (M/T model)

# ECM CONNECTOR C (31P)



Wire side of female terminals

G03680938

#### **Fig. 235: Measuring Voltage Between Body Ground And ECM Connector Terminal C28 With Ignition Switch ON (II) Courtesy of AMERICAN HONDA MOTOR CO., INC.**

#### Is there about 5 V?

**YES** - Replace the sensor that restored about 5 V when disconnected. **NO** - Go to step 61.

- 61. Turn the ignition switch OFF.
- 62. Disconnect the connector from these sensors:
  - Exhaust gas recirculation (EGR) valve position sensor

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

- Brake booster pressure sensor
- Fuel tank pressure (FTP) sensor
- Throttle position (TP) sensor
- Brake fluid pressure sensor A (M/T model)
- 63. Disconnect ECM connector C (31P).
- 64. Check for continuity between ECM connector terminal C28 and body ground.

## ECM CONNECTOR C (31P)



### Wire side of female terminals

G03680939

**Fig. 236: Checking Continuity Between ECM Connector Terminal C28** <u>And Body Ground</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

#### Is there continuity?

**YES** - Repair short in the wire between the ECM (C28) and the EGR valve position sensor, the brake booster pressure sensor, the FTP sensor, the TP sensor, or brake fluid pressure sensor A (M/T model).

**NO** - Update the ECM if it does not have the latest software, or substitute a known-good ECM (see <u>ECM UPDATING AND SUBSTITUTION</u> <u>FOR TESTING-2002-2006 M/T MODELS AND CVT MODEL</u>), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u>).

65. Measure voltage between body ground and ECM connector terminal C23.

#### 5 6 8 9 4 13 19 15 16 18 20 14 17 2 30 26 25 VCC3 (RED/WHT)

Wire side of female terminals

G03680940

### ECM CONNECTOR C (31P)

#### **Fig. 237: Measuring Voltage Between Body Ground And ECM Connector** <u>Terminal C23</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Is there about 5 V?

**YES** - Update the ECM if it does not have the latest software, or substitute a known-good ECM (see <u>ECM UPDATING AND SUBSTITUTION</u> <u>FOR TESTING-2002-2006 M/T MODELS AND CVT MODEL</u>), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u>).

NO - Go to step 66.

- 66. Turn the ignition switch OFF.
- 67. Disconnect the brake fluid pressure sensor B 3P connector.
- 68. Turn the ignition switch ON (II).
- 69. Measure voltage between body ground and ECM connector terminal C23.

# ECM CONNECTOR C (31P)



Wire side of female terminals

G03680941

#### **Fig. 238: Measuring Voltage Between Body Ground And ECM Connector** <u>Terminal C23</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Is there about 5 V?

**YES** - Replace brake fluid pressure sensor B.

**NO** - Go to step 70.

- 70. Turn the ignition switch OFF, and wait for 10 seconds.
- 71. Disconnect ECM connector C (31P).
- 72. Check for continuity between ECM connector terminal C23 and body ground.

# ECM CONNECTOR C (31P)



Wire side of female terminals

G03680942

#### Fig. 239: Checking Continuity Between ECM Connector Terminal C23 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Is there continuity?

**YES** - Repair short in the wire between the ECM (C23) and brake fluid pressure sensor B.

**NO** - Update the ECM if it does not have the latest software, or substitute a known-good ECM (see <u>ECM UPDATING AND SUBSTITUTION</u> <u>FOR TESTING-2002-2006 M/T MODELS AND CVT MODEL</u>), then recheck. If the symptom/indication goes away with a known-good ECM,

replace the original ECM (see <u>ECM REPLACEMENT</u>).

73. Measure voltage between body ground and ECM connector terminal B6.

### ECM CONNECTOR B (25P)



Wire side of female terminals

G03680943

#### **Fig. 240:** Measuring Voltage Between Body Ground And ECM Connector <u>Terminal B6</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Is there about 5 V?

**YES** - Update the ECM if it does not have the latest software, or substitute a known-good ECM (see <u>ECM UPDATING AND SUBSTITUTION</u> <u>FOR TESTING-2002-2006 M/T MODELS AND CVT MODEL</u>), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u>).

NO - Go to step 74.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

- 74. Turn the ignition switch OFF.
- 75. Disconnect TCM connector B (22P).
- 76. Turn the ignition switch ON (II).
- 77. Measure voltage between body ground and ECM connector terminal B6.

#### VREF (WHT/RED) 3 5 2 6 4 1 12 11 9 10 14 15 16 17 20 21 23 24 22

ECM CONNECTOR B (25P)

Wire side of female terminals

G03680944

#### **Fig. 241: Measuring Voltage Between Body Ground And ECM Connector** <u>Terminal B6</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Is there about 5 V?

**YES** - Substitute a known-good TCM, and recheck (see <u>HOW TO</u> <u>**TROUBLESHOOT CIRCUIT AT THE TCM**</u>). If the symptom/indication goes away, replace the original TCM.

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

NO - Go to step 78.

- 78. Turn the ignition switch OFF, and wait for 10 seconds.
- 79. Disconnect ECM connector B (25P).
- 80. Check for continuity between ECM connector terminal B6 and body ground.

#### VREF (WHT/RED) 2 5 3 4 6 1 12 15 9 10 11 14 16 17 20 21 22 23 24

**ECM CONNECTOR B (25P)** 

Wire side of female terminals

G03680945

#### **Fig. 242: Checking Continuity Between ECM Connector Terminal B6 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

#### Is there continuity?

**YES** - Repair short in the wire between the ECM (B6) and the TCM (B20).

NO - Update the ECM if it does not have the latest software, or substitute

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

a known-good ECM (see <u>ECM UPDATING AND SUBSTITUTION</u> <u>FOR TESTING-2002-2006 M/T MODELS AND CVT MODEL</u>), then recheck. If the symptom/indication goes away with a known-good ECM,

replace the original ECM (see <u>ECM REPLACEMENT</u>).

81. Measure voltage between ECM connector terminal B17 and body ground.

# ECM CONNECTOR B (25P)



Wire side of female terminals

G03680946

**Fig. 243: Measuring Voltage Between ECM Connector Terminal B17 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.** 

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

#### Is there about 5 V (or battery voltage)?

YES - Go to step 85.

**NO** - Go to step 82.

- 82. Turn the ignition switch OFF, and wait for 10 seconds.
- 83. Disconnect ECM connector B (25P).
- 84. Check for continuity between ECM connector terminal B17 and body ground.

# ECM CONNECTOR B (25P)



Wire side of female terminals G03680947

#### Fig. 244: Checking Continuity Between ECM Connector Terminal B17

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

#### **And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.**

#### Is there continuity?

YES - Repair short in the wire between the DLC and the ECM (B17).

**NO** - Update the ECM if it does not have the latest software, or substitute a known-good ECM (see <u>ECM UPDATING AND SUBSTITUTION</u> <u>FOR TESTING-2002-2006 M/T MODELS AND CVT MODEL</u>), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u>).

- 85. Turn the ignition switch OFF, and wait for 10 seconds.
- 86. Disconnect ECM connector B (25P).
- 87. Turn the ignition switch ON (II).

#### Is the MIL on?

**YES** - Repair short in the wire between the gauge assembly and the ECM (B17). If the wire is OK, replace the gauge assembly.

**NO** - Update the ECM if it does not have the latest software, or substitute a known-good ECM (see <u>ECM UPDATING AND SUBSTITUTION</u> <u>FOR TESTING-2002-2006 M/T MODELS AND CVT MODEL</u>), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u>).

#### **DLC CIRCUIT TROUBLESHOOTING**

- If the ECM does not communicate with the HDS, do this troubleshooting procedure.
- Check that the MIL circuit is normal, then do this troubleshooting.
- 1. Measure voltage between DLC terminal No. 16 and body ground.

## DATA LINK CONNECTOR (DLC)



### Terminal side of female terminals

G03680948

#### Fig. 245: Measuring Voltage Between DLC Terminal No. 16 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

#### Is there battery voltage?

**YES** - Go to step 2.

**NO** - Repair open in the wire between DLC terminal No. 16 and the No. 18 (7.5 A) fuse in the under-hood fuse/relay box.

2. Measure voltage between DLC terminals No. 4 and No. 16.
## DATA LINK CONNECTOR (DLC)



## Terminal side of female terminals G03680949

### **Fig. 246:** Measuring Voltage Between DLC Terminals No. 4 And 16 Courtesy of AMERICAN HONDA MOTOR CO., INC.

### Is there battery voltage?

**YES** - Go to step 3.

**NO** - Repair open in the wire between DLC terminal No. 4 and body ground.

3. Measure voltage between DLC terminals No. 5 and No. 16.

## DATA LINK CONNECTOR (DLC)



## Terminal side of female terminals G03680950

### **Fig. 247: Measuring Voltage Between DLC Terminals No. 5 And 16** Courtesy of AMERICAN HONDA MOTOR CO., INC.

## Is there battery voltage?

**YES** - Go to step 4.

**NO** - Repair open in the wire between DLC terminal No. 5 and body ground.

4. Turn the ignition switch ON (II).

5. Measure voltage between DLC terminals No. 5 and No. 7.

## DATA LINK CONNECTOR (DLC)



## Terminal side of female terminals G03680951

**Fig. 248: Measuring Voltage Between DLC Terminals No. 5 And 7** Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there 8.5 V or more?

YES - Go to step 10.

NO - Go to step 6.

- 6. Turn the ignition switch OFF, and wait for 10 seconds.
- 7. Disconnect ECM connector A (32P).
- 8. Check for continuity between DLC terminal No. 7 and body ground.

## DATA LINK CONNECTOR (DLC)



## Terminal side of female terminals G03680952

Fig. 249: Checking Continuity Between DLC Terminal No. 7 And Body Ground Courtesy of AMERICAN HONDA MOTOR CO., INC.

## Is there continuity?

**YES** - Repair short to ground in the wire between DLC terminal No. 7 and the ECM (A21). After repairing the wire, check the DTC with the HDS, and go to the indicated **DTC TROUBLESHOOTING**.

NO - Go to step 9.

9. Check for continuity between DLC terminal No. 7 and ECM terminal A21.



ECM CONNECTOR A (32P)

Terminal side of female terminals

G03680953

Fig. 250: Checking Continuity Between DLC Terminal No. 7 And ECM <u>Terminal A21</u> Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there continuity?

**YES** - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u> <u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see <u>ECM REPLACEMENT</u> ).

**NO** - Repair open in the wire between DLC terminal No. 7 and the ECM (A21). After repairing the wire, check the DTC with the HDS, and go to the indicated **DTC TROUBLESHOOTING**.

- 10. Turn the ignition switch OFF, and wait for 10 seconds.
- 11. Disconnect ECM connector A (32P).
- 12. Turn the ignition switch ON (II).
- 13. Measure voltage between DLC terminals No. 5 and No. 7.

## DATA LINK CONNECTOR (DLC)



## Terminal side of female terminals G03680954

**Fig. 251:** Measuring Voltage Between DLC Terminals No. 5 And 7 Courtesy of AMERICAN HONDA MOTOR CO., INC.

Is there 0 V?

**YES** - Update the ECM if it does not have the latest software, or substitute a known-good ECM; 2000-2001 M/T models (see <u>HOW TO</u> <u>SUBSTITUTE THE ECM FOR TESTING PURPOSES (2000-2001</u>

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

<u>M/T MODELS</u>) ), 2002-2006 M/T models and CVT model (see <u>ECM</u> <u>UPDATING AND SUBSTITUTION FOR TESTING-2002-2006 M/T</u> <u>MODELS AND CVT MODEL</u> ), then recheck. If the symptom/indication goes away with a known-good ECM, replace the original ECM (see ECM REPLACEMENT ).

**NO** - Repair short to power in the wire between DLC terminal No. 7 and the ECM (A21). After repairing the wire, check for DTCs with the HDS, and go to the indicated **<u>DTC TROUBLESHOOTING</u>**.

## INJECTOR REPLACEMENT

- Relieve the fuel pressure; 2000-2003 models (see <u>2000-2003 MODELS</u>), 2004-2005 models (see <u>2004-2005 MODELS</u>), 2006 model (see <u>2006</u> <u>MODEL</u>).
- 2. Remove the fuel rail cover (A), then disconnect the connectors from the fuel injectors (B).



## Fig. 252: Removing Fuel Rail Cover And Disconnecting Connectors From

2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

## **Fuel Injectors** Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 3. 2000-2005 M/T models: Disconnect the vacuum hose and fuel return hose from the fuel pressure regulator (C). Place a rag or shop towel over the hoses before disconnecting them.
- 4. CVT model, 2006 M/T model: Disconnect the vacuum hose from the fuel pulsation damper (D).
- 5. Remove the retainer nuts (E).
- 6. 2000-2004 models: Disconnect the PCV valve (F).
- 7. 2005-2006 models: Disconnect the PCV hose (G).
- 8. Disconnect the fuel rail.
- 9. Remove the fuel injectors from the cylinder head (H).
- 10. Slide new cushion rings (A) onto the fuel injectors (B).

#### 2000-06 ENGINE PERFORMANCE PGM-FI System - Insight



## G03680956

### **Fig. 253: Sliding Cushion Rings Onto Fuel Injectors** Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 11. Coat new O-rings (C) with clean engine oil, and put them on the fuel injectors.
- 12. Insert the fuel injectors into the fuel rail (D).
- 13. Coat new seal rings (E) with clean engine oil, and press them into the cylinder head.
- 14. Install the fuel injectors into the cylinder head.
- 15. Install and tighten the retainer nuts.
- 16. 2000-2005 models: Connect the fuel hose to the fuel rail with new washers.
- 17. 2000-2005 M/T models: Connect the vacuum hoses and fuel return hose to the fuel pressure regulator (F).
- 18. CVT model, 2006 M/T model: Connect the vacuum hose to the fuel pulsation

#### 2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

damper (G).

- 19. 2005-2006 models: Connect the PCV tube.
- 20. 2000-2004 models: Connect the PCV valve.
- 21. Turn the ignition switch ON (II), but do not operate the starter. After the fuel pump runs for about 2 seconds, the fuel pressure in the fuel line rises. Repeat this two or three times, then check for fuel leakage.

## A/F SENSOR REPLACEMENT

## **Special Tools Required**

02 sensor socket wrench, Snap-on YA8875, SP Tools 93750, or equivalent, commercially available

Disconnect the A/F sensor 4P or 8P connector (A), and remove the A/F sensor (B).

#### 2000-06 ENGINE PERFORMANCE PGM-FI System - Insight



G03680957

### **Fig. 254: Disconnecting A/F Sensor 4P Or 8P Connector Courtesy of AMERICAN HONDA MOTOR CO., INC.**

2. Install the A/F sensor in the reverse order of removal.

### SECONDARY HO2S REPLACEMENT

## **Special Tools Required**

02 sensor socket wrench. Snap-on YA8875, SP Tools 93750, or equivalent, commercially available

# NOTE: When the secondary HO2S is replaced the third HO2S must be replaced at the same time (2002-2006 M/T models only).

1. Disconnect the secondary HO2S 4P connector (A), and remove the secondary HO2S (B).

#### 2000-06 ENGINE PERFORMANCE PGM-FI System - Insight



G03680958

**Fig. 255: Removing Secondary HO2S** Courtesy of AMERICAN HONDA MOTOR CO., INC.

2. Install the secondary HO2S in the reverse order of removal.

## THIRD HO2S REPLACEMENT

Special Tools Required

O2 sensor socket wrench, Snap-on YA8875, SP Tools 93750, or equivalent, commercially available

2002-2006 M/T MODELS

# NOTE: When the third HO2S is replaced, the secondary HO2S must be replaced at the same time.

1. Disconnect the third HO2S 4P connector (A), and remove the third HO2S (B).



2000-06 ENGINE PERFORMANCE PGM-FI System - Insight

## **Fig. 256: Removing Third HO2S** Courtesy of AMERICAN HONDA MOTOR CO., INC.

2. Install the third HO2S in the reverse order of removal.

## ECM REPLACEMENT

- 1. Make sure you have the anti-theft code for the radio, then write down the audio presets.
- 2. Turn the ignition switch OFF.
- 3. Wait 1 minute. If the radiator fan is running, wait 1 minute after the radiator fan stops.
- 4. Disconnect the negative cable from the battery.
- 5. Pull the passenger's side carpet back to expose the ECM (A).

#### 2000-06 ENGINE PERFORMANCE PGM-FI System - Insight



G03680960

### **Fig. 257: Pulling Passenger's Side Carpet Back To Expose ECM** Courtesy of AMERICAN HONDA MOTOR CO., INC.

- 6. Remove the ECM cover (B).
- 7. Lift the lower edge of the ECM cover off of the lower studs. Make sure the ECM is not touching the studs.
- 8. Lift the upper edge of the ECM cover enough to clear the upper studs, then pull the cover down away from the evaporator drain tube.
- 9. Remove the ECM from the cover.
- 10. Disconnect the ECM connectors.
- 11. Install the ECM in the reverse order of removal.
- 12. Turn the ignition switch ON (II).

## NOTE: For 2005-2006 models: DTC P0630 "VIN Not Programmed or Mismatch" may be stored because VIN has not been programmed into the ECM; ignore it, and continue this procedure.

- 13. For 2005-2006 models: Input the VIN to the ECM with the HDS.
- 14. Rewrite the immobilizer code with the ECM replacement procedure in the HDS; it allows you to start the engine.
- 15. Do the ECM idle learn procedure (see ECM IDLE LEARN PROCEDURE ).
- 16. Remove the No. 15 (40 A) fuse from the under-hood fuse/relay box.
- 17. If the IMA battery level gauge (BAT) displays no segments, start the engine, and hold it between 3,500 rpm and 4,000 rpm without load (in Park or neutral) until the BAT displays at least three segments.
- 18. Reinstall the No. 15(40 A) fuse.
- 19. Do the start clutch calibration procedure (see **START CLUTCH CALIBRATION PROCEDURES** ).
- 20. Enter the anti-theft code for the radio, then enter the audio presets, and set the clock.