Last Modified: 12-04-2024	6.11:8.1.0	**Doc ID:** RM1000000028UYU
Model Year Start: 2023	**Model:** Prius Prime	**Prod Date Range:** [12/2022 -]

Title: SUPPLEMENTAL RESTRAINT SYSTEMS: OCCUPANT CLASSIFICATION SYSTEM: VEHICLE CONTROL HISTORY (RoB); 2023 - 2024 MY Prius Prius Prime [12/2022 -]

VEHICLE CONTROL HISTORY (RoB)

NOTICE:

When checking the vehicle control history, make sure to record the output histories. Then, remove the histories and recheck the output histories again.

CHECK VEHICLE CONTROL HISTORY

(a) According to the display on the GTS, check the Vehicle Control History (RoB).

Body Electrical > SRS Airbag > Utility

TESTER DISPLAY
Vehicle Control History (RoB)

Vehicle Control History (RoB)

WARNING LIGHT	CODE	TESTER DISPLAY	MEASUREMENT ITEM	DIAGNOSTIC NOTE
SRS warning light illuminated	X204A	Acceleration Sensor Malfunction	Recorded when airbag ECU assembly received a malfunction signal of accelerator sensor output from skid control ECU.	Refer to How to Proceed with Troubleshooting in Electronically Controlled Brake System. INFO
SRS warning light illuminated	X20AF	Guess Vehicle Speed Malfunction	Recorded when an estimated vehicle speed flag malfunction signal (invalid value) is received from the skid control ECU.	Refer to How to Proceed with Troubleshooting in Electronically Controlled Brake System. INFO
SRS warning light illuminated	X20D0	Zero Point Calibration of Occupant Detection Load Sensor Undone	Recorded when occupant classification zero point calibration is not performed or could not be completed normally.	INFO
SRS warning light illuminated	X210B	SRS Airbag ECU IG Voltage Drop	Recorded when the IGR terminal input voltage is continuously less than 8 V for 60 seconds.	INFO

CLEAR VEHICLE CONTROL HISTORY

(a) According to the display on the GTS, clear the Vehicle Control History (RoB).

Body Electrical > SRS Airbag > Utility

TESTER DISPLAY
Vehicle Control History (RoB)