THEFT DETERRENT / KEYLESS ENTRY: DIGITAL KEY RECEIVER (for Rear Door): INSTALLATION; 2023 - 2024 MY Prius Pri...

Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM100000029TVV	
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [12/2022 -]	
Title: THEFT DETERRENT / KEYLESS	ENTRY: DIGITAL KEY REC	EIVER (for Rear Door): INSTALLATION; 2023 - 2024	
MY Prius Prius Prime [12/2022 -]		

INSTALLATION


CAUTION / NOTICE / HINT

HINT:

- Use the same procedure for the LH side and RH side.
- The following procedure is for the LH side.

CAUTION / NOTICE / HINT

COMPONENTS (INSTALLATION)



PROCEDURE	PART NAME CODE	!		\$
1 BLE DOOR DIGITAL KEY RECEIVER ASSEMBLY (for Rear Door)	890D0	INFO	-	-

	PROCEDURE	PART NAME CODE	!		¢
2	REAR DOOR SERVICE HOLE COVER	67842E	INFO	-	-
3	REAR DOOR TRIM BOARD SUB-ASSEMBLY	67604	-	-	-
4	REAR DOOR REAR FRAME BRACKET	67498	-	-	-
5	REAR POWER WINDOW REGULATOR SWITCH ASSEMBLY WITH REAR DOOR UPPER ARMREST BASE PANEL	-	-	-	-
6	REAR DOOR TRIM UPPER COVER	67782D	-	-	-
7	REAR DOOR WINDOW FRAME FRONT MOULDING	75762A	INFO	-	-
8	REGISTRATION DIGITAL KEY ECU	-	-	-	INFO
	Non-reusable part				


•	Non-reusable part	-	-

PROCEDURE

1. INSTALL BLE DOOR DIGITAL KEY RECEIVER ASSEMBLY (for Rear Door)

NOTICE:


Be careful when installing the digital key receiver. If the digital key receiver is dropped, replace it with a new one.



*а	Double-sided Tape: 50 mm X 5.6 mm (1.97 in. X 0.22 in.)	*b	Double-sided Tape Application Area

Standard Measurement:

AREA	MEASUREMENT AREA MEASUREMENT		MEASUREMENT
A	8.6 mm (0.34 in.)	В	53 mm (2.09 in.)
С	18.5 mm (0.73 in.)		-



(1) Clean the rear door surface.

1. Using a heat light, heat the double-sided tape remaining on the rear door surface and the ble door digital key receiver assembly (for rear door).


Heating Temperature

AREA	TEMPERATURE	AREA	TEMPERATURE	
Rear	40 to 60°C (104 to	BLE Door Digital Key Receiver Assembly (for rear door)	20 to 30 °C (68 to 86	
Door	140°F)		°F)	

CAUTION:

- Do not touch the heat light and heated parts, touching the heat light may result in burns.
- Touching heated parts for a long time may result in burns.

12/16/24, 11:36 AM



NOTICE:

Do not heat the front fender panel excessively.

2. Remove any remaining double-sided tape from the rear door surface and the ble door digital key receiver assembly (for rear door).

3. Wipe off any tape adhesive residue with cleaner.

- (2) The double-side tape shall be attached in specified area regardless of position and orientation.
- (3) Connect the connector to the ble door digital key receiver assembly (for rear door).
- (4) Slide the ble door digital key receiver assembly (for rear door) while pressing the ble door digital key receiver assembly (for rear door) against the glass channel.
- (5) When ANT falls into the recess peeling off the release paper. After that, fix it firmly with your finger pad.
- (6) Engage the 3 clamps.

2. INSTALL REAR DOOR SERVICE HOLE COVER

!	Click here
---	------------

3. INSTALL REAR DOOR TRIM BOARD SUB-ASSEMBLY

4. INSTALL REAR DOOR REAR FRAME BRACKET

5. INSTALL REAR POWER WINDOW REGULATOR SWITCH ASSEMBLY WITH REAR DOOR UPPER ARMREST BASE PANEL

6. INSTALL REAR DOOR TRIM UPPER COVER

7. INSTALL REAR DOOR WINDOW FRAME FRONT MOULDING



Click here

8. REGISTRATION DIGITAL KEY SYSTEM

Click here

.

Э ТОУОТА