

Transaxle



Clutch

HONDA

Special Tools	12-2
Component Location Index	12-3
System Description	12-4
Clutch Hydraulic System Bleeding	12-6
Clutch Pedal, Clutch Pedal Position Switch, and Clutch Interlock Switch Adjustment	12-7
Clutch Pedal Assembly Replacement	12-8
Clutch Master Cylinder Replacement	12-9
Slave Cylinder Replacement	12-12
Clutch Hose Replacement	12-13
Clutch Replacement	12-15



Clutch

Special Tools

Ref.No.	Tool Number	Description	Qty
①	07746-0010800	Attachment, 22 x 24 mm	1
②	07749-0010000	Driver Handle, 15 x 135L	1
③	07936-3710100	Remover Handle	1
④	07936-371020A	Slide Hammer	1
⑤	07936-3710600	Bearing Remover Shaft Set, 20 mm	1
⑥	07JAF-PM7011A	Clutch Alignment Disc	1
⑦	07LAB-PV00100 or 07924-PD20003	Ring Gear Holder	1
⑧	07PAF-0020000	Clutch Alignment Tool Set	1
⑨	07PAF-0020370	Clutch Alignment Pilot, 21 mm	1
⑩	07ZAF-PR8A100	Clutch Alignment Shaft	1

