

VSA Sensor Neutral Position Memorization

Procedure

NOTE:

- The VSA sensor neutral position must be learned whenever you do any of these actions:
 - Update or replace the VSA modulator-control unit.
 - Update or replace the SRS unit.
 - Removing and installing the steering wheel.
 - Disconnecting and reconnecting the steering joint.
 - Wheel alignment.

- Before doing the memorization procedure, park the vehicle on a flat and level surface.

1. HDS - Connect

2. VSA Sensor Neutral Position - Memorize

NOTE: Do not press the brake pedal during this procedure.

1. Set the steering wheel in the straight ahead position.

2. Select ADJUSTMENT from ABS/VSA menu with the HDS, then select ALL SENSOR, and follow the screen prompts.