

2000-2006 Honda Insight Body Repair Manual

INTRODUCTION

How to Use This Manual

This manual covers the repairs of a 2000-2006 Honda Insight that has been involved in an accident, and it describes the work related to the replacement of damaged body parts.

Please read through these instructions and familiarize yourself with them before actually using this manual.

NOTE: Refer to the applicable 2000-2006 Honda Insight Service Manual for specifications, wire harness locations, safety stand support points, etc.

Special Information

WARNING

You CAN be KILLED or SERIOUSLY HURT if you don't follow instructions.

CAUTION

You CAN be HURT if you don't follow instructions.

NOTE: Gives helpful information.

CAUTION

Detailed descriptions of standard workshop procedures, safety principles and service operations are not included. Please note that this manual does contain warnings and cautions against some specific service methods which could cause PERSONAL INJURY, damage a vehicle, or make it unsafe. Please understand that these warnings cannot cover all conceivable ways in which service, whether or not recommended by Honda, might be done or of the possible hazardous consequences of each conceivable way, nor could Honda investigate all such ways. Anyone using service procedures or tools, whether or not recommended by Honda, must satisfy himself thoroughly that neither personal safety or vehicle safety will be jeopardized.

All information contained in this manual is based on the latest product information available at the time of printing. We reserve the right to make changes at any time without notice. No part of this publication may be reproduced, stored in retrieval system, or transmitted, in any form by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of the publisher. This includes text, figures and tables.

HONDA MOTOR CO., LTD.
Service Publication Office

1 General Info

2 Preparation of Work

3 *Replacement

4 Body Dimensional Drawings

5 Rust Prevention

6 Paints

Sections with an * include SRS components; special caution is required when servicing.