

Removal

- When removing the roof panel, leave the front roof rail extension attached to the front pillar.

