


Opening Repair Chart


Hatch Opening

Unit: mm (in.)

H
Rear roof rail upper,
flange notch



I, i
Rear fender panel,
flange end (2 places)



J
Rear panel upper stiffener,
center Mark

