



# Ground-to-Components Index

NOTE: All ground wires are BLK unless otherwise noted.

Ground	Page	Component or Circuit Grounded
G1	14-7	Battery
G2	14-7	Engine block
G3	14-7	Transmission
G4	14-7	EPS motor
G101 and G102 ('02-'06)	14 and 14-1	BCM module (BRN/YEL), ECM (PG1 and PG2 are BLK; LG1 and LG2 are BRN/BLK), DLC (BRN/YEL), EGR valve and EGR valve position sensor, IAC valve, Ignition coils, Immobilizer receiver unit (BRN/YEL), MCM (BRN/YEL), Neutral position switch (M/T), PGM-FI main relay ('00-'04), Primary HO2S ('00, early production '01), Radiator fan switch, Rocker arm oil pressure switch (VTEC oil pressure switch), TCM (CVT), Transmission range switch (CVT), Voltage converter module (BRN/YEL), VSS  Shielding between the ECM and these components have BRN/BLK wires: CKP sensor, CMA, CMB, and CMC motor sensors, Knock sensor, Motor current sensor, Primary HO2S, Secondary HO2S, TDC sensors.
G201	14-2	ABS modulator-control unit (2 wires), CAS solenoid valves A and B (CVT), Rear window washer motor, Right front parking light, Right front side marker light, Right front turn signal light, Windshield washer motor
G301	14-2	Blower motor relay, ELD unit, Intermittent wiper relay, Left front parking light, Left front side marker light, Left front turn signal light, Radiator fan main relay, Radiator fan motor
G401 and G402	14-3 and 14-4	Brake fluid level switch, Cable reel (CVT), Ceiling light/Spotlights, Clutch pedal position switch (M/T), Combination light switch, DLC, DRL control unit (Canada) (2 wires), Driver's door lock knob switch/lock actuator, Driver's door lock switch, EPS motor relay, Fuel consumption display select switch, Gauge assembly (2 wires), Idle stop switch (CVT), Ignition key switch/key light, Keyless door lock control unit, Power mirror switch, Power window master switch (2 wires), Power window relay, Turn signal/hazard relay, Windshield wiper motor, Wiper/washer switch
G403	14-4	Audio unit
G404	14-4	Accessory power socket, Blower motor high relay, Blower power transistor, Climate control unit/Heater control panel
G451	14-4	EPS control unit
G501	14-5	SRS unit (2 wires)
G502	14-5	BCM module (2 wires), Bypass contactor, Driver's seat belt switch, Fuel gauge sending unit, Fuel pump, High voltage contactor, Battery module fan resistor, High speed battery module fan control relay, High speed MPI module fan control relay, High voltage contactor relay, Ignition hold relay, Junction board (3 wires), Low speed battery module fan control relay, Low speed MPI module fan control resistor, MCM (2 wires), MES connector, Park pin switch (CVT)
G601	14-6	Hatch key cylinder switch, Hatch latch/unlock switch (2 wires), Hatch opener actuator, License plate light, Taillights
G651	14-7	DC-DC converter
G701	14-6	High mount brake light, Lower rear window defogger, Rear window defogger, Rear window wiper motor