



# Power Distribution

## - Under-dash Fuse/Relay Box – Fuses 21 (Canada), 22, and 23

