

Splice and Junction Connector Details

- Circuit E88 (CVT) TP Sensor Signal

